

Sprinter

Operator's Manual



Symbols

Warning

 $\widehat{\Psi}$ Environmental note

Possible vehicle damage

1 Tip

▶ A prompt to act▷▷ Continuation symbol

(▷ page) Page reference

Display Messages in the display and in the monitor of the rear view camera

Registered trademarks

ESP® is a registered trademark of Daimler.

Vehicle distributor

In the USA:	In Canada:
Mercedes-Benz USA, LLC One Mercedes Drive Montvale, NJ 07645-0350 www.mbusa.com www.mbsprinterusa.com Customer Assistance Center: 1-877-762-8267	Mercedes-Benz Canada Inc. 98 Vanderhoof Avenue Toronto, ON M4G 4C9 www.mercedes-benz.ca Customer Relations Department: 1-800-387-0100

Mercedes-Benz USA, LLC and Mercedes-Benz Canada Inc. are Daimler companies. Canada only:

[&]quot;Authorized Sprinter Dealer" is defined as an authorized Mercedes-Benz Sprinter Dealer.

Thank you for choosing the new Sprinter.

Before you drive off, familiarize yourself with your vehicle and read the Operator's Manual. This will help you to obtain the maximum pleasure from your vehicle and avoid endangering yourself and others.

The equipment or model designation of your vehicle may differ according to:

- model
- order
- · country specification
- availability

Individual warning and indicator lamps may not be functional.

The manufacturer constantly updates its vehicles to the state of the art.

We reserve the right to make changes to the following:

- design
- · equipment
- technology

You cannot therefore base any claims on the illustrations or descriptions in this manual.

The following are integral parts of the vehicle:

- Operator's Manual
- Maintenance Booklet
- Service and Warranty Information booklet
- equipment-dependent operating instructions

Keep these documents in the vehicle at all times. Should you sell the vehicle, always pass the documents on to the new owner.

We wish you pleasant motoring at all times.



Index 4	At a glance25	
Introduction 17	Safety 33	
	Controls 53	
	Operation 137	
	Practical advice 183	
	Wheels and tires	
	Technical data 283	

1, 2, 3	Ashtray 130
	ASR (Acceleration Skid Control) 50
12 V socket	Activating/deactivating 51
	ATA (Anti-Theft Alarm system)
A	Activating/deactivating 64
ABS (Anti-lock Braking System)	Function 64
Display message 203	Switching off the alarm 65
Function/notes	ATA (Anti-Theft Alarm-System)
Accessories and conversions 20	ATA troubleshooting 214
see Add-on equipment	Attachments
Add-on equipment 20, 284	see Bodies 20
ADR	Audible warning signal 214
Working speed governor (ADR) 118	Automatic car wash 168
Air bags	Automatic headlamp mode 93
Front air bag (driver, front	Automatic locking 57
passenger) 41	Automatic transmission 115
Important safety notes 39	Driving tips 117
Safety guidelines	Malfunction 216
Side impact air bag 41	Releasing the parking lock
Window curtain air bag 42	manually 253
Air-conditioning system	Shift ranges 116
Air vents in the roof duct 104	Touchshift 116
Refrigerant 164	Transmission oil change 161
see Climate control	Auxiliary heating
Air-conditioning system in the rear	Before switching on 107
compartment	Heater booster function 109
see Climate control	Malfunction 219
Air distribution	Safety notes 106
Setting 104	Switch 107
Air filter	Switch-on time 107
Indicator lamp 197	see Auxiliary heating
Airflow	
Setting 104	В
Air pressure	Backup lamp
see Tire pressure	Changing bulbs 238, 239
Air-recirculation mode 106	Ball coupling
Air vents	Installing
Setting 103	BAS (Brake Assist System) 50
Alarm system	Battery 178
see ATA	Charge indicator lamp 193
Antifreeze additives	Charging 181
see Coolant 163	Disconnecting 179
Anti-lock Braking System	Display message
see ABS	Isolating switch 90
Anti-Theft Alarm system	Notes on care 182
see ATA	Reconnecting 181
Armrests 71	Removing/installing 180

Belt	Central locking system
see Seat belts	see Key54
Bio-diesel 156	Troubleshooting 220
Bi-Xenon headlamps	Changing bulbs 235
Driving abroad 138	B Display message 211
Bleeding the fuel system 224	
Bodies	Exterior lighting 236
Body/equipment mounting	Headlamps 236
directives for trucks 20	Indicator and warning lamps 199
Bottle holder 133	Interior light 240, 241
see Cup holder	Perimeter lamp 240
Brake fluid 162	Tail lamp 238, 239
Display message 207	Chassis number
Fluid change 162	see Vehicle identification number 285
Fluid level 173	
Warning lamp 190	Rear doors 47
Brake lamp	Children
Changing bulbs 238, 239	In the vehicle 43
Brake linings	Restraint systems 43
Display message 207	' Child seat
Indicator lamp 193	
Brakes	anchors 45
ABS 49	•
BAS 50	Top Tether 46
Brake system	Chock 185
Fluid level 173	B Cigarette lighter 130
Malfunction 207	' Cleaning
Warning lamp 189, 190	After driving off-road or on
Breakdown	construction sites 169
see Flat tire	Alloy wheels 168
Breaking-in 138	B Automatic car wash 168
Bulb failure indicator 91	Cleaning the engine 168
	High-pressure cleaning 167
C	Vehicle exterior 165
Comovo	Vehicle interior 165
Camera	Cleaning and care 165
see Rear view camera	Climate control
Capacities	Adiustilis the all vents 103
Care of the vehicle	All Conditioning in the real
Cargo tie-down rings	
Installing	
	Air-recirculation mode 100
CD player/CD changer 81	Oleaning the all filter 170
Center console	Control panels 99
Central locking	, occining with an achamiamoation 102
Automatic locking	, Democring the windows 100
Malfunction 220	1 ogged up willdows 103
	General notes 100

Heating	100	DEF	
Heating in the rear compartment	101	See Diesel Exhaust Fluid (DEF)	158
Rear-compartment air		Delayed switch-off	
conditioning	101	Diagnostics connection	20
Rear-compartment heating	101	Diesel	
Reheat function (air		Consumption	140
dehumidification)	105	Fuels	156
Setting the air distribution	104	Low outside temperatures	157
Setting the airflow	104	Reserve fuel warning lamp 7	'5, 195
Setting the temperature	102	Tank capacity	294
Switching air-recirculation mode		Diesel engine	
in the rear compartment on/off	106	Preglow indicator lamp	
Switching on and off	102	Winter driving	
Cockpit		Diesel Exhaust Fluid (DEF)	158
Combination switch	. 93	Capacities	294
Consumption statistics (vehicles		Consumption	
with steering wheel buttons)	. 88	Display message 201, 20	
Control panel		Exhaust gas aftertreatment	117
Above the windshield	. 30	Indicator lamp	
Conversions and accessories		Level indicator	118
see Add-on equipment		Ranges	
Coolant	163	Refilling	
5 5	163	Storage	
Display message	208	Tool for the tank filler cap	184
Expansion tank	172	Diesel particle filter	
Level	172	Digital odometer	
Temperature gauge (vehicles with		Digital speedometer	19
steering wheel buttons)		Setting the unit (vehicles with	
Topping up		steering wheel buttons)	83
Warning lamp		Display	
Cornering lamps		Display messages	199
Changing bulbs		Outside temperature (vehicles	
Correct use		with steering wheel buttons)	80
Cruise control		Outside temperature display	
Display message		(vehicles without steering wheel	
Malfunction		buttons)	76
Cup holders	133	Standard display (vehicles	
-		without steering wheel buttons)	/5
D		Standard display (vehicles with	
Data stored in the vehicle	. 23	steering wheel buttons)	80
Daytime running lamp		see Warning and indicator lamps	40 75
Daytime running lamp mode		Distance recorder	
Setting (vehicles without steering-		see Odometer	/5
wheel buttons)	. 76	Door lock	- /
Setting (vehicles with steering	-	see Central locking	56
wheel buttons)	. 86	Doors	0.4
		Control panel	
		Display message	211

Indicator lamp 199	Electrical step
Opening (from the inside) 58	Cleaning and care 166
see Central locking	Display message 208
Unlocking/locking with key 54	Entry and exit 59
Doorway lamp	Indicator lamp 199
Changing bulbs 240	Manual retraction 252
Drinks holder	Electrical system 91
see Cup holder	Electromagnetic compatibility 18
Driver's door and co-driver's door 58	Electronic Stability Program
Driving abroad 138	see ESP®
Driving off-road 138	Emergency equipment 184
Driving on rough terrain	Emergency exit window 47
see Driving off-road 138	Emergency Tensioning Devices
Driving safety systems	Function 37
ABS (Anti-lock Braking System) 49	Safety guidelines
ASR (Acceleration Skid Control) 50	Engine
BAS (Brake Assist System) 50	Changing the power output
Electronic brake force distribution 50	Check engine indicator lamp 196
ESP® (Electronic Stability	Electronics 284
Program) 51	Maximum speeds 287
Important safety information 49	Operating safety 20
Overview 49	Starting the engine with the key 111
Driving systems 119	Wash 168
Cruise control 119	Engine oil
Malfunctions 217	Adding 176
PARKTRONIC 121	Checking the oil level (on-board
Rear view camera 124	computer) 174
Driving tips 138	Checking the oil level using the
Driving abroad 138	dipstick 176
Pulling away 111	Consumption 140
Stopping the vehicle and	Display message 210
switching off the engine 113	Mixing 160
Towing a trailer 150	Oil change 159
	SAE classification 159
E	Warning lamp 194
EBD (elecronic brake force	Engine oil filler neck 172
distribution)	Error memory
Indicator lamps	see Message memory (vehicles
EBD (electronic brake force	with steering wheel buttons) 81
distribution)	ESP® (Electronic Stability
Function/notes 50	Program) 51
Electrical/electronic devices	Exhaust gas aftertreatment 117
Communications equipment 135	DEF capacities 294
Retrofitting 284	DEF level indicator 118
Electrical closing assist 59	DEF reducing agent 117, 158
,	Diesel Exhaust Fluid (DEF) 158
	Display message 201 204 206

Indicator lamp 192	G
Malfunction 197, 201, 204, 206	General driving tips 112
Refilling DEF 143	.
Exterior lighting	•
Bulb failure indicator 91	Glove box
Changing bulbs 235	GTW (Gross Trailer Weight)
Daytime running lamp mode	(definition)
(vehicles without steering wheel	Guarantee 19
buttons) 76	
Daytime running lamp mode	Н
(vehicles with steering wheel	Handbrake
buttons) 86	see Parking brake 114
Delayed switch-off (vehicles with	Hazard warning lamps 94
steering wheel buttons) 87	Headlamps
Light switch 92	Changing bulbs 236
Locator lighting (vehicles with	Cleaning 167
steering wheel buttons)	Cleaning system 98, 174
Surround lighting (vehicles with	
steering wheel buttons)	Fogged up
Exterior mirrors	Head restraints 71
Eyeglasses compartment 133	Heater booster function 109
, 6	Heating
F	3
	see Climate control
Fatty acid methyl ester FAME 156	High beam flasher
Fire extinguisher 186	High-beam headlamps
First-aid kit	Changing bulbs
Flat tire	High-pressure cleaning 167 Hood
Notes 224	
Wheel change	Opening/closing 171
Folding seat 70	
Folding table 133	1
Front fog lamps	Ignition lock 58
Front windshield	Immobilizer 64
see Windshield	Indicator and warning lamps
Fuel	ABS 191
Additives	Air filter 197
Consumption 140	ASR 189, 190
Display message 211	BAS 189, 190
Fuel filter with water separator 223	Battery charge 193
Indicator lamp 198	Brakes 190
Fuel gauge 75	Brake wear 193
Fuel tank content	Bulbs 199
Reserve, display message 211	Check engine 196
Fuses	Coolant 195
Fuse allocation 243, 247	Doors 199
Fuse box under the left front seat 246	Engine oil level 194
Main fuse box 242	ESP [®] 189, 192
	23

Poly-V-belt 193	L
Preglow 196	
Reserve fuel 195	Lamp
SRS 193	Failure indicator 91
Tire pressure monitor 197	Language
Water separator 198	Display (vehicles with steering
Windshield washer fluid 198	wheel buttons) 84
Indicator lamps	Lashing points and materials 147
see Warning and indicator lamps 27	Lashing points and tie downs
Installations and conversions	Permissible tensile load
see Bodies	License plate lamp
Instrument cluster	Changing bulbs 238, 239
Lighting	Lighting
Speedometer	Bulb failure indicator 91
Tachometer	Changing bulbs 235, 236
Instrument cluster illumination	Instrument
	Light switch 92
see Instrument lighting	Lights
	Automatic headlamp mode 93
Interior lighting	Combination switch 93
Changing bulbs	Cornering light function 94
Front	Daytime running lamp
Rear	mode 76, 86, 92
Interior motion sensor	Interior lighting 94, 95
ISOFIX (LATCH-type child seat	
securing system)	Light switch 92
	Light switch
	Light switch
securing system)	Light switch 92 Limited Warranty 22 Load distribution 146 Loading guidelines 144
J Jack 184	Light switch 92 Limited Warranty 22 Load distribution 146 Loading guidelines 144 Loads
J Jack 184 Jacking points 232	Light switch 92 Limited Warranty 22 Load distribution 146 Loading guidelines 144 Loads Securing 147
J Jack 184 Jacking points 232 Preparation 232	Light switch 92 Limited Warranty 22 Load distribution 146 Loading guidelines 144 Loads Securing 147 Transporting 144, 146
J Jack 184 Jacking points 232 Preparation 232 Jump-starting 253	Light switch 92 Limited Warranty 22 Load distribution 146 Loading guidelines 144 Loads Securing 147 Transporting 144, 146 Locator lighting
J Jack 184 Jacking points 232 Preparation 232 Jump-starting 253 Jump-starting connection point in	Light switch 92 Limited Warranty 22 Load distribution 146 Loading guidelines 144 Loads Securing 147 Transporting 144, 146 Locator lighting Setting (vehicles with steering
J Jack 184 Jacking points 232 Preparation 232 Jump-starting 253	Light switch 92 Limited Warranty 22 Load distribution 146 Loading guidelines 144 Loads 147 Transporting 144, 146 Locator lighting Setting (vehicles with steering wheel buttons) 86
J Jack	Light switch 92 Limited Warranty 22 Load distribution 146 Loading guidelines 144 Loads 147 Transporting 144, 146 Locator lighting Setting (vehicles with steering wheel buttons) 86 Locking 86
J Jack 184 Jacking points 232 Preparation 232 Jump-starting 253 Jump-starting connection point in	Light switch 92 Limited Warranty 22 Load distribution 146 Loading guidelines 144 Loads 147 Securing 144, 146 Locator lighting 144, 146 Setting (vehicles with steering wheel buttons) 86 Locking 40 Automatic 57
J Jack	Light switch 92 Limited Warranty 22 Load distribution 146 Loading guidelines 144 Loads 147 Securing 144, 146 Locator lighting 144, 146 Setting (vehicles with steering wheel buttons) 86 Locking 86 Automatic 57 With button 57
Jack	Light switch 92 Limited Warranty 22 Load distribution 146 Loading guidelines 144 Loads 147 Securing 144, 146 Locator lighting 144, 146 Setting (vehicles with steering wheel buttons) 86 Locking 86 Automatic 57 With button 57 With key 54
J J Jack	Light switch 92 Limited Warranty 22 Load distribution 146 Loading guidelines 144 Loads 147 Securing 144, 146 Locator lighting 144, 146 Setting (vehicles with steering wheel buttons) 86 Locking 4utomatic 57 With button 57 With key 54 Locking system
J J Jack	Light switch 92 Limited Warranty 22 Load distribution 146 Loading guidelines 144 Loads 147 Securing 144, 146 Locator lighting 144, 146 Setting (vehicles with steering wheel buttons) 86 Locking 86 With button 57 With key 54 Locking system see Central locking 56
J Jack	Light switch 92 Limited Warranty 22 Load distribution 146 Loading guidelines 144 Loads 147 Transporting 144, 146 Locator lighting Setting (vehicles with steering wheel buttons) 86 Locking Automatic 57 With button 57 With key 54 Locking system see Central locking 56 Low-beam headlamps 92
J J Jack	Light switch 92 Limited Warranty 22 Load distribution 146 Loading guidelines 144 Loads 147 Securing 144, 146 Locator lighting 144, 146 Setting (vehicles with steering wheel buttons) 86 Locking 57 With button 57 With key 54 Locking system 56 see Central locking 56 Low-beam headlamps 92 Automatic headlamps 93
J Jack	Light switch 92 Limited Warranty 22 Load distribution 146 Loading guidelines 144 Loads 147 Securing 144, 146 Locator lighting 144, 146 Setting (vehicles with steering wheel buttons) 86 Locking 57 With button 57 With key 54 Locking system 56 see Central locking 56 Low-beam headlamps 92 Automatic headlamps 93 Changing bulbs 237
J Jack	Light switch 92 Limited Warranty 22 Load distribution 146 Loading guidelines 144 Loads 147 Securing 144, 146 Locator lighting 144, 146 Setting (vehicles with steering wheel buttons) 86 Locking 57 With button 57 With key 54 Locking system 56 see Central locking 56 Low-beam headlamps 92 Automatic headlamps 93 Changing bulbs 237 Daytime running lamp mode
J Jack	Light switch 92 Limited Warranty 22 Load distribution 146 Loading guidelines 144 Loads 147 Securing 144, 146 Locator lighting 144, 146 Setting (vehicles with steering wheel buttons) 86 Locking 57 With button 57 With key 54 Locking system 56 see Central locking 56 Low-beam headlamps 92 Automatic headlamps 93 Changing bulbs 237

Daytime running lamp mode	On-board computer
(vehicles with steering wheel	Vehicles without steering wheel
buttons) 76, 86	buttons 75
Driving abroad 138	Vehicles with steering wheel
	buttons 77
M	On-board diagnostics interface
	see Diagnostics connection
M+S tires	Opening/closing the windows 63
Maintenance points under the	Outside temperature display
hood 172	Vehicles without steering wheel
Malfunctions 189	buttons 76
Message memory (vehicles with	Vehicles with steering wheel
steering wheel buttons) 81	buttons 80
Malfunctions relevant to safety	Overhead control panel
Reporting23	Overview 30
Maximum speed 141	Overrevving range
Menu (vehicles with steering	Overview
wheel buttons)	Menus (Vehicles with steering
Audio 80	wheel buttons) 79
Message memory 81	wheel buttons) 79
Operation 80	D
Settings 82	P
Telephone 89	Paint code number 285
Trip computer 88	Paper holder 133
Message memory (vehicles with	Parking
steering wheel buttons) 81	see Stopping the vehicle and
Messages	switching off the engine 113
Vehicles without steering wheel	Parking aid
buttons 201	see PARKTRONIC
Vehicles with steering wheel	Parking brake 114
buttons 203	Display message 208
Mirrors	Parking lamps 92
Exterior mirrors	Changing bulbs 237
Rear-view mirror 73	PARKTRONIC 121
Mobile phone 135	Activating/deactivating 123
Display message	Cleaning the sensors
Installation	Indicator lamp
Monitor	Malfunction
see Rear view camera	Range of the sensors 121
TET	Roll-back warning 123
0	Trailer towing
O .	Warning display 122, 218
Occupant safety	Partition sliding door 62
Children in the vehicle 43	_
System overview	Perimeter lamps
Odometer	Changing bulbs
Setting the unit (vehicles with	Poly-V-belt Molfunction 103
steering wheel buttons)	Malfunction 193

Power supply	Rear lamp
Battery isolating switch 90	Changing bulbs 238, 239
Power windows 63	Rear view camera 124
Practical advice	Malfunction 219
Auxiliary heating 219	Monitor menu 125
Central locking system 220	Switching off the monitor while
Engine 215	driving 129
Fuel and fuel tank 222	Switching on 124
Headlamps and turn signals 221	Switching the monitor on/off 125
Windshield wipers 222	Rear-view camera
Preparing for a journey 110	Cleaning 166
Checks in the vehicle 110	Cleaning the monitor 165
Visual check of the vehicle	Rear-view mirror 73
exterior 110	Rear window defroster 98
Protection of the environment 17	Rear window heating
	Malfunction 213
Q	Rear window wiper 97
O Produced Part and the state of the state o	Refilling
Qualified specialist workshop 19	Diesel Exhaust Fluid (DEF) 143
-	Tool for DEF tank filler cap 184
R	Refrigerant 164
Radio	Refueling
Changing stations (vehicles with	Relays 241
steering wheel buttons) 81	Main fuse box 246
Cleaning the display 165	Remote control
Setting station selection (vehicles	see Key 54
with steering wheel buttons) 87	Replacing bulbs
Rain/light sensor	see Changing bulbs 235, 236
Setting the sensitivity (vehicles	Reporting
with steering wheel buttons) 87	Malfunctions relevant to safety 23
Windshield wipers 97	Reserve fuel
Range (vehicles with steering	Tank 75, 195
wheel buttons) 89	Restraint systems
Reading lamp 95	Display message 205
Rear bench seat	Malfunction 193
Folding (Crew Van) 68	see SRS
Installing/removing (Passenger	Reverse gear
Van) 69	Engaging (automatic
Stowage compartment (crewcab) 132	transmission) 115
Rear-compartment air-	Reverse warning feature 141
conditioning system	Rims
see Climate control	Roll-back warning
Rear-compartment heating	see PARKTRONIC 123
see Climate control	Roof carrier 149, 291
Rear doors 60	Roof load (maximum) 291
Rear fog lamp 93	Roof rack
Changing bulbs 238, 239	see Roof carrier 149, 291

Roof ventilator	109	Fuel additive	157
		Fuel additives	157
S		Power steering fluid	161
CAE alassification (anaine ails)	150	Refrigerant	164
SAE classification (engine oils)	159	Transmission oil	161
Safety		Settings	
Children in the vehicle		Resetting all (vehicles with	
Child restraint systems	. 43	steering wheel buttons)	. 82
Overview of occupant safety		Resetting submenus (vehicles	
systems	. 34	with steering wheel buttons)	. 82
Safety systems		Setting the clock	
see Driving safety systems		Vehicles without steering wheel	
Seat belts		buttons	. 76
Adjusting the height	. 36	Setting the date	, , ,
Belt force limiters		Vehicles without steering wheel	
Cleaning	165	buttons	. 76
Correct usage	. 35	Vehicles with steering wheel	. / (
Display message	208	buttons	0.5
Emergency Tensioning Devices	. 37		. 00
Fastening		Setting the time	
Important safety guidelines		Vehicles with steering wheel	0.5
Releasing		buttons	. 85
Safety guidelines		Shift ranges	
Special seat belt retractor		Automatic transmission	
Warning lamp		Side impact air bag	. 41
Warning lamp (function)		Side windows	
Seat heating		Resetting	
Malfunction		Sliding door	
Seats	210	Cleaning	
Co-driver's seat	66	Closing assist	. 59
Driver's seat		Snow chains	263
		Sockets	134
Folding seat		Spare wheel	
Luxury seat		Bracket	186
Rear bench seat		see Spare wheel	186
Standard seat		Wheel change	
Suspension seat		Specialist workshop	
Swivel seat		Speed	
Twin co-driver's seat		Setting, see Cruise control	120
Selector lever position		Speed limiter	
Service interval display	170	Speedometer	
Service products		Setting the unit (vehicles with	. , ,
Bio-diesel		steering wheel buttons)	QΩ
Brake fluid	162		. 03
Capacities	294	Sprinter Dealer	
Coolant	163	see Qualified specialist workshop	
Diesel Exhaust Fluid (DEF)	158		
Engine oil	159		

Fuel 156

SRS (Supplemental Restraint System)	Switching off the alarm (ATA) 65 Switch unit
Introduction	Additional 31
Warning lamp (function)	Center console
Standing lamps	Driver's door 31
Changing bulbs	Swivel seat
Starting	OWIVE Seat
see Starting the engine	T
Steering wheel 72	•
Adjusting 72	Tachometer 74
Buttons (vehicles with steering	Tank content
wheel buttons)	Range (vehicles with steering
With buttons	wheel buttons) 89
Step	Reserve fuel warning lamp 195
see Electrical step	Technical data
Stowage spaces and stowage	Capacities 294
compartments	Speed 287
Eyeglasses compartment	Tire pressure 288
Glove box	Tires/wheels 288
Paper holder	Vehicle dimensions 287
Stowage compartment above the	vehicle weights 287
windshield 131	Telephone 135
Stowage compartment in the	Operation (vehicles with steering
center console	wheel buttons) 89
Stowage compartment in the	Temperature
dashboard 131	Setting (climate control) 102
Stowage compartment in the	Setting the unit (vehicles with
door 132	steering wheel buttons) 83
Stowage space above the	Theft deterrent systems
headliner 131	ATA (Anti-Theft Alarm system) 64
Stowage space under the rear	Immobilizer 64
bench seat 132	Tightening torque
Stowage space under the twin co-	Wheel nuts/wheel bolts 234
driver's seat	Time
Submenu (on-board computer)	Setting the time (vehicles without
Clock/Date 85	steering wheel buttons)
Convenience	Setting the time (vehicles with
Instrument cluster	steering wheel buttons) 85
Lighting	Tire and Loading Information label 286
Selecting	Tire Inflation Pressure label 286
Settings overview 83	Tire pressure
Vehicle	Calling up (on-board computer) 266
Summer tires	Calling up (vehicles with steering
Supplemental Restraint System	wheel buttons) 267
see SRS	Checking manually 266
Surround lighting	Display message 201, 205, 210
Setting (vehicles with steering	Maximum 265
wheel buttons)	Recommended 263, 288

	Setting the unit (vehicles with		Maximum tire load (definition)	278
	steering wheel buttons)	. 85	Optional equipment weight	
	Tables	288	(definition)	279
	Tire and Loading Information		PSI (pounds per square inch)	
	label		(definition)	278
	Tire Inflation Pressure label	286	Replacing	279
	Tire label 264	, 286	Service life	262
	Warning lamp	197	Sidewall (definition)	279
Ti	re pressure monitoring system		Speed rating (definition)	277
	Function/notes	266	Storing	281
Ti	res		Structure and characteristics	
	Aspect ratio (definition)	278	(definition)	276
	Average weight of the vehicle		TIN (Tire Identification Number)	
	occupants (definition)	277	(definition)	279
	Bar (definition)	276	Tire bead (definition)	279
	Characteristics	276	Tire pressure (definition)	278
	Checking	261	Tire pressures (recommended)	277
	Definition of terms	276	Tire size (data)	288
	Direction of rotation	281	Tire size designation, load-bearing	
	Distribution of the vehicle		capacity, speed rating	274
	occupants (definition)	279	Tire tread	261
	DOT, Tire Identification Number		Tire tread (definition)	278
	(TIN)	276	Total load limit (definition)	279
	DOT (Department of		Traction (definition)	279
	Transportation) (definition)	277	TWR (permissible trailer drawbar	
	Flat tire	224	noseweight) (definition)	279
	GAWR (Gross Axle Weight Rating)		Uniform Tire Quality Grading	
	(definition)	277	Standards (definition)	277
	GTW (Gross Trailer Weight)		Unladen weight (definition)	278
	(definition)	277	valve, Snap-In	260
	GVW (Gross Vehicle Weight)		Wear indicator (definition)	279
	(definition)	277	Wheel change	231
	GVWR (Gross Vehicle Weight		Wheel rim (definition)	277
	Rating) (definition)	277	Tires and wheels (important safety	
	Increased vehicle weight due to		information)	260
	optional equipment (definition)	277	Tire sealant	
	Kilopascal (kPa) (definition)	278	Storage location	186
	Labeling (overview)	274	Using	224
	Labels	286	Tools	
	Load bearing index (definition)	279	see Vehicle tool kit	184
	Load index (definition)	278	Top speed	
	Maximum loaded vehicle weight		Technical data	287
	(definition)	278	Top Tether	46
	Maximum load on a tire		Touchshift	116
	(definition)	278	Tow-away protection	
	Maximum permissible tire		Towing	
	pressure (definition)	278	-	
	Maximum tire load			

Towing a trailer		V	
Coupling up a trailer	153	Valiale	
Decoupling a trailer	154	Vehicle	177
Driving tips	150	Assemblies	
Important safety notes	150	Cleaning	
Installing the ball coupling	152	Correct use	
Power supply	155	Data acquisition	
Towing eye	256	Dimensions	
Tow-starting	255	Electronics	
Trailer		Equipment	. 17
Brake force booster malfunction	190	Individual settings (vehicles with	
Towing with PARKTRONIC	123	steering wheel buttons)	
Trailer tow hitch		Limited Warranty	
Trailer coupling	_,.	Loading	
Permitted weights and loads	291	Registration	
Trailer loads and drawbar	2/1	Reporting problems	. 22
noseweights	15/	Towing	255
Trailer towing	134	Tow-starting	255
Permissible trailer loads and		Transporting	257
	151	Weights	
drawbar noseweights		Vehicle identification number	285
Transmission oil		Vehicle identification plates	285
Transport by rail	140	Vehicle key	
Transporting		Malfunction	220
Load distribution	146	Vehicle tool kit	184
Loading	144	Voltage supply	101
Securing a load	147	Fuses	241
Trip computer (vehicles with		1 4000	211
steering wheel buttons)		W	
Trip meter	. 75	VV	
see Trip odometer		Warning and indicator lamps	
Trip odometer		Diesel Exhaust Fluid (DEF)	192
Resetting	. 75	Electrical step	199
Troubleshooting		Overview	. 27
Automatic transmission	216	PARKTRONIC	218
Driving systems	217	Seat belt	198
Turn signals	. 93	Warning lamp	184
Changing bulbs 237, 238,	239	Warning tones	214
Two-way radio		Warning triangle	185
Installation	284	Washer fluid	
TWR (Tongue Weight Rating)		Display message	211
(definition)	279	Indicator lamp	198
(Topping up	174
U		Wiping with	
		Wheel nuts/wheel bolts	. 70
Unlocking		Tightening torque	221
With button	. 57	rigiticining torque	234
With key	. 54		

Wheels	
Changing 23	1
Checking 26	1
Interchanging/changing 27	9
Rim size 28	8
Spare wheel 18	6
Storing 28	1
Wheel size/tire size 28	8
Window curtain air bag 4	2
Windows	
Cleaning 16	5
Cleaning the windshield 16	7
Washing system 98, 17	4
Windshield	
Cleaning 16	•
Windshield heating 9	-
Malfunction 21	3
Windshield washer fluid	
Indicator lamp 19	_
Windshield wipers 9	7
Malfunction 22	
Rain/light sensor 9	7
Replacing the wiper blades 17	7
Setting the sensitivity (vehicles	
with steering wheel buttons and	
rain/light sensor) 8	
Winter diesel 15	7
Winter operation 156, 26	2
Winter tires	
M+S tires	2
Working speed governor (ADR) 11	8

Xenon headlamps

see Bi-Xenon headlamps

Environmental protection

⊕Environmental note

Our declared policy is integrated environmental protection.

Our objectives are to use the natural resources which form the basis of our existence on this planet sparingly and in a manner which takes the requirements of both nature and humanity into consideration.

You too can help to protect the environment by operating your vehicle in an environmentally-responsible manner.

Fuel consumption and the rate of engine, transmission, brake and tire wear depend on the following factors:

- · operating conditions of your vehicle
- · your personal driving style

You can influence both factors. Therefore, please bear the following in mind:

Operating conditions:

- avoid short trips, as these increase fuel consumption.
- observe the correct tire pressure.
- · do not carry any unnecessary weight in the vehicle.
- monitor the vehicle's fuel consumption.
- remove the roof rack once you no longer need it.
- · a regularly serviced vehicle will contribute to environmental protection. You should therefore adhere to the service intervals.
- · all maintenance work should be carried out at a qualified specialist workshop.

Personal driving style:

- · do not depress the accelerator pedal when starting the engine.
- do not warm up the engine when the vehicle is stationary.
- drive carefully and maintain a safe distance from the vehicle in front.
- · avoid frequent, sudden acceleration.
- switch off the engine in stationary traffic.

Environmental issues and recommendations

Whenever this Operator's Manual prompts you to dispose of substances, attempt to recycle and reuse them first. Observe the relevant environmental rules and regulations when disposing of materials. This helps to protect the environment.

Vehicle equipment

The Operator's Manual describes all models and standard and optional equipment of your vehicle that were available at the time of going to print.

Country-specific variations are possible. Note that your vehicle may not be equipped with all of the described functions. This also applies to systems and functions relevant to safety. The equipment in your vehicle may therefore differ from that shown in the descriptions and illustrations. The original purchase contract documentation for your vehicle contains a list of all of the systems in your vehicle.

If you have questions about equipment and operation, consult any authorized Sprinter Dealer.

The Operator's Manual, the Maintenance Booklet and the equipment-dependent operating instructions are important documents and should be kept in the vehicle.

Operating safety and vehicle approval

Safety notes

↑ WARNING

Exhaust fumes, some of its constituents, and certain vehicle components contain or emit chemicals known to the State of California to cause cancer and birth defects or other heritable genetic damage.

In addition, certain fluids contained in vehicles, and certain products that are used as components, contain chemicals known to the State of California to cause cancer and birth defects or other heritable genetic damage.

Air bags and pyrotechnic Emergency
Tensioning Devices (ETDs) and remote
control batteries contain perchlorate
material, which may require special handling
and regard for the environment. Check with
your local government's disposal guidelines.
In California, see www.dtsc.ca.gov/
HazardousWaste/Perchlorate/index.cfm.

↑ WARNING

Always have all work on the vehicle, especially work relevant to safety and work on safety-relevant systems or service work, carried out at a qualified specialist workshop.

↑ WARNING

Some safety systems only function when the engine is running. You should therefore never switch off the engine when driving. Otherwise, the safety systems of your vehicle may not function correctly and as a result will no longer protect you and other persons as intended. In addition, there is a risk that you may lose control of your vehicle and thus cause an accident.

↑ WARNING

If you drive over obstacles at high speed or if the vehicle bottoms out in rough terrain, it could cause heavy impacts to the vehicle underbody, tires or wheels. This could cause your vehicle to be damaged, which in turn might lead to an accident. This also applies to vehicles which are equipped with underbody protection.

You should therefore drive over obstacles slowly. Prevent the vehicle from bottoming out when driving off-road and if necessary, have your vehicle inspected at a qualified specialist workshop.

↑ WARNING

Work carried out incorrectly, or alterations made to the vehicle, e.g. re-routing of cables under coverings, could cause the safety systems of your vehicle to stop working properly. The safety systems would thus no longer protect you and other persons as intended. In addition, there is a risk that you may lose control of your vehicle and thus cause an accident.

All work and alterations to the vehicle, e.g. installations or modifications, should therefore be carried out at a qualified specialist workshop.

\triangle

♠ WARNING

If work on electronic equipment and its software is carried out incorrectly, this equipment could stop working. The electronic systems are networked via interfaces. Tampering with these electronic systems could cause malfunctions in systems which have not been modified. Malfunctions such as these can seriously jeopardize the vehicle's operating safety and therefore your own safety.

You should therefore have all work and modifications to electronic components carried out at a qualified specialist workshop.

Electromagnetic compatibility

The following information applies to all wireless components in the vehicle:

USA only:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. this device must withstand any interference received, including interference that may cause undesired operation.

Unauthorized modifications to the device could void the user's authority to operate the equipment.

Canada only:

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation.

Unauthorized modifications to the device could void the user's authority to operate the equipment.

Further information can be obtained at any authorized Sprinter Dealer.

Qualified specialist workshops

An authorized Sprinter Dealer is a qualified specialist workshop. A qualified specialist workshop has the necessary specialist knowledge, tools and qualifications to correctly carry out the work required on the vehicle. This is especially the case for work relevant to safety.

Observe the information in the Maintenance Booklet.

The following work should always be carried out at qualified specialist workshop:

- · work relevant to safety
- service and maintenance work
- repair work
- modifications as well as installations and alterations
- · work on electronic components

For this reason, we recommend an authorized Sprinter Dealer.

Service and warranty information

The Service and Warranty Information booklet contains detailed information on the types of warranty that your Sprinter is covered by, including:

- New Vehicle Limited Warranty
- Diesel Engine Limited Warranty
- Corrosion Warranty
- Limited Warranty for Restraint Systems (only vehicles that have been sold and registered in the state of Kansas)
- Legally required Emission Performance Warranty

Registering your vehicle

We may ask our authorized Sprinter Dealers to carry out technical inspections on certain vehicles to improve their quality or safety.

We can only inform you about vehicle checks if we have your registration data.

Your registration data is not stored if:

- you did not purchase your vehicle at an authorized Sprinter Dealer.
- your vehicle has never been inspected at an authorized Sprinter Dealer.

It is advisable to register your vehicle with an authorized Sprinter Dealer. Please inform us as soon as possible about any change of address or vehicle ownership.

Digital speedometer and odometer

Do not modify the vehicle's electronically stored odometer by tampering with the electronics.

If the odometer has been altered and you subsequently sell the vehicle but do not inform the buyer, this may constitute a punishable offense under local legislation.

Changing the engine power output

- Increases in engine power can:
 - change the emission values
 - · cause malfunctions
 - cause consequential damage

The operating reliability of the engine is not guaranteed in all cases.

Any tampering with the engine management system in order to increase the engine power output will lead to the loss of New Vehicle Limited Warranty and other warranty entitlements.

If you sell the vehicle, inform the purchaser about the changes to the engine power output of the vehicle. If you do not inform the buyer, this may constitute a punishable offense under national legislation.

Diagnostics connection

↑ WARNING

If you connect equipment to the on-board diagnostics connection, it can affect the operation of the vehicle systems. This can impair the operating safety of your vehicle while driving. There is a risk of an accident.

Do not connect any equipment to the onboard diagnostics connection.



↑ WARNING

Loose equipment or equipment cables which are connected to the on-board diagnostics connection can obstruct the area around the pedals. The equipment or the cables could come between the pedals in the event of sudden braking or acceleration. This may affect the function of the pedals. There is a risk of an accident.

Do not attach any equipment or cables in the driver's footwell.

If the engine is switched off and a device which is connected to the on-board

diagnostics connection is being used, the battery may discharge.

All the diagnostics connections on the vehicle are intended for connecting diagnostic testing equipment at a qualified specialist workshop.

Connecting equipment to the diagnostics connections can lead to emissions monitoring information being reset. The possible outcome may be that the vehicle no longer fulfills the emissions laws and regulations. This may be a criminal offense or breach of road traffic regulations in certain countries.

Diesel particle filter

If the vehicle is predominantly used for short-distance driving, this could lead to a malfunction in the automatic cleaning function for the diesel particle filter. As a result, fuel may accumulate in the engine oil and cause engine failure.

Therefore, if you mainly drive short distances, you should drive on a highway or on rural roads for 20 minutes every 310 miles (500 km). This ensures sufficient regeneration of the diesel particle filter.

Therefore, if you mainly drive short distances, you should drive on a freeway or on a federal highway for 20 minutes every 300 miles (500 km). This will allow the diesel particle filter to be sufficiently purged.

Attachments, bodies, equipment and conversions

We recommend genuine Sprinter parts as well as conversion parts and accessories that have been approved expressly for the respective type of vehicle.

These parts have been specially tested to establish their safety, reliability and suitability.

I For safety reasons, have add-on equipment manufactured and installed according to the Sprinter body/equipment mounting directives in force. These body/equipment mounting directives ensure that the chassis and the body form one unit and that maximum operating and road safety is achieved.

We recommend for safety reasons that:

- you carry out no other modifications to the vehicle.
- you obtain the agreement of the distributor named on the inside of the front cover for any deviations from the approved body/equipment mounting directives.

Approval from certified inspection agencies or official approvals cannot rule out risks to your safety.

I The wooden or plastic cargo area floor fitted at the factory is an integral component of the vehicle structure. The vehicle body could be damaged if you have the load area floor removed. This then affects the securing of loads and the maximum loading capacity of the lashing points is no longer guaranteed.

Therefore, do not have the load area floor removed.

Even seemingly small changes to the vehicle, such as attaching a radiator trim for winter driving or as protection against insects, are not permitted. These could cause the engine diagnostics to register distorted and incorrect data. The recording of specific engine diagnostic data is a legal requirement, and must always be verifiable and accurate. Further information can be obtained at any authorized Sprinter Dealer.

Sprinter body/equipment mounting directives

If you intend to make modifications to your vehicle, we strongly recommend that you contact the distributor named on the inside

of the front cover. There you will receive all the necessary information and a charge may be levied.

You alone accept the responsibility if body manufacturers or dealers make modifications that affect the final certification of the engine, the vehicle or the equipment. This also applies to the identification and documentation of modifications to the affected vehicle components.

You are responsible for certification and confirmation that:

- all the applicable standards and regulations that are affected by the vehicle modification are met
- the modified vehicle fulfills the vehicle safety standards and emissions laws and regulations
- the modifications or installation of accessories does not affect the safety of the vehicle.

MARNING

Any modifications or alterations of the vehicle not in compliance with the Sprinter body/ equipment mounting directives and the Sprinter Operator's Manual may seriously inhibit its roadworthiness and safety and may lead to an accident resulting in serious injury or death.

Consult the Sprinter body/equipment mounting directives and the Sprinter Operator's Manual prior to initiating any alterations or modifications.

We are not responsible for the final certification, product liability or warranty claims which result from the modifications. This applies to:

- the modified components, assemblies or systems
- any resulting noncompliance with any of the emissions laws and regulations or the motor vehicle safety standards
- any consequences arising from the changes that make the vehicle less safe or even render it defective

We do not accept any responsibility as end manufacturer or for the resulting product liability.

Limited Warranty

Follow the instructions in this Operator's Manual about the proper operation of your vehicle as well as about possible vehicle damage. Damage to your vehicle that arises from culpable contravention of these instructions is not covered by the Limited Warranty of the distributor named on the inside of the front cover.

Correct use



♠ WARNING

There are various warning stickers affixed to your vehicle. Their purpose is to alert you and others to various dangers. Therefore, do not remove any warning stickers unless the sticker clearly states that you may do so.

If you remove any warning stickers, you or others could fail to recognize certain dangers and be injured.

♠ WARNING

Gases and fluids from substances that constitute a health hazard or react aggressively can escape even from securely closed containers. When transporting such substances in the vehicle interior, your ability to concentrate or your health could be affected during the journey. Malfunctions, short circuits or electrical component system failures may also result. There is a risk of an accident and fire.

Do not store or transport any substances in the vehicle interior which are hazardous to health or react aggressively.

In order to use the vehicle correctly, you are required to familiarize yourself with the following information:

- the safety notes in this Operator's Manual
- the technical data in this Operator's Manual
- · traffic rules and regulations
- motor vehicle laws and safety standards

Do not store or transport any substances in the cab which constitute a health hazard or react aggressively. These include:

- solvents
- fuel
- · oils and greases
- · cleaning agents
- acids

Problems with the vehicle

If you should experience a problem with your vehicle, particularly one that you believe may affect its safe operation, we urge you to contact an authorized Sprinter Dealer immediately to have the problem diagnosed and rectified.

If the problem cannot be rectified to your satisfaction there:

- please discuss the problem with a management representative from the authorized Sprinter Dealer.
- · if necessary, contact the distributor named on the inside of the front cover.

Safety-relevant malfunction message

In the USA:

In all 50 states and Washington, D.C.:

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying the vehicle distributor named on the inside of the front cover.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or the vehicle distributor.

To contact NHTSA, you may either call the Vehicle Safety Hotline toll-free at 1-888-327-4236(TTY: 1-800-424-9153); or go to http://www.safercar.gov;

or write to:

Administrator, NHTSA, 400 Seventh Street SW, Washington, DC 20590.

In Canada:

If you believe that your vehicle has a safety defect, you should contact immediately the Customer Service Department of the vehicle distributor named on the inside of the front cover.

Data stored in the vehicle

Information about electronic data acquisition in the vehicle

(Including notice pursuant to California Code § 9951)

Please note that your vehicle is equipped with devices that can record vehicle systems data.

This information helps, for example, to test vehicle systems after an accident and to continually improve vehicle safety. We can access this data and submit it:


- for safety research or vehicle diagnosis purposes
- with the consent of the vehicle owner or lessee
- on the instruction of prosecuting authorities or other governmental agencies
- for use in arbitration of disputes that involve the manufacturer, its affiliates or its sales and service organizations
- as otherwise required or permitted by law.

Data for multimedia devices

Depending on the equipment level, your vehicle may feature communications and/or entertainment systems (e.g. telephone systems). The data necessary for the operation of the multimedia devices can be stored and edited on the devices themselves. Further information on operation (e.g. on deleting data) can be found in the separate operating instructions.

Cockpit	26
Instrument cluster variants	27
Steering wheel with buttons	29
Center console	29
Switch units	30


Cockpit



	Function	Page
1	Door control panel	31
2	Light switch	92
3	Combination switch: • turn signals • high-beam headlamps • windshield wipers • rear window wiper	93 93 97 97
4	Cruise control lever	120
5	Horn	
6	Steering wheel without/ with buttons	29
7	Instrument cluster	27
8	Stowage compartment	
9	Stowage compartment with interior lightOverhead control panel	95 30
10	Rear-view mirror	73

-		201101
	Function	Page
11)	Rear view camera monitor	124
12	PARKTRONIC warning display	121
13	Opens/closes the right- hand side window	63
14)	Jack and vehicle tool kit	184
15)	Glove box	132
16	Center console	29
17	Ignition lock	58
18	Additional switch unit	31
19	Steering wheel adjustment	72
20	Selector lever (automatic transmission)	111
21)	Parking brake	114
22	Opens the hood	171
23	Additional switch unit	31

Instrument cluster variants



	Function	Page
1	Instrument cluster on vehicles without steering-wheel buttons	73
2	Speedometer with indicator and warning lamps	74
3	Indicator and warning lamps	
4	Tachometer with indicator and warning lamps	74
5	•, • Brightens/dims the instrument cluster lighting	75
6	Fuel gauge with fuel filler flap location indicator	75
7	Display	75
8	Display	77
9	Reset button ①	73
10	• Service button Checks the engine oil level	174


	Function	Page
11)	Instrument cluster on vehicles with steering-wheel buttons	73
12	Menu button:changes standard displayselects menus	76 76
	Indicator and warning lamps	
\triangle	ESP® warning lamp	51, 189
	ASR warning lamp	50, 189
	Coolant level too low	195
	Coolant temperature too high	195
SRS	Restraint systems malfunction	193

	Function	Page
(①) BRAKE	Brake fluid level too low EBD malfunctioning Trailer brake force booster malfunction	190 189 190
##X:	Engine oil level warning	194
	Check engine indicator lamp Exhaust gas aftertreatment malfunction	196 197
00	Preglow system	196
•	Left-hand turn signal	93
U	Tire pressure loss or the tire pressure monitor is malfunctioning (USA only) Tire pressure loss (Canada only)	197 197
	Fluid level too low in windshield washer/ headlamp cleaning system	198
	Door or hood open Electrically operated step malfunction	199 199
	Brake pads/linings worn	193
•	Right-hand turn signal	93
(ABS)	ABS malfunction	191

1 Vehicles with steering-wheel	buttons:
Corresponding messages may	also be
shown in display (8)(⊳ page 27	').

Function ASR malfunction BAS malfunction BAS malfunction BESP® malfunction BEF supply low or contaminated/thinned Exhaust gas aftertreatment malfunction Dirt accumulation in air filter Dirt accumulation in air filter Paul filler cap open Water in the fuel Battery charging malfunction Bulb defective Parking brake applied Low-beam headlamps on Paul High-beam headlamps on Reserve fuel Fuel filler cap open 193 ADR Working speed governor (ADR) on Reserve fuel Fuel filler cap open 195 Fuel filler cap open 196 Fasten seat belt 198			
BAS malfunction 191 ESP® malfunction 189 DEF supply low or contaminated/thinned 201 Exhaust gas aftertreatment malfunction 202 Dirt accumulation in air filter 197 Reserve fuel 195 Fuel filler cap open 196 Water in the fuel 198 Battery charging malfunction 193 Bulb defective 199 Parking brake applied 114 Developmen 198 ADR Working speed governor (ADR) on 118 High-beam headlamps on 93 Reserve fuel 195 Fuel filler cap open 196		Function	Page
ESP® malfunction DEF supply low or contaminated/thinned Exhaust gas aftertreatment malfunction Dirt accumulation in air filter Paul filler cap open Water in the fuel Battery charging malfunction Bulb defective Parking brake applied Low-beam headlamps on Parking speed governor (ADR) on Reserve fuel Puel filler cap open 193 Development Parking speed governor (ADR) on Reserve fuel Fuel filler cap open 195 Fuel filler cap open 196		ASR malfunction	190
DEF supply low or contaminated/thinned Exhaust gas aftertreatment malfunction 202 Dirt accumulation in air filter 197 Reserve fuel 195 Fuel filler cap open 196 Water in the fuel 198 Battery charging malfunction 193 Bulb defective 199 Parking brake applied 114 Description 198 ADR Working speed governor (ADR) on 118 High-beam headlamps on 93 Reserve fuel 195 Fuel filler cap open 196		BAS malfunction	191
contaminated/thinned Exhaust gas aftertreatment malfunction Dirt accumulation in air filter Reserve fuel Fuel filler cap open Water in the fuel Battery charging malfunction Bulb defective Parking brake applied Low-beam headlamps on Parking speed governor (ADR) on Reserve fuel Fuel filler cap open 193 ADR Working speed governor (ADR) on Reserve fuel Fuel filler cap open 195 Fuel filler cap open 196	25	ESP® malfunction	189
Dirt accumulation in air filter 197 Reserve fuel 195 Fuel filler cap open 196 Water in the fuel 198 Battery charging malfunction 193 Bulb defective 199 Parking brake applied 114 Description 193 Working speed governor (ADR) on 118 High-beam headlamps on 93 Reserve fuel 195 Fuel filler cap open 196		contaminated/thinned	201
filter 197 Reserve fuel 195 Fuel filler cap open 196 Water in the fuel 198 Battery charging malfunction 193 Bulb defective 199 Parking brake applied 114 Duw-beam headlamps on 92 ADR Working speed governor (ADR) on 118 High-beam headlamps on 93 Reserve fuel 195 Fuel filler cap open 196		malfunction	202
Fuel filler cap open 196 Water in the fuel 198 Battery charging malfunction 193 Bulb defective 199 Parking brake applied 114 D Low-beam headlamps on 92 ADR Working speed governor (ADR) on 118 High-beam headlamps on 93 Reserve fuel 195 Fuel filler cap open 196	9 4		197
Battery charging malfunction 193 Bulb defective 199 Parking brake applied 114 Low-beam headlamps on 92 ADR Working speed governor (ADR) on 118 High-beam headlamps on 93 Reserve fuel 195 Fuel filler cap open 196	I	Reserve fuel	195
Battery charging malfunction 193 Bulb defective 199 Parking brake applied 114 Low-beam headlamps on 92 ADR Working speed governor (ADR) on 118 High-beam headlamps on 93 Reserve fuel 195 Fuel filler cap open 196		Fuel filler cap open	196
malfunction 193 Bulb defective 199 Parking brake applied 114 Low-beam headlamps on 92 ADR Working speed governor (ADR) on 118 High-beam headlamps on 93 Reserve fuel 195 Fuel filler cap open 196		Water in the fuel	198
Parking brake applied 114 Description Low-beam headlamps on 92 ADR Working speed governor (ADR) on 118 Description High-beam headlamps on 93 Reserve fuel 195 Fuel filler cap open 196	= +	, ,	193
Low-beam headlamps on 92 ADR Working speed governor (ADR) on 118 Thigh-beam headlamps on 93 Reserve fuel 195 Fuel filler cap open 196	<u>-</u> Ф;	Bulb defective	199
ADR Working speed governor (ADR) on 118 D High-beam headlamps on 93 Reserve fuel 195 Fuel filler cap open 196	(®) PARK	Parking brake applied	114
(ADR) on 118 High-beam headlamps on 93 Reserve fuel 195 Fuel filler cap open 196		Low-beam headlamps on	92
Reserve fuel 195 Fuel filler cap open 196	ADR		118
Fuel filler cap open 196	≣ D	High-beam headlamps on	93
Fasten seat belt 198	•		
	*	Fasten seat belt	198

Steering wheel with buttons



	N2	6.10-2097-31
	Function	Page
1	Display	77
	Controls the on-board computer	
2	Selects a submenu or adjusts the volume + Up/increases the volume - Down/reduces the volume	77
3	Using the telephone Accepts a call/starts dialing Ends a call/rejects an incoming call	89
4	Scrolling from one menu to another Forwards Back	77
5	Scrolling within a menu Forwards Back	77

Center console



	Function	Page
1	Stowage compartment	132
2	Radio; see the separate operating instructions	
3	Air-conditioning control panel	99
4	Center console switch unit	30
5	• Stowage compartment or • CD changer; see the separate operating instructions	
6	Cup holder with: • ashtray • cigarette lighter	133 130 130
7	12 V socket	134

Switch units

Center console



		•
	Function	Page
₩	Switches the left/right- hand seat heating on/off	71
(#)	Switches the windshield heating on/off	98
T##	Switches the rear window defroster on/off	98
OFF P-i ▲	Activates/deactivates PARKTRONIC	123
	Switches the hazard warning lamps on/off	94
ASR OFF	Activates/deactivates ASR	50
	Central locking, interior/ rear compartment	56

Roof




	Function	Page
1	Microphone for the telephone	135
2	Switches the right-hand reading lamp on/off	95
3	Switches the automatic interior lighting on/off	95
4	Eyeglasses compartment orAnti-Theft Alarm system (ATA)	133
5	Switches the interior lighting on/off	95
6	Switches the left-hand reading lamp on/off	95

Driver's door




	Function	Page
1	Adjusts the exterior mirrors	73
2	Selects an exterior mirror	73
3	Opens/closes the left-hand side window	63
4	Opens/closes the right- hand side window	63

Additional switch units



Switch unit between the light switch and the steering wheel

	Function	Page
<u> </u>	Switches the auxiliary heating on/off	106
1#1	Switches the heater booster function on/off	106
(h)	Sets the working speed	119
(1)	Switches the working speed governor (ADR) on/off	118
S	Ventilates the cargo compartment	109



Switch unit between the steering wheel and ignition lock

Function	Page
Switches the rear- compartment convenience lighting on/off	95

34
34
47
49

Useful information

This Operator's Manual describes all models as well as standard and optional equipment of your vehicle that were available at the time of going to print. Country-specific variations are possible. Note that your vehicle may not be equipped with all of the described functions. This also applies to systems and functions relevant to safety.

Read the information on qualified specialist workshops: (> page 19).

Occupant safety

Restraint systems

In this section you will learn the most important facts about the restraint system components of the vehicle.

The restraint systems are:

- Seat belts
- · Child restraint systems
- LATCH-type (ISOFIX) child seat securing system

Additional protection potential is provided by SRS (Supplemental Restraint System) and the air bag system.

The protective functions of the systems work in conjunction with each other. The systems are, however, autonomous.

↑ WARNING

Modifications to or work improperly conducted on restraint system components or their wiring, as well as tampering with interconnected electronic systems, can lead to the restraint systems no longer functioning as intended.

Air bags or Emergency Tensioning Devices (ETDs), for example, could deploy inadvertently or fail to deploy in accidents although the deceleration threshold for air bag deployment is exceeded. Therefore, never modify the restraint systems. Do not

tamper with electronic components or their software.

More information on the subject of children in the vehicle and child restraint systems can be found in the "Children in the vehicle" section (> page 43).

Seat belts

Important safety notes

The use of seat belts and infant or child restraints is required by law in all 50 states, the District of Columbia, the U.S. territories and all Canadian provinces.

Even if this is not the case, all vehicle occupants should have their seat belts fastened when the vehicle is in motion.

• For further information on infants and children traveling in the vehicle as well as on child restraint systems, see the "Children in the vehicle" section (▷ page 43).

↑ WARNING

Always fasten your seat belt before driving off. Always make sure all of your passengers are properly restrained. You and your passengers should always wear seat belts.

Failure to wear and properly fasten and position your seat belt greatly increases your risk of injuries and their likely severity in an accident.

If you are ever in an accident, your injuries can be considerably more severe without your seat belt properly buckled. Without your seat belt buckled, you are much more likely to hit the interior of the vehicle or be ejected from it. You can be seriously injured or killed.

In the same crash, the possibility of injury or death is lessened if you are properly wearing your seat belt. The air bags can only protect as intended if the occupants are properly wearing their seat belts.

↑ WARNING

Never ride in a moving vehicle with the seat backrest in an excessively reclined position as this can be dangerous. You could slide under the seat belt in a collision. If you slide under it, the seat belt would apply force at the abdomen or neck. That could cause serious or even fatal injuries. The seat backrest and seat belt provide the best restraint when the wearer is in a position that is as upright as possible and the seat belt is properly positioned on the body.

↑ WARNING

Never let more people ride in the vehicle than there are seat belts available. Make sure everyone riding in the vehicle is correctly restrained with a separate seat belt. Never use a seat belt for more than one person at a time.

↑ WARNING

Damaged seat belts or seat belts that have been subjected to stress in an accident must be replaced. Their anchoring points must also be checked.

Only use seat belts which have been approved by the distributor named on the inside of the front cover.

Do not make any modifications to the seat belts. This can lead to unintended activation of the ETDs or to their failure to activate when necessary.

Do not bleach or dye seat belts as this may severely weaken them. In a crash they may not be able to provide adequate protection.

Have all work carried out only by qualified technicians. Please contact a qualified specialist workshop.

Proper use of the seat belts

↑ WARNING

USE SEAT BELTS PROPERLY

- · Seat belts can only work when used properly. Never wear seat belts in any other way than as described in this section, as that could result in serious injuries in the event of an accident.
- Each occupant should wear their seat belt at all times, because seat belts help reduce the likelihood of and potential severity of injuries in accidents, including rollovers. The integrated restraint system includes SRS (driver front air bag, front-passenger front air bag, side impact air bags, window curtain air bags for the side windows), Emergency Tensioning Devices, seat belt force limiters, and front seat knee bolsters. The system is designed to enhance the protection offered to properly belted occupants in certain frontal (front air bags and ETDs) and side (side impact air bags, window curtain air bags, and ETDs) impacts which exceed preset deployment thresholds and in certain rollovers (window curtain air bags and ETDs).
- Never wear the shoulder belt under your arm, across your neck or off your shoulder. In a frontal crash, your body would move too far forward. That would increase the chance of head and neck injuries. The seat belt would also apply too much force to the ribs or abdomen, which could severely injure internal organs such as your liver or spleen.

Adjust the seat belt so that the shoulder section is located as close as possible to the middle of the shoulder. It should not touch the neck. Never pass the shoulder portion of the seat belt under your arm. For this purpose, you can adjust the height of the seat belt outlet.

 Position the lap belt as low as possible on your hips and not across the abdomen. If the lap belt is positioned across your

abdomen, it could cause serious injuries in a crash.

- Never wear seat belts over rigid or breakable objects in or on your clothing, such as eyeglasses, pens, keys etc., as these might cause injuries.
- Make sure the seat belt is always routed snugly. Take special care of this when wearing loose clothing.
- Never use a seat belt for more than one person at a time. Do not fasten a seat belt around a person and another person or other objects at the same time.
- Seat belts should not be worn twisted. In a crash, you would not have the full width of the seat belt to distribute impact forces. The twisted seat belt against your body could cause injuries.
- Pregnant women should also always use a lap-shoulder belt. The lap belt portion should be positioned as low as possible on the hips to avoid any possible pressure on the abdomen.
- Place the seat backrest in a position that is as upright as possible.
- Check your seat belt during travel to make sure it is properly positioned.
- Never place your feet on the instrument panel, dashboard, or on the seat. Always keep both feet on the floor in front of the seat.
- When using a seat belt to secure infant restraints, toddler restraints, or children in booster seats, always follow the child seat manufacturer's instructions.

★ WARNING

Do not pass seat belts over sharp edges. They could tear.

Do not allow the seat belt to get caught in the door or in the seat adjustment mechanism. This could damage the seat belt.

Never attempt to make modifications to seat belts. This could impair the effectiveness of the seat belts.


Fastening seat belts

MARNING

According to accident statistics, children are safer when properly restrained on the rear seats than on the front-passenger seat. Thus, we strongly recommend that children be placed in the rear seat whenever possible. Regardless of seating position, children 12 years old and under must be seated and properly secured in an appropriately sized child restraint system or booster seat recommended for the size and weight of the child. For additional information, see the "Children in the vehicle" section.

A child's risk of serious or fatal injuries is significantly increased if the child restraints are not properly secured in the vehicle and/ or the child is not properly secured in the child restraint.

▶ Adjust the seat and move the backrest to an almost vertical position (⊳ page 66).



- ▶ To fasten the seat belt: pull the seat belt smoothly through belt sash guide 2).
- ▶ Without twisting it, place the shoulder section of the seat belt over the center of the shoulder and the lap section across the hips.

- ► Engage belt tongue ③ in seat belt buckle ⑤.
- ▶ If necessary, pull upwards on the shoulder section of the seat belt to tighten the belt across your body.
- ► The upper part of the seat belt must be routed across the middle of your shoulder. Adjust the seat belt to the appropriate height as necessary.

↑ WARNING

Only adjust the belt height when the vehicle is stationary and the parking brake is applied.

You could otherwise lose control of the vehicle as a result of adjusting movements and endanger yourself and others.

- ➤ To raise the seat belt: slide belt sash guide ② upwards.

 Belt sash guide ② engages in various positions.
- ► To lower the seat belt: press and hold release button (1).
- ► Adjust belt sash guide ② to the appropriate height.
- ► Let go of release button ① and make sure that belt sash guide ② has engaged.
- ➤ To release the seat belt: press release button ④ on seat belt buckle ⑤.

All seat belts in the vehicle, except the driver's seat belt, are equipped with a special seat belt retractor. This helps to secure the child restraint system properly in the vehicle. For further information on "Special seat belt retractors", see (> page 45).

Make sure that the seat belt retracts fully. The seat belt or belt buckle may otherwise become trapped in the door or the seat adjustment mechanism. This could damage the door, door trim panels and the seat belt. Damaged seat belts can no longer fulfill their protective function and must be replaced at a qualified specialist workshop.

Belt warning for drivers and co-drivers

Regardless of whether the driver's and codriver's seat belts have already been fastened, the seat belt warning lamp lights up for 6 seconds each time the engine is started. It then goes out if the driver and the co-driver have fastened their seat belts. If the driver's seat belt is not fastened when the engine is started, an additional warning tone will sound. The warning tone goes out after approximately 6 seconds or once the driver's seat belt is fastened.

Emergency Tensioning Devices, seat belt force limiters

If the vehicle is equipped with a driver's air bag, the seat belts on the driver's and codriver's seats have belt tensioners.

If the front-passenger seat is not occupied, do not engage the seat belt tongue in the buckle on the front-passenger seat. Otherwise, the Emergency Tensioning Device could be triggered in the event of an accident.

ETDs tighten the seat belts in an accident, pulling them close against the seat occupant's body.

ETDs do not correct incorrect seat positions or incorrectly fastened seat belts.

ETDs do not pull vehicle occupants back towards the backrest.

If the seat belt is also equipped with a seat belt force limiter and this is triggered, the force exerted by the seat belt on the vehicle occupant is reduced.

The seat belt force limiters are synchronized with the front air bags, which take on a part of the deceleration force. Thus, the force exerted on the occupant is distributed over a greater area.

The ETDs can only be triggered if the ignition is switched on and the restraint systems are operational, see "srs warning lamp" (> page 38).

The ETDs are triggered depending on the type and severity of an accident:

- in the event of a head-on or rear-end collision, if the vehicle decelerates or accelerates rapidly in a longitudinal direction during the initial stages of the impact
- in the event of a side impact if the vehicle decelerates or accelerates rapidly in a lateral direction and the vehicle is equipped with side impact air bags and/or window curtain air bags
- in certain situations, if the vehicle overturns and the system determines that it can provide additional protection

If the ETDs are triggered, you will hear a bang and powder may also be released. Only in rare cases will the bang affect your hearing. The powder emitted is not generally hazardous to health. The srs warning lamp lights up.

↑ WARNING

Pyrotechnic ETDs that were activated must be replaced.

For your safety, when disposing of the pyrotechnic ETDs always follow our safety instructions. These instructions are available from any authorized Sprinter Dealer.

SRS (Supplemental Restraint System)

Introduction

SRS reduces the risk of occupants hitting the vehicle interior in the event of an accident. In addition, it can reduce the forces the occupants are subjected to during an accident.

SRS consists of:

- **srs** warning lamp
- · air bags
- air bag control unit (with crash sensors)
- ETDs for the driver's and co-driver's seat
- · seat belt force limiters, for the driver's and co-driver's seat

sas warning lamp

SRS functions are checked regularly when you switch on the ignition and when the engine is running. This allows malfunctions to be detected in good time.

The **SRS** warning lamp lights up in the instrument cluster for approximately 4 seconds when you switch on the ignition.

↑ WARNING

The SRS self-check has detected a malfunction if the **SRS** warning lamp:

- · does not come on at all
- fails to go out approximately 4 seconds after the engine was started
- comes on after the engine was started or while driving.

For your safety, we strongly recommend having the system checked immediately at a qualified specialist workshop. Otherwise, SRS may not be activated when it is needed in an accident, which could result in serious or fatal injury. SRS might also deploy unexpectedly and unnecessarily which could also result in injury.

In addition, improper work on SRS creates a risk of rendering SRS inoperative or causing unintended air bag deployment. Work on SRS must therefore be performed by qualified technicians. Please contact a qualified specialist workshop.

If it is necessary to modify an air bag system to accommodate a person with disabilities, contact a qualified specialist workshop.

USA only: for detailed information, please consult our Customer Assistance Center at 1-877-762-8267.

Safety guidelines for the seat belts, the **Emergency Tensioning Devices (ETDs)** and the air bags



♠ WARNING

 Damaged seat belts or seat belts that have been subjected to stress in an accident

- must be replaced and their anchoring points must also be checked. Only use seat belts which have been installed or supplied by a qualified specialist workshop.
- Air bags and pyrotechnic Emergency Tensioning Devices (ETDs) contain perchlorate material, which may require special handling and regard for the environment. Check with your local government's disposal guidelines. California residents, see

www.dtsc.ca.gov/HazardousWaste/ Perchlorate/index.cfm.

- Air bags and ETDs are designed to function on a one-time-only basis. An air bag or ETD that has deployed must be replaced.
- Do not pass seat belts over sharp edges. They could tear.
- Do not make any modification that could change the effectiveness of the seat belts.
- Do not bleach or dye seat belts as this may severely weaken them. In a crash they may not be able to provide adequate protection.
- No modifications of any kind may be made to any components or wiring of the SRS.
- Do not change or remove any component or part of the SRS.
- Do not install additional paneling, seat covers, badges etc. over the steering wheel hub, co-driver's front air bag cover, outboard sides of the seat backrests, door trim panels, or door frame trims.
- Do not install additional electrical/ electronic equipment on or near SRS components and wiring.
- Keep the area between air bags and occupants free of objects (e.g. packages, purses, umbrellas etc.).
- Do not hang items such as coat hangers from the coat hooks or handles over the door. These items may be thrown around in the vehicle and cause head and other injuries when the window curtain air bag is deployed.

- Air bag system components will be hot after an air bag has inflated. Do not touch them.
- Never place your feet on the instrument panel or on the seat. Always keep both feet on the floor in front of the seat.
- Improper repair work creates a risk of rendering the SRS inoperative or causing unintended air bag deployment. Work on the SRS must therefore only be performed by qualified technicians. Please contact a qualified specialist workshop.
- For your protection and the protection of others, when scrapping the air bag unit or ETD, our safety instructions must be followed. These instructions are available from any authorized Sprinter Dealer.
- Given the considerable deployment speed, required inflation volume, and the material of the air bags, there is the possibility of abrasions or other, potentially more serious injuries resulting from air bag deployment.

If you sell your vehicle, we strongly recommend that you inform the subsequent owner that the vehicle is equipped with SRS. Also refer them to the applicable section in the Operator's Manual.

Air bags

Important safety notes

⚠ WARNING

Air bags are designed to reduce the incidence of injuries and fatalities in certain situations:

- frontal impacts (driver's and frontpassenger front air bags)
- side impacts (side impact air bags and window curtain air bags)
- rollover (window curtain air bags)

However, no system available today can completely eliminate injuries and fatalities.

When the air bags are deployed, a small amount of powder is released. The powder generally does not constitute a health hazard

and does not indicate that there is a fire in the vehicle. In order to prevent potential breathing difficulties, you should leave the vehicle as soon as it is safe to do so. If you have any breathing difficulty but cannot get out of the vehicle after the air bag inflates, then get fresh air by opening a window or door.

/ WARNING

To reduce the risk of injury when the front air bags inflate, it is very important for the driver and co-driver to always be in a properly seated position and to wear their respective seat

For maximum protection in the event of a collision always be in normal seated position with your back against the seat backrest. Fasten your seat belt and make sure it is properly positioned on your body.

Since the air bag inflates with considerable speed and force, a proper seating position and correct positioning of the hands on the steering wheel will help to keep you at a safe distance from the air bag. Occupants who are not wearing their seat belt, are not seated properly or are too close to the air bag can be seriously injured or killed by an air bag as it inflates with great force instantaneously:

- Sit with the seat belt properly fastened in a position that is as upright as possible with your back against the seat backrest.
- . Move the driver's seat as far back as possible, still permitting proper operation of vehicle controls. The distance from the center of the driver's chest to the center of the air bag cover on the steering wheel must be at least 10 inches (25 cm) or more. You should be able to accomplish this by adjusting the seat and steering wheel. If you have any difficulties, please contact a qualified specialist workshop.
- Do not lean your head or chest close to the steering wheel or instrument panel.
- Keep hands on the outside of the steering wheel rim. Placing hands and arms inside

- the rim can increase the risk and potential severity of hand/arm injury when the driver front air bag inflates.
- Move the co-driver's seat as far as possible away from the instrument panel when the seat is occupied.
- · Occupants, especially children, should never place their bodies or lean their heads in the area of the door where the side impact air bag inflates. This could result in serious injuries or death should the side impact air bag be deployed. Always sit as upright as possible, wear the seat belt properly and use an appropriately sized infant restraint, toddler restraint, or booster seat recommended for the size and weight of the child.
- Children twelve years old and under must never travel on the co-driver's seat. They will otherwise be struck by the co-driver's front air bag when it inflates in a crash. This could result in serious or fatal injury.

Failure to follow these instructions can result in severe injuries to you or other occupants. If you sell your vehicle, it is important that you make the buyer aware of this safety information. Be sure to give the buyer this Operator's Manual.

♠ WARNING

Accident research shows that the safest place for children in an automobile is in a rear seat. A side impact air bag related injury may occur if occupants, especially children, are not properly seated or restrained when next to a side impact air bag which needs to deploy rapidly in a side impact in order to do its job. To help avoid the possibility of injury, please follow these guidelines:

Occupants, especially children, (1) should never place their bodies or lean their heads in the area of the door where the side impact air bag inflates. This could result in serious injuries or death should

- the side impact air bag be deployed.
- (2) Always sit as upright as possible and use the seat belts properly. Make sure that children 12 years old and under use an appropriately sized child restraint, infant restraint, or booster seat recommended for the size and weight of the child.
- (3) Always wear seat belts properly.

The air bags are only deployed if the air bag control unit detects the need for deployment. Only in the event of such a situation will they provide their supplemental protection.

The driver and passenger should always wear their seat belts. Otherwise, it is not possible for the air bags to provide their supplemental protection.

In the event of other types of impacts and impacts below air bag deployment thresholds, air bags will not deploy. The driver and passengers will then be protected to the extent possible by a properly fastened seat belt. A properly fastened seat belt is also needed to provide the best possible protection in a rollover.

Air bags provide supplemental protection, but are not a substitute for the seat belts. All vehicle occupants must fasten their seat belts regardless of whether your vehicle is equipped with air bags or not.


It is important for your safety and that of your passengers to have deployed air bags replaced and to have any malfunctioning air bags repaired. This will help to make sure the air bags continue to perform their protective function for the vehicle occupants in the event of a crash.

Front air bags

↑ WARNING

Observe "Important safety notes" (⊳ page 39).

The front air bags increase the degree of protection afforded to the driver and co-driver against head and chest injuries.



Driver's front air bag (1) deploys in front of the steering wheel; co-driver's front air bag (2) deploys in front of and above the glove box. They are deployed:

- in the event of certain frontal impacts
- if the system determines that air bag deployment can offer additional protection to that provided by the seat belt
- if the respective seat belt is fastened
- independently of other air bags in the vehicle

If the event of a rollover, the front air bags are generally not deployed unless the system detects high vehicle deceleration in a longitudinal direction.

The air bags will not deploy in impacts which do not exceed the system's preset deployment thresholds. You will then be protected by the seat belt, provided that it is fastened.

Side impact air bags



/ WARNING

Observe "Important safety notes" (⊳ page 39).



↑ WARNING

If you wish to use seat covers, we recommend for safety reasons that you use only those approved for Sprinter vehicles.

The seat covers must feature a special tear seam for the side impact air bags. The side impact air bag may otherwise not deploy correctly and may fail to provide the intended degree of protection in the event of a collision. Suitable seat covers can be obtained, e.g. at a qualified specialist workshop.

↑ WARNING

The pressure sensors for side impact air bag control are located in the doors. Do not modify any components of the doors or door trim panels including, for example, the addition of door speakers.

Improper repair work on the doors, modification to the doors or the addition of components to the doors creates a risk of rendering the side impact air bags inoperative or causing unintended air bag deployment. Work on the doors must therefore only be performed by qualified technicians. Please contact a qualified specialist workshop.

↑ WARNING

Only use seat covers which have been tested and approved for your vehicle type by the distributor named on the inside of the front cover. Using other seat covers may interfere with or prevent the deployment of the front side impact air bags. Please contact a qualified specialist workshop for availability.

When deployed, the side impact air bags offer additional protection for the thorax of the vehicle occupants on the side of the vehicle on which the impact occurs. However, they do not protect the:

- head
- neck
- arms



Side impact air bags (1) deploy next to the outer seat cushions.

Side impact air bags (1) are deployed:

- on the side on which the impact occurs
- at the start of an accident with a high rate of lateral vehicle deceleration or acceleration, e.g. in a side impact
- · whether or not the seat belt is fastened
- independently of the front air bags
- independently of the Emergency Tensioning Devices

The side impact air bags are generally not deployed in the event of a rollover, unless the system detects high vehicle deceleration or acceleration in a lateral direction and determines that they can offer additional protection to that provided by the seat belt.

The side impact air bags are not deployed in side impacts which do not exceed the system's deployment threshold.

Window curtain air bags




/ WARNING

Observe "Important safety notes" (⊳ page 39).

The window curtain air bags enhance protection for the head (but not the chest or arms) of the vehicle occupants on the side of the vehicle on which the impact occurs.

The window curtain air bags are installed in the side of the roof frame above the front doors.



Window curtain air bags ① are deployed:

- on the side on which the impact occurs
- at the start of an accident with a high rate of lateral vehicle deceleration or acceleration, e.g. in a side impact
- regardless of whether the co-driver's seat is occupied
- whether or not the seat belt is fastened
- in the event of a rollover where the system determines that air bag deployment can offer additional protection to that provided by the seat belt
- independently of the front air bags
- independently of the Emergency Tensioning Devices

The window curtain air bags will not deploy in impacts which do not exceed the system's preset thresholds. You will then be protected by the seat belt, provided that it is fastened.

Child restraint systems

Important safety notes

We recommend all infants and children be properly restrained using infant and child restraint systems at all times while the vehicle is in motion.

The use of infant or child restraints is required by law in all 50 states, the District of Columbia, the U.S. territories and all Canadian provinces.

Infants and small children should always be seated in an infant or child seat restraint

system appropriate for the size and weight of the child. This must be properly secured in accordance with the manufacturer's installation instructions for the infant or child seat restraint system. All infant and child seat restraint systems must comply with the US Federal Motor Vehicle Safety Standards 213 and 225 and Canadian Motor Vehicle Safety Standards 213 and 210.2.

A statement by the child restraint manufacturer of compliance with these standards can be found on the instruction label on the child restraint system. You will also find the statement in the instruction manual provided with the child restraint system.

When using any infant restraint, child restraint or booster seat, make sure to carefully read and follow all manufacturer's instructions for installation and use.

Please read and observe warning labels affixed to the inside of the vehicle and to infant or child restraints.

↑ WARNING

Accident statistics show that children secured in the rear seats are safer than children secured in the co-driver's seat. For this reason, we strongly advise that you always secure children in the rear seats. Regardless of the seat position, children under 12 years must be secured correctly in a suitable infant or child restraint system or booster seat suitable for the size and weight of the child.

Never place anything between the seat cushion and child seat (e.g. pillow). The bottom of the child seat must make full contact with the vehicle seat cushion. An incorrectly mounted child seat could cause injuries to the child in the event of an accident, instead of protecting the child.

The infant or child restraint must be properly secured with the vehicle's seat belt, the seat belt and Top Tether strap, or lower anchors and Top Tether strap, fully in accordance with the child seat manufacturer's instructions.

Always observe the manufacturer's instructions when installing special child restraint systems.

Occupants, in particular children, must sit as upright as possible, fasten the seat belt correctly and use a suitable infant restraint system, child restraint system or booster seat suitable for the size and weight of the child.

Children can be seriously or even fatally injured by an air bag deploying. Observe the following important information if it is absolutely necessary to carry a child on the co-driver's seat:

- The co-driver's front air bag is not deactivated.
- Never secure your child in a rearwardfacing child restraint system on the codriver's seat. A child in a rearward-facing child restraint system on the co-driver's seat can be seriously injured or even killed if the co-driver's front air bag deploys. Only install a rearward-facing child restraint system on a suitable rear seat.
- Where permitted by state law, if you secure your child in a forward-facing child restraint system on the co-driver's seat, move the co-driver's seat as far back to the rear as possible. You must then use an appropriately sized child restraint system recommended for the age, size and weight of the child and secure it with the vehicle seat belt in accordance with the child seat manufacturer's instructions.

/ WARNING

Infants and small children should never share a seat belt with another occupant. In the event of an accident, they could be crushed between the occupant and seat belt.

A child's risk of serious or fatal injuries is significantly increased if the child restraints are not properly secured in the vehicle and/or the child is not properly secured in the child restraint.

Children that are too large for a child restraint must travel in seats using normal seat belts.

Position the shoulder belt across the chest and shoulder, not face or neck. A booster seat may be necessary to achieve proper seat belt positioning for children over 41 lb (18 kg) until they reach a height where a lap-shoulder belt fits properly without a booster.

When the child restraint is not in use, remove it from the vehicle or secure it with the seat belt to prevent the child restraint from becoming a projectile in the event of an accident.

If an infant or child is traveling in the vehicle:

- ► Secure the child using an infant or child restraint system appropriate to the age and weight of the child.
- Make sure that the infant or child is properly secured at all times while the vehicle is in motion.

↑ WARNING

When leaving the vehicle, always remove the key from the ignition lock. Always take the key with you and lock the vehicle. Do not leave children unattended in the vehicle, even if they are secured in a child restraint system, or with access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury.

Children could injure themselves on parts of the vehicle or could suffer severe or fatal injury due to extreme heat or cold.

If children open a door, they could injure other persons or get out of the vehicle and injure themselves or be injured by following traffic.

Do not expose the child restraint system to direct sunlight. This could cause, for example, metal parts of the child restraint system to become very hot. Touching these parts could cause burns.



Do not carry heavy or hard objects in the passenger compartment unless they are firmly secured in place.

Unsecured or improperly positioned cargo increases a child's risk of injury in the event of:

- strong braking maneuvers
- sudden changes of direction
- · an accident

Special seat belt retractor

↑ WARNING

Observe "Important safety notes" (⊳ page 43).

All seat belts in the vehicle, except the driver's seat belt, are equipped with a special seat belt retractor. When activated, the special seat belt retractor ensures that the seat belt cannot slacken once the child seat is secured.

Installing a child restraint system:

- ► Always comply with the manufacturer's installation instructions.
- ▶ Pull the seat belt smoothly from the inertia
- ► Engage the belt tongue in the seat belt buckle.

Activating the special seat belt retractor:

- ▶ Pull the seat belt out fully and let the inertia reel retract it again.
 - While the seat belt is retracting, you should hear a ratcheting sound. The special seat belt retractor is enabled.
- ▶ Push down on the child restraint system to take up any slack.

Removing a child restraint system/ deactivating the special seat belt retractor:

- ► Always comply with the manufacturer's installation instructions.
- ▶ Press the release button of the seat belt and guide the belt tongue to the belt outlet. The special seat belt retractor is deactivated.

↑ WARNING

Never release the seat belt buckle while the vehicle is in motion, since the special seat belt retractor will be deactivated.

LATCH-type (ISOFIX) child seat securing system in the rear compartment

↑ WARNING

Observe "Important safety notes" (⊳ page 43).

↑ WARNING

Children that are too large for a child restraint must travel in seats using normal seat belts. Position shoulder belt across the chest and shoulder, not face or neck.

A booster seat may be necessary to achieve proper seat belt positioning for children over 41 lb (18 kg) until they reach a height where a lap/shoulder belt fits properly without a booster.

Install the child restraint system in accordance with the manufacturer's instructions.

Attach the child restraint system to both securing rings.

An incorrectly installed child restraint system could come loose during an accident and seriously or even fatally injure the child.

Child restraint systems or child seat securing rings that are malfunctioning or damaged as the result of a collision must be replaced.

ISOFIX is a standardized securing system for special child restraint systems on the rear seats.

The securing rings for 2 LATCH-type (ISOFIX) child restraint systems are located between the seat cushions and the seat backrest:

- on the outer left and right-hand sides on a narrow rear bench seat with three seats
- on the outer left side on a rear bench seat with two seats

Non-LATCH-type (ISOFIX) child seats may also be used and can be installed using the vehicle's seat belt system. Follow the manufacturer's instructions for installation of child restraint systems.

When installing the child restraint system, make sure that the seat belt for the middle seat does not get trapped. The seat belt could otherwise be damaged.



- (1) Securing rings
- ► Install the LATCH-type (ISOFIX) child restraint system. Comply with the manufacturer's instructions when installing the LATCH-type (ISOFIX) child restraint system.


Top Tether


↑ WARNING

Observe "Important safety notes" (⊳ page 43).

Top Tether provides an additional connection between a child restraint system, secured with a LATCH-type (ISOFIX) child seat mount, and the rear seat. This helps reduce the risk of injury even further.

The Top Tether anchorages are located on the feet at the rear of the rear bench seats.





- ▶ Slide head restraint (1) upwards.
- ► Install the LATCH-type (ISOFIX) child restraint system with Top Tether. Comply with the manufacturer's installation instructions when doing so.
- ► Route Top Tether belt ④ under head restraint ① between both head restraint bars.
- ► Hook Top Tether hook ③ into Top Tether anchorage ②.

Make sure that:

- Top Tether hook ③ is hooked into Top Tether anchorage ②, as shown.
- Top Tether belt (4) is not twisted.
- ► Tension Top Tether belt ④. Comply with the manufacturer's installation instructions when doing so.
- ▶ If necessary, push the head restraint back down slightly. Make sure that the routing of Top Tether belt (4) is not interfered with.

Child-proof locks

Important safety notes

↑ WARNING

When leaving the vehicle, always remove the key from the ignition lock. Always take the key with you and lock the vehicle. Do not leave children unattended in the vehicle, even if they are secured in a child restraint system, or with access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury.

Children could injure themselves on parts of the vehicle or could suffer severe or fatal injury due to extreme heat or cold.

If children open a door, they could injure other persons or get out of the vehicle and injure themselves or be injured by following traffic.

Do not expose the child restraint system to direct sunlight. This could cause, for example, metal parts of the child restraint system to become very hot. Touching these parts could cause burns.

Child-proof locks for the rear doors

↑ WARNING


Observe "Important safety notes" (> page 43).

MARNING


Children could open a rear door from inside the vehicle. This could result in serious injuries or an accident. Therefore, when children ride in the rear always secure the rear doors with the child-proof locks.

You can use the child-proof locks in the doors to secure the sliding door and the rear door individually.

A door with an activated child-proof lock cannot be opened from the inside. It can only be opened from the outside if the vehicle is unlocked.



Child-proof lock for the sliding door



Child-proof lock for the rear door

- 1) Latch
- ② To activate
- ③ To deactivate
- ► To activate/deactivate: push latch ① in the corresponding direction.
- ► Then, make sure that the child-proof locks are working properly.

Emergency exit

Emergency exit window

The vehicle may feature an emergency exit window. The emergency exit window is intended for use in an emergency only and must not be opened unless the vehicle is stationary.

DANGER

Observe the following notes to make sure that the emergency exit window can be used safely in the event of an emergency:

- Before beginning a journey, inform the vehicle occupants of the emergency exit window and explain how to use it. Make sure to explicitly point out the risks described here.
- Only vehicle occupants who know how to use the emergency exit window are permitted to sit next to it.
- Access to the emergency exit window must remain unobstructed. Do not place any large or heavy objects on or in front of the seats next to the emergency exit window.
- The window handles must not be used as hooks, e.g. to hang up light objects, bags or items of clothing.

↑ WARNING

To reduce the risk of accident or injury when exiting the vehicle through the emergency exit window, observe the following notes:

- Only open the emergency exit window when the vehicle is stationary.
- Make sure that nobody becomes trapped, both when closing and when opening the emergency exit window. The emergency exit window must be held open by one nerson
- Pay attention to the traffic conditions and make sure that there is sufficient space when exiting through the emergency exit window.
- Pay attention to the traffic conditions when exiting the vehicle. Also pay attention to the vehicle height and the local surroundings.

Be especially careful if there are children in the vicinity.

↑ WARNING

An open or unlocked emergency exit window can be torn from its anchorages when the

vehicle is in motion and can thereby cause an accident.


For this reason, always check the lock and the locking pins of the emergency exit window before driving off.

Never open the emergency exit window while the vehicle is in motion.

Make sure there is sufficient clearance when opening the emergency exit window. Hold the open window in position. You could otherwise damage the emergency exit window.

In an emergency, or after an accident, the vehicle occupants can exit the vehicle through the emergency exit window.

The emergency exit window is the first window behind the driver's seat on the driver's side. It is marked by the "Emergency Exit" label.



► To open: turn both handles ① to a vertical position. Locking pins ② will break in the process.

The window is unlocked.

- Swing the window outward by the handles and hold it in this position. Make sure there is sufficient clearance when doing so.
- ▶ To close: close the window.

- ► Turn both handles (1) to a horizontal position. Make sure that locks (3) are in front of the window frame on the inside. The window is locked.
- ▶ Replace locking pins ② before beginning a new journey at the latest. Relevant information can be obtained at any qualified specialist workshop.

Driving safety systems

Overview

In this section, you will find information about the following driving safety systems:

- ABS (Anti-lock Braking System)
- BAS (Brake Assist System)
- ESP® (Electronic Stability Program)
- ASR (Acceleration Skid Control)
- EBD (**E**lectronic **B**rake-force **D**istribution)

Important safety notes

↑ WARNING

The following factors increase the risk of accidents:

- Excessive speed, especially in turns
- Wet and slippery road surfaces
- Following another vehicle too closely

The driving safety systems described in this section cannot reduce these risks or prevent the natural laws of physics from acting on the vehicle. They cannot increase braking or steering efficiency beyond that afforded by the condition of the vehicle brakes and tires or the traction afforded.

Only a safe, attentive, and skillful driver can prevent accidents.

The capabilities of a vehicle equipped with the driving safety systems described in this section must never be exploited in a reckless or dangerous manner which could jeopardize the user's safety or the safety of others.

Always adjust your driving style to the prevailing road and weather conditions and keep a safe distance to other road users and objects on the street.

If a driving system malfunctions, other driving safety systems may also switch off. Observe indicator and warning lamps that may come on as well as messages in the multifunction display that may appear.

1 In wintry driving conditions, always use winter tires (M+S tires) and if necessary, snow chains. Only in this way will the driving safety systems described in this section work as effectively as possible.

ABS (Anti-lock Braking System)

Important safety notes



↑ WARNING

Observe "Important safety notes" (⊳ page 49).



↑ WARNING

Do not pump the brake pedal. Use firm, steady brake pedal pressure instead. Pumping the brake pedal defeats the purpose of the ABS and significantly reduces braking effectiveness.

ABS regulates brake pressure in such a way that the wheels do not lock when you brake. This allows you to continue steering the vehicle when braking.

ABS works from a speed of about 3 mph (5 km/h) upwards, regardless of road-surface conditions. ABS works on slippery surfaces, even when you only brake gently.

When the ignition is switched on, the warning lamp in the instrument cluster lights up. When the engine is running, it goes out.

Braking

If ABS intervenes when braking, you will feel a pulsating in the brake pedal.

- ▶ If ABS intervenes: continue to depress the brake pedal with force until the braking situation is over.
- ► To make a full brake application: depress the brake pedal with full force.

↑ WARNING

If the ABS malfunctions, other driving systems such as the BAS or the ESP® are also switched off. Observe indicator and warning lamps that may come on as well as messages in the multifunction display that may appear.

If the ABS malfunctions, the wheels may lock during hard braking, reducing the steering capability and extending the braking distance.

The pulsating brake pedal can be an indication of hazardous road conditions and functions as a reminder to take extra care while driving.

BAS (Brake Assist System)



↑ WARNING

Observe "Important safety notes" (⊳ page 49).

BAS operates in emergency braking situations. If you depress the brake pedal quickly, BAS automatically boosts the braking force, potentially reducing the stopping distance.

► Keep the brake pedal firmly depressed until the emergency braking situation is over. ABS prevents the wheels from locking.

The brakes will function as usual once you release the brake pedal. BAS is deactivated.

↑ WARNING

If the BAS malfunctions, the brake system still functions, but without the additional brake boost available that the BAS would normally

provide in an emergency braking maneuver. Therefore, the braking distance may increase.

EBD (electronic brake force distribution)



♠ WARNING

Observe "Important safety notes" (⊳ page 49).

EBD monitors and controls the brake pressure on the rear wheels to improve driving stability while braking.



⚠ WARNING

If the 📜 , 📵 , 📵 and 🖾 BRAKE indicator lamps light up while the vehicle is in motion, EBD may be defective.

If EBD malfunctions, the brake system will still function with full brake boost. However, the rear wheels could lock up during emergency braking situations, for example. You could lose control of the vehicle and cause an accident.

Adapt your driving style to the changed driving characteristics.

ASR (acceleration skid control)

Important safety notes



♠ WARNING

Observe "Important safety notes" (⊳ page 49).

ASR significantly improves traction, i.e. the transmission of power from the tires to the road surface, and thus increases the vehicle's driving stability. ASR assists in pulling away and accelerating, particularly on smooth and slippery surfaces.

ASR brakes individual wheels and limits the engine torque. Thereby, ASR prevents the drive wheels from spinning.

If ASR intervenes, the warning lamp flashes in the instrument cluster.

If, taking tires, cargo load and gradient into consideration, the surface driven on still provides insufficient traction, you may experience difficulties in pulling away despite ASR.

Vehicles without steering wheel buttons: the indicator lamp in the instrument cluster lights up when you switch on the ignition. When the engine is running, it goes out.

Activating/deactivating ASR

↑ WARNING

ASR should not be switched off during normal driving other than in the circumstances described below. Deactivating the system will reduce vehicle stability in driving maneuvers. Do not switch off ASR when a spare wheel is mounted.

ASR is activated automatically when the engine is running.

It may be best to deactivate ASR in the following situations:

- · when using snow chains
- in deep snow
- · on sand or gravel

If you deactivate ASR:

- the engine's torque is no longer limited and the drive wheels can spin. The spinning of the wheels results in a cutting action, which provides better grip.
- traction control remains active and the brake system intervenes if a drive wheel begins to spin, e.g. if only the side of the road is slippery. The wheel will be braked and traction increased under such circumstances.
- active brake intervention by ESP® to increase driving stability remains active.

MARNING

Even with ASR deactivated, ESP® remains active and continues to perform brake interventions where this is necessary to

improve driving stability. The warning lamp flashes.

With ASR deactivated, there is an increased risk of your vehicle's brake system overheating and suffering damage due to prolonged application. A hot brake system will also result in increased stopping distance.

Therefore, only deactivate ASR when absolutely necessary.



► Press button ①.

When ASR is deactivated, the ⚠ warning lamp in the instrument cluster lights up.

ESP® (Electronic Stability Program)



Observe "Important safety notes" (> page 49).

If ESP® detects that the vehicle is deviating from the direction desired by the driver, one or more wheels are braked to stabilize the vehicle. If necessary, the engine output is also modified. Thereby, the vehicle is kept on the desired course, within physical limits. ESP® assists the driver when pulling away on wet or slippery roads. ESP® can also stabilize the vehicle during braking.

If ESP® intervenes, the warning lamp flashes in the instrument cluster.

↑ WARNING

Never switch off ASR when you see the warning lamp flashing in the instrument cluster. In this case proceed as follows:

- when driving off, apply as little throttle as possible.
- while driving, ease off the accelerator pedal.
- adapt your speed and driving style to the prevailing road conditions.

Failure to observe these guidelines could cause the vehicle to skid. ESP® cannot prevent accidents resulting from excessive speed.

MARNING

If the indicator lamp remains lit, ESP® is not available due to a malfunction. Vehicle stability in standard driving maneuvers is reduced.

Adapt your speed and driving style to the prevailing road conditions and to the non-operating status of ESP[®].

If $\mathsf{ESP}^{\circledast}$ is malfunctioning, the engine output may be reduced.

- Only operate the vehicle for a maximum of ten seconds on a brake test dynamometer. Switch off the ignition.

 Application of the brakes by ESP® may otherwise destroy the brake system.
- Do not run the vehicle on a roller dynamometer (e.g. for performance tests). If you must operate the vehicle on a roller dynamometer, please consult a qualified specialist workshop in advance. You could otherwise damage the drive train or the brake system.
- 1 Only use wheels with the recommended tire sizes. Only then will ESP® function properly.

Useful information	. 54
Opening and closing	. 54
Theft deterrent locking system	. 64
Seats	. 66
Steering wheel	. 72
Mirrors	. 73
Instrument cluster	. 73
On-board computer without steer- ing wheel buttons	. 75
On-board computer with steering wheel buttons	. 77
Power supply	. 90
Lighting	. 91
Good visibility	. 97
Climate control	. 99
Driving and parking	110
Braking	114
Automatic transmission	115
Driving the vehicle	117
Driving systems	119
Features	130
Communications	135

Useful information

This Operator's Manual describes all models as well as standard and optional equipment of your vehicle that were available at the time of going to print. Country-specific variations are possible. Note that your vehicle may not be equipped with all of the described functions. This also applies to systems and functions relevant to safety.

Read the information on qualified specialist workshops: (⊳ page 19).

Opening and closing

Key

/ WARNING

Do not leave children unsupervised in the vehicle, even if they are secured in a child restraint system. Children could otherwise injure themselves on parts of the vehicle. They could be severely or even fatally injured by prolonged exposure to intense heat or cold.

If children open a door, they could:

- injure other people
- get out of the vehicle and thereby injure themselves or be injured by a passing
- · severely injure themselves by falling down, in particular due to the vehicle height

Always take the key with you when leaving the vehicle, even if you are only leaving for a short time.

The vehicle comes equipped with 2 or 4 remote controls with an integrated folding key, or 4 keys.

You must have any keys that are not delivered with the vehicle programmed before use. Further information can be obtained from any authorized Sprinter Dealer.

Always take the key with you when leaving the vehicle, even if you are only leaving it for a short time.

Information on unlocking and locking the vehicle with a key can be found in the "Locking/unlocking the vehicle using the remote control with integrated key" (⊳ page 56)

Remote control with an integrated folding key

General notes

The vehicle comes equipped with two or four remote controls with an integrated folding key, which are referred to simply as key in this manual. The remote control of the key has a range of up to 32 ft (10 m). You must have any keys that are not delivered with the vehicle programmed before use. Further information can be obtained from any authorized Sprinter Dealer.

The key's remote control locks/unlocks the driver's door and/or the following centrally if the factory settings have not been changed:

- · the driver's and the co-driver's door
- · the sliding doors
- · the rear doors
- 1 If the driver's or co-driver's door is not closed, the corresponding door is not locked. If a sliding door or a rear door is not closed properly, none of the rear doors are locked.

If there is a key is in the ignition lock, the remote control is inoperative. When you lock or unlock the vehicle with the remote control, always pay attention to the flashing of the turn signal lamps. Also check the locking knobs of the doors.



↑ WARNING

Do not leave children unsupervised in the vehicle, even if they are secured in a child restraint system. Children could otherwise injure themselves on parts of the vehicle. They could be severely or even fatally injured by prolonged exposure to intense heat or cold.

If children open a door, they could:

- injure other people
- get out of the vehicle and thereby injure themselves or be injured by a passing vehicle
- severely injure themselves by falling down, in particular due to the vehicle height

Always take the key with you when leaving the vehicle, even if you are only leaving for a short time.



Remote control with an integrated folding key

- 1 To unlock the sliding doors and the rear door
- ② To unlock the driver's door only or the vehicle centrally
- (3) To lock the vehicle centrally
- (4) Key release button
- ⑤ Battery check lamp
- Do not expose the key to high levels of electromagnetic radiation since this could interfere with the operation of the key. Protect the key from moisture to prevent malfunctions.
- ① Use the remote control of the key only when in immediate proximity of the vehicle. This prevents theft.

You can also unlock the driver's door and the rear door using the folding key (> page 56).

Checking the batteries

- ▶ Press the 🕡 📵 button for longer than two seconds.
 - If battery indicator lamp ⑤ lights up briefly, the batteries in the remote control still have sufficient charge. Otherwise, change the batteries immediately (▷ page 252).
- When you are testing the batteries and your vehicle is within the range of the remote control, the vehicle is unlocked/ locked each time you operate the respective button.

Unlocking/locking the vehicle using the remote control

The turn signals flash once. The Anti-Theft Alarm system (ATA) is deactivated.

- ► To unlock the sliding doors and rear door: press the button.


 The turn signals flash once.
- ► To unlock centrally: unlock the driver's door.
- ▶ Press the unlocking button again within two seconds.
 The turn signals flash once.
- 1 Cargo Vans and Passenger Vans only: if you unlock the vehicle using the remote control and do not open a door within 40 seconds, the vehicle is automatically relocked.
- ► To lock centrally: press the locking button.

The turn signals flash three times when the drive authorization system or the Anti-Theft Alarm system (ATA) is activated and all the doors are closed.


Make sure that the locking knobs have dropped down.

Locking the vehicle using the folding key

You can also unlock/lock the driver's door and the rear door using the folding key.



Driver's door



Rear door

- 1 To lock
- 7 To unlock
- ➤ To unlock the driver's or rear door: press the key release button on the remote control.

The key folds out.

- Slide the key into the door lock as far as it will go and turn to position 2.
 The door is unlocked.
- 1 The Anti-Theft Alarm system (ATA) is triggered when you open the vehicle using the folding key.

The alarm can be disabled in the following ways:

- ▶ Press or on the remote control.
- ▶ Insert the key into the ignition lock.

- ➤ To lock the vehicle: lock all doors except the driver's door and, if necessary the rear door, from inside. To do this, press down the door locking buttons.
- Press the key release button on the remote control.

The key folds out.

► Insert the key into the door lock of the rear door as far as it will go and turn to position 1.

The rear doors are locked.

► Insert the key into the door lock of the driver's door as far as it will go and turn to position 1.

The driver's door is locked.

Central locking

Important safety notes

You can open a locked door from the inside at any time.

MARNING

Do not leave children unsupervised in the vehicle, even if they are secured in a child restraint system. Children could otherwise injure themselves on parts of the vehicle. They could be severely or even fatally injured by prolonged exposure to intense heat or cold.


If children open a door, they could:

- injure other people
- get out of the vehicle and thereby injure themselves or be injured by a passing vehicle
- severely injure themselves by falling down, in particular due to the vehicle height

Always take the key with you when leaving the vehicle, even if you are only leaving for a short time.

Locking and unlocking manually

Using the central locking button, you can centrally lock/unlock either the entire vehicle or just the sliding doors and rear doors from the inside.




- ► To lock/unlock the entire vehicle: press upper section ① of the central locking button when the doors are closed. When the entire vehicle is locked, the indicator lamp in the central locking button lights up.
- If the key is in position 0 or no longer in the ignition lock, the indicator lamp in the central locking button remains lit for five seconds.
- ➤ To lock/unlock the sliding doors and rear doors: press lower section ② of the central locking button when the doors are closed.

When the sliding doors and rear doors are locked, the indicator lamp in the central locking button lights up.

Automatic locking

General notes

The vehicle locks automatically as standard once a speed of 9 mph (15 km/h) has been reached. Depending on the vehicle's equipment, the doors may be locked automatically once the ignition is switched on. Information on the functions of the automatic locking mechanism of your vehicle can be obtained from any authorized Sprinter Dealer.



If the automatic locking when driving function is activated, there is a risk of being locked out when the vehicle is pushed or towed.

For this reason, deactivate the automatic locking when driving function:

- before pushing the vehicle
- · before towing the vehicle
- if you are only leaving the vehicle for a brief period

If activated, automatic locking is deactivated when the vehicle is unlocked or locked using the central locking button.

Automatic locking is reactivated after the ignition is switched off or a door is opened with the vehicle stationary.

Activating automatic locking when driving

- ► Turn the key to position 1 or 2 in the ignition lock when the doors are closed.
- ► For the entire vehicle: press upper section ① of the central locking button until the indicator lamp in the button flashes four times.
- ► For the sliding doors and rear doors only: press lower section ② of the central locking button until the indicator lamp in the button flashes four times.

Deactivating automatic locking when driving


- ► Turn the key to position 1 or 2 in the ignition lock when the doors are closed.
- ► For the entire vehicle: press upper section ① of central locking button until

the indicator lamp in the button flashes twice.

► For the sliding doors and rear doors **only:** press lower section (2) of the central locking button until the indicator lamp in the button flashes twice.


You could otherwise cause injury to yourself and others.

You can open the driver's or co-driver's door from the inside at any time, even if it is locked.



▶ Pull door handle ①. Locking knob (2) pops up. The door opens.

Ignition lock



- o To insert/remove the key, to lock the steering wheel
- 1 To unlock the steering wheel, power supply for some consumers (e.g. the radio)
- **2** To switch on the ignition, power supply for all consumers, preglow and drive position
- 3 To start the engine
- 1 To unlock the steering wheel, move the steering wheel slightly while turning the key to position 1.

On vehicles with a battery isolating switch, you must first switch on the electrical system (⊳ page 90).

Driver's door and co-driver's door

↑ WARNING

Make sure that nobody can become trapped as you close and open the doors. Exercise particular care, especially if children are near the vehicle.

Only open the doors when road and traffic conditions permit. Make sure that there is sufficient clearance when opening the doors.

Sliding door

General notes



↑ WARNING

Make sure that nobody can become trapped as you close and open the doors. Exercise particular care, especially if children are near the vehicle.

Only open the doors when road and traffic conditions permit. Make sure that there is sufficient clearance when opening the doors. You could otherwise cause injury to yourself and others.

↑ WARNING


If the vehicle is parked on an incline, the sliding door may move of its own accord if it is open but not engaged. You and others could then become trapped.

Make sure that the sliding door is engaged in the active retainer.

The sliding door is equipped with an active retainer, which engages the door at the end stop when opened.

The sliding door of your vehicle can be equipped with an electrical access step. Observe the notes on the electrical step when opening and closing the sliding door (> page 59).

You can also lock the sliding door in place around halfway when opening/closing. The door does not have to be opened fully when getting into or out of the vehicle. The intermediate detent does not fully engage the sliding door.



Opening/closing the sliding door from the outside

- ► **To open:** pull door handle ①. The sliding door opens.
- ► Slide the sliding door by handle ① back to the stop.
- ► Check the sliding door detent.

 The sliding door must be engaged.
- ► **To close:** pull door handle ① in the "close door" direction.
 - The sliding door is released from its detent.
- ► Holding door handle ①, slide the door firmly towards the front until it engages.

Opening/closing the sliding door from the inside

- ► To unlock: pull locking knob ④ upwards. Only this sliding door unlocks. All other doors that were previously locked remain locked.
- ▶ To open: press button ②.

- ► Slide the sliding door by handle ③ back to the stop.
- Check the sliding door detent.
 The sliding door must be engaged.
- ► To close: slide the sliding door firmly forwards by handle ③ until it engages.
- ➤ To lock: press locking knob ④ down.

 Only the sliding door is locked. All other doors that were previously unlocked remain unlocked.

Electrical closing assist

If your vehicle is equipped with electrical closing assist, you will require less force to close the sliding door.

↑ WARNING

Make sure that nobody can become trapped as you close the sliding door.

If there is a risk of entrapment, pull the outside door handle or press the button on the inside door handle and open the door.

Electrical step

↑ WARNING

If you do not use the grab handle and the step, you could injure yourself when getting in and out of the vehicle.

In order to reduce risks:

- draw the passengers' attention to the electrical step. Wait until the electrical step is fully extended.
- do not jump out of the vehicle.
- only use the grab handle and step. These are the only parts of the vehicle designed to take a person's weight.
- keep access steps and entry sills free from dirt, e.g. mud, clay, snow and ice.

MARNING

The electrical access step extends automatically and can come into contact with

body parts when the sliding door is opened. There is a risk of injury.

Please pay particular attention when opening a sliding door with an electrical access step. Ensure that there is sufficient clearance for the access step when opening the sliding door.

The sliding door of your vehicle can be equipped with an electrical access step.



Electrical step

▶ When getting in and out of the vehicle, use the grab handles and step (1).

Electrical access step (1) extends when the sliding door is opened and retracts when the sliding door is closed.

Electrical step (1) is equipped with an obstruction detection device on the front side. If the step comes into contact with an obstacle while it is extending, it stops. After you have removed the obstacle, you must first close the sliding door and open it once again so that the step can extend completely.

f the electrical step obstructs loading, you can prevent the step from extending when opening the sliding door via obstacle detection. The electrical step can then remain retracted and a forklift or other lifting equipment can be moved nearer to the load compartment.

Vehicles without steering-wheel buttons: if the indicator lamp in the instrument cluster lights up and a warning tone sounds, electrical step (1) is malfunctioning (⊳ page 199).

Vehicles with steering-wheel buttons: if the Electrical Step message is shown in the display and a warning tone sounds, electrical step (1) is malfunctioning (\triangleright page 208).

If electrical step (1) is malfunctioning, the step may only partially extend/retract or may not extend/retract at all. If a malfunction does occur, you will have to retract and lock electrical step (1) manually before continuing the journey (⊳ page 252).

Before the passengers get out of the vehicle, let them know that electrical step (1) might not be extended.

Rear doors

Important safety notes



♠ WARNING

Always make sure that there is sufficient room for approaching traffic when opening the rear doors and that nobody can become trapped. You could otherwise injure yourself or others by opening the rear doors.

♠ WARNING

If you open the rear doors to 90° (detent position), the rear lamps are no longer visible.

The vehicle is no longer sufficiently visible from the rear and will only be recognized as an obstacle at a late stage by other road users. This could lead to an accident.

Therefore, in such a situation, ensure that the vehicle is visible from the rear according to the respective national regulations, e.g. with a warning triangle.


Make sure that there is sufficient clearance when opening the rear doors. You could otherwise damage the vehicle and objects in close range of the rear doors.

You can lock the rear doors at an angle of 90°, 180° and 270°. Always make sure that the

open rear door is correctly engaged in the detent.

Opening the rear doors from the outside

Opening the right-hand rear door




- ▶ Pull handle ①.
- ➤ Swing the rear door to the side until it engages.

Opening the left-hand rear door



- ► Make sure that the right-hand rear door is open and engaged.
- ▶ Pull release handle ① in the direction of the arrow.
- ► Swing the rear door to the side until it engages.

Opening the rear doors to an angle of 180° or 270°




• Vehicles with 270° pivoting rear doors: If you prefer to keep door retainer • out of the loading area when loading the vehicle, you can swivel it 180° against the spring force and onto the door and engage it. The door retainer remains in this position and will not swivel back to its original

Before closing the door, release door retainer ① from the detent and return it to its original position.

▶ Open the rear door to about 45°.

position.

- ▶ Pull and hold door retainer ① in the direction of the arrow.
- ► Open the rear door more than 90°, so that the door retainer cannot engage.
- ► Release the door retainer and open the door to an angle of 180° or 270°.



▶ With the rear door opened to an angle of 270°, push it against magnetic door retainer (2) on the side wall. When the magnet on the rear door is in contact with magnetic door retainer (2), the rear door is held in this position.

Closing the rear doors from the outside

↑ WARNING

Make sure that nobody can become trapped as you close the rear doors.

- ▶ Pull the rear door away from magnetic door retainer (2).
- ► Close the left-hand rear door firmly from the outside.
- ► Close the right-hand rear door firmly from the outside.

Opening/closing the rear doors from the inside

The handle is on the inside of the right-hand rear door. If a white marking is visible, this indicates that the rear door is unlocked.



Rear door

- ▶ To unlock: slide latch ② to the left. You will see a white marking. Only the rear door unlocks. All other doors that were previously locked remain locked.
- ▶ To open: pull opening lever (1) and open the unlocked rear door.

↑ WARNING

Make sure that nobody can become trapped as you close the rear doors.

- ▶ To close: make sure that the left-hand rear door is closed.
- ▶ Pull the rear door firmly by the door handle to close it.
- ▶ To lock: slide latch ② to the right. The white section is no longer visible. Only the rear door is locked. All other doors that were previously unlocked remain unlocked.

Partition sliding door

Important safety notes



↑ WARNING

If the partition sliding door is open and not engaged, it could move automatically while the vehicle is in motion. You or others could become trapped or could be distracted from the traffic conditions, thus causing an accident.

Before driving off, make sure that the partition sliding door is closed and that the lock is engaged.




↑ WARNING

Make sure that nobody can become trapped as you close the partition sliding door.

The partition sliding door is in the partition between the cab and the cargo compartment.

Opening/closing the partition sliding door from the cab




▶ To open: turn the key counter-clockwise

The sliding door is unlocked.

- ▶ Slide the sliding door to the stop in the direction of arrow (2).
- ► To close: slide the sliding door in the direction of arrow (1) until it engages. The sliding door can be locked using the key.

Opening/closing the partition sliding door from the cargo compartment



▶ To unlock: press the catch in the direction of arrow (3).

The sliding door is unlocked.

- ▶ Slide the sliding door to the stop in the direction of arrow (1).
- ▶ To close: slide the sliding door in the direction of arrow (2) until it engages.

Opening/closing the windows

Side windows


Reset the side windows if there has been a malfunction or an interruption in the voltage supply (⊳ page 64).

↑ WARNING

Make sure that nobody can become trapped between the side window and the door frame when a side window is opened. Do not touch or lean against the side window during the opening procedure. You could become trapped between the side window and the door frame as the side window moves down. If there is a risk of becoming trapped, release the switch or pull the switch upwards to close the side window again.

↑ WARNING

Make sure that nobody can become trapped as you close the side windows. If there is a risk of somebody becoming trapped, release the switch or push the switch again to reopen the side window.



Control panel (example, driver's door)

- 1) Power window, left
- 2 Power window, right
- ► Turn the key to position 2 in the ignition
- ► To open/close: pull or press switch (1) or (2) until the window has reached the desired position.

If you press the switch beyond the pressure point and then release it, the window opens automatically. To stop the movement, press or pull the switch again.

↑ WARNING

Do not leave children unsupervised in the vehicle, even if they are secured in a child restraint system. Children could otherwise injure themselves on parts of the vehicle. They could be severely or even fatally injured by prolonged exposure to intense heat or cold.

If children open a door, they could:

- injure other people
- get out of the vehicle and thereby injure themselves or be injured by a passing
- · severely injure themselves by falling down, in particular due to the vehicle height

Always take the key with you when leaving the vehicle, even if you are only leaving for a short time.

Resetting the side windows

Reset the side windows if there has been a malfunction or an interruption in the voltage supply.

▶ Pull the two power window switches and hold for approximately one second after closing the side window.

Theft deterrent locking system

Immobilizer

The immobilizer prevents the vehicle from being started without the correct key.

When leaving the vehicle, always take the key with you and lock the vehicle. The engine can be started by anyone if the key is left inside the vehicle.

- ▶ To activate: remove the key from the ignition lock.
- ▶ To deactivate: insert the key into the ignition lock and turn to position 2.
- 1 The immobilizer is always deactivated when you start the engine.

In the event that the engine cannot be started when the starter battery is fully charged, the immobilizer may be faulty. Contact an authorized Sprinter Dealer or call 1-877-762-8267 (USA) or 1-800-387-0100 (Canada).

ATA (Anti-Theft Alarm system)

If the alarm system is armed, a visual and audible alarm is triggered when the following are opened:

- a door
- · the hood

The alarm is not switched off, even if you close the open door that triggered it, for example.

- ► To arm: close all doors.
- ► Lock the vehicle using the button on the key.

The indicator lamp in the upper central locking button (⊳ page 57) flashes.

- ▶ To deactivate: unlock the vehicle using the button on the remote control. The indicator lamp in the upper central locking button (⊳ page 57) goes out.
- Cargo Van and Crew Van only: Unless you open a door within 40 seconds after unlocking the vehicle:
 - the vehicle will be locked again.
 - the anti-theft alarm system will be re-
- 1 The alarm system will be triggered if the vehicle was previously locked with the key and is then unlocked from the inside.

► To stop the alarm: insert the key into the ignition lock.

or

▶ Press the button on the remote control.

The alarm is switched off.

Tow-away alarm

A visual and audible alarm is triggered if the inclination of the vehicle changes when towaway protection is armed.

1 The alarm signal is triggered, for example if the vehicle is being jacked up on one side, shortly before the wheel leaves the ground.

Tow-away protection is automatically armed approximately 20 seconds after you lock the vehicle.

Tow-away protection is automatically deactivated when you unlock the vehicle.

Deactivate tow-away protection if the vehicle is being transported or loaded onto another vehicle. This will prevent a false alarm.



- ➤ To deactivate when transporting the vehicle: turn the key to position 0 or 1 in the ignition lock or remove the key.
- ► Press button ①.
 Indicator lamp ② lights up for approximately five seconds after the button is released.
- ► Lock the vehicle with the key. Tow-away protection remains deactivated until you lock the vehicle again.

Interior motion sensor

If the anti-theft alarm system is armed and the vehicle is locked, a visual and audible alarm is triggered if one of the side windows or the rear window on your vehicle is smashed and someone reaches into the interior, for example.

i If the interior motion sensor is armed and the auxiliary heating system (▷ page 106) switches on, a false alarm may occur as a result of interior temperature monitoring. In this case, switch off either the interior motion sensor or the auxiliary heating.

Arming the interior motion sensor

- ► Close the side windows.

 This will prevent false alarms.
- ► Lock the vehicle.

 The interior motion sensor is armed after approximately 40 seconds.
- Do not leave anything (e.g. mascots or coat hangers) hanging on the rear-view mirror or on the grab handles on the headliner. This will prevent a false alarm.

Deactivating the interior motion sensor

Deactivate the interior motion sensor if people or animals remain in the vehicle or you are having the vehicle transported, e.g. by ferry. This will prevent a false alarm.



- ► Turn the key to position **0** or **1** in the ignition lock or remove the key.
- ▶ Press button ①. Indicator lamp ② lights up for approximately five seconds after the button is released.
- ► Lock the vehicle with the key.

 The interior motion sensor remains deactivated until you lock the vehicle again.

Seats

Driver's and co-driver's seat

Standard/luxury/suspension seat

↑ WARNING

If you adjust the driver's seat while the vehicle is in motion, your attention will be distracted from the traffic conditions. You could lose control of the vehicle as a result of sudden seat movements and, thereby, cause an accident.

Therefore, only adjust the driver's seat when the vehicle is stationary and the parking brake is applied.

↑ WARNING

Make sure that nobody can become trapped as you adjust the seat. Never place your hands under the seat or in the vicinity of moving parts.


Your seat must be adjusted in such a way that you can wear the seat belt correctly.

Observe the following points:

- Position the backrest in an almost vertical position so that you are sitting virtually upright.
- Avoid seat positions that prevent the seat belt from being routed correctly. The shoulder section of the belt must be routed over the middle of your shoulder and be pulled tight against your upper body. The lap belt must always pass across your lap as low down as possible, i.e. over your hip

- joints. Do not drive or ride with the backrest reclined too far back.
- Your arms should be slightly bent when you are holding the steering wheel.
- The distance from the pedals should be such that you can depress them fully.
- Adjust your head restraint so that its upper edge is at the same level as the top of your head.
- Make sure that you hear the seat engage.
 Otherwise, the seat is not correctly locked in place.

Failing to observe these instructions may lead to injury.



- (1) Seat fore-and-aft adjustment
- ② Lumbar support adjustment
- 3 Seat backrest adjustment
- 4 Seat height adjustment
- Seat cushion angle adjustment
- 6 Seat suspension adjustment
- (7) Seat suspension lock
- Depending on the seat model, some adjustments may not be available.
- ► To adjust the seat fore-and-aft position: pull lever ① up.
- ► Slide the seat forwards or back until you can depress the pedals.

- ▶ Release lever (1).
- ► Slide the seat forwards or back until you hear it engage.
- ► To adjust the backrest: turn handwheel

 ③ towards the front.

The seat backrest moves to a vertical position.

- ► Turn handwheel ③ towards the rear.

 The seat backrest tilts towards the rear.
- ➤ To adjust the seat height: press or pull lever ④ repeatedly until you have reached the desired seat height.
- ► To adjust the seat angle: turn handwheel
 (5) towards the front.

The front of the seat cushion is lowered.

- ► Turn handwheel ⑤ towards the rear.

 The front of the seat cushion is raised.
- 1 The lumbar support allows you to use the backrest to increase the support provided to the lumbar spine.

When the lumbar support is correctly adjusted, it reduces strain on your back while driving.

► To adjust the lumbar support: turn handwheel ② upwards.

This increases the support provided to the lumbar region.

► Turn handwheel ② downwards.

This reduces the support provided to the lumbar region.

The seat suspension must be adapted to your body weight. Adjust the seat suspension only while the seat is unoccupied.

- ► To adjust the seat suspension: take your weight off the seat.
- ► Use handwheel (a) to select the body weight (between 40 and 120 kg) for optimal seat suspension.

The seat suspension will become more rigid the higher you set the weight. It will then not move as far. If the seat moves up and down frequently and to a great extent, you can lock the seat in the lower movement range..

- ➤ To engage the seat suspension lock: turn handle ⑦ downwards.
 When it next moves, the seat will lock in
- 1 The seat suspension lock will only engage if your body weight equals or exceeds the weight selected for the seat suspension.
- ► To release the seat suspension lock: turn lever (7) upwards.

The seat can now move up and down again.

Swiveling front seats

↑ WARNING

position.

Do not start the engine unless the driver's and co-driver's seats are facing in the direction of travel and are locked in position. Only adjust the seats when the vehicle is stationary and the parking brake is applied. You could otherwise lose control of the vehicle as a result of sudden seat movements and thereby cause an accident.

The safety systems only work when the driver's and co-driver's seats are facing in the direction of travel.

The driver's seat and co-driver's seat can be rotated through 180°.

The seats engage when facing in the direction of travel as well as when facing in the opposite direction and also engage at an angle of 50° to the door.

When rotating the seats, make sure that there is sufficient space to do so.

Move the seat forward or back first. This will help to avoid contact with other parts of the interior.


Push the handbrake lever down to the stop. The parking brake or handbrake lever could otherwise be damaged.

1 Always slide the co-driver's seat forwards before rotating it (▷ page 66).

- ► Make sure that the parking brake has been engaged and that the handbrake lever has been pushed down to the stop (▷ page 114).
- Adjust the steering wheel to provide the necessary space to rotate and adjust the driver's seat (⊳ page 72).

↑ WARNING

When releasing and rotating the seats, make sure that you do not trap yourself or others. Never place your hands under the seat or in the vicinity of moving parts.



Seat release (example: co-driver's seat)

- ➤ To rotate the seat: push lever ① on the rear of the seat towards the center of the vehicle and slightly rotate the seat inwards. The rotation device is released.
- ▶ Release lever ①.
- ► Rotate the seat inwards to the desired position.

↑ WARNING

When the seat is facing in the opposite direction to the direction of travel and has been moved to the rearmost position, you could knock against the exposed frame and be injured.

Therefore, always move the seat to a central position above the seat base when leaving it unoccupied. Inform others traveling with you of this risk.

Twin co-driver's seat



- ➤ To fold the seat cushions forwards: lift the seat cushion out of front anchorage ①.
- ▶ Pull the seat cushion forwards slightly and out of rear anchorage ②.
- ► Fold the rear edge of the seat cushion up.
- 1 You can stow various articles in the space under the twin co-driver's seat.
- ► To fold the seat cushion back: fold down the seat cushion by the rear edge.
- ➤ Slide the seat cushion under the seat backrest into rear anchorage ②.
- ▶ Push down on the seat cushion at the front until it engages in front anchorage (1).

Rear bench seat

Rear bench seat of the Crew Van

Important safety notes



Always secure the folded-up seat cushion with the retainer loop. The seat cushion could otherwise drop down unexpectedly and thereby cause injury to yourself or others.




When folding down the seat cushion, make sure that nobody can become trapped.

■ The retainer loop is neither a grab handle for people to use nor a securing point for loads. It may tear if used incorrectly.

Folding the seat cushions



► To fold up the seat cushion: lift seat cushion ① out of the front anchorage and fold upwards in the direction of the arrow.



- 1 The retainer loops are secured to the outer head restraints.
- ► Attach retainer loop ② to hook ③ underneath the folded-up seat cushion ①.
- ► To fold down the seat cushion: hold on to seat cushion ① and detach retainer

- loop ② from hook ③ underneath the folded-up seat cushion.
- ► Fold down seat cushion ①.

 The seat cushion engages automatically.

Rear bench seat in the Passenger Van

Important safety notes

↑ WARNING


The levers on the feet of the rear bench seat must be parallel to the vehicle floor. A two-seat rear bench must only be installed on the driver's side. You can obtain further information from any authorized Sprinter dealer.

The integrated seat belts can only offer the degree of protection for which they are designed if you install the specified rear bench seats correctly. For this reason, only have a four-seat rear bench installed at a qualified specialist workshop.

Keep the seat bench mounting recesses in the vehicle floor free from dirt and foreign objects. This is the only way to guarantee that the locking mechanisms will engage securely. For safety reasons, only have the seat bench mounting recesses for rear bench seats retrofitted at an authorized Sprinter dealer.

- 1 Do not exceed the maximum permissible number of seats for models registered as passenger vehicles.
- I For safety reasons, the four-seat rear bench must only be removed or installed at a qualified specialist workshop.


Removing/installing a two or three-seat rear bench



Locking mechanism lever on the feet of the bench seat

- ➤ To remove the rear bench seat: swivel all levers ① of the bench seat upwards completely.
 - The bench seat moves back into the seat mounting recesses on the vehicle floor.
- ► Lift the bench seat upwards out of the seat mounting recesses.
- ➤ To install the rear bench seat: observe the specified installation position of the bench seat.

Only install the two-seat rear bench on the driver's side.



- ► Examine seat mounting recesses ② on the vehicle floor.
 - Seat mounting recesses ② must be kept free from dirt and foreign objects.
- ▶ Position the bench seat in the direction of travel in the corresponding seat mounting recesses ②.

- ► Slide the bench seat forwards until you hear the locking mechanisms engage.
- ► Check levers ① on the feet of the bench seat.

All levers ① must be flush to the vehicle floor.

Folding seat



Folding seat (example with partition sliding door)

↑ WARNING

When folding down the seat cushion, make sure that nobody can become trapped.

If the key is inserted in the lock of the partition sliding door the risk of injury to the co-driver in the case of steering movements and in the event of an accident is increased.

Remove the key of the partition sliding door before using the folding seat.

- ► Remove key ① from the partition sliding
- ▶ Pull the handle of catch ② in the direction of the arrow and fold seat cushion ③ up or down.
- ▶ Release handle ② when seat cushion ③ has reached the respective end position.
- ► Move seat cushion ③ until it locks into place.

The handle of catch ② must be against the seat frame.

Head restraints

Important safety notes


↑ WARNING

Only drive with the head restraints installed and adjusted correctly. You could otherwise suffer serious or fatal injuries in the area of the upper spinal column.

Adjust your head restraint so that its upper edge is at the same level as the top of your head. The back of your head should be as close as possible to the head restraint when relaxed, so that your head can be properly supported in the event of an accident.

The head restraint must be engaged in a detent.

Adjusting the head restraints



Head restraint (example: luxury head restraint on the co-driver's seat)

- (1) Release button
- ② Head restraint height
- 3 Head restraint angle (luxury head restraints only)
- ▶ To raise: pull the head restraint up to the desired position.
- ▶ To lower: press release button (1) and slide the head restraint down to the desired position.
- ▶ To adjust the angle: hold the head restraint by the lower edge and tilt it to the desired position.


Removing the head restraints

- ▶ Pull the head restraint up to the stop.
- ▶ Press release button (1) and pull out the head restraint.

Installing the head restraints

- Install the head restraints with the front side facing forwards (luxury head restraints).
- ▶ Insert the head restraint so that the rod with the detents is on the left.
- ▶ Push the head restraint down until it engages.

Armrests



- ► To set the armrest angle: fold the armrest upwards (2) by more than 45°. The armrest is released.
- ► Fold the armrest forwards ③ to the stop.
- ▶ Slowly fold the armrest upwards to the desired position.
- ► To fold the armrest up: if necessary, fold the armrest upwards (1) by more than 90°.


Seat heating



↑ WARNING

Repeatedly setting the seat heating to level 3 may result in excessive seat temperatures. The health of passengers that have limited

temperature sensitivity or a limited ability to react to excessively high temperatures may be affected or they may even suffer burn-like injuries. Therefore, do not use seat heating level 3 repeatedly.



The three red indicator lamps in button (1) show the activated heating level 1 to 3.

The system automatically switches down from level 3 to level 2 after approximately five minutes.

The system automatically switches down from level 2 to level 1 after approximately ten minutes.

When you leave your seat, do not place anything on the seat and switch off the seat heating. Do not switch the seat heating on when the seat is not occupied, e.g. when driving without a co-driver. The seat heating may otherwise overheat, causing damage to the seat.

At level 1, the seat heating remains in continuous operation.

- ▶ To switch on: make sure that the key is in position 1 in the ignition lock.
- ▶ Press button (1) repeatedly until the desired heating level is set.
- ▶ To switch off: press button (1) repeatedly until all indicator lamps go out.

Steering wheel



↑ WARNING


Only adjust the steering wheel when the vehicle is stationary. Only drive with the steering wheel locked in position.

An incorrectly secured steering wheel could make it more difficult to steer the vehicle safely since the steering wheel could move unexpectedly when turned. This could result in you losing control of the vehicle and causing an accident, thereby endangering vourself and others.



WARNING

Never leave children unsupervised in the vehicle. They could become trapped if they try to adjust the steering column.



- (1) Steering column fore-and-aft adjustment
- ② Steering column height
- (3) Lever
- ▶ Push lever (3) down to the stop. The steering wheel is unlocked.
- ► Move the steering wheel to the desired position.
- ▶ Pull lever ③ up to the stop. The steering wheel is locked again.

Mirrors

Rear-view mirror

▶ Before starting off, adjust the rear-view mirror by hand in such a way that you can get a good overview of road and traffic conditions.



► Anti-glare mode: push anti-glare lever (1) in the direction of the arrow.

Exterior mirrors

Important safety notes



↑ WARNING

The additional mirrors in the exterior mirrors reduce the size of the image. The objects are actually closer than they appear. You could cause an accident if you only observe the traffic through the additional mirrors.

Therefore, pay particular attention to traffic behind you when maneuvering or passing using the main mirror in the exterior mirrors also and, if necessary, the rear-view mirror.

Adjusting manually

▶ Before starting off, manually adjust the exterior mirrors in such a way that you can get a good overview of road and traffic conditions.

Adjusting electrically

1 The exterior mirrors are automatically heated at low outside temperatures.



Button and switch for mirror adjustment

- ▶ Before pulling away, turn the key to position 2 in the ignition lock.
- ▶ Press the switch to position (1) for the lefthand exterior mirror or to position (2) for the right-hand exterior mirror.
- ▶ Press button ③ at the top, bottom, right or

Adjust the exterior mirrors in such a way that you can get a good overview of road and traffic conditions.

Instrument cluster

Overview



WARNING

No information will be displayed if either the instrument cluster or the display is inoperative.

As a result, you will not be able to see warning and indicator lamps or information about the driving conditions, such as speed or outside temperature. Driving characteristics may be impaired. Adjust your driving style and vehicle speed accordingly.

Contact a qualified specialist workshop immediately.

↑ WARNING

Only use the adjustment buttons on the instrument cluster when the traffic conditions permit. You would otherwise be too distracted and could cause an accident.

Do not reach through the steering wheel to operate the adjustment buttons. The movement of the steering wheel would be significantly impeded. Your attention would also be diverted from road and traffic conditions. This could cause you to lose control of the vehicle, and lead to an accident.

Do not rest your head or chest on the steering wheel or dashboard when operating the adjustment buttons.

You will find page references for further information in the index under "Air bag".

You will find a full overview of the instrument cluster in the "At a glance" section (> page 27).



- 1101.02 2171
- Instrument cluster on vehicles without steering wheel buttons
- ② Instrument cluster on vehicles with steering-wheel buttons
- Adjustment buttons +/-, menu button
 M, reset button 0, service button
 (engine oil level check)

You will find information on the engine oil level check in the "Maintenance" section (> page 174).

The display in the instrument cluster is activated when you:

- open the driver's door
- turn the key to position 2 in the ignition lock
- press the (0) reset button
- switch on the lights

The display switches off automatically after approximately 30 seconds if:

- the vehicle lighting is not switched on.
- the key is in position **0** in the ignition lock.

Speedometer

1 In some countries, a warning sounds when the vehicle reaches the maximum speed limit, e.g. at 75 mph (120 km/h).

The speed can also be shown in the display. You can find information on the digital speedometer for vehicles without steering wheel buttons under (> page 75) and for vehicles with steering wheel buttons under (> page 80).

Tachometer

The red band in the tachometer indicates the engine's overrevving range.


To protect the engine, the fuel supply is interrupted when the red band is reached.

Do not drive in the overrevving range, as this could damage the engine.

○ Environmental information

Avoid driving at high engine speeds. This unnecessarily increases the fuel consumption of your vehicle and harms the environment as a result of increased emissions.

Fuel gauge



- Fuel gauge on vehicles without steering wheel buttons
- ② Fuel gauge on vehicles with steering wheel buttons
- ③ Fuel filler flap location indicator

 the fuel filler cap is on the left-hand side. Fuel filler flap location indicator

 the fuel filler cap is on the right-hand side
- ④ Reserve fuel warning lamp (> page 195)

Information on the Diesel Exhaust Fluid (DEF) gauge can be found in the "Driving the vehicle" section (> page 118).

Trip odometer

- ➤ **To reset:** make sure that the display is showing the trip odometer if you have a vehicle with steering wheel buttons (▷ page 80).
- ► Press and hold the ① reset button until the trip odometer is reset to 0.0.

Instrument lighting

With the lights switched on, you can adjust the brightness of the instrument lighting using the + and - buttons.

- ▶ **Brighter:** press the (+) button.
- ▶ **Dimmer:** press the (-) button.
- Vehicles with automatic headlamp mode: the instrument lighting also adapts to automatic headlamp mode.

On-board computer without steering wheel buttons

Layout and controls

Important safety notes

↑ WARNING

Only use the adjustment buttons on the instrument cluster when the traffic conditions permit. You would otherwise be too distracted and could cause an accident.

Do not reach through the steering wheel to operate the adjustment buttons. The movement of the steering wheel would be significantly impeded. Your attention would also be diverted from road and traffic conditions. This could cause you to lose control of the vehicle, and lead to an accident. Do not rest your head or chest on the steering wheel or dashboard when operating the adjustment buttons.


You will find page references for further information in the index under "Air bag".

The on-board computer is activated as soon as you turn the key to position 1 in the ignition lock.

The on-board computer shows vehicle information and settings in the display. You can control the display and the settings in the on-board computer using the adjustment buttons on the instrument cluster.

Standard display

Overview



- ① Odometer
- 2 Trip odometer

- ③ Clock
- ④ Outside temperature or digital speedometer
- ⑤ Fuel gauge (⊳ page 75)
- Selector lever position or current shift range with automatic transmission

Changing the standard display

- ► Turn the key to position 2 in the ignition lock.
- ► Press the M menu button for longer than one second.

The information shown in the display changes from the outside temperature to the digital speedometer.

Outside temperature display

↑ WARNING

When the temperature displayed is just above freezing point, the road surface may be icy, especially in wooded areas or on bridges. The vehicle could skid if you fail to adapt your driving style. Always adapt your driving style and drive at a speed to suit the prevailing weather conditions.

Changes in outside temperature are displayed with a slight delay.

Menus

Overview

Using the +, -, () or () adjustment buttons, you can select the following functions:

- calling up the service due date (> page 170)
- checking the oil level (▷ page 174)
- preselecting/setting the auxiliary heating switch-on time (> page 106)
- tire pressure monitor (> page 266)
- setting the time (> page 76)

- setting the date (▷ page 76)
- setting constant headlamp mode (> page 76)
- ➤ To return to the standard display: press the (M) menu button for longer than 1 second.

or

Do not press any button for 10 seconds. The display accepts the changed settings.

Setting the time

- ► Turn the key to position 2 in the ignition lock.
- ► Press the (M) menu button repeatedly until the hours figure flashes.
- ▶ Press (+) or (-) to set the hours.
- ▶ Press reset button ①.
 The minute display flashes.
- ▶ Press (+) or (-) to set the minutes.
- ightharpoonup figure 1 in the first the first

Setting the date

- ► Turn the key to position 2 in the ignition lock.
- ▶ Press the M menu button repeatedly until the day flashes.
- ▶ Press (+) or (-) to set the day.
- ► Press reset button ①.

 The month display flashes.
- ▶ Press (+) or (-) to set the month.
- ► Press reset button ①.

 The year display flashes.
- ▶ Press (+) or (-) to set the year.
- 1 If you keep the + or button pressed, the value will change continuously.

Setting constant headlamp mode

If you have switched constant headlamp mode on and the light switch is in the **o** position, the following light up automatically

when the engine is running: the parking lamps, the low-beam headlamps, the tail lamps and the license plate lamps.

For safety reasons, it is only possible to change this setting when the vehicle is stationary. The factory setting is ON in countries in which constant headlamp mode is mandatory.

- ► Turn the key to position 2 in the ignition lock.
- ► Press the M menu button repeatedly until the D indicator lamp in the instrument cluster flashes and the message ON or OFF appears in the display.
- ▶ Press ⊕ or to switch constant headlamp mode on/off.
- 1 USA only:

If you turn the light switch to \bigcirc or \bigcirc , the corresponding light is switched on. Constant headlamp mode remains switched on if you turn the light switch to \bigcirc AUTO.

Canada only:

If you turn the light switch to D, the low-beam headlamps are switched on. Constant headlamp mode remains switched on if you turn the light switch to DOC OF AUTO.

On-board computer with steering wheel buttons

Layout and controls

The on-board computer is activated as soon as you turn the key to position 1 in the ignition lock.

MARNING


Only use the on-board computer when road and traffic conditions permit. You would otherwise be distracted and unable to concentrate properly on driving, and could cause an accident.

The on-board computer shows vehicle information and settings in the display.



Steering wheel with buttons

You can control the display and the settings in the on-board computer with the buttons on the steering wheel.



Several functions are combined thematically in the menus.

The display changes when you press one of the buttons on the steering wheel. You can use a function to call up information or to change the settings for the vehicle.

For example, the **AUDIO** menu has functions for controlling the radio or CD player.

i Operation of the audio equipment using the steering wheel buttons and making settings using the **AUDIO** menu only function with Sprinter audio equipment. If you are using audio equipment from another manufacturer, the described functions may be restricted or not available at all.

You can think of the order of the menus and of the functions within a menu as a circle:

- ▶ Press the ☐ or ☐ button repeatedly.


 The menus are displayed one after the other.
- ▶ Press the or button repeatedly. The functions in the menu/submenu are displayed one after the other.

Unlike other menus, you will find submenus within the Settings menu. For information on how to use these submenus, see the "Settings menu" section (⊳ page 82).

The number of menus depends on your vehicle's equipment.

Menu overview

Diagrams



Generic terms

This is what the displays look like when you scroll through the menus.

1 The generic terms in the tabular overview should make orientation easier for you. However, they are not always shown on the display.

On Sound 5/Audio 20, the on-board computer always shows the **AUDIO** and **TEL** (telephone) menus in English. This is the case even if a different language is selected for the display.

Operation

- ① Operation menu (⊳ page 80)
 - Standard display
 - Calls up the service due date (> page 170)
 - Tire pressure monitor (▷ page 266)
 - Checks the engine oil level (⊳ page 174)
- ② Audio menu (⊳ page 80)
- Message memory menu (⊳ page 81)
- ④ Settings menu (▷ page 82)
- 5 Trip computer menu (⊳ page 88)
- Telephone menu (⊳ page 89)

Operation menu

Overview

Press or to select the following functions in the **Operation** menu:


- display the trip odometer and odometer (standard display)
- display the coolant temperature (> page 80)
- call up the service due date (> page 170)
- tire pressure monitor (⊳ page 266)
- check the oil level (> page 174)

Standard display

In the basic setting, the odometer and the trip odometer are shown in the upper part of the display. This is referred to as the standard display.

Using the steering wheel buttons

▶ Press the ☐ or ☐ button repeatedly until the standard display appears.




- ① Odometer
- (2) Trip odometer
- ③ Outside temperature or digital speedometer
- 4 Clock
- Selector lever position or current shift range

Displaying the coolant temperature

Using the steering wheel buttons

- ▶ Press the ☐ or ☐ button repeatedly until the standard display appears.
- ▶ Press or to select the coolant temperature.



The temperature displayed may climb to 250 °F (120 °C) when the vehicle is being driven in normal conditions, and if the coolant contains the correct concentration of corrosion inhibitor and antifreeze. At high outside temperatures and when driving in mountainous terrain, the coolant temperature may rise to the end of the scale.

Audio menu

General notes

You can use the functions in the **AUDIO** menu to control the audio equipment that you have just switched on.

Operation of the audio equipment using the steering wheel buttons and making settings using the **AUDIO** menu only function as described if Sprinter audio equipment is installed. If you are using audio equipment from another manufacturer, the described functions may be restricted or not available at all.


If no audio equipment (Sound 5 or Audio 20) is switched on, you will see the AUDIO off message.

Selecting a radio station

Using the steering wheel buttons

- ► Switch on the radio (see the separate operating instructions).
- ▶ Press the or button repeatedly until the display shows the currently selected station.

The kind of search depends on the setting for radio station selection (▷ page 87). The nearest stored station will be selected or the station search starts (except on Audio 20).



- Reception frequency
- ② Waveband or waveband with memory preset number
- ▶ Press ♠ or ❖ to select the desired station.
- 1 You can only store new stations on the audio system itself. See the separate operating instructions.

You can also operate the radio in the same way as usual.

Operating the CD player

Using the steering wheel buttons

- ► Switch on the radio (see the separate operating instructions) and select the CD player.
- ▶ Press the or button repeatedly until the settings for the current CD appear in the display.



- ① Current CD (with CD changer)
- ② Current track
- ▶ Press 🗘 or ⊽ to select a CD track.

Message memory menu

The on-board computer stores certain display messages. In the **Message memory** menu, you can call up stored display messages.

↑ WARNING

The on-board computer only records and displays malfunctions and warnings from certain systems. For this reason, you should always make sure that your vehicle is safe to use. You could otherwise cause an accident by driving an unsafe vehicle.

Using the steering wheel buttons

▶ Press the or button repeatedly, until the number of stored display messages, e.g. 2 messages, appears in the display.

If no malfunctions have occurred, the No messages message appears.

- ▶ Press or to scroll through the stored display messages.

 Potential display messages are described in the "Practical advice" section (> page 203).
- ▶ Press the or button to change to a different display.
- 1 The message memory is cleared when you switch off the ignition.

Settings menu

You will find two functions in the Settings menu: the To reset: Press the 0 button for 3 sec. function, with which you can reset all settings to the factory defaults. You will also find submenus which you can use to make individual settings on the vehicle.

Using the steering wheel buttons

▶ Press the or button repeatedly until the Settings menu appears in the display.



Settings menu

Resetting all settings

You can reset the functions in all submenus to the factory settings.

Using the steering wheel buttons

- ▶ Press the ☐ or ☐ button repeatedly until the Settings menu appears in the display.
- ► Press the ① reset button for about three seconds.
 - You will see a message in the display prompting you to press the ① reset button again to confirm.
- Press the ① reset button again.
 The functions of all submenus are reset to the factory settings.
- 1 If you do not press the ① reset button a second time to confirm, the settings are retained. The Settings menu appears again after approximately five seconds. For safety reasons, it is not possible to reset all of the functions while the vehicle is in motion. For example, the Hd1mp

mode function in the Lighting submenuremains unchanged.

Resetting the functions of a submenu

You can reset the functions of an individual submenu to the factory settings.

Using the steering wheel buttons

- ▶ Press the ☐ or ☐ button repeatedly until the Settings menu appears in the display.
- ► Press to switch to the submenu selection.
- ▶ Press + or to select a submenu.
- ▶ Press the ① reset button for about three seconds.

You will see a message in the display prompting you to press the ① reset button again to confirm.

- ▶ Press the ⑥ reset button again. All functions of the submenu are reset to the factory settings.
- 1 If you do not press the ① reset button a second time to confirm, the settings are retained. The Settings menu appears again after approximately five seconds. For safety reasons, it is not possible to reset all of the functions while the vehicle is in motion. For example, the Hd1mp mode function in the Lighting submenu remains unchanged.

Submenus in the Settings menu

Using the steering wheel buttons

- ▶ Press the ☐ or ☐ button repeatedly until the Settings menu appears in the display.
- ▶ Press to switch to the submenu selection.

You will see the collection of submenus. There are more submenus than can be displayed at the same time.



- ▶ Press + or to select a submenu. The submenu currently selected is highlighted.
- ▶ Press to select the function within a submenu.
- ► Change the setting by pressing + or -.

The changed setting is saved.

You can select the following submenus:

- Instrument cluster (> page 83)
 - Units and language settings
 - Status bar settings
- Clock/Date (> page 85)
- Lighting (▷ page 86)
- Activating/deactivating daytime running lamp mode and surround lighting (locator lighting)
- Setting the exterior lighting delayed switch-off
- Vehicle (⊳ page 87)
 - Setting the radio station selection
- Setting the windshield wiper sensitivity
- Auxiliary heating(> page 106)
- Convenience(> page 88)
 - Key-dependent settings

Instrument cluster submenu

Selecting the unit for temperature

Using the steering wheel buttons

- ▶ Press the or button repeatedly until the Settings menu appears in the display.
- ► Press to switch to the submenu selection.

- ► Press + or button to select the Inst. cluster submenu.
- ► Press to select the Temperat.

The selection marker is on the current setting.



▶ Press + or - to select the unit for all messages in the display: °C (degrees Celsius) or °F (degrees Fahrenheit).

Selecting the unit for the digital speedometer

Using the steering wheel buttons

- ▶ Press the or button repeatedly until the Settings menu appears in the display.
- ► Press + or button to select the Inst. cluster submenu.
- ► Press to select the Dig. speedo.

The selection marker is on the current setting.



▶ Press + or - to select the unit for the digital speedometer: km/h or mph.

Selecting the unit for the odometer

Using the steering wheel buttons

- ▶ Press the or button repeatedly until the Settings menu appears in the display.
- ► Press to switch to the submenu selection.
- ► Press + or button to select the Inst. cluster submenu.
- ► Press to select the Trip function.

 The selection marker is on the current setting.



▶ Press + or - to select the unit for all messages in the display: km (kilometers) or miles.

Selecting the language

Using the steering wheel buttons

- ▶ Press the ☐ or ☐ button repeatedly until the Settings menu appears in the display.
- ► Press + or button to select the Inst. cluster submenu.
- ► Press to select the Language function.

The selection marker is on the current setting.



► Use + or - to set the language for all messages.

The languages available are:

- German
- British English
- US English
- French
- Italian
- Spanish

Selecting the display for the status bar

Using the steering wheel buttons

- ▶ Press the or button repeatedly until the Settings menu appears in the display.
- ▶ Press to switch to the submenu selection.
- ► Press + or button to select the Inst. cluster submenu.
- ► Press to select the Select disp.

The selection marker is on the current setting.



Press + or - to select whether to display the outside temperature or the speed (digital speedometer).
The selected display is then shown permanently in the lower part of the display (▷ page 80).

Selecting the unit for the tire pressure

Using the steering wheel buttons

- ▶ Press the or button repeatedly until the Settings menu appears in the display.
- ► Press to switch to the submenu selection.
- ► Press + or button to select the Inst. cluster submenu.
- ► Press to select the Tire pres. function.

The selection marker is on the current setting.



▶ Press + or - to select the unit for the tire pressure in the display: bar or psi.

Clock/Date submenu

Setting the clock

Using the steering wheel buttons

- ▶ Press the ☐ or ☐ button repeatedly until the Settings menu appears in the display.
- ▶ Press to switch to the submenu selection.
- ▶ Press + or to select the Clock/ Date submenu.
- ► Press to select the Set clock Hours or Minutes function.



▶ Press + or - to set the values.

Selecting the time format

Using the steering wheel buttons

- ▶ Press the ☐ or ☐ button repeatedly until the Settings menu appears in the display.
- ▶ Press to switch to the submenu selection.
- ▶ Press + or to select the Clock/ Date submenu.
- ► Press to select the 12/24 h function. The selection marker is on the current setting.



▶ Press + or - to select the 12 h or 24 h clock format.

Setting the date

Using the steering wheel buttons

- ▶ Press the or button repeatedly until the Settings menu appears in the display.
- ► Press + or to select the Clock/
 Date submenu.
- ► Press to select the Date Day or Month or Year function.



▶ Press + or - to set the values.

Lighting submenu

Setting daytime running lamp mode

If you have set daytime running lamp mode and the light switch is in the **0** position, the following light up automatically when the engine is running: the parking lamps, the lowbeam headlamps, the tail lamps and the license plate lamps.

For safety reasons, it is only possible to change this setting when the vehicle is stationary. The factory setting is Constant in countries in which daytime running lamp mode is mandatory.

Using the steering wheel buttons

- ▶ Press the or button repeatedly until the Settings menu appears in the display.
- ► Press to switch to the submenu selection.
- ► Press + or to select the Lighting submenu.
- ► Press to select the Hdlmp mode function.

The selection marker is on the current setting.



- Press + or to select the Manual or Constant (daytime running lamp mode) setting.
- ① USA only:

If you turn the light switch to \bigcirc or \bigcirc , the corresponding light is switched on. Daytime running lamp mode remains activated if the light switch is turned to \bigcirc AUTO.

Canada only:

If you turn the light switch to ①, the low-beam headlamps are switched on. Daytime running lamp mode remains activated if the light switch is turned to ②0000 or AUTO.

1 For safety reasons, it is not possible to reset the Hdlmp mode function to the factory setting while the vehicle is in motion. You will see the following message in the display: Setting only possible at standstill

Switching surround lighting (locator lighting) on/off

If you switch the surround lighting to 0n, the following lamps light up in the dark after you have unlocked the vehicle using the key:

- the parking lamps
- the tail lamps
- the license plate lamps
- the fog lamp

The surround lighting automatically switches off after 40 seconds or when you:

- open the driver's door
- insert the key into the ignition lock
- lock the vehicle using the key

Using the steering wheel buttons

- ▶ Press the ☐ or ☐ button repeatedly until the Settings menu appears in the display.
- ▶ Press to switch to the submenu selection.
- ► Press + or to select the Lighting submenu.
- ► Press to select the Loc. lighting function.

The selection marker is on the current setting.



► Press + or - to switch the surround lighting (locator lighting) to 0n or 0ff.

Setting the exterior lighting delayed switch-off

The Headlamps (delayed headlamp shut-off) function enables you to set whether and for how long the exterior lighting is to remain on in the dark after closing the doors.

If you have set the delayed switch-off and switch off the engine, the following remain lit:

- · the parking lamps
- the tail lamps
- the license plate lamps
- the fog lamp
- 1 You can reactivate this function by opening a door within 10 minutes.

The exterior lighting is switched off after 60 seconds if you do not open a door or if you do not close an opened door after the engine has been switched off.

Using the steering wheel buttons

- ▶ Press the or button repeatedly until the Settings menu appears in the display.
- ► Press to switch to the submenu selection.
- ► Press + or to select the Lighting submenu.
- ► Press to select the Headlamps function.

The selection marker is on the current setting.



▶ Press + or - to select whether and for how long you wish the exterior lighting to remain on.

Vehicle submenu

Setting the radio station selection

The Search function enables you to determine whether the radio should search for a new station or a previously stored station each time the radio is operated using the steering wheel buttons (not with Audio 20).

The Frequency setting starts the station search. The Memory setting selects the next stored station.

Using the steering wheel buttons

- ▶ Press the or button repeatedly until the Settings menu appears in the display.
- ▶ Press + or to select the Vehicle submenu.
- ► Press to select the Search function.

 The selection marker is on the current setting.



▶ Press + or - to select the station search mode.

Setting the windshield wiper sensitivity

You can use the Wipe sensor function to set the sensitivity of the rain/light sensor:

- Level 1: high sensitivity wiping begins even in light rain
- Level 2: moderate sensitivity
- Level 3: low sensitivity wiping only begins in heavy rain

Using the steering wheel buttons

- ▶ Press the or button repeatedly until the Settings menu appears in the display.
- ▶ Press + or to select the Vehicle submenu.
- ► Press to select the Wipe sensor function.

The selection marker is on the current setting.



▶ Press + or - to set the sensitivity of the rain/light sensor.

Convenience submenu

Key-dependent settings

The Key function allows you to define whether settings for the following submenus are stored with a key dependence:

- Inst. cluster (instrument cluster)
- Lighting
- Vehicle

Using the steering wheel buttons

- ▶ Press the or button repeatedly until the Settings menu appears in the display.
- ► Press + or to select the Convenience submenu.
- ► Press the △ button to select the Key function.

The selection marker is on the current setting.



- ▶ Press + or to activate or deactivate key dependency.
- For safety reasons, it is not possible to set the Key function while the vehicle is in motion. You will see the following message in the display: Setting only possible at standstill

Trip computer menu

Settings menu.


You can call up or reset statistical data for the vehicle in the **Trip computer** menu.

Consumption statistics after start

Using the steering wheel buttons

- i When you call up the trip computer again, it displays the last function called up.

 The units of the statistical information displayed are set permanently for each specific country, and are therefore independent of the units selected in the
- ▶ Press the or button repeatedly until the display shows the After start message.



- (1) Distance driven since start
- (2) Time elapsed since start
- (3) Average speed since start
- (4) Average fuel consumption since start

1 If you turn the key to position 0 in the ignition lock or remove it, all the values are reset after approximately four hours.

The values will not be reset if you turn the key back to position 1 or 2 during this time.

Consumption statistics after reset

Using the steering wheel buttons

- ▶ Press the ☐ or ☐ button repeatedly until the display shows the After start message.
- ► Press or repeatedly until the After reset message appears.



- 1) Distance driven since last reset
- 2 Time elapsed since last reset
- 3 Average speed since last reset
- 4) Average fuel consumption since last reset

Calling up the range

Using the steering wheel buttons

- ▶ Press the or button repeatedly until the display shows the After start message.
- ▶ Press the or button repeatedly until the Range message appears. The approximate distance which can be covered with the tank's current contents and your current style of driving is shown.
- If the fuel tank is almost empty, the Please refuel message is shown instead of the range.

Resetting the consumption statistics

Using the steering wheel buttons

- ▶ Press the ☐ or ☐ button repeatedly until the display shows the After start message.
- ▶ Press △ or ▽ to select the function you would like to reset.
- ▶ Press and hold the ① reset button until the values are reset to "0".
- 1 The consumption statistics After start are automatically reset after 999 hours or 9,999 miles (kilometers).

The consumption statistics After Reset are automatically reset after 9,999 hours or 99,999 miles (kilometers).

Telephone menu

You can operate the mobile phone using the buttons on the steering wheel, provided it is connected to the Sprinter hands-free system. See the separate operating instructions. When the mobile phone is ready to receive calls, you will see the mobile phone operational readiness symbol in the TEL menu.

↑ WARNING

The driver's attention to the road must always be his/her primary focus when driving. For your safety and the safety of others, we recommend that you pull over to a safe location and stop before placing or taking a telephone call. If you choose to use the telephone while driving, please use the handsfree device and only use the telephone when road, weather and traffic conditions permit. Some jurisdictions prohibit the driver from using a mobile phone while driving a vehicle. Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your vehicle covers a distance of 44 feet (approximately 14 m) every second.

Accepting a call

You can accept a call at any time, provided the mobile phone is ready to receive calls.

▶ Press the button. The display shows the phone number and/ or the call duration.

Rejecting or ending a call

▶ Press the button. The display shows the mobile phone operational readiness symbol again.

Dialing a number from the phone book

You may select and dial a number from the phone book at any time, provided the mobile phone is ready to receive calls.

- 1 It is only possible to create new phone number entries in the phone book using the mobile phone itself. See the separate operating instructions.
- ▶ Press the press the button repeatedly until the TEL menu appears in the display. The display shows the mobile phone operational readiness symbol.
- ▶ Press 🗘 or 🔯 to switch to the phone book.
- ▶ Press 🗘 or 💎 to select the desired

The display shows the stored names in alphabetical order.

1 The display scrolls through the names rapidly if you press 🔼 or ⊽ for longer than 1 second. Releasing the button stops the rapid scroll.

If you do not wish to make a call, press the **b**utton.

▶ Press the button. The on-board computer dials the corresponding phone number. The display shows the dialing message.

The on-board computer stores the phone numbers in the redial memory.

When a connection is made, the display shows the name of the other person and/ or the call duration.

Redialing

The on-board computer stores the last phone numbers dialed. This means that you do not have to search through the entire phone book.

- ▶ Press the 🗊 or 🗂 button repeatedly until the TEL menu appears in the display. The display shows the mobile phone operational readiness symbol.
- ▶ Press the button. The display shows the most recently dialed numbers or names in the redial memory.
- ▶ Press 🗘 or 🔽 repeatedly until the number or name you are looking for is displayed.
- ▶ Press the button. The on-board computer dials the corresponding phone number.

When a connection is made, the display shows the name and/or the call duration. If the name is not stored in the phone book, the display shows the number you are dialing.

Power supply

Battery isolating switch

Important safety notes

You can use the battery isolating switch to disconnect the power supply to all your vehicle's consumers. This will prevent uncontrolled battery discharge caused by offload current consumption.




↑ WARNING

If the vehicle is equipped with an additional battery in the engine compartment, it is necessary to disconnect both batteries when working on the vehicle electrical circuit. Only then is the electrical system fully disconnected from the power supply.

- 1 Only disconnect the vehicle electrical system from the power supply using the battery isolating switch if the vehicle is to be parked for an extended period or if it is absolutely necessary. After the power supply has been activated, you will need to reset the side windows (⊳ page 64).
- Make sure that the key is in position **0** in the ignition lock and wait at least 20 seconds before disconnecting or connecting the battery isolating switch. You could otherwise damage electrical system components.

Switching off the electrical system




Battery isolating switch in the driver's footwell, on the right-hand side next to the accelerator pedal

- ► Remove the key from the ignition lock and wait for about 20 seconds.
- ▶ Press and hold button ② and unplug connector ① from the ground bolt.
- Clamp connector ① under the accelerator pedal so that it does not make contact with the ground bolt. All starter battery consumers are
 - disconnected from the power supply.
- When you clamp the connector under the accelerator pedal, make sure that the connector does not become damaged or dirty. It may otherwise not be possible to

restore the electrical connection when the parts are reassembled.

Switching on the electrical system



- ▶ Insert the key into the ignition lock.
- ► Press connector ① onto ground bolt ② until you feel it engage and the lock inhibitor is released.

Connector ① must be in full contact with ground bolt ②.

All consumers are reconnected to the DC power supply.

Lighting

General notes

1 When driving in countries in which traffic drives on the opposite side of the road from the country where the vehicle is registered, the oncoming traffic may be blinded. On vehicles with halogen headlamps you must first have the headlamps partially masked. On vehicles with Bi-Xenon headlamps you must first have the headlamps switched over beforehand.

You will find further information in the "Operation" section (▷ page 138).

Lamp failure indicator

The bulb failure indicator monitors all lamps of the exterior lighting with the exception of the front position lamps and the trailer lighting. If a bulb fails, either the

(▷ page 199) indicator lamp lights up or a corresponding message is shown in the display (▷ page 211).

1 Depending on the equipment, the bulb failure indicator can be omitted for all lamps with the exception of the turn signal lamps.


⚠ WARNING

The bulb failure indicator is only an aid. You are responsible for the proper functioning of the vehicle lighting. Insufficient or nonfunctioning vehicle lighting puts the operating safety of the vehicle at risk. You could cause an accident and injure yourself or others.

Therefore, check the lighting equipment of the vehicle before each journey and, if necessary, check the operation and condition of the trailer lighting equipment.

Light switch

Configuration



Light switch between driver's door and steering wheel

1 Light switch

The symbols on the light switch have the following meanings:

Automatic headlamp mode

Lights off/daytime running lamp mode

- Parking lamps, license plate lamp and instrument lighting on
- Low-beam/high-beam headlamps (depending on the position of the combination switch)

Low-beam headlamps

- ► Turn the key to position 1 in the ignition lock.
- ► Turn the light switch to ☑.

 The ☑ indicator lamp in the instrument panel lights up.

Daytime running lamp mode

You can adjust daytime running lamp mode in the on-board computer:

- vehicles with steering wheel buttons (> page 86)
- vehicles without steering wheel buttons
 (▷ page 76)

This is not possible in countries where daytime running lamp mode is a legal requirement.

➤ Turn the light switch to **0**. The low-beam headlamps, parking lamps and license plate lamp are switched on when the engine is running.

The indicator lamp in the instrument panel lights up.

1 USA only:

When you turn the light switch to 30% or 30%, the respective light comes on. When the light switch is turned to 30%, daytime running lamp mode remains switched on.

1 Canada only:

When you turn the light switch to D, the low-beam headlamps are switched on.
When the light switch is turned to C or AUTO, daytime running lamp mode remains switched on.

Automatic headlamp mode

Parking lamps, low-beam headlamps and the license plate lamp are switched on automatically, depending on the ambient light.

↑ WARNING

If the light switch is set to AUTO, the low-beam headlamps will not come on automatically if it is foggy. This could endanger you and others. Therefore, turn the light switch to ID in fog.

The automatic headlamp feature is only an aid. The driver is responsible for the vehicle's lighting at all times.

► Turn the light switch to AUTO.

The parking lamps are switched on/off automatically when the key is in position 1 in the ignition lock.

The parking lamps, low-beam headlamps and license plate lamp are switched on/off in accordance with the ambient light and only when the engine is running.

Front fog lamps/rear fog lamp

- ► Turn light switch (1) to 🗊 or 💢.
- 1 If your vehicle is only equipped with rear fog lamps, you must turn the light switch to
- ► Front fog lamps: pull light switch ① out to the first stop.


The green indicator lamp next to the light switch lights up.

▶ Rear fog lamp: pull light switch ① out to the second stop.

The yellow 0\(\frac{1}{2}\) indicator lamp next to the light switch lights up.

Combination switch

High-beam headlamps and high-beam flasher



- 1 High-beam headlamps
- 2 High-beam flasher
- ► To switch on the high-beam headlamps: switch on the low-beam headlamps (> page 92).
- ► Press combination switch ① forwards.

 The ☐ indicator lamp in the instrument cluster lights up.
- ➤ To operate the high-beam flasher: turn the key to position 1 or 2 in the ignition lock.
- ▶ Pull the combination switch briefly in direction ②.

Turn signals



- ① To indicate a right turn
- (2) To indicate a left turn

▶ To indicate: press the combination switch in desired direction (1) or (2), until it engages.

The combination switch automatically returns to its original position after large steering movements.

► To indicate briefly: press the combination switch briefly in desired direction (1) or (2).

The corresponding turn signal flashes three times.

Cornering light function (vehicles with Bi-Xenon headlamps)

When the low-beam headlamps are switched on, the cornering light function improves the illumination of the road in the direction you are turning.

The cornering light function switches on automatically, if:

- you are traveling at a speed of less than 25 mph (40 km/h) and you switch on the indicator lamp or turn the steering wheel.
- you are traveling at a speed of between 25 mph (40 km/h) and 43 mph (70 km/h) and you turn the steering wheel.

The cornering light may continue to be lit for a short time, but is deactivated automatically after a maximum of three minutes.

Hazard warning lamps

The hazard warning lamps work even when the ignition is switched off.

The hazard warning lamps switch on automatically if:

· you brake sharply and bring the vehicle to a halt from a speed of more than 43 mph (70 km/h).



- ► To switch on/off: press button ①.
- If you have indicated a turn while the hazard warning lamps are switched on, only the turn signal lamps on the side of the vehicle selected will light up.

If the hazard warning lamps have been switched on automatically, press the hazard warning lamp switch to switch them off.

↑ WARNING

If you open the rear doors 90° (detent position) or fold down the platform tailgate on vehicles with a platform, the rear lights are covered.

The vehicle will then be unsafe as its rear lights will not be visible for approaching traffic. Other road users may not realize until too late that it is an obstruction. This could lead to an accident.

You should ensure that the vehicle is visible from the rear in accordance with the relevant national regulations, by using the warning triangle for instance.

Front interior lighting

Automatic control

The interior lighting comes on if you:

- · unlock the vehicle
- open a door
- remove the key from the ignition lock

The interior lighting switches off automatically. If a door is left open, the interior lighting switches off after approximately 20 minutes.

Standard front interior lighting



- 1 To switch on the interior lighting
- ② Automatic control
- 3 To switch off the interior lighting

Front interior lighting with overhead control panel



- To switch the left-hand reading lamp on/ off
- ② To switch the right-hand reading lamp on/ off
- ③ Right-hand reading lamp
- (4) Interior light
- To switch the automatic control system on/off
- (6) To switch the interior lighting on/off
- (7) Left-hand reading lamp

If you switch on interior lights or the reading lamps manually, they switch off automatically after about twenty minutes.

Rear interior lighting

Switching the standard interior lighting on/off

In Cargo Vans/Crew Vans equipped with standard interior lighting, the switch for the interior lighting is located on the rear lights in the cargo compartment/vehicle interior.



Interior light with switch

- (1) To switch on the interior lighting
- ② To switch off the interior lighting
- ③ Automatic control

If the switches on the interior lights are set to automatic control, the interior lights are switched on as soon as you open a door or unlock the vehicle.

1 The interior lights switch off automatically after 20 minutes.

The interior lights switch on again if you:

- open a door
- switch on the ignition again

Switching convenience interior lighting on/off

In Crew Vans equipped with convenience interior lighting, you can switch the rear interior lighting on and off from the driver's workstation.

In addition, there is also a switch on each interior light, which can be used to switch the lights on / off separately.



Switch for the rear interior lighting

- (1) To switch on the interior lighting
- ② Automatic control
- To switch off the interior lighting
- ▶ To activate: press upper section (1) on the switch.

The interior lights are switched on if the switches on the interior lights (⊳ page 95) have been switched to the On position.

▶ To deactivate: press lower section (3) of the switch.

The interior lights are all switched off, regardless of the position of the switch on the interior light.

- ► To switch on automatic control: move the central control switch for the rear interior lighting to position (2). If the switches on the interior lights (⊳ page 95) are set to automatic control, the interior lights are switched on as soon as you open a door or unlock the vehicle.
- The interior lights switch off automatically after 20 minutes.

The interior lights switch on again if you:

- open a door
- · switch on the ignition again

Cargo compartment motion detector

The interior lighting is also switched on by the motion detector in the cargo compartment on Cargo Vans equipped with this feature.

↑ WARNING

Motion detectors use the invisible infrared radiation emitted by LEDs (light emitting diodes).

Do not view invisible infrared radiation, laser class 1M, directly using optical instruments, such as eyeglasses.

Your eyes could be injured.

If the motion detector detects a movement in the cargo compartment when the vehicle is stationary, the interior lighting switches on for approximately 2 minutes.

The interior lighting can be switched on by the motion detector within 4 seconds if:

- the interior light switch (▷ page 95) is set to "Automatic control"
- the vehicle is stationary, the parking brake is applied and the brake pedal is not being depressed


or

- the selector lever is in position **P** on vehicles with automatic transmission and the brake pedal is not being depressed and
- the vehicle has not been locked from the outside using the key

The motion detector switches off automatically if no change is detected in the vehicle for several hours, e.g. if a door is opened, if the ignition key is turned, etc. This prevents the battery from becoming discharged.

Good visibility

Windshield wipers



- ① Single wipe/to wipe with washer fluid (▷ page 98)
- (2) To switch on the windshield wipers
- ► To switch on: turn the key to position 1 or 2 in the ignition lock.
- Wehicles with rain/light sensor:
 Switch the wipers off in dry weather.
 Otherwise, dirt or optical effects may cause undesired windshield wiper sweeps. This could then damage the windshield wiper blades or scratch the windshield.
- ► Turn the combination switch in the direction of arrow ② to the appropriate setting depending on the intensity of the rain.

The detent positions of the combination switch correspond to the following wiper speeds:

- 0 Windshield wipers off
- I Intermittent wipe
- II Normal wipe
- III Rapid wipe
- 1 Canada only:

If the windshield wipers are switched on and you stop the vehicle, the windshield wiper speed is reduced. For example, if you have selected level II and stop the vehicle, wiping continues with intermittent wipe while the vehicle is stationary. If

intermittent wipe is selected, the intervals become longer.


Vehicles with a rain/light sensor: you can use level I as the universal setting. The rain/light sensor sets the appropriate wiping frequency automatically, according to the intensity of the rain. When you stop the vehicle, levels III and II are switched down to level I automatically.

The windshield wipers will return to the original level when you drive faster than 5 mph (8 km/h) again.

Setting the sensitivity of the rain/light sensor (▷ page 87).


Rear window wiper

The rear window wiper switches on automatically if you engage reverse gear and the windshield wipers are on.



- 1) Switch
- 2 To wipe with washer fluid
- 3 Intermittent wipe
- 4 To switch off the wiper
- 5 To wipe with washer fluid
- ➤ To switch on: turn the key to position 1 or 2 in the ignition lock.
- ► Turn switch ① to the corresponding position
- 1 Use washer fluid to wipe the rear window even when it is raining. This prevents the rear window from smearing.

Windshield washer system



- 1 To wipe with washer fluid
- (2) To switch on the windshield wipers
- ▶ To switch on: press the combination switch beyond the pressure point in the direction of arrow (1).

The windshield wipers wipe with washer fluid.

Wipe the windshield using washer fluid even if it is raining. By doing so, you will prevent smears on the windshield.

Headlamp cleaning system

- ► To activate: switch on low-beam headlamps.
- ▶ Switch on the windshield washer system. The headlamps are cleaned with a highpressure water jet.

Windshield defroster

Important safety notes



↑ WARNING

Clear all windows of ice and snow before driving off. Reduced visibility can, otherwise, endanger you or others.

Windshield heater

The windshield heater is operational when the engine is running.

The windshield heater consumes a lot of power. You should therefore switch off the heater as soon as the windshield is clear. The heating switches off automatically after five minutes.




Windshield heater switch

- ▶ Start the engine.
- ▶ To switch on/off: press the (1) switch. The indicator lamp in the switch comes on when the windshield heater is switched on.

Rear window defroster

The rear window defroster consumes a lot of power. Switch the rear window defroster off when the rear window is clear. The rear window defroster switches off automatically after approximately twelve minutes.



Rear window defroster switch

- ▶ Start the engine.
- ▶ To switch on/off: press the (1) switch. The indicator lamp in the switch comes on when the rear window defroster is switched on.

Climate control

Overview of climate control systems

The vehicle is equipped with one of the following climate control systems:

Heating



The heating system is a heating and ventilation system, without a cooling function (▷ page 100).

N83.20-2255-31

Air-conditioning system



N83.25-2061-31

The air-conditioning system is a combination of a heating and ventilation system, together with a cooling system (▷ page 101).

Rear-compartment heating



The separately activated rear-compartment heating allows a separate temperature and airflow setting for the rear compartment (> page 101).

N83.20-2256-31

Rear-compartment air-conditioning system



N83.60-2023-31

The separately activated rear-compartment air conditioning allows a separate temperature and airflow setting for the rear compartment (\triangleright page 101).

On vehicles without rear-compartment climate control in the center console, the control panel is equipped with a paper holder (> page 133).

General notes

↑ WARNING

A driver's attention to the road and traffic conditions must always be his/her primary focus when driving.

For your safety and the safety of others, we recommend that the driver should only select functions through the control panel of the climate control system when traffic and road conditions permit it to be done safely.

Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your vehicle is covering a distance of 44 feet (approximately 14 m) every second.

The air-conditioning system regulates the temperature and humidity of the vehicle interior and filters undesired particles out of the air.

The heating/air-conditioning system can only be operated when the engine is running. The heating/air-conditioning system functions best only when the side windows are closed.

The installed filter removes most dust particles, pollen and unpleasant odors drawn in from the outside air. A clogged filter reduces the airflow into the vehicle interior. The interval for replacing the filter depends on environmental influences. The interval may be shorter than that indicated in the Maintenance Booklet.


1 Ventilate the vehicle for a brief period during warm weather. On vehicles with an air-conditioning system, in order to cool the vehicle rapidly, switch on air-recirculation mode briefly. In this way, you will accelerate the cooling process and achieve the desired temperature faster.

⚠ WARNING

Observe the settings recommended on the following pages. The windows could otherwise fog up. This could prevent you from observing the traffic conditions, thereby causing an accident.

Overview of the functions of the climate control system

Heating




Operation

- Sets the temperature (⊳ page 102)
 - Defrosts the windshield
- 2 Sets the airflow (⊳ page 104)
 - Defrosts the windshield
- 3 Switches air-recirculation mode on/off (⊳ page 106)
- Sets the air distribution (⊳ page 104)
 - ▲ Defrosts the windshield

Recommendations for optimum climate control:

- Set the temperature control to the middle level. Only change the temperature in small increments.
- Only use the defrosting function until the windshield is clear again (▷ page 105).
- Only use air-recirculation mode briefly, e.g. in a tunnel. When the flow of fresh air is cut off and the air inside the vehicle is recirculated, the windows could fog up.

Air-conditioning system



Operation


- ① Sets the temperature (▷ page 102)
 - Defrosts the windshield
- ② Sets the airflow (▷ page 104)
 - Increases the airflow
 - □ Decreases the airflow
- ③ Switches air-recirculation mode on/off (⊳ page 106)
- ④ Switches the reheat function (window air dehumidification) on/off (▷ page 105)
- Sets the air distribution(▷ page 104)
 - Defrosts the windshield
- A/C Switches cooling with air dehumidification on/off
 (▷ page 102)
- Blower setting bar display
 - Defrosts the windshield

Recommendations for optimum climate control:

- set the temperature to 72 °F (22 °C). Only change the temperature in small increments.
- switch on cooling with air dehumidification. The indicator lamp in the switch comes on.
- only use the defrosting function until the windshield is clear again (▷ page 105).

- only use the reheat function until the fogged up windows are clear again.
- only use air-recirculation mode briefly, e.g. in a tunnel. When the flow of fresh air is cut off and the air inside the vehicle is recirculated, the windows could fog up.

Rear-compartment heating




Operation

- ① Switches air-recirculation mode on/off (> page 102)
- ② Sets the airflow (⊳ page 104)
- ③ Sets the temperature (▷ page 102)

For optimum climate control, set the temperature control to the middle level. Only change the temperature in small increments.

Rear-compartment air-conditioning system



Operation

- ① Sets the airflow (⊳ page 104)
 - Increases the airflow
- ② Sets the temperature (▷ page 102)

Operation

3 Blower setting bar display



For optimum climate control, set the temperature control to the middle level. Only change the temperature in small increments.

Switching the climate control on/off

General notes

When the climate control is switched off, air intake and air circulation also stop. Only use this setting for a brief period. Otherwise, the windows could fog up.

Air-conditioning system

- ▶ To activate: press the 🛞 button and set the blower speed to at least the first level. The blower speeds are shown in bars next to the button.
- ► To switch off: press the 😸 button and, after reaching the lowest blower speed, press it again.

Rear-compartment heating/rearcompartment air conditioning

▶ Press the 😰 button. If the indicator lamp in the button lights up, the rear-compartment heating/rearcompartment air conditioning is switched on.

Switching cooling with air dehumidification on/off

To cool the air inside the vehicle, if equipped with an air-conditioning system, cooling with air dehumidification must be switched on. The air inside the vehicle is then cooled and

dehumidified to the temperature level set. This prevents the windows from misting up. Condensation may appear on the underside of the vehicle when in cooling mode.

↑ WARNING

If you switch off the cooling function, the vehicle will not be cooled when weather conditions are warm. The windows can fog up more quickly. This may prevent you from observing the traffic conditions, thereby causing an accident.

► Press the 🔼 button. If the indicator lamp in the button lights up, cooling with air dehumidification is switched on.

Setting the temperature

Heating/air-conditioning system

► Turn temperature control (1) for the heating (> page 100) or the air-conditioning system (⊳ page 101) clockwise to increase or counterclockwise to reduce the temperature. Start at the center position, or at 22 °C. Only change the temperature in small increments.

Rear-compartment heating/rearcompartment air conditioning

- ► Make sure that the rear-compartment climate control (rear-compartment heating/air-conditioning system) is switched on (⊳ page 102).
- ► Turn rear-compartment temperature control (3)(⊳ page 101) or rearcompartment air-conditioning system (2) (⊳ page 101) clockwise to increase or counterclockwise to reduce the temperature. Only change the temperature in small increments.
- 1 Your vehicle may be equipped with rearcompartment heating and rearcompartment air conditioning.

If you set the temperature control to the center position, only one of the two climate control systems is activated in the rear compartment and set to air-recirculation mode (> page 106).

Setting the air vents

General notes

/ WARNING

Air flowing out of the air vents may be very hot or very cold. Therefore, there is a risk of frostbite or burns to exposed skin in the immediate proximity of these air vents. Keep exposed parts of the body away from these air vents. If necessary, direct the airflow to a different area of the vehicle interior.


You can set the center and side air vents. On vehicles with a rear-compartment air-conditioning system, you can also adjust the air vents in the roof duct.

The entire vehicle interior is ventilated via the air vents.

Observe the following instructions so air can flow freely through the air vents:


- keep the air inlet on the hood free from ice and snow.
- never cover the vents or the ventilation grilles in the vehicle interior.
- for virtually draft-free ventilation, move the sliders on the center air vents to the central position.

Center air vents



- (1) Center air vent, left
- ② Center air vent, right
- 3 Thumbwheel for center air vent, right
- 4 Thumbwheel for center air vent, left
- ► Turn thumbwheel ③ or ④ to the right to open and to the left to close the center air vent.

Side air vents



Side air vent (example: right-hand side of the vehicle)

► Turn thumbwheel ③ up to open and down to close side air vent ①.

If the symbol can be seen on thumbwheel (3), defroster vent (2) is open.

Air vents

You can use the air vents to ventilate the vehicle interior on the left and right, in the rear and the headroom.



Air vents (example: right-hand side of the vehicle)

- Air vent thumbwheel, left-hand side of the vehicle
- ② Air vent thumbwheel, right-hand side of the vehicle
- ► Turn thumbwheel ① or ② to the right to open and to the left to close the air vents.

Air vents in the roof duct

On vehicles with rear-compartment/ passenger compartment air conditioning, adjustable air vents are integrated into the roof duct.



- ► Set the airflow by opening/closing the air flaps.
- ► Set the air distribution by turning air vents (1).
- Always leave at least one air vent open. If the rear-compartment air conditioning is switched on and all the air vents are closed, the air-conditioning system may be damaged.

Setting the air distribution

Heating/air-conditioning system

The air distribution symbols for the heating/ air-conditioning system have the following meanings:

- Directs air through the center
- Directs air to the windshield and the air vents
- Directs air to the windshield, the air vents and into the footwell
- ▼ Directs air to the air vents and into the footwell
- ► Set air-distribution control ④ for the heating (▷ page 100) or air-conditioning system ⑤(▷ page 101) to the corresponding symbol.

Setting the airflow

Heating/rear-compartment heating

- ► On vehicles with rear-compartment heating, make sure that the rear-compartment climate control is activated (> page 102).
- ➤ Set airflow control ② for the heating (▷ page 100) or rear-compartment heating (▷ page 101) to the desired level.

Air-conditioning system/rearcompartment air conditioning

- ► On vehicles with rear-compartment heating, make sure that the rear-compartment climate control is activated (> page 102).
- ▶ Press the button to reduce the airflow or the button to increase the airflow. The blower speeds are shown in bars next to the buttons.

Defrosting the windows

General notes

MARNING

Clear all windows of ice or snow before setting off. Otherwise, impaired visibility could endanger you and others.

Only use the following settings until the windows are clear again.

► Vehicles with window heating: switch on the front and/or rear window defroster (> page 98).

Heating

- ► Set temperature control ① and airflow control ② to ∰ (▷ page 100).
- ► Close the center air vents and the air outlets for the headroom and the rear compartment (> page 103).
- Direct the side air vents towards the side windows and open the defroster vents for the side windows (▷ page 103).

Air-conditioning system

- ► Set temperature control ① to ☐☐☐ (▷ page 101).
- ▶ Press the \$\begin{align*} \text{\$\}\$}}}\$}}}}}}} \endotinesetitilet{\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\}}}}}}}}}}} butingentures}}}} \engmtinesetitilet{\text{\$\tex
- ► Close the center air vents and the air outlets for the headroom and the rear compartment (> page 103).
- ▶ Direct the side air vents towards the side windows and open the defroster vents for the side windows (▷ page 103).

Defrosting the windows

Windows fogged up on the inside

General notes

Only use the following settings until the windows are clear again.

- Vehicles with window heating: switch on the front and/or rear window defroster (▷ page 98).
- ► Switch off air-recirculation mode (> page 106).

Heating

- ► Set temperature control ① to a higher temperature (▷ page 100).
- ► Set airflow control ② to a higher blower setting. It should be set at least to level two (> page 100).

If the windows still fog up, set the control as described for defrosting (> page 105).

Air-conditioning system

- ► Activate cooling with air dehumidification (> page 102).
- ▶ Press the button (▷ page 101).

 The reheat function is switched on. The indicator lamp in the switch lights up.

 To switch off the reheat function, press the button again. The indicator lamp in the button goes out.

Windows fogged up on the outside

Only use the following settings until the windshield is clear again.

- ➤ Switch on the windshield wipers (> page 97).
- ► Adjust air distribution to the footwell (> page 104).
- ► Close the air vents (> page 103).

Switching air-recirculation mode on/ off

General notes

You can deactivate the intake of fresh air if unpleasant odors enter the vehicle from outside. The air inside the vehicle will only be circulated.

/ WARNING

At low outside temperatures, only switch over to air-recirculation mode for brief periods. Otherwise, the windows could fog up, thus impairing visibility and endangering yourself and others. This may prevent you from observing the traffic conditions and thereby cause an accident.

Heating/air-conditioning system

▶ Press the 🔊 button. If the indicator lamp in the button lights up, air-recirculation mode is activated.

Air-recirculation mode switches off automatically after about 10 to 30 minutes, depending on the outside temperature.

Rear-compartment heating/rearcompartment air conditioning

On vehicles with a rear-compartment heating and air-conditioning system, you can activate/deactivate air-recirculation mode for the rear-compartment climate control.

- ▶ To activate: set the temperature control of rear-compartment heating
 - (3)(⊳ page 101) or rear-compartment air conditioning system ②(⊳ page 101) to the center position.
 - Only one of the two climate control systems in the rear compartment is activated and is in air-recirculation mode.
- ► To deactivate: turn the temperature control of rear-compartment heating ③(▷ page 101) or rear-compartment airconditioning system ② (▷ page 101) clockwise or counterclockwise. Only

change the temperature in small increments.

Auxiliary heating

Important safety notes

↑ WARNING

Exhaust fumes are produced while the auxiliary heating system is in operation. If you breathe in these exhaust fumes, you could be poisoned. Therefore, always switch off the auxiliary heating in enclosed spaces without an extraction system, e.g. a garage.

↑ WARNING

Parts of the vehicle can become very hot during operation of the auxiliary heating. Make sure that the exhaust system does not under any circumstances come into contact with highly flammable material such as dry grass or fuels. Otherwise, the highly flammable material could ignite and set the vehicle alight.

Auxiliary heating operation is prohibited at gas stations or when your vehicle is being refueled. Therefore, the auxiliary heating must be switched off at gas stations.

The auxiliary heating system operates independently of the engine and complements the vehicle heating or air conditioning.

You can use the auxiliary heating at an outside temperature of up to 39 °F (4 °C) in order to:

- pre-heat the vehicle interior
- · additionally warm the coolant, thereby conserving the engine and saving fuel
- · support the vehicle's heating system while the engine is running and outside temperatures are low (heater booster function)
- 1° At an outside temperature above 39 °F (4 °C), the auxiliary heating system and the


heater booster function switch off automatically.

- Switch on the auxiliary heating system at regular intervals (at least once a month) for approximately 10 minutes.
 - Make sure that the flow of hot air is not blocked. Otherwise, the auxiliary heating will overheat and switch off.
- i If the interior motion sensor (▷ page 65) is armed and the auxiliary heating is switched on, it is possible that the interior temperature monitoring may cause a false alarm. In this case, either deactivate the interior motion sensor or switch off the auxiliary heating.

Before switching on

- ► The fuel tank must be at least one-quarter full
- ► Set the desired temperature using the temperature control of the heating or the air-conditioning system (> page 102).
- ► Set the air distribution as required (> page 104).
- ▶ Open the center and side air vents and set them to the middle position (> page 103).
- 1 The auxiliary heating automatically switches to heater booster mode after the engine is started.

Operating using the switch



- 1) To switch the auxiliary heating on/off
- ② To switch the heater booster function on/ off (▷ page 109)
- ➤ To switch on the auxiliary heating: press the <a>tin switch for longer than 2 seconds.
 - The auxiliary heating heats or ventilates the interior to the temperature that you have set.
 - The blower switches to the first level.
 - The red indicator lamp in the switch comes on.
- ► To switch off the auxiliary heating: press the switch.

or

► Turn the key to position **0** in the ignition lock

The red indicator lamp in the switch goes out.

The auxiliary heating operates for approximately another 2 minutes and then switches off automatically.

Selecting a switch-on time

You can use the on-board computer to define up to three switch-on times, one of which can be selected.

On-board computer without steering wheel buttons

- ► Turn the key to position **2** in the ignition lock.
- ► Press the switch.

 The symbol in the display flashes.

or

- ► Use the ⊕ or ⊖ buttons on the instrument cluster to select switch-on time 1 to 3.

 The switch-on time selected is displayed.
- ► Wait 10 seconds for the standard display to appear.

The switch-on time is selected. The yellow indicator lamp in the ______ switch comes on.

If you have not preselected a switch-on time and --: -- is shown in the display, this means that automatic switch-on mode is deactivated. The yellow indicator lamp in the switch goes out.

1 If you turn the key to position **0** in the ignition lock, the yellow indicator lamp in the **111** switch goes out after 30 minutes.

The red indicator lamp in the [555] switch comes on when the auxiliary heating switches on.

On-board computer with steering wheel buttons

- ► Turn the key to position 2 in the ignition lock
- Press the switch. The Aux. heat. submenu is shown in the display.

If no switch-on time has been preselected, the selection marker highlights the preselected switch-on time, or Timer off.



- 1 You can also access the Aux. heat. submenu via the Settings(▷ page 82) menu.
- ► Use the + or buttons on the steering wheel to select the desired switchon time.

Use the **Timer** off setting to deactivate automatic switch on.

► Press the button on the steering wheel.

The switch-on time is selected. The yellow indicator lamp in the ______ switch comes on.

1 If you turn the key to position 0 in the ignition lock, the yellow indicator lamp in the _______ switch goes out after 30 minutes.

The red indicator lamp in the <u>switch</u> switch comes on when the auxiliary heating switches on.

Setting the switch-on time

On-board computer without steering wheel buttons

- ► Use the same method to select a switch-on time as described in the "Preselecting a switch-on time" section.
- ► Press the ② reset button on the instrument cluster.

The hour display flashes.

- ► Use the → and → buttons on the instrument cluster to set the hours.
- ► Press the ① reset button. The minute display flashes.
- ► Use the → and → buttons to set the minutes.

On-board computer with steering wheel buttons

- Use the same method to select a switch-on time as described in the "Preselecting a switch-on time" section.
- ▶ Press the △ button on the steering wheel.

The Hours submenu is shown in the display.

- ▶ Press the + or button on the steering wheel to set the hours.
- ► Press the △ button.

 The Minutes submenu is shown in the display.
- ▶ Press the + or button to set the minutes.
- ► Press the button.


 The switch-on time is set and selected.

Heater booster function


At an outside temperature of up to 39 $^{\circ}$ F (4 $^{\circ}$ C), the fuel-fired auxiliary heating heats the vehicle interior as quickly as possible when the engine is running.

The auxiliary heating automatically switches to heater booster mode after the engine is started.

1 At an outside temperature above 39 °F (4 °C), the auxiliary heating system and the heater booster function switch off automatically.



Vehicles with auxiliary heating




- 1) To switch the auxiliary heating on/off
- ② To switch the heater booster function on/ off

After switching off, the auxiliary heating operates for approximately another 2 minutes and then switches off automatically.

If you switch off the engine without switching off the heater booster function, the system will be switched on the next time the engine is started (memory function).

Roof ventilator

The roof ventilator can be used to ventilate or extract air from the vehicle interior.



- ► Turn the key to position **2** in the ignition lock.
- ► To extract air: press upper section ① of the किं। switch.

The roof ventilator removes used air from the cargo compartment.

► To ventilate: press lower section ② of the switch.

The roof ventilator feeds fresh air into the cargo compartment.

► To switch off: set the switch to the middle position.

Driving and parking

Preparing for a journey

Visual check of the vehicle exterior

- ► In particular, check the following components on the vehicle, and on the trailer as necessary:
 - license plates, vehicle lighting, turn signals, brake lamps and wiper blades for dirt and damage
 - tires and wheels for firm seating, correct tire pressure and general condition
 - trailer tow hitch for play and security
- 1 The towing device is one of the most important components on the vehicle with regard to road safety. The separate instructions issued by the manufacturer pertaining to operation, care and maintenance should be observed.
- ► Rectify any noticeable defects before commencing the journey.

Checks in the vehicle

Emergency equipment/first-aid kit

The equipment for first aid and breakdown assistance is located in the storage compartment in the driver's/co-driver's door and behind the driver's seat.

► Check the equipment to make sure that it is accessible, complete and ready for use.

Vehicle lighting

- ► Turn the key to position 2 in the ignition lock
- ► Check the lighting system with the aid of a second person.
- ▶ Replace defective bulbs (▷ page 236).

Before driving off

↑ WARNING

Free movement of the pedals must not be impaired. This would otherwise jeopardize the operating and road safety of the vehicle.

Objects could get caught between the pedals if you accelerate or brake suddenly. You will then be unable to brake, declutch or accelerate as intended. You could cause an accident, thereby endangering yourself and others.

- If you are using floormats and carpets, make sure that they are properly secured in the driver's footwell so that they do not slip or obstruct the pedals. Do not place floormats on top of one another.
- Do not put any objects in the driver's footwell.
- Stow and secure all loose objects in such a way that they cannot get into the driver's footwell while the vehicle is in motion.

♠ WARNING

If they are not properly closed, the doors could open while the vehicle is in motion. This may, for example, cause you to lose your load and injure passengers or endanger other road users

For this reason, please make sure that all the doors are properly closed and can be locked before starting your journey.

- ► Close all doors.
- ▶ Secure the load according to the loading guidelines (⊳ page 144).
- ▶ Make sure that the floormats and carpets are properly secured so that they cannot slip and obstruct the pedals.

Starting the engine

↑ WARNING

Do not place any objects in the driver's footwell. If you use a floormat or carpet in the driver's footwell, make sure that it is correctly secured and that there is sufficient clearance for the pedals.

Do not place several floormats on top of one another.

Loose objects or the floormats could otherwise get caught between the pedals if you accelerate or brake suddenly. You will then not be able to brake or accelerate as intended. This could lead to accidents and injury.


⚠ WARNING

Never leave the engine running in enclosed spaces. The exhaust gases contain toxic carbon monoxide. Breathing in exhaust fumes is a health hazard and can lead to unconsciousness or death.

- Do not depress the accelerator pedal when starting the engine.
- 1 If you depress the brake pedal before starting the engine, the pedal travel is short and pedal resistance is high.

If you depress the brake pedal again after starting the engine, pedal travel and resistance will be back to normal again.

- ▶ Before starting the engine, make sure that:
 - all the doors are closed.
 - · all the vehicle occupants are wearing their seat belts correctly.
 - the parking brake is applied.



Automatic transmission gearshift pattern

- P Park position with selector lever lock
- R Reverse gear
- N Neutral
- **D** Drive
- ▶ Move the selector lever to position **P**.
- 1 You can also start the engine in neutral
- ► Turn the key to position 2 in the ignition lock.

The more preglow indicator lamp in the instrument cluster lights up.

- ▶ When the 700 preglow indicator lamp goes out, turn the key to position 3 in the ignition lock and release it as soon as the engine is running.
- 1 You can start the engine without preglow when the engine is warm.
- Depending on the equipment installed, the vehicle either automatically locks centrally after switching on the ignition or after pulling away. The locking knobs in the doors drop down.

You can open the doors from the inside at any time.

Automatic door locking can be deactivated (⊳ page 57).

Driving off

↑ WARNING

Do not downshift for additional engine braking on a slippery road surface. This could cause the drive wheels to lose their grip and the vehicle could skid. You could lose control of the vehicle and cause an accident.

1 After pulling away or switching on the ignition, the vehicle automatically locks centrally. The locking knobs in the doors drop down.

You can open the doors from the inside at any time.

Automatic door locking can be deactivated (⊳ page 57).

- ▶ Depress the brake pedal and keep it depressed.
 - The selector lever lock is released.
- ▶ Move the selector lever to position **D** or **R**.
- 1 On vehicles with a reverse warning feature, when reverse gear is engaged a warning tone sounds to alert other road users.
- Only shift into reverse gear **R** when the vehicle is stationary. Otherwise, you could damage the transmission.
- ▶ Release the parking brake (▷ page 114). The mean indicator lamp in the instrument cluster goes out.
- ► Release the brake pedal.
- ► Carefully depress the accelerator pedal.

General driving tips

Steering



⚠ WARNING

Never switch the engine off while the vehicle is in motion.

There is no power assistance for the steering and the service brake when the engine is not running.

You will require considerably more effort to steer and brake, and you could therefore lose control of the vehicle and cause an accident.

Do not hold the steering wheel at full steering angle for a long time, e.g. when turning or maneuvering.

The hydraulic pump could be damaged if the hydraulic fluid temperature increases.

Overrun cut-off

If you are in overrun mode and take your foot off the accelerator pedal, the fuel supply is cut off when the engine speed is out of the idle speed control range.

Ground clearance

Always observe the ground clearance of the vehicle and avoid obstacles. On vehicles with a step, ground clearance is further restricted. Obstacles can damage the vehicle.

If you must drive over obstacles, drive especially slowly and carefully. If necessary, have another person direct you.

Driving in wet conditions



↑ WARNING

There is a danger of hydroplaning occurring, even if you are driving slowly and your tires have sufficient tread depth, depending on the depth of water on the road.

For this reason, avoid tire ruts and brake carefully.

Driving on flooded roads

If you must drive through water, the water level must not rise above the bottom edge of the bumper. The maximum speed at which you may drive is walking speed.

Bear in mind that vehicles traveling in front or in the opposite direction create waves. This may cause the maximum permissible water depth to be exceeded. Failure to observe these notes may result in damage to the engine, electrical systems and transmission.

Driving in winter

Drive particularly carefully on slippery roads in winter. Avoid sudden acceleration, steering and braking maneuvers.

↑ WARNING

Do not downshift for additional engine braking on a slippery road surface. This could cause the drive wheels to lose their grip and the vehicle could skid. You could lose control of the vehicle and cause an accident.

If the vehicle threatens to skid or cannot be stopped when moving at low speed, shift to the neutral position **N**. Try to maintain control of the vehicle using corrective steering

■ Vehicles with automatic transmission may roll only briefly in the neutral position **N**. Prolonged rolling of the wheels, e.g. when being towed, will result in transmission damage.

Road salt may adversely affect braking performance. In order to achieve the normal braking effect, you will need to apply more force to the brake pedal. Apply the brakes repeatedly when driving for longer periods on gritted or salted roads. This will restore the brakes to their normal level of performance. When stopping the vehicle after traveling on roads that have been salted, make sure that the brakes are fully functional before proceeding further.

Mount snow chains on the wheels of the driven axle in good time for driving on snow, slush or ice. Comply with the manufacturer's fitting instructions.

You will find information about winter tires and snow chains in the "Wheels and tires" section (⊳ page 156).

Tire grip

⚠ WARNING

Whereas the vehicle can be fully controlled at a certain speed on dry roads, you must reduce your speed on wet or icy roads to achieve the same road safety. You could otherwise cause an accident.

Pay particular attention to the road conditions at temperatures around freezing point.

If ice has formed on the road surface (e.g. from fog), a thin film of water rapidly forms on the ice when you brake, considerably reducing tire traction. Drive with particular care in such weather conditions.

Stopping the vehicle and switching off the engine



↑ WARNING

Always switch off the engine and apply the parking brake before leaving the vehicle. Otherwise, the vehicle could roll away if it is not secured.

On gradients steeper than 15%:

- secure an unladen vehicle at the front axle, e.g. using a wheel chock or similar object.
- additionally, secure a laden vehicle at the rear axle, e.g. using a wheel chock or similar object.



↑ WARNING

Make sure that the exhaust system does not under any circumstances come into contact with flammable materials such as dry grass or gasoline. Do not park the vehicle on dry grassland or harvested grain fields. The hot exhaust system could ignite the flammable material and set the vehicle on fire.



⚠ WARNING

Only remove the key from the ignition lock when the vehicle is stationary, since you cannot steer the vehicle with the key removed.

Never leave children unsupervised in the vehicle. They could release the parking brake. This could lead to a serious or fatal accident. When the vehicle is parked, always remove the key to prevent the battery from becoming discharged.

On vehicles with a battery isolating switch, switch off the power supply if the vehicle is to be out of use for a longer period of time.

♠ WARNING

You must use the parking lamps to enable your vehicle to be recognized on public roads when it is dark. You can also use reflective night parking signs in built-up areas. Observe legal requirements.

- ▶ Stop the vehicle.
- ▶ Shift the automatic transmission to position P.
- ► Apply the parking brake.
- 1 On steep slopes, turn the front wheels towards the curb.
- If the coolant temperature is very high, e.g. after driving on hilly roads, leave the engine running at idle speed for about two minutes before turning it off.

This allows the coolant temperature to return to normal.

▶ To switch off the engine: turn the key to position **0** in the ignition lock and remove it.

The immobilizer is activated.

- Switch on the parking lamps if necessary.
- On uphill or downhill gradients, secure the vehicle additionally against rolling away by placing a wheel chock or similar object at the axle with the heaviest load.


Use the wheel chock (⊳ page 185) for this purpose.

Braking

Parking brake

↑ WARNING

Never leave children unsupervised in the vehicle. They could release the parking brake. This could lead to a serious or fatal accident.



- Only apply the parking brake when the vehicle is stationary.
- ► To apply the parking brake: pull brake lever (1) up as far as the last possible detent.

The rindicator lamp in the instrument cluster lights up.

- On vehicles with a folding brake lever, you can then press lever (1) down to the stop.
- ▶ To release the parking brake: on vehicles with a folding brake lever, first pull brake lever (1) up to the stop.
- ► Raise brake lever (1) slightly and press release knob (2).
- ► Guide brake lever (1) down to the stop. The mean indicator lamp in the instrument cluster goes out.

As a rule, you may only apply the parking brake when the vehicle is stationary.



↑ WARNING

If the brake lever is applied abruptly, the rear wheels could lock. The vehicle could then go into a skid.

Make sure that you apply the brake lever carefully to ensure that braking application is moderated.

In exceptional cases, the parking brake can be used for emergency braking if the service brake fails.

► Emergency braking: press and hold release button (2) and carefully apply brake lever (1).

Automatic transmission

Important safety notes



↑ WARNING

Do not change down for additional engine braking on a slippery road surface. This could cause the drive wheels to lose their grip and the vehicle could skid.


↑ WARNING

Apply the parking brake and move the selector lever to **P** when working on the vehicle. Otherwise, the vehicle could roll away.

Vehicles with automatic transmission may roll only briefly in the neutral position **N**. Prolonged rolling of the wheels, e.g. when being towed, will result in transmission damage.

Overview

The 5-speed automatic transmission adapts to your individual driving style by continuously adjusting its shift points. These shift point adjustments take into account the current operating and driving conditions. If the operating or driving conditions change, the automatic transmission reacts by adjusting the gearshift program.



When the selector lever is in position **D**, the automatic transmission selects the individual gears automatically. This depends on:

- any restriction in the shift range (⊳ page 116)
- the position of the accelerator pedal
- the road speed

When the selector lever is in position **D**, you can influence the gearshifts made by the automatic transmission. You can restrict the shift range or you can perform gearshifts yourself.

The selector lever position or the current shift range is shown in the display:

- on vehicles with steering wheel buttons (⊳ page 80)
- on vehicles without steering wheel buttons (⊳ page 75)

Selector lever positions



Park position

This prevents the vehicle from rolling away when stopped. Only move the selector lever to P if the vehicle is stationary.

You can only remove the key when the selector lever is in this position. The selector lever is locked in position **P** if the key is removed.



Reverse gear

Only move the selector lever to R when the vehicle is stationary.

N

Neutral

No power is transmitted from the engine to the drive wheels. Releasing the brakes will allow you to move the vehicle freely, e.g. by pushing or towing.

Do not move the selector lever to **N** while driving. The automatic transmission could otherwise be damaged.

If ASR is deactivated or ESP[®] has malfunctioned: only move the selector lever to **N** if the vehicle is in danger of skidding, e.g. on icy roads.



Drive

The automatic transmission changes gear itself. All forward gears are available.

Touchshift

When the selector lever is in position **D**, you can perform gearshifts yourself.

- ► To shift down: press the selector lever to the left towards D-.
 - The automatic transmission shifts to the next gear down, depending on the gear currently engaged. The shift range is also restricted.
- The automatic transmission does not shift down if you press the selector lever towards D- while traveling at too high a speed. This protects the engine from overrevving.
- ► To shift up: briefly press the selector lever to the right towards D+.

The automatic transmission shifts to the next gear up, depending on the current gearshift program. This also extends the shift range.

- ► To derestrict the shift range: press and hold the selector lever towards D+ until D is shown once more in the display.

 The automatic transmission shifts from the current shift range directly to D.
- ➤ To select the optimum shift range: press and hold the selector lever to the left towards D-.

The automatic transmission will shift to a range which allows easy acceleration and deceleration. To do this, the automatic transmission will shift down one or more gears.

Shift ranges

When the selector lever is in position **D** you can restrict or derestrict the shift range for the automatic transmission.

- ▶ To extend/restrict the shift range: briefly press the selector lever to the right towards D+ or to the left towards D−. The set shift range is shown in the display. The automatic transmission shifts only as far as the relevant gear.
- i If the maximum engine speed for the restricted shift range is reached and you depress the accelerator pedal, the automatic transmission will not shift up.

Driving situations



Use the braking effect of the engine on steep downhill gradients and for driving:

- · on steep mountain roads
- in mountainous terrain
- · in arduous conditions



Use the braking effect of the engine on extremely steep downhill gradients and long downhill stretches.

Driving tips

Accelerator pedal position

Your style of driving influences how the automatic transmission shifts gear:

little throttle: early upshiftslots of throttle: later upshifts

Kickdown

Use kickdown for maximum acceleration:

- ► Depress the accelerator pedal beyond the pressure point.
 - The automatic transmission shifts to the next gear down, depending on the engine speed.
- ► Ease off on the accelerator pedal once the desired speed is reached.
 - The automatic transmission shifts up again.

Maneuvering

Maneuvering in a tight space:

- ► Control the vehicle's speed by braking carefully.
- ► Accelerate only slightly and avoid jolting.
- 1 You can shift back and forth between drive position **D** and reverse gear **R** at low speeds without applying the brakes. This can help you, for example when rapidly maneuvering the vehicle or rocking it out of snow or slush.

Towing a trailer

- ► Drive at moderate engine speeds on steep uphill gradients.
- ▶ Depending on the uphill or downhill gradient, shift down to a shift range adapted to the driving situation (▷ page 116), even if cruise control is activated.

Driving the vehicle

Exhaust gas aftertreatment

The exhaust gas aftertreatment requires a reducing agent known as Diesel Exhaust Fluid (DEF) in order to function correctly. Filling up the DEF tank is usually part of the service scope. DEF consumption depends on operational and driving conditions and it is not necessary to wait until the next scheduled service to replenish the fluid. Thus, fill up the DEF tank regularly during vehicle operation or at the latest after receiving the first warning message from the on-board computer.

To conform to emission regulations, you must operate the vehicle with DEF and refill the supply regularly. The engine management recognizes attempts to operate the vehicle without DEF, with thinned DEF or with another reducing agent. After previous warning messages, the engine management then prevents a further engine start.

If the DEF reserve drops below 1.5 US gal (5.5 l), you will receive the first warning message and a warning tone. After the initial message and under normal driving conditions, the remaining DEF reserve is enough for approximately another 1000 mi (1600 km).

You will then reach the reserve range of 0.8 US gal (3.0 I). Once the reserve range has been reached, you will receive the next warning message and you will hear a series of warning tones. After the initial message, the DEF reserve is enough for approximately another 1200 mi (1900 km). However, you will only be able to start the engine another 16 times.

Refill now at the latest with at least 2.0 US gal (7.6 l) of DEF (▷ page 143) or have the DEF tank refilled at a qualified specialist workshop.

When the number of remaining engine starts is 0, the engine management prevents the engine from being started.

If the the check engine indicator lamp lights up, the exhaust gas aftertreatment is faulty or an emission-related malfunction has occurred (⊳ page 197). You can then drive a maximum of 50 mi (80 km) before the engine management limits the number of remaining engine starts.

If the exhaust gas aftertreatment is faulty, have it checked and repaired at a qualified specialist workshop.

You will find further information on DEF in the "Service products" section (▷ page 158).

Level indicator

You will find further information about DEF consumption in the "Driving tips" section (> page 140).

Vehicles without steering wheel buttons

If the DEF reserve is less than 1.5 US gal (5.5 l), the indicator lamp lights up in the instrument cluster and the message DEF Chk appears in the display.

If the DEF reserve drops below the reserve range of 0.8 US gal (3.0 I), the indicator lamp lights up in the instrument cluster and the message StArtS RExx appears in the display. XX refers to the number of remaining engine starts (from 16 to 0).

Vehicles with steering wheel buttons

If the DEF reserve is less than 1.5 US gal (5.5 I), the message Check Diesel Exhaust Fluid See Operator's Manual appears in the display.

If the DEF reserve drops below the reserve range of 0.8 US gal (3.0 I), the message XX starts remaining appears in the display. XX refers to the number of remaining engine starts (from 16 to 0).

ADR (working speed governor)

General notes


When activated, ADR automatically increases the engine speed to a preset or adjustable speed (⊳ page 119).

After a cold start, the idling speed of the engine is increased automatically. If the preset working speed is lower than the increased idling speed, the working speed is only reached once the engine has completed the warm-up phase.

It is only possible to activate ADR with the vehicle stationary and the parking brake applied.

The selector lever must be in position **P**.

Activating/deactivating ADR



► To activate: press upper section ① of the ⊕ switch while the engine is running. The indicator lamp in the switch comes on. Vehicles without steering wheel buttons: The ADR indicator lamp in the instrument cluster lights up.


Vehicles with steering wheel buttons: The Operating speed governor active message appears in the display.

► To deactivate: press lower section ② of the ⊕ switch while the engine is running.

The indicator lamp in the switch goes out.

- ADR is automatically deactivated if:
 - you release the parking brake.
 - the brake pedal is depressed.
 - the vehicle moves.
 - the control unit detects a malfunction.

Setting the working speed



- ► Activate ADR (> page 118).
- ▶ To increase: press upper section (1) of the switch.
- ▶ To decrease: press lower section (2) of the
- 1 On vehicles with cruise control, you can use the cruise control lever to increase or decrease the engine speed in the same way as for the road speed. Set the speed using the cruise control lever (⊳ page 120).
- 1 After a cold start, the idling speed of the engine is increased automatically.

You can only reduce the working speed to the level of the current idling speed.

Driving systems

Overview

The following pages describe driving systems that may be a component in your vehicle:

- Cruise control (⊳ page 119) which you can use to control the speed of your vehicle
- PARKTRONIC (▷ page 121) and the rear view camera (⊳ page 124) which assist you with parking and maneuvering

Cruise control

Important safety information

Cruise control maintains the speed of the vehicle for you.

↑ WARNING

Cruise control is unable to take account of road and traffic conditions.

Always pay attention to the traffic conditions, even when cruise control is activated.

Cruise control is only an aid designed to assist driving. You are always responsible for the vehicle's speed and for braking in good time.

If there is a change of drivers, make sure that you inform the new driver about the set cruise speed. Otherwise, sudden acceleration or braking could endanger you or others.

↑ WARNING

Do not use cruise control:

- in road and traffic conditions which do not allow you to maintain a constant speed (e.g. heavy traffic or winding roads). You could otherwise cause an accident.
- on slippery roads. Braking or accelerating could cause the drive wheels to lose traction and the vehicle could then skid.
- when there is poor visibility, e.g. due to fog, heavy rain or snow.


Use cruise control if road and traffic conditions make it appropriate to maintain a steady speed for a prolonged period. You can set any speed from 20 mph upwards in increments of 1 mph.

f you have set km/h as the unit for the digital speedometer (> page 83), you can set any speed from 30 km/h upwards in increments of 1 km/h.

Cruise control may not be able to maintain the stored speed on uphill or downhill gradients. The stored speed is resumed if the gradient evens out and the vehicle's speed does not fall below 20 mph (30 km/h).

Cruise control lever

The cruise control lever is the uppermost lever on the left of the steering column.



- (1) To store the current speed or a higher speed
- 2) To resume the last speed stored
- (3) To store the current speed or a lower speed
- 4 To deactivate cruise control

Storing the current speed

- ► Accelerate/decelerate the vehicle to the speed desired above 20 mph (30 km/h).
- ▶ Briefly push the cruise control lever up (1) or down ③.
- ► Release the accelerator pedal. Cruise control is activated. The current speed is stored.

You cannot activate cruise control if:

- you drive slower than 20 mph (30 km/h).
- you depress the brake pedal.
- you apply the parking brake and the PARK indicator lamp in the instrument cluster lights up.
- 1 Other drive and brake systems not described in this Operator's Manual, such as a retarder, may affect cruise control. You can find information on this in the separate operating instructions provided by the body manufacturer.

Resuming the stored speed

MARNING

Only select a stored speed if you know what that speed is and whether it is suitable for the current driving and traffic situation. You can otherwise endanger yourself and others by unintentionally triggering sudden acceleration or braking.

- ▶ Briefly pull the cruise control lever in the direction of arrow (2).
- ► Release the accelerator pedal. Cruise control is activated and resumes the vehicle's speed to the last speed stored.
- When you first move the cruise control lever in the direction of arrow (2) after starting the engine, cruise control is activated and the current road speed is stored.

Setting the speed



↑ WARNING

The rate at which you increase the speed in increments of 1 mph (1 km/h) may be faster than your vehicle is able to accelerate. Your vehicle may then continue to accelerate up to the newly set speed even after you have released the cruise control lever.

Only increase the speed as the prevailing conditions permit. Sudden acceleration could otherwise endanger you and others.

▶ Briefly push the cruise control lever upwards (1) to increase the speed or downwards (3) to reduce the speed. The last speed stored is increased/ reduced in increments of 1 mph (1 km/h).

- ▶ Press and hold the cruise control lever up (1) or down (3) until the desired speed has been reached.
- ▶ Release the cruise control lever. The current speed is stored.

Cruise control is not deactivated if you depress the accelerator pedal. If you accelerate briefly, e.g. to overtake, and then ease off the accelerator pedal again, cruise control adjusts the vehicle's speed to the last speed stored.

Deactivating cruise control

There are various ways to deactivate cruise control:

► Briefly push the cruise control lever forwards (4).

Or

► Apply the brakes.

The last speed set remains stored.

- 1 The last speed stored is deleted when you switch off the engine.
- Cruise control is deactivated. automatically when:
 - you apply the brakes.
 - you apply the parking brake and the (Indicator lamp in the instrument cluster lights up.
 - vou drive slower than 20 mph (30 km/h).
 - ESP® or ASR intervenes.
 - you shift the automatic transmission to neutral position N while the vehicle is in motion.
 - there is a malfunction in the ESP®, ASR or ABS system.

PTS (PARKTRONIC)

Important safety information



⚠ WARNING

PARKTRONIC is only an aid and may not detect all obstacles. It is not a substitute for attentive driving.

You are always responsible for safety and must continue to pay attention to your

immediate surroundings when parking and maneuvering. You could otherwise endanger yourself and others.



↑ WARNING

Make sure that no persons or animals are in the maneuvering range. Otherwise, they could be injured.

PARKTRONIC is an electronic parking aid. PARKTRONIC indicates visually and audibly the distance between your vehicle and an object.

Your vehicle features two separate sound emitters with different frequencies for the warning tones. The warning ranges in front of and behind the vehicle are indicated by different warning tones.

PARKTRONIC is activated automatically when


- turn the key to position 2 in the ignition lock
- release the parking brake and
- move the selector lever to **D**, **N** or **R**.


PARKTRONIC is deactivated automatically at speeds above 11 mph (18 km/h). PARKTRONIC is reactivated automatically at speeds below 10 mph (16 km/h).

PARKTRONIC monitors the area around your vehicle with sensors in the front and rear bumpers.

Range of the sensors

The sensors must be free of dirt, ice or slush. Otherwise, they cannot function correctly. Clean the sensors regularly, taking care not to scratch or damage them (▷ page 166).





Front sensors	
Center	Approximately 39 in (100 cm)
Corners	Approximately 26 in (65 cm)

Rear sensors	
Center	Approximately 71 in (180 cm)
Corners	Approximately 39 in (100 cm)

Minimum distance	
Center	Approximately 12 in (30 cm)
Front corner sensors	Approximately 10 in (25 cm)
Rear corner sensors	Approximately 12 in (30 cm)

If an obstacle is within this range, all segments of the warning displays light up and you hear a warning tone. If the distance between the vehicle and the obstacle falls below the minimum range, it is possible that the distance may no longer be displayed.

Pay particular attention to obstacles above or below the sensors when parking, such as flower pots or trailer towbars. PARKTRONIC does not recognize such objects when they are in the immediate vicinity of the vehicle. You could damage the vehicle or objects.

PARKTRONIC can suffer interference from:

- ultrasonic sources such as a truck's compressed-air brakes, an automatic car wash or a pneumatic drill
- attachments to the vehicle, e.g. rear mounted racks
- number plates (vehicle license plates) that are not affixed flat against the bumper
- · dirty or icy sensors


Warning displays

The warning displays show the distance between the sensor and the obstacle.



Warning display, front area

- 1 Left-hand side of vehicle
- 2 Right-hand side of vehicle
- ③ Segments



Warning display for the left-hand rear area in the left-hand exterior mirror

- Warning display segments
- (5) Readiness indicator segment

The warning display is divided into five yellow and two red segments for each side of the vehicle. PARKTRONIC is operational if yellow indicator segments 3 and 5 light up.

There is a malfunction if only the red segments of the warning display light up (⊳ page 218).

The position of the selector lever determines whether the front and/or rear area is monitored.

Selector lever position	Monitoring
D	Front area
R or N	Front and rear area
P	No areas activated

One or more segments light up as the vehicle approaches an obstacle, depending on the vehicle's distance from the obstacle.

From the:

- sixth segment, an intermittent warning tone sounds for approximately two seconds.
- seventh segment, a continuous warning tone sounds. You have reached the minimum distance.


Roll-back warning

PARKTRONIC automatically monitors the area behind the vehicle if the vehicle begins to roll backwards without reverse gear engaged, e.g. after stopping on an uphill gradient.

If PARKTRONIC recognizes an obstacle at a distance of at most 31 in (80 cm), all the segments in the warning display light up. A continuous warning tone also sounds as the vehicle approaches the obstacle and for a further two seconds after the vehicle has come to a halt.

Activating/deactivating PARKTRONIC

You can activate/deactivate PARKTRONIC manually.



▶ Press button (1). If PARKTRONIC is deactivated, the indicator lamp in the switch lights up.

Towing a trailer

PARKTRONIC detects a coupled trailer if your vehicle is equipped with the corresponding electrical installations for trailer towing. The sensors for the rear area are deactivated when you establish an electrical connection with the trailer. If you use an adapter for the socket, remove it from the socket after detaching the trailer. Otherwise, PARKTRONIC remains deactivated for the

rear area.

If the trailer coupling is detachable, remove it when it is no longer required. PARKTRONIC

measures the minimum detection range to an obstacle from the bumper, not the ball coupling.

Rear view camera

Important safety information

↑ WARNING

The rear view camera is merely an aid for parking, and may show obstacles out of perspective, incorrectly or may not show obstacles at all. This system does not relieve you of the need to pay attention.

The rear view camera cannot display all objects which are very close to and/or under the rear bumper. It does not warn you of collisions, persons or objects.

You are always responsible for safety and must continue to pay attention to your immediate surroundings when parking and maneuvering. This not only applies to the area behind the vehicle, but also to the areas in front of and to the sides of the vehicle.

Otherwise, you may not notice people or objects and, by continuing to drive, injure somebody or cause damage to the objects or the vehicle. When parking, we recommend that you also always use PARKTRONIC.



↑ WARNING

Make sure that no persons or animals are in the maneuvering range. Otherwise, they could be injured.

↑ WARNING

The rear view camera either will not function or will not function to its full capability:

- if it is raining very hard, snowing or foggy.
- if you are parked somewhere very dark.
- if the camera is exposed to very bright white light. White lines may appear on the display.
- if the area is illuminated with fluorescent lighting. The display may flicker.

- if the temperature changes very quickly, for example if you drive into a heated garage in the winter.
- if the ambient temperature is very high.
- if the camera lens is dirty or obstructed.
- if the rear of the vehicle is damaged. In this case, have the position and setting checked at a specialist workshop.

The rear view camera is a visual parking aid. It shows you the area behind the vehicle on a separate monitor on the center console.

The rear view camera is activated when you engage reverse gear R.

The camera is in the middle of the roof above the high-mounted brake lamp (⊳ page 166).




1) Monitor for rear view camera

You will find information about cleaning the camera in the "Operation" section (⊳ page 166).

Switching on the rear view camera

- ▶ Make sure that the ignition is switched on.
- ► Engage reverse gear R. The rear view camera is switched on.

Using the monitor



Monitor buttons

- ① ▼ Down button
- ② **L** Up button
- 3 MENU Menu/Confirm button
- 4 ON Monitor on/off switch
- (5) Speaker cover

Switching on the monitor

You can switch on the monitor by:

- engaging reverse gear R
 The rear view camera is activated. This then switches the monitor on.
- pressing the ON button
 The input for auxiliary equipment (AUX) on the monitor is activated.
- If you have switched the monitor off using the ON button, you must press the
 ON button after engaging reverse gear
 R. Only then is the monitor switched on.



Input for auxiliary equipment (AUX)

If you engage reverse gear ${\bf R}$ while using auxiliary equipment, the monitor switches to the rear view camera.

When you disengage reverse gear \mathbf{R} , the monitor continues to show the picture from

the rear view camera for around 15 seconds. The monitor then switches back to the signal from the auxiliary equipment (AUX).

Switching off the monitor

If the monitor is switched on by engaging reverse gear **R**, it switches off automatically 15 seconds after you disengage reverse gear **R**.

You can switch off the monitor by pressing the ON button. In this case, the following message is shown for 7 seconds before it switches off.



Menu system


Setting the volume

- ▶ Briefly press the or button. The volume of the integrated loudspeaker is adjusted in increments.
- 1 The volume of the optional infrared headphones is adjusted on the headphones themselves.
- ► Press the MENU button to exit the volume adjustment.
- 1 If you do not press a button for 7 seconds, the monitor switches off the volume adjustment.

Selecting the main menu

► Press the MENU button.

The menu selection for the main menu (menu level 1) is displayed.




- ▶ Press the ▼ or ▲ button until the desired menu is highlighted.
- ► Press the MENU button. The menu is selected.

You can select the following menus:

- Display (⊳ page 126)
- Picture format (⊳ page 128)
- Standard (⊳ page 128)
- Menu language (> page 128)
- Factory setting (> page 129)

Skipping back a menu



- ▶ Press the ▼ or ▲ button until the ◄ symbol is highlighted.
- ► Press the MENU button.

 The higher-level menu is displayed.

Display menu

You can customize the monitor display in the Display menu.

You can select the following submenus:

- Lighting (⊳ page 126)
- Brightness (⊳ page 127)
- Contrast (⊳ page 127)
- Color (⊳ page 127)
- Tint


Lighting submenu

You can adjust the background illumination of the monitor in the Lighting submenu.

- ► Press the MENU button.

 The main menu (menu level 1) is displayed (▷ page 125).
- ► Press the ▼ or ▲ button until the Display menu is highlighted.
 The Display menu is selected.
- ► Press the MENU button.

 The submenus (menu level 2) are displayed.



- ► Press the ▼ or ▲ button until the Lighting submenu is highlighted.
- ► Press the MENU button.

 The lighting setting is displayed.



- ▶ Press the ▼ or ▲ button. The background lighting is adjusted in increments.
- ► Press the MENU button.

 The submenus (menu level 2) are displayed.
- 1 If you do not press a button for 7 seconds, you exit the menu automatically.

Brightness submenu

You can adjust the brightness of the monitor in the **Brightness** submenu.

- ► Press the MENU button.

 The main menu (menu level 1) is displayed (> page 125).
- ► Press the ▼ or ▲ button until the Display menu is highlighted.
 The Display menu is selected.
- ► Press the MENU button.

 The submenus (menu level 2) are displayed.
- ▶ Press the ▼ or ▲ button until the Brightness submenu is highlighted.
- ► Press the MENU button.

 The brightness setting is displayed.
- ► Press the ▼ or ▲ button.

 The brightness is adjusted in increments.
- ► Press the MENU button.

 The submenus (menu level 2) are displayed.

Contrast submenu

You can adjust the picture contrast of the monitor in the Contrast submenu.

- ► Press the MENU button.

 The main menu (menu level 1) is displayed (> page 125).
- ► Press the ▼ or ▲ button until the Display menu is highlighted.
 The Display menu is selected.
- ► Press the MENU button.

 The submenus (menu level 2) are displayed.

- ► Press the ▼ or ▲ button until the Contrast submenu is highlighted.
- ► Press the MENU button.

 The contrast setting is displayed.
- ▶ Press the ▼ or ▲ button.
 The contrast is adjusted in increments.
- ► Press the MENU button.

 The submenus (menu level 2) are displayed.

Color submenu

You can adjust the color setting of the monitor in the Color submenu.

- ► Press the MENU button.

 The main menu (menu level 1) is displayed (> page 125).
- ► Press the ▼ or ▲ button until the Display menu is highlighted.
 The Display menu is selected.
- ► Press the MENU button.

 The submenus (menu level 2) are displayed.
- ► Press the ▼ or ▲ button until the Color submenu is highlighted.
- ► Press the MENU button.

 The color setting is displayed.
- ► Press the ▼ or ▲ button.

 The color setting is adjusted in increments.
- ► Press the MENU button.

 The submenus (menu level 2) are displayed.

Tint submenu (NTSC color balance)

In the NTSC standard you can adjust the color balance of the monitor in the TINT submenu.

- ► Press the MENU button.

 The main menu (menu level 1) is displayed (▷ page 125).
- ► Press the ▼ or ▲ button until the Display menu is highlighted.
 The Display menu is selected.
- ► Press the MENU button.

 The submenus (menu level 2) are displayed.

- ► Press the ▼ or ▲ button until the Tint submenu is highlighted.
- ► Press the MENU button.

 The color balance setting is displayed.
- ▶ Press the ▼ or ▲ button. The color balance is adjusted in increments.
- ► Press the MENU button.

 The submenus (menu level 2) are displayed.


Picture format menu

You can set the display format for the monitor in the Picture format menu.

- ► Press the MENU button.

 The main menu (menu level 1) is displayed (> page 125).
- ► Press the ▼ or ▲ button until the Picture format menu is highlighted.
- ► Press the MENU button.

 The submenu (menu level 2) is displayed.
- The current picture format is marked with the ► symbol.



- ▶ Press the ▼ or ▲ button until the desired picture format is highlighted.
- ► Press the MENU button.
 Your selected format is activated.
- 1 The 16:9 format fills the entire monitor screen. The rear view camera generates a 16:9 format. Regular video signals usually require the 4:3 format.

1 If you select and press the MENU button, the monitor goes back to the main menu (menu level 1).


Standard menu

You can set the video standard for the monitor in the Standard menu.

- ► Press the MENU button.

 The main menu (menu level 1) is displayed (> page 125).
- ► Press the ▼ or ▲ button until the Standard menu is highlighted.
- ► Press the MENU button.

 The submenu (menu level 2) is displayed.
- 1 The current standard is marked with the symbol.



- ▶ Press the ▼ or ▲ button until the required standard is highlighted.
- ► Press the MENU button.

 The selected standard is activated.
- The video signal from the rear view camera uses the NTSC standard. Normal video signals generally use the PAL standard.
- i If you select → and press the MENU button, the monitor goes back to the main menu (menu level 1).

Menu language menu

You can set the language for the monitor menus in the Menu language menu.

- ► Press the MENU button.

 The main menu (menu level 1) is displayed (▷ page 125).
- ► Press the ▼ or ▲ button until the Menu language menu is highlighted.
- ► Press the MENU button.

 The submenu (menu level 2) is displayed.
- i The current language is marked with the symbol.
- ► Press the ▼ or ▲ button until the desired language highlighted.
- ► Press the MENU button.

 The selected language is activated.
- 1 If you select and press the MENU button, the monitor goes back to the main menu (menu level 1).

Factory setting menu

You can reset the monitor to the factory settings in the Factory setting menu.

- ► Press the MENU button.

 The main menu (menu level 1) is displayed (> page 125).
- ► Press the ▼ or ▲ button until the Factory settings menu is highlighted.
- ► Press the MENU button.

 The monitor displays the following message:




- ► Press the ▼ or ▲ button until the desired setting is highlighted.
- **Yes**: all settings are overwritten with the factory settings.
- return to the main menu without accepting the factory settings.
- i If you select and press the MENU button, the monitor goes back to the main menu (menu level 1).

Switching off the monitor while driving

If you drive faster than 6 mph (10 km/h), the monitor switches off for safety reasons.

You will see the following message for 7 seconds until the monitor switches off.




If the speed falls below 5 mph (8 km/h), the monitor switches on again.

Features

Ashtray

Ashtray in the center console



Ashtray in the ashtray compartment

- ▶ Pull ashtray compartment (1) out by recess 2.
- ► To open: fold cover (3) upwards.
- ► To remove the insert: hold the ashtray by the recesses on the left and right and pull the insert out to empty it.
- ▶ To replace the insert: press it down into the holder as shown.

Make sure that the insert is inserted correctly. Otherwise you will not be able to close the ashtray compartment (1) afterwards.

Ashtrays in the passenger compartment



Ashtrays on the left and right in the side trim panels

- ▶ To open: fold out the ashtray.
- ► To remove the insert: press retaining clip (1) down and remove the ashtray from the trim.
- ► To replace the insert: insert the ashtray down into the trim and close it.

Cigarette lighter


↑ WARNING

Only hold the hot cigarette lighter by its knob. Otherwise, you might burn yourself.

Make sure that children traveling in the vehicle are not able to injure themselves on the hot cigarette lighter or cause a fire with it.

⚠ WARNING

Do not press the cigarette lighter in too forcefully. The ashtray compartment could close and your fingers could become trapped.



Ashtray compartment in the center console

- ► To use the cigarette lighter: turn the key to position 1 in the ignition lock.
- ▶ Press in cigarette lighter (1). The cigarette lighter will pop out automatically when the heating element is red-hot.
- ▶ Pull the cigarette lighter out of the socket by its handle.

Stowage spaces and stowage compartments

Important safety notes

↑ WARNING

You should only load the stowage spaces in such a way that the occupants cannot be injured by objects being thrown around the passenger compartment in the event of an accident, braking or sudden change in direction.

Therefore, do not carry heavy, bulky, pointed or sharp-edged objects in the stowage spaces or stowage compartments.

Dashboard stowage compartment

⚠ WARNING

Do not store objects in the stowage space above the co-driver's air bag if they protrude out of the stowage space. This ensures that the co-driver's air bag can inflate fully.



Example, right-hand side

■ The right and left storage spaces may be loaded with a maximum of 11 lb (5 kg) each.

Stowage compartment above the windshield



Stowage compartment (example: driver's side)

- Stowage compartment
- I The right and left stowage spaces may be loaded with a maximum of 5.5 lb (2.5 kg) each.

Stowage space above the headliner



On vehicles with a partition, stowage space (1) can be loaded from the cargo compartment.

I The entire stowage space may be loaded with a maximum of 66 lb (30 kg).

Do not place high, bulky loads in the stowage space. You could otherwise damage the headliner in the event of sharp braking.

Stowage compartment in the center console



Stowage compartment with lid above the center console

- ► To open: pull release handle ②. Lid (1) swings up.
- ▶ To close: close lid (1) and engage it.

The lid of the stowage compartment must remain closed while the vehicle is in motion to ensure that stowed objects are contained safely.

Stowage compartment in the door

You can use these stowage compartments to store small, light items.

Stowage compartment under the twin co-driver's seat

On vehicles with a twin co-driver's seat, the stowage compartment is under the seat cushion (\triangleright page 68).


You can use the stowage compartment to safely store tools and other small parts.

Stowage compartment under the rear bench seat


On vehicles with a crewcab, the stowage compartment is located underneath the folding rear bench seat (> page 68).

You can use the stowage compartment to safely store tools and other small parts.

Glove box



- 1 Locked
- 2 Unlocked
- 3 Glove box handle
- 1 You can lock and unlock the glove box using the vehicle key.
- ► To open: pull glove box handle ③ in the direction of the arrow.




- (4) Card holder
- (5) Pen holder
- ➤ **To close:** fold the cover up and press it until it engages.

Eyeglasses compartment in the overhead control panel



- ► **To open:** press cover ① of the eyeglasses compartment.
 - The eyeglasses compartment folds out.
- ➤ **To close:** press cover ① of the eyeglasses compartment into the overhead control panel until it engages.

Paper holder



▶ Press the top of paper holder ①.

Folding table

Twin co-driver's seat



- ▶ Pull folding table (1) forwards by the tab.
- ► Fold folding table ① down in the direction of the arrow and onto the seat cushion.
- 1 The folding table is equipped with a pen holder and cup holder.

Cup holder

Important safety notes

↑ WARNING

Do not place objects in the cup holder while driving. Otherwise, vehicle occupants could be injured by objects being thrown around if you:

- brake sharply
- change direction suddenly
- are involved in an accident

Only use the cup holders for containers of a suitable size and which have lids. The drinks could otherwise spill.

Cup holders should not be used for hot drinks. You may otherwise burn yourself.

Do not use the cup holder recesses as ashtrays. This could damage the cup holders.

Front cup holder




Cup holder (example: right-hand side of vehicle)

① Cup holder in the dashboard stowage compartment



Bottle holder (example: right-hand side of vehicle)

② Bottle holder in the front door




Cup holders in the center console

- ▶ Pull ashtray compartment ③ out by recess ④.
 Cup holder ⑤ opens fully.
- Vehicles with the non-smoking package have an additional cup holder instead of the ashtray.

- 1 You can adjust the diameter of the cup holder.
- ▶ Place the beverage container in cup holder (5).
- ▶ Push clamping arm ⑥ against the container.
- 1 The folding table of the twin co-driver's seat is also equipped with a cup holder (> page 133).

Rear cup holder



Rear bench seat in the Passenger Van

▶ Pull out cup holder (1).

⚠ WARNING

Slide the cup holders back under the bench seat before leaving the vehicle. You could otherwise injure yourself on the protruding cup holders.

Socket

The 12 V sockets for accessories are:

- at the bottom of the center console (12 V, 25 A)
- on the inside of the driver's seat frame (12 V, 15 A)
- in the corner lining next to the rear doors in the passenger compartment (12 V, 15 A)
- in the cargo compartment next to the left rear door (12 V, 15 A)



Socket on the lower section of the center console 1 12 V socket, 25 A

You can use the 12 V sockets (15 A) for accessories with a maximum power consumption of 180 W. You can connect accessories with a maximum power consumption of 300 W to the 12 V socket (25 A) on the lower section of the center console.

- I Only use the 12 V socket (25 A) on the center console for connecting the electric air pump (premium tire sealant). You may otherwise damage the electrical systems of the vehicle.
- 1 The sockets are supplied with power even when the key is removed from the ignition lock. Please be aware that the battery may become discharged if accessories, e.g. a coolbox, remain connected while the engine is not running.

Communications

Electronic communications equipment



↑ WARNING

Always pay attention to road and traffic conditions.

Only operate electronic equipment when road and traffic conditions permit. Bear in mind that at a speed of only 30 mph (approximately 50 km/h), your vehicle covers about 44 ft (approximately 14 m) every second.

A navigation system does not supply information on the load-bearing capacity of bridges or the overhead clearance of underpasses.

The driver remains responsible for the safety of the vehicle at all times.

Observe legal requirements.

Telephones, two-way radios and fax machines without an exterior antenna could interfere with the vehicle electronics and thus compromise the operational safety of the vehicle. There is an increased risk of accident. Do not use this equipment while the vehicle is in motion.

Information on retrofitting electrical/ electronic equipment can be found in the "Technical data" section (⊳ page 284).

Telephone

↑ WARNING

The driver's attention to the road must always be his/her primary focus when driving. For your safety and the safety of others, we recommend that you pull over to a safe location and stop before placing or taking a telephone call. If you choose to use the telephone while driving, please use the handsfree device and only use the telephone when road, weather and traffic conditions permit. Some jurisdictions prohibit the driver from using a mobile phone while driving a vehicle. Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your vehicle covers a distance of 44 feet (approximately 14 m) every second.

↑ WARNING

You and others may damage your health due to excessive electromagnetic radiation. By using an external antenna, the possible health risks of electromagnetic fields, which are under discussion among the scientific community, should be largely prevented.

Therefore, only have the exterior antenna installed at a qualified specialist workshop.

We recommend the use of an approved exterior antenna for operating the mobile phone. Only in this way can optimal mobile phone reception quality in the vehicle be ensured and mutual interference between the vehicle electronics and mobile phones minimized.

Observe the legal requirements for each individual country.

The mobile phone pre-installation includes a hands-free system integrated into the vehicle. The microphone for the hands-free system is installed in the overhead control panel or in the overhead stowage compartment together with the front interior light.

In order to use the hands-free system, you will need a special bracket. The Sprinter accessories include brackets for various mobile phone models.

Mobile phone brackets which are available from various manufacturers on the open market are not compatible with the Sprinter telephone system. You can recognize suitable holders for your mobile phone by the imprinted star and the B6 spare part number on the back of the bracket.

Detailed instructions for use can be found in the operating instructions for the mobile phone bracket and in the separate operating instructions for the mobile phone preinstallation.

1 The mobile phone battery is charged depending on the charge status and the position of the key in the ignition lock. The mobile phone display indicates the charging process.

Useful information	138
Driving tips	138
Refueling	142
Transporting loads with the vehicle	144
Towing a trailer	150
Operation in winter	156
Service products	156
Cleaning and care	164
Maintenance	169

Useful information

This Operator's Manual describes all models as well as standard and optional equipment of your vehicle that were available at the time of going to print. Country-specific variations are possible. Note that your vehicle may not be equipped with all of the described functions. This also applies to systems and functions relevant to safety.

Read the information on qualified specialist workshops: (⊳ page 19).

Driving tips

Breaking-in

It is of decisive importance for the operating life, reliability and economy of the vehicle that the engine is not subjected to its full rated load during the breaking-in period.

Up to 1000 miles (1500 km)

- Break the vehicle in carefully. Drive at varying road and engine speeds.
- Avoid heavy loads (driving at full throttle) and high engine speeds. Do not exceed 3/4 of the maximum speed for each gear.
- Do not change down a gear manually in order to brake.
- Avoid depressing the accelerator pedal beyond the pressure point (kickdown) and only engage gear 4, 3, 2 or 1 while driving slowly.

After 1000 miles (1500 km)

- Gradually bring the vehicle up to full road and engine speeds.
- These instructions must also be observed if you have the engine, the transmission, or the rear axle differential of your vehicle replaced.

Driving abroad

An extensive network of authorized Sprinter Dealers is also at your disposal when you are traveling abroad. You can obtain a list of workshops at any authorized Sprinter Dealer.

In some countries, only fuels with a higher sulfur content are available.

You will find information about fuel in the "Service products" section (▷ page 156). When driving in countries in which traffic drives on the opposite side of the road to the country where the vehicle is registered, the headlamps must be:

- partially masked (halogen headlamps)
- switched over (Bi-Xenon headlamps)

↑ WARNING

Masking the headlamps incorrectly can impair your visibility when driving with the headlamps switched on. You could also impede other road users.

Always have the headlamps masked/ switched over at a qualified specialist workshop. Otherwise, you could glare oncoming traffic and cause an accident.

Driving off-road

Important safety notes



↑ WARNING

If you drive too fast off-road, you may not recognize obstacles in good time or you may underestimate the roughness of the ground. When driving off-road, always drive slowly to avoid damaging the vehicle. Such damage could impair the operating safety of your vehicle. You could lose control of the vehicle and cause an accident.

Always drive along the line of fall when you are on a slope. Never drive across a slope. The vehicle may skid to the side, tip and roll over. Never turn the vehicle around on a slope. If the vehicle cannot manage an uphill slope, drive back down the slope in reverse gear.

You could lose control of your vehicle if you shift the transmission to neutral on an incline and then try to brake the vehicle using only the service brake. Never let the vehicle roll.

Overloading the vehicle will increase the risk of the vehicle tipping over. Never exceed the gross axle weight ratings under any circumstances. Keep the vehicle's center of gravity as low as possible when the vehicle is laden.

If the vehicle is frequently or mainly operated in muddy or marshy terrain, substances that impair braking efficiency, such as sand or oil mixed with water, could get into the brake system. This may lead to excessive wear and a reduction in braking performance (up to the point of total failure).

After driving off-road, always carry out a short brake test. If you detect a reduced braking performance or hear scraping noises, have the brake system checked at a qualified specialist workshop.

↑ WARNING

When driving off-road, your body is subject to forces from all directions, due to the uneven surface. You could for example be thrown out of your seat and be injured. Always wear a seat belt, even when driving off-road.

Always observe the ground clearance of the vehicle and avoid obstacles, e.g. deep

Obstacles could damage the vehicle, for example:

- the axles
- the propeller shafts and the transmission
- · the tanks and supply reservoirs

For this reason, you should always drive slowly when driving off-road. If you have to drive over obstacles, have the co-driver direct you.

When driving the vehicle, particularly on rough terrain, ensure that the driven wheels always have sufficient traction.

Avoid letting the drive wheels spin. Spinning drive wheels can damage the differential.

Rules for driving off-road

↑ WARNING

If you drive over obstacles or in ruts, the steering wheel may jerk out of your grip and you could injure the thumbs on both hands. Always hold the steering wheel cross firmly with both hands. When driving over obstacles, you must expect steering forces to increase briefly and suddenly.

- Before driving off-road, stop the vehicle and shift to a low gear.
- Only drive off-road with the engine running and a gear engaged.
- Drive slowly and smoothly. Walking pace is necessary in many situations.
- Make sure that the wheels always remain in contact with the ground.
- Drive with extreme care over unknown terrain where you can only see for a short distance. As a precaution, get out of the vehicle to take a look at the route to be taken first.
- · Check the water depth before fording.
- · Watch out for obstacles (e.g. rocks, holes, tree stumps and ruts).
- · Avoid edges where the surface could crumble or break away.

Before driving off-road

- ▶ If the surface demands it, temporarily deactivate ASR when pulling away (⊳ page 51).
- ► Safely stow or secure any items of luggage or loads (⊳ page 144).
- 1 We recommend that you additionally carry a shovel and a recovery rope with shackle in the vehicle.

After driving off-road



↑ WARNING

Damage caused to the vehicle when driving off-road may cause consequential damage,

the failure of mechanical assemblies as well as accidents. Clean and inspect the vehicle after any off-road use. Repair any damage before using the vehicle again.

- ► Activate ASR (> page 51).
- ► Clean the vehicle (> page 169).
- ► Check the vehicle for damage.

Transport by rail

Transporting your vehicle by rail may be subject to certain restrictions or require special measures to be taken in some countries due to varying tunnel heights and loading standards.

You can obtain information on this at any qualified specialist workshop.

Fuel consumption

Fuel consumption depends on:

- the vehicle version
- the style of driving
- the operating conditions
- the type or quality of the fuel used

The vehicle will use more fuel than usual in the following situations:

- at very low temperatures
- · in city traffic
- on short trips
- · when towing a trailer
- in mountainous terrain

Observe the advice in the "Protection of the environment" section to keep fuel consumption low (▷ page 17).

The following components of the different vehicle versions influence fuel consumption:

- tire sizes, tire tread, tire pressure, tire condition
- body

- drive unit gear ratios
- additional equipment (e.g. air-conditioning system, auxiliary heating system).

Details concerning fuel consumption are recorded in the on-board computer; use the steering wheel buttons to call up the Trip computer menu (> page 88).

DEF consumption

Depending on the vehicle version, the DEF consumption is:

- for the Cargo Van/Passenger Van, approximately 2322 MPG (0.10 I/100 km)
- for the Cab Chassis, approximately 1720 MPG (0.14 I/100 km)

In each case, the stated consumption figure is a mean value between urban and extraurban driving cycles. The consumption figure does not refer to a specific vehicle, but is provided for the purposes of comparison between different vehicle types.

DEF consumption, like fuel consumption, is very dependent on the driving style and the operating conditions. This means that the real consumption figures during operation of your vehicle may deviate from those stated.

Engine oil consumption

If the vehicle is predominantly used for short-distance driving, this could lead to a malfunction in the automatic cleaning function for the diesel particle filter. As a result, fuel may accumulate in the engine oil and cause engine failure.

Therefore, if you mainly drive short distances, you should drive on a highway or on rural roads for 20 minutes every 310 miles (500 km). This ensures sufficient regeneration of the diesel particle filter.

Depending on driving style, the vehicle will consume a maximum of 1.0 US qt (1.0 I) of oil per 620 mi (1000 km).

Oil consumption may be higher if:

- the vehicle is new.
- you mainly operate the vehicle under arduous operating conditions.
- you frequently drive at high engine speeds.

Regular maintenance is one of the preconditions for moderate rates of consumption.

You can only estimate the oil consumption after you have driven a considerable distance. Check the oil level on a regular basis, e.g. weekly or each time you refuel (> page 174).

Speed limiter

You can permanently limit the maximum speed of your vehicle to 75km/h (120km/h). We recommend that you use an authorized Sprinter Dealer for the programming of the maximum speed.

Before overtaking, take into consideration that the engine speed limiter prevents the speed increasing beyond the programmed maximum speed.

On downhill gradients, the limit speed may be exceeded. Apply the brakes if necessary. Display messages indicate that you are approaching the limit speed – vehicles without steering wheel buttons (> page 201), vehicles with steering wheel buttons (> page 203).

⚠ WARNING

Exceeding the permissible maximum speed can cause tire damage, which could lead to loss of control of the vehicle.

As the driver, you must find out about the maximum speed of the vehicle and the resulting permissible maximum speed of the tires (tire and tire pressure).

You must not exceed the speed limit for the tires listed in the tire pressure tables.

1 You will find information about tire pressure in the "Technical data" section (▷ page 288).

Reverse warning device

On vehicles with a reverse warning feature, a warning signal sounds when reverse gear is engaged to alert other road users. The volume of this warning signal can be reduced for night-time driving.

↑ WARNING

Other road users could fail to hear or could ignore the reverse warning feature warning signal. For this reason, the reverse warning feature cannot guarantee that there are no people or objects behind your vehicle.

The reverse warning feature is a system designed to assist you in ensuring the safety of other road users. It does not, however, relieve you of your responsibility to make sure that there are no persons or objects behind your vehicle while you are maneuvering.

For this reason, always observe the road and traffic conditions with due caution. To avoid damage and injury, make sure that there are no persons or objects behind the vehicle while you are maneuvering. Have a second person assist you when maneuvering if necessary.

➤ To set the warning signal to quiet: engage the reverse gear twice in brief succession.

The volume of the warning signal is reduced.

The warning signal sounds at normal volume by default and will need to be reduced in volume each time reverse gear is engaged.

Refueling

Fuel

♠ WARNING

Fuel is highly flammable. Fire, naked flames and smoking as well as the use of auxiliary heaters (sparks) are therefore prohibited when handling fuel.

Switch off the engine and the auxiliary heating before refueling.

⚠ WARNING

Avoid any contact with fuels.

You can damage your health if your skin comes into direct contact with fuel or if you inhale fuel vapors.

⊕Environmental note

If fuels are handled improperly, they pose a danger to persons and the environment. Do not allow fuels to run into the sewage system, the surface waters, the ground water or into the ground.

Filter the fuel before transferring it to the vehicle if you are refueling the vehicle from barrels or containers.

This will prevent malfunctions in the fuel system due to contaminated fuel.


↑ WARNING

Do not use gasoline to refuel vehicles with a diesel engine. Never mix diesel with gasoline. This causes damage to the fuel system and engine and could result in the vehicle catching fire.

- Do not use gasoline to refuel vehicles with a diesel engine. Even small amounts of gasoline will cause damage to the fuel system and engine.
- Do not switch on the ignition if you accidentally refuel with the wrong fuel. Otherwise, the fuel will enter the fuel lines. Notify a qualified specialist workshop and

have the fuel tank and fuel lines drained completely.

The fuel filler flap is beside the front left-hand door when viewed in the direction of travel. It is only possible to open the fuel filler flap when the front door is open.



- ▶ Remove the key from the ignition lock.
- ► Switch off the auxiliary heating system (⊳ page 106).
- ▶ Open the front left-hand door first, and then the fuel filler flap.
- ► Close all vehicle doors to prevent fuel vapors from entering the vehicle.
- ► Turn fuel filler cap ② counter-clockwise, remove it and let it hang from strap (1).
- ▶ Only fill the fuel tank until the pump nozzle switches off.
- ▶ Replace tank filler cap (2) and turn clockwise.

You will hear a click when the fuel filler cap is closed fully.

▶ Open the front left-hand door first, and then close the filler flap.

You will find information about fuel in the "Service products" section (> page 156).

- ▶ Remove the key from the ignition lock.
- ▶ Switch off the auxiliary heating system (⊳ page 106).
- ► Close all vehicle doors to prevent fuel vapors from entering the vehicle.

- ► Only fill the fuel tank until the pump nozzle switches off.
- ► Replace tank filler cap ② and turn clockwise.

You will hear a click when the fuel filler cap is closed fully.

Diesel Exhaust Fluid (DEF)

Important safety notes

The exhaust gas aftertreatment requires a reducing agent, Diesel Exhaust Fluid (DEF), in order to function correctly.

↑ WARNING

If you open the DEF reservoir cap at high temperatures, ammonia vapors could be released.

Ammonia vapors have a pungent odor and are particularly irritating for your skin, respiratory organs and eyes. This may result in burning eyes, nose and throat, as well as coughing and watering eyes.

Do not inhale ammonia vapors.

↑ WARNING

Avoid contact with DEF.

DEF is hazardous to health. Do not allow DEF to come into contact with your skin. Rinse affected areas with plenty of clean water and consult a doctor if necessary.

QEnvironmental note

Dispose of DEF in an environmentally responsible manner.

■ Only use DEF in accordance with ISO 22241. Never mix DEF with additives or thin it with tap water. The exhaust gas aftertreatment may otherwise be damaged.

Observe the MB Specifications for Service Products, Sheet 352.0.

- Damage that results from the use of additives or tap water leads to the loss of the New Vehicle Limited Warranty.
- If DEF comes into contact with a painted or aluminum surface, wash the surface off immediately with plenty of water.
- DEF is not a diesel additive and must not be mixed with fuel in the tank. Even small amounts of DEF can cause engine damage. Damage that results from the blending of DEF will not be covered by the New Vehicle Limited Warranty.
- If the DEF reserve has fallen below the reserve range, add at least 2.0 US gal (7.6 I) of DEF at the latest after receiving the second warning message (> page 118).
- 1 If you switch off the engine at a low outside temperature and add DEF, restart the engine after refueling. If you leave the engine switched off without restarting and the DEF freezes in the tank, then the onboard computer cannot register the altered level until after a thawing-out time of up to 60 minutes. During this time, you may not be able to start the engine.

You will find further information on DEF in the "Service products" section (▷ page 158).

DEF filler neck in the engine compartment


- ▶ Remove the key from the ignition lock.
- ► Close all vehicle doors so that no ammonia vapors can enter the vehicle.
- 1 Do not inhale any ammonia vapors which may escape when you unscrew the tank filler cap. Ammonia vapors have a pungent odor. However, they are neither toxic nor hazardous to health in this concentration.



- ► Turn tank filler cap ① counter-clockwise and remove it.
- ▶ Only fill up the DEF tank until the DEF level is visible in the filler neck.
- ▶ Replace DEF tank filler cap ① on the filler neck and turn clockwise.
 - You will hear a click when tank filler cap ① is closed fully.


DEF filler neck on the right-hand vehicle side

- ▶ Remove the key from the ignition lock.
- ► Close all vehicle doors so that no ammonia vapors can enter the vehicle.
- 1 Do not inhale any ammonia vapors which may escape when you unscrew the tank filler cap. Ammonia vapors have a pungent odor. However, they are neither toxic nor hazardous to health in this concentration.



The DEF reservoir on the right-hand side of the vehicle (example: Cab Chassis)





Fuel filler cap

- Remove tool ⑤ for unlocking tank filler cap ② from the footwell on the co-driver's side (▷ page 184).
- ▶ Pull cover ④ up, turn 90° and release.
- ► Insert tool ⑤ into hole ③ of tank filler cap ②.
- ► Turn fuel filler cap ② counter-clockwise, remove it and let it hang from strap ①. Make sure that tool ⑤ remains in tank filler cap ② while doing so.
- ▶ Only fill up the DEF tank until the DEF level is visible for the first time in the filler neck.
- ► Replace tank filler cap ② and turn clockwise.
- ▶ Pull tool ⑤ out of tank filler cap ② and stow with the vehicle tool kit in the footwell on the co-driver's side.
- ▶ Pull cover ④ up over hole ③ of tank filler cap ②, turn and release.
- ► Turn tank filler cap ②.

 If fuel cap ② can be turned freely, then the DFF reservoir is locked.

Transporting loads with the vehicle

Loading guidelines

Important safety notes



Secure and position the load as described in the loading guidelines. You or others could

otherwise be injured by the load slipping or being thrown around in the event of sharp braking, sudden changes in direction or on poor road surfaces. This also applies to seats which have been removed if they remain in the vehicle.

Even if you follow all loading guidelines, the load increases the risk of injury in the event of an accident. Observe the tips in the "Securing a load" section.

↑ WARNING

Do not allow the load, including passengers, to exceed the permissible gross vehicle weight or the gross axle weight rating for your vehicle.

If the gross axle weight rating or permissible gross vehicle weight is exceeded during transport, tire durability and road safety are adversely affected. The vehicle's handling and steering characteristics change noticeably. Braking and stopping distances are significantly longer.

The vehicle's driving, steering and braking characteristics change as the gross vehicle weight increases or when the center of gravity is raised.

Always make sure that the distribution of the load is correct and adapt your driving style according to the load.

↑ WARNING

If you have mounted a roof carrier, the vehicle's handling, steering and braking characteristics may change due to the higher center of gravity. This is the case particularly if the roof carrier is laden. Adapt your driving style according to the vehicle load.

Observe the manufacturer's installation instructions. An incorrectly secured roof carrier and/or load could come loose, fall off and thereby endanger you or others.

Observe the maximum roof load and maximum roof carrier load. Loads transported on the roof must always be secured with particular care.

Do not allow the load, including passengers, to exceed the permissible gross vehicle weight or the gross axle weight rating for your vehicle.

↑ WARNING

When using suitable load securing aids and lashing material, always follow the manufacturer's operating instructions, in particular the notes on discard criteria contained therein.

Load securing aids and lashing material may not be used, for example, if:

- · identification marks are missing or illegible
- there are yarn breakages, damage to bearing seams or other signs of tearing
- there are signs of shearing, deformation, pinching or other damage
- there is damage to clamping or connecting elements

Load securing aids and lashing material in this condition are ready for discard and must be replaced.

If you use load securing aids or lashing materials that are ready for discard, the load is not correctly secured and could cause serious injuries to you and others and cause material damage.

⚠ WARNING

In the event of an accident, have a damaged cargo compartment floor or loading area, the cargo tie down rings and the tie down checked at a specialist workshop. Otherwise, the load may not be correctly secured the next time anything is stowed and could cause serious injuries to you and others and cause damage to property.

If you are using a roof carrier, observe the maximum roof load and maximum roof carrier load.

You will find information about the maximum roof load in the "Technical data" section (⊳ page 290) and information about roof

carriers in the "Carrier systems" section (⊳ page 149).

Before loading

- ▶ Tire pressure: check the tire pressure and correct if necessary (⊳ page 288).
- ► Cargo compartment floor: clean the cargo compartment floor.
 - The cargo compartment floor must be free from oil and dust, dry and swept clean to prevent the load from slipping.
- ▶ Place non-slip mats (anti-slip mats) on the cargo compartment floor if necessary.
- As soon as the non-slip mats show signs of deformation or develop squashed areas, or traces of cracking/cutting, they can no longer be used to secure a load and must be replaced.

During loading

- ▶ Observe the gross axle weight rating and permissible gross vehicle weight for your vehicle.
- On passenger van versions with maximum seating layout, the permissible rear axle load would be exceeded if the full payload were to be loaded in the cargo compartment.
- Bear in mind that the curb weight of the vehicle is increased by installing optional equipment and accessories.
- ▶ Observe the notes on load distribution (⊳ page 146).
- ► Secure the load (> page 147). Always observe the relevant country-specific legal requirements, laws and regulations.

Checks after loading

▶ Securing loads: check that the load is secure before every journey and at regular

- intervals during a long journey, and correct if necessary.
- ▶ **Doors:** close the sliding doors and rear doors.

WARNING

Make sure that the sliding doors and rear doors are always closed when the engine is running.

Exhaust fumes could otherwise enter the vehicle interior and poison you.

- ▶ Tire pressure: adjust the tire pressures according to the vehicle load (⊳ page 288).
- ▶ Driving style: adapt your driving style according to the vehicle load.

Load distribution

The overall center of gravity of the load should always be as low as possible, centered and between the axles near the rear axle.

Excessive loads on individual points of the cargo floor or on the load surface impair vehicle handling characteristics and could cause damage to the floor covering.

On Panel Vans/Passenger Vans:

- ► Always transport loads in the cargo compartment.
- ► Always place the load against the backrests of the rear bench seat.
- ► Move large and heavy loads as far towards the front of the vehicle as possible against the rear bench seat. Stow the load flush with the rear bench seat.
- ► Always additionally secure the load with suitable load securing aids or tie down.

- 1 Observe the following notes:
 - Do not stack loads higher than the upper edge of the backrests.
 - Transport loads behind seats that are not occupied.
 - If the rear bench seat is not occupied, insert the seat belts crosswise into the buckle of the opposite seat belt.

Securing loads

General notes

As the driver, you are responsible for ensuring that the cargo is secured against sliding, tipping, rolling or falling. This applies to general traffic situations as well as evasive maneuvers or full brake application and on poor stretches of road.

Your load must be secured in accordance with applicable regulations and technical requirements. If this is not the case, this may constitute a punishable offense under local legislation.

You should therefore observe the respective legal requirements for the relevant country. Make sure that the load is secure before every journey and at regular intervals during a long journey. Correct an incorrectly or inadequately secured load if necessary.


- 1 You can obtain information about securing the load correctly from the manufacturer of the load securing aids or tie down for securing the load.
- ► Fill spaces between the load and the cargo compartment walls or wheel housings (form fit). Use rigid load securing aids, such as wedges, wooden fixings or padding.
- ▶ Once the load has been fixed so that it cannot tip or slide, secure it in all directions to lashing points, cargo tie down rings or loading rails in the cargo compartment or on the load surface. Only use tie downs, such as lashing rods or lashing nets and lashing straps, that have been tested in

accordance with current standards (e.g. DIN EN).

Always use the cargo tie-down rings closest to the load to secure it and pad sharp edges for protection.


Lashing material tested in accordance with current standards (e.g. DIN EN) is available at any qualified specialist workshop.

Loads, and heavy loads in particular, should preferably be secured using the cargo tiedown rings.



Cargo tie-down points (example: Passenger Van)

① Cargo tie-down rings



Cargo tie-down points (example: Cargo Van)

- Cargo tie-down rings
- (2) Load rails

MARNING

You may not transport anyone in the cargo compartment or on the load surface. Never let more people ride in the vehicle than there are seat belts available. Make sure everyone riding in the vehicle is correctly restrained with a separate seat belt. Never use a seat belt for more than one person at a time.

↑ WARNING

Do not attempt to modify or repair the lashing points, cargo tie-down rings or tie downs. The load or the cargo tie-down rings could work loose and cause serious injury to you and other people as well as material damage. Spread the load evenly between the lashing points or cargo tie-down rings.

Observe the loading guidelines.

- 1 Secure loose loads with a tested lashing net or a tarpaulin.
- Always fasten the lashing net or tarpaulin to all available cargo tie-down points. Make sure that the retaining hooks are secured against accidental opening.

Observe the information on the maximum loading capacity of the lashing points.

If you use multiple lashing points to secure a load, you should observe the maximum loading capacity of the weakest lashing point.

When you brake hard, for example, forces apply that can be far higher than the weight force of the transported load. Always use multiple lashing points to distribute these forces, and distribute the load equally among them.

Information about the maximum loading capacity of the cargo tie-down points can be found in the "Technical data" section (> page 290).

ilf your vehicle is equipped with loading rails in the cargo compartment floor, you should place lashing rods directly in front of and behind the load. The lashing rods directly absorb the potential shifting forces.

↑ WARNING

If you tension the lashing straps between the side walls, or between a side wall and the cargo floor, the maximum permissible load for the loading rails or lashing points or eyelets could be exceeded if the brakes are applied suddenly, if the vehicle's direction is changed abruptly or in the event of an accident.

The load would no longer be secured, resulting in a risk of serious injury being caused by the load slipping.

For this reason, do not tension a lashing strap between the side walls or between a side wall and the cargo floor.


Only lashing rods are to be used between the loading rails on the side walls. Observe the operating instructions of the lashing rod manufacturer.

 Securing loads on the cargo compartment floor by lashing them down is only recommended for lightweight loads. Place non-slip mats (anti-slip mats) under the load to increase load security.

♠ WARNING

Before releasing the lashing straps, you must make sure that the load is standing firmly and that it cannot tip over once the straps have been removed. Otherwise, you or others could be injured by the load slipping.

Installing/removing cargo tie-down points for the loading rails



- ► To install: slide the cargo tie-down ring through a recess in the loading rail close to the load until locking mechanism (1) engages in the recess.
- 1 When you pull locking mechanism (1) up and out of the recess, the cargo tie-down ring is able to move within the loading rail. Make sure that locking mechanism (1) is always engaged in a recess.

↑ WARNING

If not firmly anchored in the loading rail, the cargo tie-down ring may slip or be torn out of the loading rail in the event of sudden braking.

The load would no longer be secured, resulting in a risk of serious injury being caused by the load slipping. For this reason, always check the cargo tie-down ring for firm seating after installing.


- ► Check the cargo tie-down ring for firm seating.
- ▶ To remove: pull locking mechanism (1) up and pull the cargo tie-down ring towards

the locking mechanism and out of the loading rail through a recess.

Carrier systems

It is possible to mount a roof carrier if your vehicle is equipped with securing rails on the roof.

Special mounting elements (grooved plates) are available as accessories. These mounting elements are available at any authorized Sprinter Dealer.



Securing rails

↑ WARNING

If you have mounted a roof carrier, the vehicle's handling, steering and braking characteristics may change due to the higher center of gravity. This is the case particularly if the roof carrier is laden. Adapt your driving style according to the vehicle load.

Observe the manufacturer's installation instructions. An incorrectly secured roof carrier and/or load could come loose, fall off and thereby endanger you or others.

Observe the maximum roof load and maximum roof carrier load. Loads transported on the roof must always be secured with particular care.

Do not allow the load, including passengers, to exceed the permissible gross vehicle weight or the gross axle weight rating for your vehicle.

You can find information about the maximum roof load in the "Technical data" section (⊳ page 290).

Make sure that:

- the fastening bolts of the roof carrier are tightened in the grooved plates provided with a torque of 6.0 - 7.4 lb-ft (8 - 10 Nm)
- the bolts do not make contact with the rails when tightened.
- the sliding blocks are not positioned near the plastic caps.
- the sliding blocks have the correct crosssection.
- the securing rails are free of dirt on the inside.
- you evenly retighten the fastening bolts after approximately 300 miles (500 km)

We recommend only using roof carriers that are tested and approved for the Sprinter. This will help avoid damage to the vehicle.

If you want to retrofit securing rails, have it done at a qualified specialist workshop. Otherwise, you could damage the vehicle.

Towing a trailer

Notes on trailer towing

Important safety notes

⚠ WARNING

When driving with a trailer, incorrect equipment and an inappropriate driving style may cause you to lose control over the vehicle.

Incorrect towing or failure to observe this Operator's Manual can lead to damage to the vehicle or serious injury. Observe the following guidelines to ensure safe diving with a trailer.

If you require explanations for the information in this Operator's Manual, contract an authorized Sprinter Dealer.

↑ WARNING

If you use a ball coupling that is not approved for your vehicle, it may cause excessive strain on the trailer tow hitch. This can cause damage to the vehicle and the trailer may come loose during the journey. The handling may be impaired and the rear axle may be overloaded. This may lead to an accident involving serious or even fatal injury.

Therefore note the following:

- Only install a ball coupling that is approved for your vehicle.
- Before the journey, make sure that the ball coupling is correctly installed and secured. To do this, observe the operating instructions of the ball coupling manufacturer.
- Do not make any modifications to the ball coupling or the trailer tow hitch.

You must observe the operating instructions of the trailer tow hitch or ball coupling manufacturer.

↑ WARNING

When reversing the towing vehicle, make sure nobody is standing between the vehicle and the trailer.

Couple and decouple the trailer carefully. A trailer which is incorrectly coupled to the towing vehicle could break away.

Ensure that the following weights are not exceeded:

- the permissible noseweight
- · the permissible trailer load
- the permissible rear axle load of the towing vehicle
- the permissible gross weight of both the towing vehicle and the trailer
- the permissible gross combination weight

The permissible values, which must not be exceeded, can be found in your vehicle documents and on the trailer tow hitch type plates for the trailer and the vehicle. Where the values differ, the lowest is valid.

The basic values approved by the manufacturer can also be found in the "Technical data" section (> page 291). If different values are stated in your vehicle documents or on the identification plates, the lowest value always applies.

↑ WARNING

When towing a trailer, your vehicle's handling characteristics will be different in comparison with when driving without a trailer.

The vehicle/trailer combination:

- · is heavier
- is restricted in its acceleration and gradient-climbing capability
- has an increased braking distance
- is affected more by strong crosswinds
- · demands more sensitive steering
- · has a larger turning circle

As a result, the handling characteristics may be impaired and you may lose control of the vehicle. This could lead to an accident with serious or even fatal injuries.

When towing a trailer, always adjust your speed to the current road and weather conditions. Do not exceed the maximum permissible speed for your vehicle/trailer combination.

↑ WARNING

Never depress the brake pedal continuously while the vehicle is in motion, e.g. never cause the brakes to rub by applying constant slight pedal pressure. This causes the brake system to overheat, increases the braking distance and can lead to the brakes failing completely.

↑ WARNING

Under no circumstances try to straighten the vehicle/trailer combination by increasing the speed.

General notes

 Observe the legally prescribed maximum speed for vehicle/trailer combinations in the respective country, state or Canadian province.

This reduces the risk of accidents.


- Install only an approved trailer coupling on your vehicle. Only use a ball coupling that is approved for your vehicle with your Sprinter trailer tow hitch. More information on the availability, mounting and installation of the trailer electrics is available at any qualified specialist workshop.
- The turn signals on the trailer are only guaranteed to function when bulbs are used. You can obtain more information about installing the trailer electrics at any qualified specialist workshop.
- The trailer coupling is one of the most important vehicle parts with regard to road safety. The notes on operation, care and maintenance issued by the manufacturer should be observed.
- The bumpers of your vehicle are not suitable for installing detachable trailer couplings.
- Do not install rented trailer couplings or other detachable trailer couplings to the bumpers.
- To reduce the risk of damage to the ball coupling, remove it from the ball coupling mounting when you are not using it.

Weight information can be found in the "Permissible trailer and drawbar noseweights" section (> page 154).

Note that when driving with a trailer,

PARKTRONIC is restricted or not available (> page 123).

1 The height of the ball neck changes according to the load on the vehicle. In this case, use a trailer with a height-adjustable trailer drawbar.



Trailer coupled ready for use

Driving tips:

The maximum permissible speed for vehicle/ trailer combination depends on the type of trailer. Before setting off, check the vehicle documents of the your trailer to find out the permissible maximum speed. Observe the legally prescribed maximum speed for vehicle/trailer combinations in the respective country, state or Canadian province.

Your vehicle behaves differently with a trailer than without one.

On long, steep downhill slopes you must select shift range 3, 2 or 1 in good time.

This also applies if you have activated cruise control.

This enables you to utilize the engine's braking effect and you do not need to brake so heavily to keep the correct speed. This protects the brake system and prevents the brakes from overheating and wearing too quickly. If you need to brake additionally, to not depress the brake pedal constantly, but periodically.

Driving tips

- Maintain a greater distance than you would when driving without towing a trailer.
- Avoid sudden braking. Apply the brakes gently at first to allow the trailer brake to

- overrun. Then, increase the brake force quickly.
- When driving in mountainous areas, note that the power output of the engine, and with it its gradient climbing capability, decrease with increasing altitude.

If the trailer begins to swing from side to side:

- do not accelerate.
- do not counter-steer.
- ▶ brake if necessary.
- 1 You can reduce the risk of the trailer swinging and rocking by retrofitting antiroll bars or trailer stability programs. More information is available from your authorized Sprinter Dealer.

Attaching and removing the ball coupling



↑ WARNING

If the ball coupling is incorrectly mounted or not properly secured, the ball coupling and the trailer may come loose. As a result, you could cause an accident.

Therefore note the following:

- Make sure the ball coupling is correctly secured. Observe the information in the operating instructions of the ball coupling manufacturer.
- · If you cannot mount the ball coupling correctly, remove it. In this case, the ball coupling may not be used for towing a

Have the entire trailer coupling checked at a qualified specialist workshop.

If your vehicle is equipped with a Sprinter trailer tow hitch, you need a ball coupling that is approved for the trailer tow hitch.

When mounting and removing the approved ball coupling, observe the relevant information in the operating instructions of the ball coupling manufacturer.

Notes on the permissible dimensions and weights can also be found on the identification plate of the trailer tow hitch. Any qualified specialist workshop will be happy to advise you.

Coupling up a trailer

Observe the maximum permissible trailer dimensions (width and length).

Most federal states and all Canadian provinces require by law:

 the use of safety chains between the towing vehicle and the trailer. The chains should be cross-wound under the trailer drawbar. They must be connected to the trailer tow hitch. They may not be connected to the bumper or the axle of the vehicle.

Leave enough slack in the chains. This allows you to drive round tight corners.

- a separate brake system for certain trailers.
- a safety switch for braked trailers. Find out the specific requirements according to the applicable laws.

If the trailer detaches from the towing vehicle, the safety switch applies the trailer's brakes.

- 1 The vehicle's wiring harness has an electric cable to the brake light indicator lamp.
- ► Make sure the selector lever of the automatic transmission is in position **P**.
- ► Apply the parking brake of the vehicle.
- ► Close all doors.
- ► Couple the trailer.
- ► Establish all electrical connections.

Towing a trailer

There are numerous legal requirements concerning the towing of a trailer, e.g. speed restrictions. Make sure your vehicle/trailer

combination complies with local laws. This not only means where you live, but also anywhere you are driving to. Information is available from the police and local authorities.

Please observe the following when towing a trailer:

- Practice driving around bends, stopping and reversing at a place where there is no traffic. This enables you to gain experience and get used to the new handling characteristics.
- Before driving, check:
 - that the trailer tow hitch and ball coupling are secure
 - that the safety switch for a braked trailer is functioning properly
 - that the safety chains are secure and not damaged
 - that the electrical connections are secure
 - that the lights are working
- that the wheels are in good order and the tire pressure is correct
- Adjust the exterior mirrors so that you have an unobstructed view of the rear of the trailer.
- If the trailer has electronically controlled brakes, pull the vehicle/trailer combination away carefully and brake manually using the brake controller. Check whether the brakes are working.
- Secure the load on the trailer according to the applicable specifications and current standards on securing loads (▷ page 147).
- When driving with a trailer, check at regular intervals that the load is secured and that the brakes and lights are working.
- Bear in mind that the handling will be less stable when towing a trailer than when driving without one. Avoid sudden steering movements.
- The vehicle/trailer combination is heavier, accelerates more slowly and has a

decreased gradient climbing capability and a longer braking distance.

It is more susceptible to crosswinds and requires cautious steering.

- If possible, do not brake suddenly but moderately, so that the trailer can activate its brake. Then increase the force on the brake pedal.
- If the automatic transmission repeatedly shifts between gears when driving on inclines, restrict the shift range. Select shift range 4, 3, 2 or 1.

Driving in a low gear and at a low speed reduces the risk of damaging the engine.

- If you drive on a downward slope, shift to a lower gear in good time. This allows you to utilize the engine's braking effect.
 - Avoid continuous brake application as this may overheat the vehicle brakes and, if installed, the trailer brakes.
- If the coolant temperature increases dramatically while the air-conditioning system is switched on, switch off the airconditioning system.
 - Coolant heat can also be dissipated if you open the windows and switch the airflow and temperature of the heating/air conditioning to maximum.
- When overtaking, pay particular attention to the extended length of your vehicle/ trailer combination.

Due to the length of your vehicle/trailer combination you need an additional distance before you can return to your original lane.

Uncoupling a trailer

⚠ WARNING

Do not disconnect a trailer with an engaged overrun brake. Otherwise, your hand could become trapped between the bumper and trailer drawbar.

- Do not disconnect a trailer with an engaged overrun brake. Otherwise, your vehicle could be damaged by the rebounding of the overrun brake.
- ► Make sure the selector lever of the automatic transmission is in position **P**.
- ▶ Apply the parking brake of the vehicle.
- ▶ Close all doors.
- ► Apply the parking brake of the trailer.
- ► Remove the trailer cable and if necessary the safety chains and uncouple the trailer.

Permissible trailer and noseweights

Weight information

The Gross Trailer Weight (GTW) is the combined weight of the trailer together with the cargo and equipment loaded on the trailer. The permissible gross weight depends on the vehicle and the equipment: 5000 lbs (2268 kg) or 7500 lbs (3402 kg).

The maximum noseweight of the trailer drawbar on the ball coupling (TWR) is 500 lbs (227 kg) or 750 lbs (340 kg). The actual noseweight may not exceed the value given on the identification plates of the trailer tow hitch or the trailer. Where the values differ, the lowest is always valid.

The Gross Combination Weight Rating (GCWR) is calculated from the gross weight of the trailer and the gross vehicle weight, including a driver weight of approximately 150 lbs (68 kg). The permissible Gross Combination Weight Rating is vehicle-specific and depends on the equipment level.

When driving with a trailer, you should not exceed the permitted Gross Combination Weight Rating (GCWR).

I On vehicles with a permissible gross vehicle weight of 11030 lbs (5003 kg), the permissible gross combination weight is less than the total of the permissible gross vehicle weight and the permissible trailer load. Exceeding the permissible gross

combination weight can lead to damage to the drivetrain, to the transmission or to the trailer tow hitch.

If the vehicle or the trailer is fully laden, the relevant value for the permissible gross vehicle weight or the permissible trailer load is therefore lower. In this case, the trailer or the vehicle may only be partially loaded.

The permissible values, which must not be exceeded, can be found in your vehicle documents and on the trailer tow hitch type plates for the trailer and the vehicle (▷ page 285). The basic values approved by the manufacturer can also be found in the "Technical data" section (▷ page 291). Where the values differ, the lowest is always valid.

Loading a trailer

- You must distribute the load on the vehicle and trailer so that the permitted maximum values for the gross vehicle weight (GVWR), gross trailer weight (GTW) and gross combined weight (GCWR) as well as permitted gross axle loads (GAWR) and noseweight (TWR) of your vehicle are not exceeded.
- Add the drawbar noseweight on the ball coupling (TWR) to the rear axle load. This will prevent you from exceeding the permissible gross axle weight (GAWR).
- Add the drawbar noseweight on the ball coupling (TWR) to the vehicle payload. This will prevent you from exceeding the permissible gross vehicle weight (GVWR).
- Utilize the maximum permissible noseweight as fully as possible. Do not allow the weight to fall below the minimum permissible noseweight, otherwise the trailer may come loose.

Checking the vehicle and trailer weight

- Make sure the weights of the towing vehicle and the trailer comply with the maximum permissible values. Have the vehicle/ trailer combination weighed on a calibrated weighbridge. The vehicle/trailer combination consists of the towing vehicle including the driver, passengers and load, as well as the loaded trailer.
- Check the permissible axle load of the front and rear axle (GAWR), the gross weight of the trailer (GTW), the gross combination weight (GCWR) and the trailer drawbar noseweight (TWR).

Trailer power supply

Your vehicle may be equipped with various electrical installations for trailer towing. Depending on your trailer, you may need an adapter to connect the electrical system of the trailer with that of the vehicle. The turn signals on the trailer are only guaranteed to function when incandescent bulbs are used. Information on the current electrical equipment of your vehicle is available at any qualified specialist workshop.

Incorrect wiring of the connector plug could, under certain circumstances, cause malfunctions in the vehicle's other electronic systems. We therefore recommend having the connector plug wired at a qualified specialist workshop.

The trailer socket of your vehicle is equipped at the factory with a permanent power supply. The permanent power supply is on the trailer socket pin assignment 4.

Note that the permanent power supply of the trailer is not switched off when the on-board voltage is low. This can completely discharge the starter battery of your vehicle.

You can connect accessories with a maximum power consumption of 240 W to the permanent power supply.

You must not charge a trailer battery using the power supply.

You can obtain more information about installing the trailer electrics at a qualified specialist workshop.

Operation in winter

General notes

Have your vehicle winterproofed at a qualified specialist workshop at the onset of winter.

This service includes the following:

- · oil change, if the engine oil currently used does not have adequate low temperature characteristics or if these are no longer sufficient due to aging
- the antifreeze/anticorrosion concentration in the coolant is checked.
- the addition of a concentrated cleaning agent to the water in the windshield washer/headlamp cleaning system
- · battery check
- · tire change

Prior to the onset of winter, ensure that snow chains are stowed in the vehicle (⊳ page 263).

Do not cover the surface of the radiator or the radiator grill, even in winter. Doing so could cause the engine diagnostics to record false or incorrect data. The recording of specific engine diagnostic data is legally prescribed and must therefore be correct, clear and comprehensible at all times.

You will find information about diesel fuel for use at low outside temperatures in the "Operation" section (▷ page 157).

Please also observe the information about winter driving (⊳ page 113).

You will find information about winter tires and about driving with snow chains in the "Wheel and tires" section (▷ page 156).

Service products

Fuel

Important safety notes



/ WARNING

Fuel is highly flammable. Fire, naked flames and smoking as well as the use of auxiliary heaters (sparks) are therefore prohibited when handling fuel.

Switch off the engine and the auxiliary heating before refueling.

↑ WARNING

Avoid any contact with fuels.

You can damage your health if your skin comes into direct contact with fuel or if you inhale fuel vapors.

I Filter the fuel before transferring it to the vehicle if you are refueling the vehicle from barrels or containers.

This will prevent malfunctions in the fuel system due to contaminated fuel.

Refuel only with commercially available vehicle diesel fuel, ULTRA-LOW SULFUR DIESEL with a sulfur content no greater than 15 ppm. Fuels such as fatty acid methyl ester FAME (bio-diesel fuels), marine diesel, heating oil etc. may not be used as a diesel fuel mixture.

Refuel with B5 bio-diesel only if it fulfills the requirements listed under "Fuel quality".

Do not use any fuel additives, and use approved flow improvers only when necessary.

There is otherwise a risk of impaired engine performance or engine and catalytic converter damage. The use of fuel additives is always the responsibility of the vehicle operator and may result in restrictions to or the loss of the New Vehicle Limited Warranty.

Fuel grade

1 You will generally find information about the fuel grade on the filling pump. Otherwise, ask the gas station attendant.

Refuel only with commercially available ULTRA-LOW SULFUR DIESEL (ULSD, maximum sulfur content of 15 ppm) that conforms to the ASTM D975 standard.

We approve the use of B5 Biodiesel (ULSD with a maximum of up to 5 Vol.-% Biodiesel) for all Sprinter diesel engines with a Common Rail Direct Injector (CDI).

You may refuel with B5 bio-diesel if the bio-diesel content is in accordance with the ASTM standard D6751. It must also have the necessary oxidation stability (at least 6 h in accordance with the EN 14112 standard). Thereby, damage caused by deposits and/or corrosion can be avoided.

Pure bio-diesel and diesel fuels which have a higher percentage of bio-diesel, such as B20, may damage the fuel system and the engine. These fuels are therefore not approved. Please contact the gas station personnel for more information. The B5 bio-diesel marking on the pump must state clearly that the Standard for ULSD has been fulfilled. If the marking does not make this clear, do not refuel from that pump.

- You can damage the engine and diesel particle filter (DPF) by refueling with the following diesel fuels:
 - LOW SULFUR DIESEL with a sulfur content of maximum 500 ppm
 - diesel fuel with a sulfur content greater than 15 ppm
 - diesel fuel with a bio-diesel content larger than 5%
 - diesel fuel with a bio-diesel content of up to 5%, which does not conform to requirements listed under "Fuel quality".

Damage caused by the use of such diesel fuels is not covered by the New Vehicle Limited Warranty.

Diesel at low temperatures

Refuel only with commercially available ULTRA-LOW SULFUR DIESEL (ULSD, maximum sulfur content 15 ppm), which complies with the ASTM D975 standard.

To prevent operating problems, diesel with better flow qualities is available during the winter months. You can obtain information at the gas station or from your fuel supplier.

At low outside temperatures, paraffin separation may cause the flow properties of the diesel fuel to be insufficient.

Your vehicle is equipped with a fuel preheating system. This system also improves the flow characteristics of the diesel fuel by about 46 °F (8 °C). ULTRA-LOW SULFUR DIESEL can therefore be used at outside temperatures of approximately 14 °F (-10 °C) without any problems.

Fuel additives

Flow improvers are fuel additives used to improve the flow characteristics of diesel fuels.

The effectiveness of flow improvers cannot be guaranteed with all fuels. Observe the manufacturer's recommendations. Information about approved flow improvers is available from any authorized Sprinter Dealer.

- Do not use fuel additives (with the exception of flow improvers), since this could lead to malfunctions or engine damage. Damage caused by the use of such additives is not covered by the New Vehicle Limited Warranty.
- Do not add gasoline or kerosene to diesel fuel to improve its flow characteristics.

 Gasoline or kerosene impairs the lubricating properties of the diesel fuel.

 This may cause damage to the injection system, for example.

At outside temperatures below 14 °F (-10 °C) and with less cold-resistant winter diesel fuel, add the amount of flow improver appropriate to the outside temperature.

Add this additive to the diesel in time, i.e. before the flow properties of the diesel are affected by paraffin separation. Malfunctions caused by paraffin separation can only be rectified by heating the entire fuel system, e.g. by parking the vehicle in a heated garage.

↑ WARNING

If you heat up the fuel system with a heat gun, for example, you may damage parts of the fuel system. Fuel could escape, be ignited, and cause a fire.

Never heat the fuel system with a heat gun or with a naked flame.

Diesel Exhaust Fluid (DEF)

DEF is the reducing agent for the exhaust gas aftertreatment. DEF is a nonflammable, nontoxic, colorless, odorless and watersoluble liquid.

- Only use DEF in accordance with ISO 22241. The exhaust gas aftertreatment system may otherwise be damaged.
 - Observe the MB Specifications for Service Products, Sheet No. 352.0.
 - Damage caused by the use of other reducing agents will invalidate the New Vehicle Limited Warranty.
- If DEF comes into contact with a painted or aluminum surface, wash the surface off immediately with plenty of water.

High ambient temperatures

If DEF in the DEF reservoir heats up to temperatures above 122 °F (50 °C) for a long period of time (e.g. due to direct sunlight), ammonia vapors form.

↑ WARNING

If you open the DEF reservoir cap at high temperatures, ammonia vapors could be released.

Ammonia vapors have a pungent odor and are particularly irritating for your skin, respiratory organs and eyes. This may result in burning eyes, nose and throat, as well as coughing and watering eyes.

Do not inhale ammonia vapors.

Low ambient temperatures

DEF freezes at a temperature of approximately 12 °F (-11 °C). The vehicle is equipped with a DEF preheating system at the factory. This ensures that the vehicle can be operated in winter, even at temperatures below 12 °F (-11 °C).

Additives and tap water

Do not mix DEF with any additives and do not dilute DEF with tap water. Otherwise, the exhaust gas aftertreatment may be damaged.

Observe the MB Specifications for Service Products, Sheet No. 352.0.

Damage that arises through the use of additives or tap water will invalidate the New Vehicle Limited Warranty.

Storage

Only store DEF in containers made of highalloy Cr-Ni steel or Mo-Cr-Ni steel in accordance with DIN EN 10 088-1/2/3 or plastic containers made of polypropylene or polyethylene.

I Containers made of aluminum, copper, copper alloys as well as unalloyed or galvanized steel are not suitable for storing DEF. If stored in these types of containers, DEF could cause constituents of these metals to dissolve and cause irreparable damage to the exhaust gas aftertreatment. Damage caused by such impurities in the DEF will invalidate the New Vehicle Limited Warranty.

Disposal

Observe country-specific laws and regulations when disposing of DEF.

⊕Environmental note

Dispose of DEF in an environmentally responsible manner.

Purity

The purity of DEF is essential to prevent malfunctions in the exhaust gas aftertreatment.

If DEF is pumped out of the DEF tank, e.g. during repair work, the same liquid must not be used to refill the tank. Its purity is no longer guaranteed.

Impurities in DEF (e.g. caused by other service products, cleaning agents, dust, etc.) result in increased emissions, malfunctions, catalytic converter damage or engine damage.

Engine oils

Use only approved engine oil that complies with the MB Specifications for Service Products.

The bottles of the various engine oil types are marked with ACEA (Association des Constructeurs Européens d'Automobiles) and/or API (American Petroleum Institute) classifications. Only use approved engine oils that conform to the following MB Specifications for Service Products and the prescribed ACEA and/or API classifications. Using engine oils of another quality is not permitted and may invalidate the New Vehicle Limited Warranty.

The use of other, non-approved engine oils for diesel engines can cause damage to the diesel particle filter (DPF).

The following MB Specifications for Service Products apply to your vehicle¹

- 228.51
- 229.31
- 229.51

These engine oils are of high quality and have a beneficial effect on:

- engine wear
- fuel consumption
- emissions

Multi-grade engine oils of the prescribed SAE class (viscosity) may be used all year round, taking the outside temperatures into account.

Oil change

Oil change intervals depend on the vehicle's operating conditions and the quality of the engine oil used.

The on-board computer automatically shows the date for the next oil change as an event message in the display.

Select the SAE class (viscosity) of the engine oil in accordance with the outside temperature.


If the SAE viscosity class of the engine oil used does not cover the outside temperature range in which you are operating the vehicle, it must be changed in good time, in particular before the cold season commences. Using an engine oil that does not have adequate temperature characteristics can lead to engine damage.

The temperature range information of the SAE classification always refers to that of fresh oil. The temperature characteristics of the engine oil may deteriorate significantly due to aging in use, especially at low outside temperatures.

We recommend that you change the engine oil before the cold season commences. Use

If the quality level for diesel engines is not available, you may refill with engine oils that comply with the MB Specifications for Service Products, Sheet Nos. 228.5, 229.3 and 229.5. The refill quantity is then limited to a maximum of 1 qt (1 l).

an approved engine oil of the specified SAE class.



Engine oil SAE classification

1 Only by using engine oil with a particularly high quality grade, e.g. according to Sheet number 228.51 of the MB Service Product Specifications, can the maximum oil change interval be achieved.

We recommend that you only add engine oil of the same quality grade and SAE class as used when the engine oil was last changed. Further information can be obtained at any qualified specialist workshop.

Do not add too much oil. adding too much engine oil can result in damage to the engine or to the catalytic converter. Have excess engine oil siphoned off.

Miscibility of engine oils

If, in exceptional cases, oil of the type in the engine is not available, top up using another approved mineral or synthetic engine oil.

Engine oils are differentiated according to:

- · engine oil brand
- quality grade (sheet number)
- SAE class (viscosity)

Subsequently have the engine oil changed at the earliest possible opportunity.

Mixing oils reduces the benefits of using high grade engine oils.

1 The Sheet Number (quality grade) and the SAE classification (viscosity) can be found on the designation on the oil bottle.

Change intervals for engine oil

Service product	Maintenance interval	Product name/number	MB Sheet No.
Engine oil for diesel engines	see the Maintenance Booklet	see the Maintenance Booklet	228.51 229.31 229.51

Transmission and steering oils

Automatic transmission

Service product	Maintenance interval	Product name/number	MB Sheet No.
Automatic transmission oil	see the	Shell ATF 3403/M-115	236.10 236.12
	Maintenance Booklet	Fuchs/Shell ATF 3353	

Further information can be obtained at any qualified specialist workshop.

Rear axle

Service product	Maintenance interval	Product name/number	MB Sheet No.
Transmission oil	see the Maintenance Booklet	BP Energear Hypo DC 80W-90	235.20
		Mobil Delvac Synthetic Gear Oil 75W-90	235.8

Further information can be obtained at any qualified specialist workshop.

Steering

Steering, no maintenance required.

Service product	Maintenance interval	Product name/number	MB Sheet No.
Power steering fluid	_	Mobil ATF-D, Exxon Mobil Corporation or equivalent	236.3

Further information can be obtained at any qualified specialist workshop.

Brake fluid



⚠ WARNING

Brake fluid is hazardous to health. Do not swallow brake fluid. See a doctor immediately if you swallow brake fluid.

Make sure that brake fluid does not come into contact with skin, clothing or eyes. Rinse affected areas with plenty of clean water and consult a doctor if necessary.

Always wear gloves and eye protection when topping up brake fluid.

Store brake fluid only in the original closed container and keep it out of the reach of children. Comply with safety regulations when handling brake fluid.

Only use approved brake fluids that comply with the Specification for Service Products, Sheet Number 331.0. You must observe the boiling points (DOT 4 plus).

The brake fluid must have the following characteristics in accordance with the FMVSS 116 and ISO 4925 standards:

- Boiling point (ERBP) of at least 500 °F (260 °C)
- Wet boiling point (WERBP) at least 356 °F (180 °C)
- Viscosity of a maximum of 1500 mm²/s

Over a period of time, the brake fluid absorbs moisture from the air. This reduces its boiling point.

MARNING

If the boiling point of the brake fluid is too low, vapor pockets may form in the brake system whenever the brakes are subjected to a heavy load (e.g. on long downhill stretches). Vapor pockets in the brake system impair braking performance. As a result, the braking distance may increase. This increases the risk of an accident.

Every **2 years**, have the brake fluid renewed with a brake fluid approved by the distributor named on the inside of the front cover and have this confirmed in the Maintenance Booklet.

1 There is usually a notice in the engine compartment to remind you when the next brake fluid change is due.

Further information can be obtained at any qualified specialist workshop.

Change intervals for brake fluid

Service product	Maintenance interval	Product name/number	MB Sheet No.
Brake fluid	see the Maintenance Booklet	Intac B026E • Boiling point: 500 °F (260 °C) • Wet boiling point: 356 °F (180 °C)	331.0

Coolant

↑ WARNING

Coolant contains glycol and is therefore toxic. Do not swallow the coolant. See a doctor immediately if you swallow coolant.

Make sure that coolant does not come into contact with skin, eyes or clothing. In case of contact with eyes, rinse immediately with plenty of clean water. Clean affected areas of skin and clothing with soap and water immediately. Change any affected clothing immediately.

Coolant is a mixture of water and antifreeze/corrosion inhibitor.

In the coolant, the antifreeze/corrosion inhibitor is responsible for:

- corrosion protection
- · antifreeze protection
- · raising the boiling point

Coolant must remain in the engine cooling system all year round to ensure anti-corrosion protection and a higher boiling point, even in countries with high outside temperatures.

At the factory, the vehicle is filled with a coolant that ensures protection against frost and corrosion and which can be mixed with approved antifreeze/corrosion inhibitors.

■ Use only approved antifreeze/corrosion inhibitor that complies with MB Specification for Service Products, Sheet Number 325. Using other, non-approved antifreeze/corrosion inhibitors may cause damage to the coolant system and reduce the engine's service life.

Check the antifreeze/corrosion inhibitor concentration in the coolant every six months.

When the coolant is renewed, the coolant must contain 50 % antifreeze/corrosion inhibitor by volume. This provides antifreeze protection down to -34.6 °F (-37 °C).

Do not exceed a proportion of 55% by volume (antifreeze protection down to approximately -49.0 $^{\circ}$ F (-45 $^{\circ}$ C)). Otherwise heat dissipation is reduced.

If there is a loss of coolant, do not replenish with water only, but also add approved antifreeze/corrosion inhibitor. The water in the coolant must meet certain requirements, which are often fulfilled by drinking water. If the water quality is not sufficient, you must treat the water.

Observe the MB Specifications for Service Products, Sheet No. 325.

Further information can be obtained at any qualified specialist workshop.

Change intervals for coolant

Service product	Maintenance interval	Product name/number	MB Sheet No.
Coolant, antifreeze/corrosion inhibitor	see the Maintenance	EURO Peak Coolant/Antifreeze, OLD WORLD INDUSTRIES	
	Booklet	Zerex G05, The Valvoline Company	325.0
		Zerex G48, The Valvoline Company	325.0
		Glysantin G05, BASF AG	325.0

Refrigerant

The air-conditioning system uses the refrigerant R-134a. This refrigerant does not damage the ozone layer.

Further information can be obtained at any qualified specialist workshop.

Service product	Maintenance interval	Product name/number	MB Sheet No.
Refrigerant	_	Refrigerant R-134a	361.0

Cleaning and care

General notes

Regular care serves to maintain the value of your vehicle.

Preferably use Sprinter car care products. They are specially adapted to Sprinter vehicles and to the latest technology. You can obtain these car care products at any authorized Sprinter Dealer.

Do not cover the surface of the radiator or the radiator grill, e.g. with a protective screen. Doing so could cause the engine diagnostics to record false or incorrect data. The recording of specific engine diagnostic data is legally prescribed and must therefore be correct, clear and comprehensible at all times.

↑ WARNING

Always keep care products sealed and out of the reach of children.

Always follow the instructions for use of the care products.

Do not use fuel as a cleaning agent. Fuel is highly flammable and constitutes a health hazard.

⊕Environmental note

Wash the vehicle only at a properly equipped wash bay. Dispose of empty containers and used cleaning materials in an environmentally-responsible manner.

↑ WARNING

Never use openings in the bodywork as steps. You may otherwise damage the vehicle or lose your footing and injure yourself or others.

If you have to clean the upper areas of the vehicle, always use suitable ladders or other secure climbing aids.

↑ WARNING

Dirty or iced-up steps and entrances create a risk of slipping or falling.

Keep steps, entrances and footwear free from dirt (e.g. mud, clay, snow and ice).

Cleaning the interior of the vehicle

Seat belts

- Observe the following notes on cleaning the seat belts:
 - remove any stains or dirt immediately. This will avoid residue or damage.
 - do not bleach or dye the seat belts. This could impair the function of the seat belts.
 - do not dry the seat belts in direct sunlight or at temperatures above 176 °F (80 °C).

Steering wheel boss and cockpit

/ WARNING

When cleaning the steering wheel boss and dashboard, do not use cockpit sprays or cleaning agents containing solvents. Cleaning agents containing solvents cause the surface to become porous, and as a result, plastic parts may break away and be thrown around the interior when an air bag is deployed, which may result in severe injuries.

Use a damp, clean and lint-free cloth to clean the plastic components and the cockpit. If particularly dirty, use a mild detergent.

Do not use dry, coarse or hard cloths and do not scrub. You could otherwise scratch or damage the surfaces.

Audio equipment and monitor display

- ► Switch off the audio equipment or monitor of the rear-view camera and allow to cool.
- ► Clean the display surface with a commercially available microfiber cloth and cleaner for TFT/LCD displays.
- After drying, polish the display surface with a dry microfiber cloth, applying only light pressure.
- Do not use dry, rough or hard cloths or abrasive products, solvents or cleaning agents containing solvents. Do not scrub. Only apply light pressure when cleaning. Otherwise, you will damage the display surface, as it is sensitive to pressure and susceptible to scratches.

Windows

Do not use dry cloths, abrasive products, solvents or cleaning agents containing solvents to clean the inside of the windows. Clean the inside of the windows with a damp cloth or a commercially available glass cleaner.

Do not touch the inside of the rear and side windows with hard objects, e.g. an ice scraper or ring. You could otherwise damage the windows or the rear window defroster.

Cleaning the exterior of the vehicle

General notes

Scratches, corrosive deposits, areas affected by corrosion and damage caused by neglect or inadequate care cannot always be completely remedied. In this case, visit a qualified specialist workshop.

- In order to avoid consequential damage, repair damage caused by loose chippings and remove any dirt immediately, in particular:
 - insect remains
 - · bird droppings
 - flash rust
 - tree resin
 - · oils and grease
 - fuels
 - tar stains
 - · salt residue

Wash your vehicle more frequently if it gets dirty more often.

Do not park the vehicle for an extended period straight after cleaning it, particularly after having cleaned the wheels with wheel cleaner. Wheel cleaners could cause increased corrosion of the brake discs and brake pads/linings. For this reason, you should drive for a few minutes after cleaning. Braking heats the brake discs and the brake pads/linings, thus drying them. The vehicle can then be parked.


Electrical step

Clean the step, when fully extended, and its housing at least once a month using a power washer. Dirt should not be allowed to accumulate in the housing or on the step.

After cleaning, spray the step guides on each side with silicone spray when the housing and step are dry. Do not use oil or grease as a lubricant.

1 If you close the sliding door just far enough to engage the door lock, the step remains extended for cleaning.

PARKTRONIC sensors



PARKTRONIC sensors (example: front bumper, left side of vehicle)

(1) Sensors

Clean all the sensors in the front and rear bumpers with water, shampoo and a soft cloth.

■ Do not use dry, coarse or hard cloths and do not scrub. You will otherwise scratch or damage the sensors.

If you clean the sensors with a power washer or steam cleaner, observe the information provided by the manufacturer regarding the distance to be maintained between the vehicle and the nozzle of the power washer.

Rear-view camera lens



Rear-view camera in the middle of the roof above the high-mounted brake lamp

- Rear-view camera lens
- ② Microphone openings

Make sure not to put any wax on the lens of rear-view camera ① when waxing the vehicle. If necessary, remove the wax using water, shampoo and a soft cloth.

Do not use dry, coarse or hard cloths and do not scrub. Otherwise, you will scratch or damage the lens of the rear-view camera. If you clean the vehicle with a high-pressure or steam cleaner, maintain a distance of at least 1.650 cm from the rear-view camera. Do not aim directly at the rear-view camera or at the microphone opening on the underside of the rear-view camera. You could otherwise damage the rear-view camera.

Outer windshield and wiper blades

MARNING

Before cleaning the windshield or wiper blades, turn the key to **0** in the ignition lock. The windshield wipers may otherwise move and injure you.

- ► Turn the key to position **0** in the ignition lock or remove it.
- Do not fold the windshield wipers away from the windshield unless the hood is closed. Otherwise, you could damage the hood.
- ► Fold the windshield wiper arms away from the windshield until you feel them engage.
- ► Clean the windshield and the wiper blades.
- ► Fold the windshield wipers back again before switching on the ignition.

Headlamps

Wipe the headlamp lenses with a wet sponge.

Only use washer fluid which is suitable for plastic lamp lenses. Unsuitable washer fluid could damage the plastic lamp lenses of the headlamps.

Therefore, do not use:

- · dry cloths
- · abrasive products
- solvents

• cleaning products containing solvents

You could otherwise scratch or damage the surface of the lenses.

Sliding door

Clean the contact plates and the tips of the contact pins around the sliding door with water, shampoo and a soft cloth.

Do not oil or grease the contact plates and contact pins.

Remove foreign objects.

Power washers

- Maintain the following minimum distances between the high-pressure nozzle and the object being cleaned:
 - for round-jet nozzles, approximately 2.2 ft (70 cm)
 - for 25° flat-spray jets and dirt grinders approximately 1 ft (30 cm)

Keep the water jet moving while cleaning. To avoid causing damage, do not point the water jet directly at:

- · door joints
- brake hoses
- electrical components
- · electrical connections
- seals
- the drive train, especially not at the intermediate bearing of the propeller shaft
- the rear-view camera or the microphone opening on the bottom of the rear-view camera. Here, observe a minimum distance of 1.6 ft (50 cm)

↑ WARNING

The pulsating water jet from a round-jet nozzle can cause damage to the substructure of the tires that is not visible from the outside. This type of damage only becomes noticeable at a much later stage and can cause the tires to burst. You could thereby lose control of the vehicle and cause an accident, injuring yourself or others.

Do not use round-jet nozzles to clean the tires. Replace damaged tires immediately.

Automatic car wash

If the vehicle is very dirty, prewash it before you put it through an automatic car wash.

↑ WARNING

If a wax preservative is applied after the vehicle is washed, you should remove the wax from the windshield and the wiper blades to prevent smearing. Smears impair the driver's view, and their effect is made worse in conditions where visibility is poor (e.g. glare, mist, darkness, snow). You may therefore fail to recognize dangers, or not recognize them in time, and thereby cause an accident.

- Make sure that the automatic car wash is suitable for the size of the vehicle.

 Before washing the vehicle in an automatic car wash, fold in the exterior mirrors and remove the radio/telephone antenna.

 Otherwise, the exterior mirror, antenna or the vehicle itself could be damaged.

 Make sure that the antenna is installed and that the exterior mirrors are fully folded out again when you leave the automatic car wash.
- Make sure that the side windows are completely closed, that the ventilation/ heating is switched off and that the windshield wiper switch is set to **0**. Otherwise, the rain/light sensor could be activated, triggering unintended wiper

movements. This can cause damage to the vehicle.

After putting the vehicle through an automatic car wash, wipe off the wax from:

- the rear-view camera lens (⊳ page 166)
- the windshield and the wiper blades. This
 prevents smears and reduces wiping noise
 which can be caused by residue on the
 windshield.

Cleaning the engine

Water must not enter intake or ventilation openings. When cleaning with high pressure water or steam cleaners, the spray must not be aimed directly at electrical components or the terminals of electrical lines.

Preserve the engine after the engine has been cleaned. Protect the belt drive system from exposure to the preservative agent.

Radiator

If the radiator fins have become clogged with dirt, blow out the radiator with compressedair, first from the fan side, then from the front. In extreme cases of dirt accumulation, use a steam jet.

I You must avoid damaging the radiator fins. Direct the compressed-air, water or steam jet at right angles to the radiator. On vehicles with an intercooler, oil cooler or condenser air-conditioning system, examine the spaces between the radiators for dirt accumulation. If these are dirty, consult a qualified specialist workshop, e.g. an authorized Sprinter Dealer.

Alloy wheels

Clean the alloy wheels regularly.

Do not use any acidic or alkaline cleaning agents. They can cause corrosion on the

wheel bolts (wheel nuts) or the retainer springs for the wheel-balancing weights.

After driving off-road or on construction sites

⚠ WARNING

Dirt on the vehicle can affect road and operating safety.

It can specifically result in the following dangers:

Stone impact. Stones trapped between the tires can be thrown out while driving. This could injure other road users or damage other vehicles (especially windscreens).

Risk of skidding. Dirt and mud on the tires/ on the road reduce the grip of the tires on the road. This especially applies when the surface is wet. The vehicle could then start to skid.

Risk of injury. Dirt and mud on the steps and entrance can make the steps unsafe. This could cause you to slip off the steps and be injured.

For this reason, you should always clean your vehicle carefully after driving off-road or on construction sites before driving on public roads. Observe the corresponding safety notices in this chapter if you use a power washer or an automatic car wash to clean your vehicle.

- ► Clean the vehicle, paying special attention to the following:
 - · lighting system
 - · windows, side windows and exterior mirrors
 - access steps and entrances
 - · grab handles
 - wheels, tires and wheel housings
 - license plates
- ▶ Remove any trapped foreign objects, e.g. stones.
- ► Check the wheel suspension for damage.

↑ WARNING

Dirt on the brake discs and brake pads/ linings can impair braking performance (up to the point of total failure). This could lead to an accident. Before driving the vehicle on public roads, check the operating safety of the service brake by testing the brakes.

In the event of impaired braking performance, stop the vehicle while paying attention to the traffic conditions and contact a qualified specialist workshop.

After driving in mud, sand, water or in similar conditions:

- check the operating safety of the service
- clean the wheels, chassis and brake system.
- check the wheels, chassis and brake system for damage. Have any damage repaired at a qualified specialist workshop.

Maintenance

General notes

The scope and regularity of the maintenance work primarily depend on the often diverse operating conditions.

The vehicle's Maintenance Booklet describes the extent and frequency of the maintenance work and contains additional information on the New Vehicle Limited Warranty and on the service products.

Specialist knowledge beyond the scope of this Operator's Manual is required when carrying out testing and maintenance work. This work should only be carried out by trained staff.

Maintenance services must be carried out in accordance with the provisions and recommendations in the Maintenance Booklet.

Not doing so could void the warranty claim and lead to refusal of goodwill gestures

after the manufacturer has submitted a damage report.

♠ WARNING

Before carrying out maintenance operations and repairs, you must read the sections referring to maintenance operations and repairs:

- this includes relevant sections of the technical documentation, such as the operating instructions and workshop information.
- you should also familiarize yourself with the legal requirements, such as work safety regulations and accident prevention measures.

You could otherwise fail to recognize dangers and thereby injure yourself or others.

You must secure the vehicle on axle stands of sufficient load bearing capacity if work is being carried out beneath it.

Never use the jack as a substitute. The jack could slip and the vehicle could drop. This could result in serious injury to yourself or others.

The vehicle jack is intended only to raise the vehicle for a short time.

Always have the maintenance work carried out at a qualified specialist workshop.

Observe the notes on parts in the "Technical data" section (⊳ page 284).

Observe measures to protect the environment when working on the vehicle. You must observe the legal requirements when disposing of service products, e.g. engine oil. This also includes all components, e.g. filters, which have come into contact with service products. Any qualified specialist workshop can provide information about this. Dispose of empty containers, cleaning cloths

and care products in an environmentallyresponsible manner. Comply with the instructions for use of the care products. Do not run the engine for longer than necessary when the vehicle is stationary.

Service interval display

General notes

The service interval display shows a due service approximately 1 month in advance. A message is then displayed while the vehicle is in motion or when the ignition is switched on.

1 The service interval display does not provide information about the oil level. The service interval display should therefore not be confused with the 🖼 engine oil level display.

The service due date is displayed in days or miles (kilometers), depending on the total distance driven.

The symbols or letters in the service indicator show the service due.

or A for a minor service

or B for a major service

Service due date indicator

Vehicles with steering wheel buttons

The following messages may be displayed:

- Service A in ... days
- Service A in ... mi (km)
- Service A due now

Vehicles without steering wheel buttons

The following messages may be displayed:

- 🖍 for service A
- for service B

Additionally, you will see the remaining distance in miles (mi) or kilometers (km) or the remaining time in days (d).

Service due date exceeded

An authorized Sprinter Dealer resets the service indicator when the service has been carried out.

Vehicles with steering wheel buttons

If you have missed the service due date, one of the following messages appears in the display:

• Service A overdue by ... days • Service A overdue by ... mi (km)

Additionally, a warning tone sounds.

Vehicles without steering wheel buttons

If you have exceeded the service due date, the or symbol indicates the scope of the service and will flash for 10 seconds after switching on the ignition. You will also see a minus sign before the service due date.

Calling up the service due date

► Turn the key to position 2 in the ignition lock.

The display is activated.

Vehicles with steering wheel buttons

- ▶ Press the 🗊 or 📵 button on the steering wheel repeatedly until you see the standard display (⊳ page 80).
- ▶ Press the 🗘 or 🔽 button on the steering wheel repeatedly until you see the following in the display, for example:
 - Service A in ... days
 - Service A in ... mi (km)

Vehicles without steering wheel buttons

▶ Press the (M) menu button on the instrument cluster repeatedly until the or symbol for the service appears.

Additionally, you will see the remaining distance in miles (mi) or kilometers (km) or the remaining time in days (d).

Hood

Opening the hood



↑ WARNING

Do not pull the release lever while the vehicle is in motion. If you do so, the hood may open up and block your view.

↑ WARNING

There is a risk of injury if the hood is open, even if the engine is not running.

Some engine components can become very hot.

To avoid the risk of burns, only touch those components described in the Operator's Manual and observe the relevant safety notes.

↑ WARNING

The radiator fan between the radiator and the engine can start automatically, even if the key has been removed from the ignition lock. Keep away from the area of rotation of the fan blades. You could otherwise be injured.

The electronic injector control operates at high voltage. For this reason, you must never touch injection system components while:


- the engine is running.
- the engine is being started.
- · the ignition is switched on.

You could otherwise receive an electric shock and be severely or fatally injured.




Hood release lever in the driver's footwell

- ► Pull release handle ①. The hood is released.
- Make sure that the windshield wipers are not folded away from the windshield. You could otherwise damage the windshield wipers or the hood.



► Push hood catch release handle ② upwards.



Swing the hood upwards until support strut3 engages and the hood is supported.

Closing the hood

⚠ WARNING


When closing the hood be careful that nobody becomes trapped.

- ▶ Lift the hood slightly.
- ▶ Press support strut ③ towards the back.
- When you press the support strut back, make sure that you do not press it against the detent position and cause it to bend.
- ² Only on Cargo Van/Passenger Van.

- ► Lower the hood and let it drop shut from a height of approximately 1 ft (30 cm).

 The hood engages audibly. If the hood can be raised slightly, it is not properly engaged.
- ► If the hood is not properly engaged, open it once more and allow it to drop shut from a slightly greater height.
- Do not use your hands to push the hood down. You could damage it otherwise.

Maintenance points under the hood



- Coolant expansion tank cap
 (▷ page 172)
- ② Diesel Exhaust Fluid (DEF) filler neck cap²(⊳ page 143)
- ③ Engine oil filler neck cap (⊳ page 174)
- (4) Brake fluid reservoir cap (⊳ page 173)
- (5) Washer fluid reservoir cap (▷ page 174)

Coolant level

Only add coolant with the vehicle standing on a level surface and with the engine switched off. The coolant temperature must be under 122 $^{\circ}$ F (50 $^{\circ}$ C).



↑ WARNING

When opening the coolant expansion tank there is risk of scalding by hot coolant spraying out. The engine cooling system and the coolant expansion tank are pressurized when the engine is at regular operating temperature. Wear gloves and eye protection.

Only open the coolant expansion tank at a coolant temperature of less than 122 °F (50 °C).

↑ WARNING

Coolant contains glycol and is therefore toxic. Do not swallow the coolant. See a doctor immediately if you swallow coolant.

Make sure that coolant does not come into contact with skin, eyes or clothing. In case of contact with eyes, rinse immediately with plenty of clean water. Clean affected areas of skin and clothing with soap and water immediately. Change any affected clothing immediately.

- ▶ Slowly turn cap (1) counter-clockwise and allow the excess pressure to escape.
- ▶ Turn cap (1) further and remove it.
- ► Add coolant until it is at the **MAX** mark. Observe the correct coolant mixture ratio and the required water quality (⊳ page 163).
- ▶ Replace cap (1) and tighten it until the stop.
- Check the engine cooling and heating system regularly for leaks.

If a large quantity of coolant is lost, have the cause traced and rectified at a qualified specialist workshop.

Clutch system and brake system

↑ WARNING

Brake fluid is hazardous to health. Do not swallow brake fluid. See a doctor immediately if you swallow brake fluid.

Make sure that brake fluid does not come into contact with skin, clothing or eyes. Rinse affected areas with plenty of clean water and consult a doctor if necessary.

Always wear gloves and eye protection when topping up brake fluid.

Store brake fluid only in the original closed container and keep it out of the reach of children. Comply with safety regulations when handling brake fluid.

↑ WARNING

If the boiling point of the brake fluid is too low, vapor pockets may form in the brake system when the brakes are subjected to a heavy load (e.g. on long downhill stretches). This would impair braking efficiency. The vehicle's stopping distance may then be longer. This increases the risk of an accident.

Have the brake fluid renewed every two years.

The brake fluid reservoir is located in the engine compartment.

Check the brake fluid level:

- regularly, e.g. weekly or when refueling
- only with the vehicle standing on a level surface and with the engine switched off
- Brake fluid corrodes paint, plastic and rubber. If paint, plastic or rubber has come into contact with brake fluid, rinse with water immediately.



Brake fluid reservoir cap

The brake fluid level must be between the **MIN** and **MAX** marks.

If the brake fluid does not reach the MIN mark, the vehicle's hydraulic system could be faulty. Do not add brake fluid under any circumstances. This will not rectify the malfunction.

Do not drive any further. Have the system checked immediately at a qualified specialist workshop.

1 There is usually a notice in the engine compartment to remind you when the next brake fluid change is due.

Windshield washer system

⚠ WARNING


Windshield washer concentrate is highly flammable.

Fire, naked flames and smoking are therefore prohibited when you are handling windshield washer concentrate.

Add windshield washer concentrate to the washer fluid all year round.

I Only use washer fluid concentrate which is suitable for plastic lenses. Unsuitable washer fluid concentrate could damage the plastic lenses of the headlamps.

Adapt the mixing ratio to the ambient temperature. If the temperature is above freezing, use Summerwash to prevent smearing. If there is a risk of frost, use Winterwash to prevent the water from freezing on the windshield.



The washer fluid reservoir contains approximately 6.3 US qt (6.0 l).

- ► Mix the washer fluid to the appropriate mixing ratio in a container beforehand.
- ▶ Remove washer fluid reservoir cap ①.
- ► Add washer fluid.
- ▶ Replace cap (1).

Engine oil level

General notes

You will find information about engine oil consumption in the "Driving tips" section (> page 140).

Check the engine oil level on a regular basis, e.g. weekly or each time you refuel.

Checking the engine oil level in the display

Only check the engine oil level when the engine is at operating temperature.

- ▶ Park the vehicle on a level surface.
- ► Switch off the engine.
- ▶ Wait 5 minutes.
- ► Turn the key to position 2 in the ignition lock.

The display is activated.

 If at extremely low temperatures the display does not show the oil level after 5 minutes, repeat the engine oil level check after a further 5 minutes.

If an oil level reading is still not displayed, check the engine oil level with the oil dipstick.

Have the oil level display checked at a qualified specialist workshop.

Vehicles without steering wheel buttons

► Press the (M) menu button on the instrument cluster repeatedly until the display shows the (ﷺ) symbol.

The --: -- display flashes while the oil level is being measured.

The following messages may be displayed:

82	
OK	► Do not add oil.
- 1.0 qts - 1.5 qts - 2.0 qts	 ▶ Add the amount of oil shown (▷ page 176). ▶ Check the engine oil level again after a few minutes.
HI	► Have excess oil removed. The oil level is too high.

Measurement units in the display:

- qts USA only
- 1t. Canada only

Vehicles with steering wheel buttons

► Press the ③ button on the instrument cluster (> page 73).

The following message is displayed for the duration of the measurement process:

Engine oil level Measuring in progress

The following messages may be displayed:

8	
Engine oil level OK	► Do not add oil.

Engine oil Add 1.0 quart Engine oil Add 1.5 quarts Engine oil Add 2.0	 ► Add the amount of oil shown (⊳ page 176). ► Check the engine oil level again after a few minutes.
quarts	
Engine oil level Reduce oil level	► Have excess oil removed. The oil level is too high.
Eng. oil lev. Turn ignition on for level	► Turn the key to position 2 in the ignition lock.
Observe wait. period	 If the engine is at regular operating temperature, carry out a new measurement after approximately 5 minutes. If the engine is not at regular operating temperature, carry out a new measurement after approximately 30 minutes.
Engine oil level Not when eng. running	► When the engine is at regular operating temperature, switch off the engine and wait 5 minutes for the measurement.

Measurement units in the display:

- quart(s) USA only
- liter(s) Canada only


Checking the engine oil level using the dipstick

Vehicles with a red oil dipstick: only check the oil level when the engine is at normal operating temperature.

- ▶ Park the vehicle on a level surface.
- ► Switch off the engine.
- ▶ Wait 5 minutes.

Vehicles with a yellow oil dipstick: only check the oil level when the engine is cold.

▶ Park the vehicle on a level surface.



- ▶ Pull out oil dipstick (1).
- ▶ Wipe oil dipstick ① using a lint-free cloth.
- ► Insert oil dipstick ① back into the guide tube as far as it will go and remove it again.
- ► Check the oil level on oil dipstick ①.

 The oil level must be between MIN mark
 ③ and MAX mark ②.

The difference between the two marks ② and ③ is approximately 2 US qt (2 I).

► Add engine oil if necessary.

Adding engine oil

You will find information about approved engine oils in the "Service products" section (> page 159).

- ► Unscrew cap ④ of the filler neck and remove it.
- The alternator is located below the engine oil filler neck. If engine oil spills onto the alternator, there is a danger of alternator

damage. Be very careful when adding engine oil.

- ► Add the amount of oil required.
- Do not add too much oil. If the oil level is above the MAX mark on the dipstick, too much oil has been added. This can lead to engine damage or catalytic converter damage. Have excess oil siphoned off.

⊕Environmental note


When adding oil, take care not to spill any. If oil enters the soil or waterways, it is harmful to the environment.

▶ Place cap ④ on the filler neck and tighten.

Air filter for the rear-compartment air conditioning

An increased amount of sand or dust may collect in the air filter of the rear-compartment air conditioning when you drive on dusty or sandy roads.

Regularly check the air filters for visible dirt. Clean or replace a dirty filter mat. The dirt may otherwise lead to damage to the air-conditioning system.



Filter magazine, located on the roof in the rear compartment

- ► To remove the filter mat: carefully lift cover (1) from openings (2) and remove.
- ▶ Remove the filter mat from cover (1).
- ➤ To clean the filter mat: wash the filter mat with clear water.

- ► Leave the filter mat to dry.
- 1 The filter mat must not be cleaned or dried in a machine.
- ► To re-insert the filter mat: insert the filter mat in cover (1).
- ► Attach and engage cover (1).

Vehicle assemblies

Check the assemblies regularly for leaks. If fluid is being lost (e.g. there are oil stains where the vehicle is parked), have the cause diagnosed and rectified immediately at a qualified specialist workshop.

⊕Environmental note

When used improperly, service products are harmful to the environment.

Do not allow service products to enter the sewage system, surface waters, ground water or soil.

Replacing the wiper blades

General safety notes

↑ WARNING

If the windshield wipers are set to intermittent wipe or the rain/light sensor is active, the windshield wipers could start moving at any time and injure you or others.

Always remove the key from the ignition lock before replacing the wiper blades.

↑ WARNING

Wiper blades are wear parts. Change the wiper blades every six months, ideally in the spring and fall. Otherwise, the windshield and rear window will not be wiped properly. This may prevent you from observing the traffic conditions, thereby causing an accident.


Never open the hood when a wiper arm is folded out. Otherwise, you can damage the hood.

Do not fold the wiper arm onto the windshield without a wiper blade. You can otherwise damage the windshield.

• Only hold the wiper blade by the wiper arm. You could otherwise damage the wiper rubber.

Removing

- ► Apply the parking brake.
- ► Shift the selector lever to position **P** in vehicles with automatic transmission.
- ▶ Remove the key from the ignition lock.



Front windshield wiper arm with wiper blade

- ► Fold out wiper arm ③ away from the windshield.
- ► Set wiper blade ① at right angles to the wiper arm.
- ▶ Press retainer clips ② together in the direction of the arrows and pivot wiper blade ① away from wiper arm ③.
- ▶ Pull wiper blade ① upwards out of the bracket on wiper arm ③.

Installing

- ► Slide wiper blade ① into the bracket of wiper arm ③.
- ▶ Press wiper blade ① onto wiper arm ③ until retainer clips ② engage audibly.
- ► Fold wiper arm ③ back onto the windshield.

Batteries

Important safety notes



↑ WARNING



Risk of explosion. Explosive oxyhydrogen is produced when batteries are being charged. Only charge batteries in wellventilated areas.



Risk of explosion. Avoid creating sparks. Avoid naked flames and do not smoke in the vicinity of the battery.



Battery acid is caustic. Wear acid-proof protective gloves. If skin or clothes are splashed with acid, neutralize the splashes immediately with soapy water or an acid neutralizer, and then clean the affected areas with water.



Wear eye protection. When mixing water and acid, the liquid can splash into your eyes. Rinse acid splashes to the eyes immediately with clean water and contact a doctor immediately.



Keep children at a safe distance. Children are not able to assess the dangers posed by batteries and acid.



When handling batteries, observe the safety precautions and special protective measures contained in these Operating Instructions.

QEnvironmental note



Batteries contain pollutants. It is against the law to dispose of them with the household garbage. They must be collected separately and recycled to protect the environment.



Dispose of batteries in an environmentally responsible manner. Return discharged batteries at a qualified specialist workshop.

In order for the batteries to achieve their maximum possible service life, they must always be sufficiently charged.

Have the charge status checked for the batteries more frequently if you use the vehicle mainly for short trips or if you leave it parked for an extended period.

If you wish to park your vehicle for an extended period of time, seek advice from a qualified specialist workshop or switch off the electrical system with the battery main switch (⊳ page 90).

Your vehicle may be equipped with two batteries, depending on the equipment version:

- · a starter battery in the battery case in the driver's footwell
- · an additional battery in the engine compartment

Have the batteries removed at a qualified specialist workshop.

Disconnecting the battery

Important safety notes

MARNING

If the positive terminal of the connected battery comes into contact with vehicle parts, there is a risk of a short circuit. This could cause the flammable gas mix to ignite. You and others could be seriously injured.

- Do not place any metal objects or tools on the batteries.
- When disconnecting the batteries, always disconnect the negative terminal clamp before the positive terminal clamp.
- When connecting the batteries, always connect the positive terminal clamp before the negative terminal clamp.
- Do not loosen or disconnect the batteries when the engine is running.
- Switch off the engine and remove the key from the ignition lock before you loosen or disconnect the terminal clamps. You may otherwise destroy electronic components such as the alternator.


Always disconnect the starter battery in the battery case in the driver's footwell first.

Always disconnect the battery in the order described below. Never swap the terminal clamps. You may otherwise damage the vehicle electronics.

Disconnecting the starter battery Removing/installing the floor covering in the driver's footwell

The starter battery is located in the battery case in the driver's footwell.

▶ Switch off all electrical consumers.



- ➤ To remove: loosen screws ③ and take off trim ②.
- ► Remove floor covering (1).
- ► To install: replace floor covering ① in the driver's footwell.

↑ WARNING

Free movement of the pedals must not be impaired. This would otherwise jeopardize the operating and road safety of the vehicle.

Make sure that the floor covering is pushed under the carrier of the accelerator pedal and cannot slide between the carrier and the accelerator pedal when you install it.


This would otherwise prevent you from depressing the accelerator pedal completely, thereby restricting your vehicle's acceleration, e.g. during overtaking.

➤ Slide floor covering ① underneath the carrier for the accelerator pedal and align it at the base of the driver's seat and at the door sill.


Make sure that the floor covering does not obstruct the accelerator pedal.

▶ Put trim ② in place and screw the screws ③ back in.

Removing the battery cover in the driver's footwell




- Remove screws ② and slide cover ① in the direction of the arrow. The screws must protrude beyond the recesses.
- ▶ Remove cover (1) upwards.



Starter battery in the driver's footwell

- ► First loosen and remove the negative terminal clamp so that it is no longer in contact with the terminal.
- ► Remove the cover from the positive terminal.
- ► Loosen the positive terminal clamp and fold it up to the side together with the pre-fuse box.

Disconnecting the additional battery




Additional battery in the engine compartment

- ▶ Switch off all electrical consumers.
- ▶ Remove the key from the ignition lock.
- ▶ Open the hood (> page 171).
- ► First loosen and remove the negative terminal clamp so that it is no longer in contact with the terminal.
- ► Remove the cover from the positive terminal.
- ► Loosen and remove the positive terminal clamp.

Removing the battery


Starter battery



- ▶ Disconnect the battery (▷ page 179).
- ▶ Pull breather hose with connector bracket ② from connection ① on the degassing cover.



► Loosen the bolts holding retainer ③, which prevents the battery from moving around.



- ▶ Pull retainer ③ upwards and slide the battery out of its anchorage in the direction of travel.
- ► Fold the bar upwards and remove the battery from the battery case.

Additional battery in the engine compartment

- ▶ Disconnect the battery (> page 180).
- ► Loosen the bolts holding the retainer that prevents the battery from moving around.
- ► Remove the battery holder and take out the battery.

Charging the battery

↑ WARNING

Only charge the battery in a well-ventilated area. As the battery is being charged, gases can escape and generate minor explosions, which can injure you and others or may cause

damage to the paintwork or acid corrosion on the vehicle.

There is a risk of acid burns during the charging process due to the gases which escape from the battery. Do not, therefore, lean over the battery while it is being recharged.

- Recharge the removed battery. Observe the notes in the operating instructions for your battery charger.
- Follow the above steps in the reverse order to install the battery again.
- Only charge the installed battery with a battery charger that has been tested and approved by the distributor named on the inside of the front cover. This device allows the battery to be charged when it is installed in the vehicle. The vehicle's electronics may otherwise be damaged.
- 1 It is also possible to charge the starter battery using the jump-starting connection point in the engine compartment (> page 253).

Reconnecting the battery

- Always connect the battery in the order described below. Never mix up the terminal clamp disconnection/connection order and never mix up the terminal clamps. You may otherwise damage the vehicle electronics.
- ▶ Switch off all electrical consumers.
- ► Connect the positive terminal clamp.
- ▶ Attach the cover to the positive terminal.
- ► Connect the negative terminal clamp.
- After the battery has been reconnected, you must reset the side windows (▷ page 64).

Battery care

- Please always observe the following notes:
 - dirty battery clamps and battery surfaces cause leak currents, which lead to the batteries discharging. Always keep the battery terminals and battery surfaces clean and dry. Grease the battery terminals, particularly the terminal undersides, with a light coating of acidresistant grease.
 - cleaning agents containing fuel corrode the battery housing. Only clean the battery housing with commercially available cleaning agents.
 - only clean the batteries when the caps are screwed on. Dirt may otherwise enter the battery cells and damage the battery.
 - the breathers in the caps and the cell ventilation tubes must be open.
 Otherwise, gas cannot escape. Unscrew blocked breathers and clean them with a suitable tool such as a piece of wire. If you do not unscrew the caps for cleaning, there is a risk of short circuit.
 - regularly check the battery terminals and the fastening of the negative cable to the chassis to ensure that they are firmly seated.
 - if batteries are not being used, you should charge them once a month.

Useful information	184
Where will I find?	184
Troubleshooting	189
Engine	223
Flat tire	224
Electrical system	235
Batteries for the remote control	251
Opening/closing in an emergency	252
Automatic transmission	253
Jump starting, tow-starting and	
towing away	253

Useful information

This Operator's Manual describes all models as well as standard and optional equipment of your vehicle that were available at the time of going to print. Country-specific variations are possible. Note that your vehicle may not be equipped with all of the described functions. This also applies to systems and functions relevant to safety.

Read the information on qualified specialist workshops: (▷ page 19).

Where will I find ...?

Vehicle tool kit and emergency equipment

The jack and the vehicle tool kit are located in the co-driver's footwell.


MARNING

To reduce the risk of serious or fatal injuries and to avoid damage to the vehicle, observe the following:


 the jack is designed only to raise the vehicle for a short time, e.g. while a wheel is being changed.

It is not designed to enable work to be carried out underneath the vehicle.

- the jack must be placed on a firm, level surface.
- never change a wheel on uphill or downhill gradients.
- never lie under the raised vehicle.
- make sure that no persons are present in the vehicle when the vehicle is raised.
- never start the engine when the vehicle is raised.
- make sure that the distance between the underside of the tires and the ground does not exceed 1.2 in(30 mm).
- if you intend to work under the vehicle, place the vehicle on stands.




- ► To unlock the cover: turn quick-release lock ① counter-clockwise or clockwise 2.
- ▶ Remove the cover.
- ► To lock the cover: press quick-release lock (1) down until it engages.



- ► If necessary, use tool³(3) for the DEF tank fuel filler cap to remove the fixture.
- ▶ Remove vehicle tool kit (6).
- ► Pull up quick-release lever ④ and unhook the retaining strap of jack ⑤.
- ▶ Lift jack (5) upwards out of the holder.
- When stowing away the jack, place it in the holder as shown in the illustration. Make sure that the retaining strap of the jack is hooked in and tensioned.

Warning lamp

The warning lamp is behind the cover in the storage compartment of the driver's door.




- 1 Locked
- 2 Unlocked



- ▶ Unlock quick-release fasteners 2 and fold out the cover.
- ► Take warning lamp ③ out of the retainer.

Warning triangle




Warning triangles at the back of the driver's seat base

- ① Warning triangles
- ► Pull warning triangles ① up and out of the holder.

Wheel chock


Cargo Van/Passenger Van



Wheel chock in the load/passenger compartment

- ▶ Pull restraining cable ① down slightly and then remove it from bracket ②.
- ► Remove the chock.
- When stowing it away, make sure that the chock is secured in the retainer by the restraining cable.

Cab Chassis




Wheel chock on the left-hand side of the vehicle

- ▶ Pull the retainer spring downwards and remove the chock.
- When stowing it away, make sure that the chock is secured in the retainer by the retainer springs.

First-aid kit

The first-aid kit is located in the stowage compartment in the co-driver's door.




- 1 Locked
- 2 Unlocked



- (3) First-aid kit
- ▶ Unlock quick-release fasteners 2 and fold out the cover.
- Check the expiration date of the first-aid kit annually, and replace the contents when necessary.

Fire extinguisher



Fire extinguisher at the front of the base of the codriver's seat

- ▶ Pull shackles ② upwards.
- ► Take fire extinguisher ① out of its holder.
- Please read the instructions on the fire extinguisher carefully and familiarize yourself with its operation.

Tire sealant

The Premium tire sealant is located in the stowage compartment in the right-hand door sill.



- ① Catch spring
- ② Electric air pump
- (3) Premium tire sealant

Spare wheel

General notes


If you are replacing the tires on the vehicle, you may use the spare wheel as a complete wheel provided that:

- the tire is no more than six years old.
- the wheel and tire are of the prescribed design.

The spare wheel is located in a spare wheel carrier under the rear of the vehicle.


I Check the spare wheel regularly to see that it is secure and has the prescribed tire pressure.

Cargo Van/Passenger Van




Bolt covers for the safety catches (example: Cargo Van)

- ▶ Open the tailgate.
- ► Apply a screwdriver to recesses ② and then pry off covers ①.
- ► Using the lug wrench from the vehicle tool kit (> page 184), unscrew the now visible bolts counter-clockwise by approximately 20 turns.



- ► Slightly raise spare wheel carrier ⑤ and unhook left-hand safety catch ③.
- ► Assemble the pump lever for the jack and slide it into sleeve ④ on spare wheel carrier ⑤.
- ▶ Raise spare wheel carrier ⑤ with the pump lever and unhook right-hand safety catch ③.
- ► Slowly lower spare wheel carrier ⑤ down to the ground.
- ► Lift spare wheel carrier ⑤ slightly and pull the pump lever out of sleeve ④.




- Use the pump lever to lift the spare wheel beyond the rear edge of the spare wheel carrier.
- Carefully remove the spare wheel from the bracket.

↑ WARNING

When the spare wheel is removed, the center of gravity changes due to the heavy weight of the wheel. The spare wheel could slip off or tip and cause injury to yourself or others. Pull the spare wheel out carefully. Take care not to trap your fingers when lifting out the spare wheel.

Cab Chassis



- ► Loosen wing nuts ③ manually and then remove them.
- ▶ Loosen nuts ② as far as the thread end.
- ► Slightly raise spare wheel carrier ④ and unhook left-hand safety catch ①.
- ► Assemble the pump lever for the jack and slide it into the sleeve on the right-hand side of spare wheel carrier (4).

- ► Raise spare wheel carrier ④ with the pump lever and unhook right-hand safety catch ①.
- ► Slowly lower spare wheel carrier ④ down to the ground.
- ► Lift spare wheel carrier ④ slightly and pull the pump lever out of the sleeve.



- ▶ Use the pump lever to lift the spare wheel beyond the rear edge of the spare wheel carrier.
- ► Carefully remove the spare wheel from the bracket.

⚠ WARNING

When the spare wheel is removed, the center of gravity changes due to the heavy weight of the wheel. The spare wheel could slip off or tip and cause injury to yourself or others. Pull the spare wheel out carefully. Take care not to trap your fingers when lifting out the spare wheel.

Troubleshooting

Indicator and warning lamps in the instrument cluster

/ WARNING

If service work is not carried out correctly, the operating safety of your vehicle may be affected. This could cause you to lose control of your vehicle and cause an accident. Moreover, the safety systems may no longer be able to protect you or others as they are designed to do.

Always have service work carried out at a qualified specialist workshop.

Problem

The yellow ASR/ ESP® warning lamp flashes while the vehicle is in motion.

Possible causes/consequences and ▶ Solutions

ESP® or ASR is intervening because at least one of the wheels has reached its tire grip limit.

Cruise control is deactivated for the duration of the intervention.

- ▶ Adapt your driving style to suit the road and traffic conditions. Do not use too much throttle.
- ▶ Drive slowly.

The yellow ASR/ ESP® warning lamp is lit while the engine is running.

ASR is deactivated.

► Activate ASR again. Exceptions (> page 51).



and ASR/BAS warning

brake system warning

lamp light up while the

lamps, and the red


engine is running.



EBD has malfunctioned.

The rear wheels could lock sooner than expected when you apply the brakes.

- ▶ On vehicles with steering wheel buttons, also observe the messages in the display (⊳ page 199).
- ▶ Stop the vehicle as soon as possible, paying attention to road and traffic conditions.
- ▶ Do not drive on.
- ► Consult a qualified specialist workshop.



The yellow ESP®, ABS and ASR/BAS warning lamps, and the red brake system warning lamp light up while the engine is running.

Possible causes/consequences and ▶ Solutions



Risk of accident

EBD has been deactivated due to undervoltage.

The battery may not be being charged.

The rear wheels could lock sooner than expected when you apply the brakes.

- ▶ On vehicles with steering wheel buttons, also observe the messages in the display (⊳ page 199).
- ▶ Stop the vehicle as soon as possible, paying attention to road and traffic conditions.
- ▶ Do not drive on.
- ► Consult a qualified specialist workshop.

(①) BRAKE

The red brake system indicator lamp is lit while the engine is running. A warning tone also sounds.

Risk of accident

There is insufficient brake fluid in the expansion tank.

- ▶ On vehicles with steering wheel buttons, also observe the messages in the display (⊳ page 199).
- ▶ Stop the vehicle as soon as possible, paying attention to road and traffic conditions.
- ► Check the brake fluid level in the expansion tank (> page 173).
- ▶ If the brake fluid is below the MIN mark: do not drive on!
- ▶ Do not add brake fluid. This does not solve the problem.
- ► Consult a qualified specialist workshop.

(①) BRAKE

When towing a trailer: the red brake system indicator lamp is lit while the engine is running.

A warning tone also sounds.

The brake force booster in the trailer is faulty.

The driving and braking characteristics of your vehicle could change. There is a risk of the trailer overbraking and of you losing control over the truck/trailer combination.

- ▶ On vehicles with steering wheel buttons, also observe the messages in the display (⊳ page 199).
- ▶ Stop the vehicle as soon as possible, paying attention to road and traffic conditions.
- ▶ Do not drive on.
- ► Consult a qualified specialist workshop.

│ ⑩ │ The yellow ASR / BAS indicator lamp is lit while the engine is running.

Risk of accident

ASR has been deactivated due to a malfunction.

The engine power output may be reduced.

- ▶ Drive on with care.
- ► Consult a qualified specialist workshop as soon as possible.

The yellow ASR/ **BAS** indicator lamp is lit while the engine is running.

Possible causes/consequences and ▶ Solutions

BAS has been deactivated due to a malfunction.

The brake system continues to function normally, but without electronic support.

- ▶ Drive on with care.
- ► Consult a qualified specialist workshop as soon as possible.

The yellow ASR/ **BAS** indicator lamp is lit while the engine is running.

ASR and BAS have been deactivated due to undervoltage.

The battery may not be being charged.

The brake system is still available with the normal braking effect.

- ▶ Drive on with care.
- ▶ Visit a qualified specialist workshop immediately.

The yellow ABS indicator lamp is lit while the engine is running.

ABS has been deactivated due to a malfunction. ESP®, ASR and BAS, as well as cruise control, have also been deactivated as a result.

The brake system continues to function normally, but without electronic support. The wheels could therefore lock, e.g. if the brakes are applied with maximum force.

- ▶ On vehicles with steering wheel buttons, also observe the messages in the display (⊳ page 199).
- ▶ Drive on with care.
- ▶ Visit a qualified specialist workshop immediately.

The yellow ABS indicator lamp is lit while the engine is running.

ABS is temporarily unavailable. Self diagnosis may not have been completed yet.

The brake system is still available with the normal braking effect.

▶ Drive on for a short distance at a speed of more than 13 mph(20 km/h).

ABS is available again if the message goes out.



The yellow ABS indicator lamp is lit while the engine is running.

Possible causes/consequences and ▶ Solutions




Risk of accident

ABS has been deactivated due to undervoltage. The battery may not be being charged.

The brake system continues to function normally, but without electronic support. The wheels could therefore lock, e.g. if the brakes are applied with maximum force.

- ▶ Drive on with care.
- ▶ Visit a qualified specialist workshop immediately.



running.

The exhaust gas aftertreatment is malfunctioning or the current Diesel Exhaust Fluid (DEF) supply is limiting the vehicle range.

▶ Observe the messages in the display (> page 201).



The yellow ESP® indicator lamp is lit while the engine is running.

Risk of accident

ESP® has been deactivated due to a malfunction. As a result, cruise control has also been deactivated.

The vehicle's stability is no longer automatically regulated at an early stage. Engine power output may be reduced.

- ▶ On vehicles with steering wheel buttons, also observe the messages in the display (⊳ page 199).
- Drive on with care.
- ► Consult a qualified specialist workshop as soon as possible.

The yellow ESP® indicator lamp is lit while the engine is

running.

Risk of accident

ESP® has been deactivated due to undervoltage. As a result, cruise control has also been deactivated.

The battery may not be being charged.

The vehicle's stability is no longer automatically regulated at an early stage. Engine power output may be reduced.

- ▶ Drive on with care.
- ► Consult a qualified specialist workshop as soon as possible.

Possible causes/consequences and ▶ Solutions

SRS

The red SRS warning lamp does not go out approximately 4 seconds after switching on the ignition, or it lights up again.

The restraint systems have malfunctioned. The air bags or belt tensioners could be triggered unintentionally or might not be triggered at all in the event of an accident.

- ▶ Drive on with care.
- ▶ Visit a qualified specialist workshop immediately.



The red battery charge indicator lamp lights up while the engine is running.

The battery is not being charged. Possible causes are a defective alternator or a torn poly-V-belt.

- ▶ Stop the vehicle as soon as possible, paying attention to road and traffic conditions.
- ► Check the poly-V-belt.

If it is torn: do not drive on. Consult the nearest qualified specialist workshop.

If it is not damaged: have the vehicle checked at a qualified specialist workshop.

The red battery charge indicator lamp lights up while the engine is running.

The battery is faulty.

- ▶ Stop the vehicle as soon as possible, paying attention to road and traffic conditions.
- ▶ Do not continue driving under any circumstances.
- ► Contact a breakdown service, e.g. a qualified specialist workshop.

The yellow brake pad wear indicator lamp lights up after the engine is started or while the vehicle is in motion.

Risk of accident

The brake pads/linings have reached their wear limit.

▶ Have the brake pads/linings replaced as soon as possible at a qualified specialist workshop.

Possible causes/consequences and ▶ Solutions



The yellow engine oil level warning lamp lights up after the engine is started or while the vehicle is in motion.

The oil level has dropped to the minimum level.

- ► Check the engine oil level and add at the nearest gas station (⊳ page 174).
- ▶ If there is visible oil loss from the engine, have the malfunction rectified immediately at a qualified specialist workshop.



The yellow engine oil level warning lamp flashes, the -2.0 gts (Canada: -2.0 1tr) oil level message, for example, appears in the display and the warning buzzer sounds after the engine is started or while the vehicle is in motion.

There is not enough or no oil in the engine.

There is a danger of engine damage.

- ▶ Stop the vehicle as soon as possible, paying attention to road and traffic conditions.
- ► Check the oil level using the oil dipstick (> page 176). If the engine oil level is correct: have the malfunction rectified immediately at a qualified specialist workshop.

If the engine oil level is too low: have the vehicle towed to a qualified specialist workshop.



The yellow engine oil level warning lamp lights up, the display shows, for instance, the HI oil level display message and the warning buzzer sounds after the engine is started or while the vehicle is in motion.

The engine oil level is above the maximum level.

▶ Check the oil level. If the oil level is too high, have engine oil siphoned off at the nearest gas station (▷ page 176). You could otherwise damage the engine or the catalytic converter.

If the oil level is correct, have the malfunction rectified as soon as possible at a qualified specialist workshop.

Problem Possible causes/consequences and ▶ Solutions The yellow There is a malfunction in the engine oil level display. engine oil level ▶ Have the vehicle checked immediately at a qualified specialist warning lamp workshop. lights up repeatedly while the vehicle is in motion. The yellow The coolant level is too low. coolant level Do not run the engine if the coolant level is too low. The engine warning lamp could overheat and be damaged. lights up while ▶ Stop the vehicle as soon as possible, paying attention to road the engine is and traffic conditions. running. ▶ Switch off the engine and let it cool down. ▶ Add coolant and be sure to observe the warning notes (⊳ page 172). ▶ If you need to add coolant frequently, have the engine cooling system checked at a qualified specialist workshop. The red coolant The coolant temperature is too high. ~.E. warning lamp ▶ Stop the vehicle as soon as possible, paying attention to road lights up while and traffic conditions. the engine is ► Consult a qualified specialist workshop. running. The red coolant The coolant temperature is too high. warning lamp If the vehicle is stopped after being subjected to extreme loads, lights up while the coolant warning lamp may light up when the ignition is the engine is switched on or the engine is restarted. Driving in mountainous running. terrain or driving with a trailer are examples of such loads. ▶ Run the engine for approximately 1 minute at idling speed. ► Consult a qualified specialist workshop if the coolant warning lamp remains lit. The yellow The fuel level has fallen into the reserve range. reserve fuel ▶ Refuel at the nearest gas station (▷ page 142). warning lamp lights up while driving.

check engine

indicator lamp

flashes while the

lights up or

engine is running.

Problem Possible causes/consequences and ▶ Solutions The yellow The fuel filler cap is not closed. reserve fuel ► Close the fuel filler cap. warning lamp You will hear a click when the fuel filler cap is closed fully. lights up while ▶ If the malfunction continues to be displayed, have it rectified the engine is immediately at a qualified specialist workshop. running and the display for the tank content shows 0, even though there is still fuel in the tank. 700 The yellow There is a malfunction in the preglow system. preglow ► Consult a qualified specialist workshop. indicator lamp lights up while the engine is running. The yellow You have used up all fuel in the tank. check engine The engine is running in emergency mode. indicator lamp ▶ Refuel at the nearest gas station (> page 142). lights up or ▶ Bleed the fuel system (> page 224). flashes while the ▶ Start the engine three to four times in succession after refueling. engine is Emergency running mode will be canceled. The vehicle does not running. need to be checked. The yellow The injection control is malfunctioning.

The engine is running in emergency mode.

▶ Have the vehicle checked as soon as possible at a qualified

workshop immediately. Observe legal requirements.

In some states it is legally prescribed that after the check engine indicator lamp lights up you must contact a qualified specialist

Engine power output may be reduced.

specialist workshop.

Possible causes / consequences and ▶ Solutions

The yellow check engine indicator lamp lights up while the engine is running.

The exhaust gas aftertreatment is malfunctioning or an emission relevant malfunction has occurred. This malfunction or defect can damage the exhaust gas aftertreatment.

After the first message and under normal operating conditions, you can drive on for up to approximately 500 miles (800 km). Then a warning tone sequence sounds and the engine can only be started another 16 times.

- ▶ Observe the messages in the display:
 - on vehicles without steering-wheel buttons (▷ page 201)
 - on vehicles with steering-wheel buttons (▷ page 204) and (⊳ page 206).
- ▶ Have the exhaust gas aftertreatment checked as soon as possible at a qualified specialist workshop.

In some states it is legally prescribed that after the check engine indicator lamp lights up you must contact a qualified specialist workshop immediately. Observe legal requirements.

| # | The yellow air filter indicator lamp lights up while the engine is running.

The service limit for the air filter has been reached. The air filter is dirty.

► Have the air filter element replaced as soon as possible at a qualified specialist workshop.

| (!) | The yellow tire pressure monitor warning lamp comes on.

The tire pressure monitor indicates a rapid or severe loss of pressure in at least one tire.

- ▶ Stop the vehicle without making any extreme steering maneuvers or braking suddenly. Pay attention to the traffic conditions while doing so.
- ▶ Check the tires and correct the tire pressure. If a tire continues to lose pressure, it must be replaced. Replace damaged tires immediately.

The warning lamp goes out after you have been driving for a few minutes with the malfunction rectified.

▶ On vehicles with steering wheel buttons, also observe the messages in the display (▷ page 199).

Problem Possible causes/consequences and ▶ Solutions US vehicles The tire pressure monitor has malfunctioned. only: ▶ Have the tire pressure monitor and the wheels checked at a The yellow tire qualified specialist workshop. pressure monitor warning lamp flashes for 60 seconds and then remains lit. The yellow water The water that has collected in the water separator has reached separator the maximum level. indicator lamp ▶ Drain the water separator (▷ page 223). lights up when the ignition is started. The yellow The water level is too low. washer fluid ► Add washer fluid (> page 174). level indicator lamp for the windshield washer/ headlamp cleaning system lights up after the engine is started or while the vehicle is in motion. │ 🚜 │ When the key is The warning lamp is to remind you to fasten your seat belt. turned to ► Fasten seat belt (> page 36). position 2 in the ignition lock, the red seat belt warning lamp lights up for approximately 6 seconds. A warning tone also sounds.

Problem	Possible causes/consequences and ▶ Solutions
When the key is turned to position 2 in the ignition lock, the yellow bulb warning lamp lights up.	A bulb in the exterior lighting (with the exception of the front perimeter lamps and trailer lighting) is defective ⁴ . ▶ Replace defective bulbs as soon as possible (▷ page 235).
The yellow door indicator lamp lights up while you are driving.	The vehicle is moving without all doors or the hood being closed. ▶ Close the doors or hood.
The yellow door indicator lamp lights up.	 The electrical step has retracted or extended only partially or not at all. ▶ Make sure that there is sufficient free space for the electrical step. ▶ Open or close the sliding door again. ▶ If the electrical step still does not extend or retract fully, push the step in manually (▷ page 252). Before stepping out, remind the passengers that the step is missing.

Notes on display messages

Important safety notes



↑ WARNING

No information will be displayed if either the instrument cluster or the display is inoperative.

As a result, you will not be able to see warning and indicator lamps or information about the driving conditions, such as speed or outside temperature. Driving characteristics may be impaired. Adjust your driving style and vehicle speed accordingly.

Contact a qualified specialist workshop immediately.

↑ WARNING

If service work is not carried out correctly, the operating safety of your vehicle may be affected. This could cause you to lose control of your vehicle and cause an accident. Moreover, the safety systems may no longer be able to protect you or others as they are designed to do.

Always have service work carried out at a qualified specialist workshop.

1 If you turn the key to position 2 in the ignition lock, all warning/indicator lamps (except the turn signal indicator lamps) and the display are activated. Please make sure that they are working properly before commencing a journey.

4 The lamp failure indicator may, depending on equipment, be omitted for all lamps with the exception of turn signals.

Vehicles without steering wheel buttons

Warnings, malfunctions or additional information may also be shown in the display. The following tables show all the display messages. For certain display messages, a warning tone or a continuous tone will also sound.

Vehicles with steering wheel buttons

The on-board computer shows warnings, malfunctions or additional information in the display. For certain display messages, a warning tone or a continuous tone will also sound. Display messages of a high priority are shown in red.

Please respond in accordance with the display messages and follow the additional notes in this Operator's Manual.

You can hide low-priority display messages using the [], [], [] or [] button on the steering wheel or the reset button on the instrument cluster.

You cannot hide display messages of the highest priority. These messages will continue to be shown in the display until their cause has been eliminated.

The on-board computer stores certain display messages in the **message memory** (> page 81).

The following tables show all the display messages. They are divided into alphabetically sorted text messages (⊳ page 203) and symbol messages (⊳ page 206).

Display messages

Display messages on vehicles without steering wheel buttons

Display messages	Possible causes/consequences and ▶ Solutions
NO TPMS	The NO message is displayed for 30 seconds. The TPMS message is also displayed after 30 seconds. The tire pressure monitor has malfunctioned. ▶ Have the tire pressure monitor and the wheels checked at a
	qualified specialist workshop.
NO TPMS	The NO message is displayed for 30 seconds. The TPMS message is also displayed after 30 seconds. The tire pressure monitor is not receiving signals from one or more wheels because:
	• a wheel has been replaced with the spare wheel without wheel electronics.
	• the maximum temperature on one of the wheel electronics units has been exceeded.
	the wheel electronics are malfunctioning.
	► Have wheels with suitable wheel electronics units installed at a qualified specialist workshop.
— TPMS	The message — is displayed for 30 seconds. The TPMS message is also displayed after 30 seconds. The pressure is insufficient in one or more tires, or the pressures of the individual tires differ significantly.
	► Check the tire pressure at the next opportunity and correct it if necessary (> page 288).
DEF Chk	In addition, the yellow engine diagnosis indicator lamp and the yellow DEF indicator lamp light up and a warning tone sounds. The DEF reducing agent is contaminated, diluted or is not compliant with ISO 22241.
	After the message appears for the first time, and under normal driving conditions, you can continue driving for approximately 50 miles (80 km). After this, a warning tone sequence sounds and the engine can then only be started another 16 times.
	► Have the DEF tank cleaned and refilled at a qualified specialist workshop as soon as possible.

Display messages	Possible causes/consequences and ▶ Solutions
DEF Chk	In addition, the yellow DEF indicator lamp lights up and a warning tone sounds. The DEF supply has dropped below 1.5 US gal (5.5 I). After the message appears for the first time and under normal driving conditions, the remaining DEF supply will last for approximately 1000 miles (1600 km). After that, the 0.8 US gal (3.0 I) reserve mark is reached. A warning tone sequence sounds and the engine can then only be started another 16 times. ▶ Add DEF supply (▷ page 143). After refilling, the system check takes approximately 20 seconds. The DEF indicator lamp then goes out.
StArtS RExx	In addition, the yellow engine diagnosis indicator lamp and the yellow DEF indicator lamp light up and a warning tone sounds. A warning tone sequence sounds. After the message appears for the first time, the engine can only be started another 16 times. The number of remaining engine starts xx (16 to 0) is shown in the message every time the engine is started. Once the number 0 is shown, the engine can no longer be started. The DEF reducing agent is contaminated, diluted or is not
	compliant with ISO 22241. ▶ Have the DEF tank cleaned and refilled at a qualified specialist workshop as soon as possible.

Display messages	Possible causes/consequences and ▶ Solutions
	The exhaust gas aftertreatment system is defective or an emissions-relevant malfunction has occurred. The defect or malfunction can result in damage to the exhaust gas aftertreatment system. Visit a qualified specialist workshop immediately.
StArtS RExx	In addition, the yellow DEF indicator lamp lights up and a warning tone sequence sounds. The DEF supply has dropped below the 0.8 US gal (3.0 l) reserve mark. After the message appears for the first time, the remaining DEF supply will last for approximately 1000 miles (1600 km) and the engine can then only be started another 16 times. The number of remaining engine starts xx (16 to 0) is shown in the message every time the engine is started. Once the number 0 is shown, the yellow engine diagnosis indicator lamp lights up and the engine can no longer be started. ▶ Add at least 2.0 US gal (7.6l) of DEF (▷ page 143). After refilling, the system check takes approximately 20 seconds. The DEF indicator lamp then goes out.

Text messages on vehicles with steering wheel buttons

Display messages	Possible causes/consequences and ▶ Solutions
ABS Visit workshop	Risk of accident ABS has been deactivated due to a malfunction. ESP®, ASR and BAS, as well as cruise control, have also been deactivated as a result. The brake system is still available with complete brake boosting effect but without ABS. ▶ Drive on carefully. ▶ Visit a qualified specialist workshop immediately.
ABS Unavailable	

Display messages	Possible causes/consequences and ▶ Solutions
ABS Unavailable	Risk of accident ABS has been deactivated due to undervoltage. The battery might not be charging. The brake system is still available with the normal braking effect. ▶ Drive on carefully. ▶ Visit a qualified specialist workshop immediately.
Check Diesel Exhaust Fluid see Operator's Manual	The Diesel Exhaust Fluid (DEF) supply has dropped below 1.5 US gal (5.5 I). After the message appears for the first time and under normal driving conditions, the remaining DEF supply will last for approximately 1000 miles (1600 km). After that, the 0.8 US gal (3.0 I) reserve mark is reached. A warning tone sequence sounds and the engine can then only be started another 16 times. ▶ Add DEF supply (▷ page 143). After refilling, the system check takes approximately 20 seconds. The display message then disappears.
Check Diesel Exhaust Fluid see Operator's Manual	If the yellow engine diagnosis indicator lamp lights up in addition, the DEF reducing agent is contaminated, diluted or not compliant with ISO 22241. After the message appears for the first time, and under normal driving conditions, you can continue driving for approximately 50 miles (80 km). After this, a warning tone sequence sounds and the engine can then only be started another 16 times. Have the DEF tank cleaned and refilled at a qualified specialist workshop as soon as possible.
ESP Visit workshop	Risk of accident ESP® has been deactivated due to a malfunction. This also deactivates cruise control. The vehicle's stability is no longer automatically regulated at an early stage. Engine power output may be reduced. Drive on carefully. Visit a qualified specialist workshop immediately.

Display messages	Possible causes/consequences and ▶ Solutions
ESP Unavailable	ESP® has been deactivated due to undervoltage. This also deactivates cruise control. The battery might not be charging. The vehicle's stability is no longer automatically regulated at an early stage. Engine power output may be reduced. ▶ Drive on carefully. ▶ Visit a qualified specialist workshop as soon as possible.
Tire pres. Adjust pres.	The pressure is insufficient in one or more tires, or the pressures of the individual tires differ significantly. ▶ Check the tire pressure at the next opportunity and correct it if necessary (> page 288).
Tire pres. monitor inoperative	The tire pressure monitor has malfunctioned. ▶ Have the tire pressure monitor and the wheels checked at a qualified specialist workshop.
Tire pres. monitor currently unavailable	The tire pressure monitor function is temporarily unavailable due to radio interference or undervoltage. ▶ As soon as the causes have been remedied, the tire pressure monitor activates itself automatically.
Tire pres. monitor inoperative No wheel sensors	The tire pressure monitor is not receiving signals from one or more wheels because: • a wheel has been replaced with the spare wheel without wheel electronics. • the maximum temperature on one of the wheel electronics units has been exceeded. • the wheel electronics are malfunctioning. ▶ Have wheels with suitable wheel electronics units installed at a qualified specialist workshop.
Cruise control Visit workshop	Cruise control has been deactivated due to a malfunction. • Have cruise control checked at a qualified specialist workshop.
SRS Restraint system Visit workshop	

Symbol messages on vehicles with steering wheel buttons

Display messages	Possible causes/consequences and ▶ Solutions
XX starts remaining	The Diesel Exhaust Fluid (DEF) supply has dropped below the 0.8 US gal (30 I) reserve mark. After the message appears for the first time, the remaining DEF supply will last for approximately 1000 miles (1600 km) and the engine can then only be started another 16 times. The number of remaining engine starts XX (16 to 0) is shown in the message every time the engine is started. Once the number 0 is shown, the yellow engine diagnosis indicator lamp lights up and the engine can no longer be started. ▶ Add at least 2.0 US gal (7.6 I) of DEF (▷ page 143). After refilling, the system check takes approximately 20 seconds. The display message then disappears.
XX starts remaining	In addition, the yellow engine diagnosis indicator lamp lights up. After the message appears for the first time, the engine can only be started another 16 times. The number of remaining engine starts XX (16 to 0) is shown in the message every time the engine is started. Once the number 0 is shown, the engine can no longer be started.
	The DEF reducing agent is contaminated, diluted or is not compliant with ISO 22241. ▶ Have the DEF tank cleaned and refilled at a qualified specialist workshop as soon as possible.
	The exhaust gas aftertreatment system is defective or an emissions-relevant malfunction has occurred. The defect or malfunction can result in damage to the exhaust gas aftertreatment system. ▶ Visit a qualified specialist workshop immediately.
Visit workshop	

Display messages	Possible causes/consequences and ▶ Solutions
Visit workshop	Risk of accident BAS has been deactivated due to a malfunction. The brake system continues to function normally, but without electronic support. ▶ Drive on carefully. ▶ Visit a qualified specialist workshop immediately.
Unavailable	ASR and BAS have been deactivated due to undervoltage. The battery might not be charging. The brake system is still available with the normal braking effect. ▶ Drive on carefully. ▶ Visit a qualified specialist workshop immediately.
Battery / Alternator Visit workshop	The battery is not being charged. This could be caused by a defective alternator or a torn poly-V-belt. ▶ Pull over immediately, paying attention to road and traffic conditions. ▶ Check the poly-V-belt. If it is torn: do not drive any further. Consult the nearest qualified specialist workshop. If it is undamaged: have the vehicle checked as soon as possible at a qualified specialist workshop.
Brake wear Visit workshop	
©BRAKE Brake fluid Visit workshop	 Risk of accident There is insufficient brake fluid in the expansion tank. Pull over immediately, paying attention to road and traffic conditions. Check the brake fluid level in the expansion tank (▷ page 173). If the brake fluid level is below the MIN mark: do not drive any further. Do not add brake fluid. This will not rectify the problem. Consult a qualified specialist workshop.

Display messages Possible causes/consequences and ▶ Solutions (I) BRAKE EBD has been deactivated due to undervoltage. Brake force distribution The battery might not be charging. The rear wheels could lock sooner than expected when you apply the brakes. ▶ Pull over immediately, paying attention to road and traffic conditions. ▶ Do not continue driving. ► Consult a qualified specialist workshop. Risk of accident (I) BRAKE EBD has been deactivated due to undervoltage. Brake force distribution Visit The rear wheels could lock sooner than expected when you apply workshop the brakes. ▶ Pull over immediately, paying attention to road and traffic conditions. ▶ Do not continue driving. ► Consult a qualified specialist workshop. The electrical step has retracted or extended only partially or not Electrical Step ▶ Make sure there is sufficient free space for the electrical step. ▶ Open or close the sliding door again. ▶ If the electrical step still does not extend or retract fully, push the step in manually (⊳ page 252). Make your passengers aware of the missing step before they disembark. A warning tone also sounds. (P) PARK You are driving with the parking brake applied. Parking brake ▶ Release the parking brake (▷ page 114). Release brake Risk of injury The belt system has malfunctioned. Seatbelt sys. Visit workshop ▶ Visit a qualified specialist workshop as soon as possible. The coolant temperature is too high. ▶ Pull over immediately, paying attention to road and traffic Coolant Stop, turn conditions. engine off ► Consult a qualified specialist workshop.

Display messages	Possible causes/consequences and ▶ Solutions
Coolant Stop, turn engine off	The coolant temperature is too high. If the vehicle is stopped after being subjected to extreme loads, the coolant warning lamp may come on when the ignition is switched on or the engine is restarted. Such loads can be, for example, driving in mountainous terrain or driving with a trailer. ▶ Run the engine for approximately one minute at idling speed. ▶ Consult a qualified specialist workshop if the display message continues to be shown.
Check coolant level	The coolant level is too low. Never run the engine if the coolant level is too low. The engine could overheat and be damaged. ▶ Add coolant, observing the warning notes while doing so (▷ page 172). ▶ Have the coolant system checked at a qualified specialist workshop if coolant needs to be added more often than usual.
Hood open	You are already driving at walking pace, even though the hood is not closed. ▶ Close the hood.
Engine oil Add 1.0 quart(Canada: 1.0 liter)	The oil level is too low. ► Check the oil level the next time you refuel (> page 174), and add oil.
Engine oil level Not when eng. running	You want to check the oil level even though the engine is running. ► Switch off the engine. ► Check the oil level (▷ page 174).
Engine oil level Reduce oil level	You have added too much engine oil. There is a risk of damaging the engine or catalytic converter. ▶ Siphon off excess oil until the oil is at the specified level. Observe the legal requirements.

Display messages	Possible causes/consequences and ▶ Solutions
Engine oil level Stop, turn engine off	There is not enough oil, or no oil in the engine. There is a danger of engine damage. ▶ Pull over immediately, paying attention to road and traffic conditions. ▶ Check the oil level with the oil dipstick (▷ page 176). If the oil level is OK: have the malfunction repaired immediately at a qualified specialist workshop. If the oil level is too low: have the vehicle towed to a qualified specialist workshop.
Oil sensor Visit workshop	The measuring system is malfunctioning. ▶ Have the measuring system checked at a qualified specialist workshop.
Please enter PIN:	You have not yet entered your PIN in the mobile phone. ▶ Enter the PIN for the SIM card.
Check tire(s)	The pressure of one or more tires has dropped significantly. If the tire pressure monitor has detected the affected wheel, the wheel position is also displayed. ▶ Pull over immediately, paying attention to road and traffic conditions. ▶ Check the tires. ▶ Repair or change the wheel if necessary (▷ page 224). ▶ Check the tire pressure and correct it if necessary (▷ page 288). The display message disappears automatically after driving for a few minutes with the corrected tire pressure.
Warning Tire defect	One or more tires is losing air rapidly. If the tire pressure monitor has detected the affected wheel, the wheel position is also displayed. ▶ Stop the vehicle without making any sudden steering or braking maneuvers, paying attention to the traffic conditions as you do so. ▶ Repair or change the wheel (▷ page 224).
Check Immobilizer Visit workshop	The key is no longer working. ▶ Visit a qualified specialist workshop.

Display messages	Possible causes/consequences and ▶ Solutions
Reserve fuel Drive to a gas station	The fuel level has fallen into the reserve range. ▶ Refuel at the nearest gas station (▷ page 142).
Doors open	You are already driving at walking pace, even though not all the doors are closed. ▶ Close the doors.
Water in fuel Visit workshop	The water that has collected in the water separator has reached the maximum level. ▶ Drain the water separator (▷ page 223).
Check wash. fluid level	The washer fluid level has dropped to approximately ⅓ of the total reservoir capacity. ▶ Add washer fluid (▷ page 174).
- Low beam left	The left-hand low beam is faulty ⁵ . ► Halogen headlamps: replace the bulb as soon as possible. (▷ page 235) ► Bi-Xenon headlamps: consult a qualified specialist workshop as soon as possible.
- <mark>次</mark> - Low beam right	The right-hand low beam is faulty ⁵ . ► Halogen headlamps: replace the bulb as soon as possible. (> page 235) ► Bi-Xenon headlamps: consult a qualified specialist workshop as soon as possible.
िक् Cornering lt. left	The left-hand cornering light is faulty ⁵ . ▶ Visit a qualified specialist workshop as soon as possible.
िक् Cornering lt. right	The right-hand cornering light is faulty ⁵ . ▶ Visit a qualified specialist workshop as soon as possible.
Lights on automatic. Remove key	The automatic headlamp feature is active: the light switch is in the ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐

⁵ Depending on the equipment, the bulb-failure indicator may not be featured for any lamps other than the turn signals.

Display messages	Possible causes/consequences and ▶ Solutions
可 Turn signal left	The left-hand turn signal is faulty. ▶ Replace the bulb as soon as possible (▷ page 235).
顶: Turn signal right	The right-hand turn signal is faulty. ▶ Replace the bulb as soon as possible (▷ page 235).
_ क् Brake lamp left	The left-hand brake lamp is faulty ⁵ . ▶ Replace the bulb as soon as possible (> page 235).
िक् Brake lamp right	The right brake lamp is faulty ⁵ . ▶ Replace the bulb as soon as possible (> page 235).
high-mounted brake lamp	The high-mounted brake lamp is faulty ⁵ . This display message will only appear if all LEDs have failed. ▶ Visit a qualified specialist workshop as soon as possible.
High beam left	The left-hand high-beam is faulty ⁵ . ▶ Replace the bulb as soon as possible (> page 235).
歌 High beam right	The right-hand high beam is faulty ⁵ . ▶ Replace the bulb as soon as possible (> page 235).
License plate lamp	A license plate lamp is faulty ⁵ . ▶ Replace the bulb as soon as possible (> page 235).
Switch off lights	You have forgotten to switch off the lights when leaving the vehicle. ▶ Turn the light switch to
Fog lamp front left	The left-hand fog lamp is faulty ⁵ . ▶ Replace the bulb as soon as possible (> page 235).
Fog lamp front right	The right-hand fog lamp is faulty ⁵ . ▶ Replace the bulb as soon as possible (> page 235).
歌 Rear fog lamp	The rear fog lamp is faulty ⁵ . ▶ Replace the bulb as soon as possible (> page 235).

⁵ Depending on the equipment, the bulb-failure indicator may not be featured for any lamps other than the turn signals.

Display messages	Possible causes/consequences and ▶ Solutions
歌 Standing lamp front left	The front left parking lamp/standing lamp is faulty ⁵ . ▶ Replace the bulb as soon as possible.
Standing lamp front right	The front right standing lamp/standing lamp is faulty ⁵ . ▶ Replace the bulb as soon as possible (▷ page 235).
्र ्के Reverse lamp	A backup lamp is faulty ⁵ . ▶ Replace the bulb as soon as possible (> page 235).
可 Tail lamp left	The left-hand tail lamp is faulty ⁵ . ▶ Replace the bulb as soon as possible (> page 235).
可 Tail lamp right	The right-hand tail lamp is faulty ⁵ . ▶ Replace the bulb as soon as possible (> page 235).
-Ф: Marker lamp	A perimeter lamp is faulty ⁵ . ▶ Replace the bulb as soon as possible (> page 235).
Additional ind.	An additional turn signal is faulty ⁵ . ▶ Visit a qualified specialist workshop as soon as possible.

Indicator and warning lamps in switches and buttons

⚠ WARNING

If service work is not carried out correctly, the operating safety of your vehicle may be affected. This could cause you to lose control of your vehicle and cause an accident. Moreover, the safety systems may no longer be able to protect you or others as they are designed to do.

Always have service work carried out at a qualified specialist workshop.

⁵ Depending on the equipment, the bulb-failure indicator may not be featured for any lamps other than the turn signals.

Problem	Possible causes/consequences and ▶ Solutions
One or more indicator lamps in the #2 button for the seat heating are flashing.	Insufficient voltage is available because too many consumers are switched on. The seat heating has switched off automatically. ▶ Switch off non-essential consumers, e.g. reading lamps, interior lighting. The seat heating will automatically switch back on as soon as there is sufficient voltage.
The indicator lamp in the windshield heating and/or the windshield heating and/or the rear window defroster are flashing.	Insufficient voltage is available because too many consumers are switched on. The windshield heating and/or rear window defroster have switched off automatically. ► Switch off non-essential consumers, e.g. reading lamps, interior lighting. If sufficient voltage is available again within 30 seconds, the windshield heating and/or rear window defroster automatically switch on again. Otherwise, they remain switched off.

Warning tones



⚠ WARNING

If service work is not carried out correctly, the operating safety of your vehicle may be affected. This could cause you to lose control of your vehicle and cause an accident. Moreover, the safety systems may no longer be able to protect you or others as they are designed to do.

Always have service work carried out at a qualified specialist workshop.

Problem	Possible causes/consequences and ▶ Solutions
The anti-theft alarm system is suddenly triggered.	You opened the vehicle using the key without first deactivating the anti-theft alarm system. ▶ Press the or button on the remote control. or ▶ Insert the key into the ignition lock. The anti-theft alarm system is deactivated.
A warning tone sounds.	A message is shown in the display. ▶ Observe the information on display messages (▷ page 199).
A warning tone sounds.	You are driving with the parking brake applied. ▶ Release the parking brake (▷ page 114).

Problem	Possible causes/consequences and ▶ Solutions
A warning tone sounds.	You have opened the driver's door and forgotten to switch off the lights. ▶ Turn the light switch to □.
A warning tone sounds.	

Engine



⚠ WARNING

If service work is not carried out correctly, the operating safety of your vehicle may be affected. This could cause you to lose control of your vehicle and cause an accident. Moreover, the safety systems may no longer be able to protect you or others as they are designed to do.

Problem	Possible causes/consequences and ▶ Solutions
The engine does not start. The starter motor can be heard.	 There is air in the fuel system. ▶ Turn the key back to position 0 in the ignition lock before attempting to start the engine again. ▶ Start the engine again. Please bear in mind that lengthy and frequent starting attempts will drain the battery. If the engine does not start after several attempts: ▶ Consult a qualified specialist workshop.
The engine does not start. The starter motor can be heard. The reserve fuel warning lamp is lit and the fuel gauge is at 0 .	The fuel tank has been run dry. ▶ Refuel the vehicle. ▶ Bleed the fuel system (▷ page 224).

Problem	Possible causes/consequences and ▶ Solutions
The engine does not start. The starter motor cannot be heard. The yellow check engine indicator lamp and the yellow DEF indicator lamp ⁶ lights up.	The exhaust gas aftertreatment is faulty, an emission-relevant malfunction has occurred or the DEF reserve has been used up. The engine management prevents the engine from starting. This malfunction or malfunction can damage the exhaust gas aftertreatment. ▶ Observe the messages in the display: • on vehicles without steering-wheel buttons (▷ page 201) • on vehicles with steering-wheel buttons (▷ page 204) and (▷ page 206).
The engine does not start. The starter motor cannot be heard.	The battery isolating switch is switched off. ▶ Switch on the power supply (> page 91).
The engine does not start. The starter motor cannot be heard.	The on-board voltage is too low (the battery is too weak or discharged). ▶ Jump-start the vehicle (▷ page 253). If the engine does not start despite attempts to jump-start it: ▶ Consult a qualified specialist workshop.
The engine does not start. The starter motor cannot be heard.	The battery is discharged or faulty. ▶ Check the battery for damage. ▶ Charge the battery (▷ page 181).
The engine does not start. The starter motor cannot be heard.	The starter is faulty. ▶ Have the starter checked at a qualified specialist workshop.

Automatic transmission



⚠ WARNING

If service work is not carried out correctly, the operating safety of your vehicle may be affected. This could cause you to lose control of your vehicle and cause an accident. Moreover, the safety systems may no longer be able to protect you or others as they are designed to do. Always have service work carried out at a qualified specialist workshop.

⁶ Only vehicles without steering-wheel buttons.

Problem	Possible causes/consequences and ▶ Solutions
The transmission malfunctions when shifting gear.	The transmission is losing oil. ▶ Have the transmission checked immediately at a qualified specialist workshop.
The acceleration characteristics have deteriorated noticeably. The transmission does not shift.	The transmission is in emergency mode. It is only possible to shift into second gear or reverse gear R. ➤ Stop the vehicle. ➤ Depress the brake pedal. ➤ Move the selector lever to position P. ➤ Switch off the engine. ➤ Wait at least 10 seconds before restarting the engine. ➤ Depress the brake pedal. ➤ Move the selector lever to position D or R. In position D, the transmission shifts into second gear; in position R, the transmission shifts into reverse gear. ➤ Have the transmission checked immediately at a qualified specialist workshop.

Driving systems



MARNING

If service work is not carried out correctly, the operating safety of your vehicle may be affected. This could cause you to lose control of your vehicle and cause an accident. Moreover, the safety systems may no longer be able to protect you or others as they are designed to do.

Problem

Only the red segments in the PARKTRONIC warning displays are lit.

A warning tone also sounds for approximately two seconds.

PARKTRONIC is deactivated after approximately 20 seconds.

The indicator lamp on the switch lights up and the red segments in the PARKTRONIC warning display go out.

Possible causes/consequences and ▶ Solutions

PARKTRONIC has malfunctioned and has switched itself off.
When you press the switch, the red segments in the
PARKTRONIC warning displays light up again and the warning tone
sounds for approximately two seconds.

► Have PARKTRONIC checked as soon as possible at a qualified specialized workshop.

The PARKTRONIC warning displays implausible distances. For example, all the segments may be lit even though there is no obstacle present.

The PARKTRONIC sensors are dirty or iced up.

- ► Clean the PARKTRONIC sensors (> page 166).
- ► Turn the key to position 2 again in the ignition lock.

The PARKTRONIC warning displays implausible distances. For example, all the segments may be lit even though there is no obstacle present.

An external radio or ultrasonic source may be causing interference.

▶ Check PARKTRONIC functions in a different location.

The PARKTRONIC warning displays implausible distances. For example, all the

For example, all the segments may be lit even though there is no obstacle present.

The license plate or other parts attached near the sensors may not be secured correctly.

► Check the license plate and attachment parts near the sensors for correct seating.

Problem	Possible causes/consequences and ▶ Solutions
The speed cannot be set when cruise control is activated ⁷ .	The display is showing a message of high priority and cannot therefore show a change in speed. ▶ Proceed as instructed by the message in the display. ▶ Deactivate cruise control
White stripes appear on the rear view camera's monitor display or the picture flickers.	The rear view camera is exposed to very bright white light or fluorescent light. ▶ Check whether the rear view camera works at another location.
The rear view camera is functioning incorrectly or not at all.	 The surrounding area is very dark. The outside temperature has changed rapidly or is very high. The camera lens is dirty or obstructed. Check the rear view camera and clean the camera lens if necessary (⊳ page 166).

Auxiliary heating



MARNING

If service work is not carried out correctly, the operating safety of your vehicle may be affected. This could cause you to lose control of your vehicle and cause an accident. Moreover, the safety systems may no longer be able to protect you or others as they are designed to do.

Problem	Possible causes/consequences and ▶ Solutions
The auxiliary heating does not switch on.	The outside temperature is above 39 °F (4 °C). The auxiliary heating switches off automatically.
The auxiliary heating switches off automatically and/or cannot be switched on.	Lack of fuel The fuel tank is less than ¼ full. The auxiliary heating switches off automatically. ▶ Refuel at the nearest gas station. ▶ Then, start the auxiliary heating several times until the fuel lines are full.
The auxiliary heating switches off automatically and/or cannot be switched on.	The undervoltage protection integrated in the control unit switches off the auxiliary heating because the on-board voltage is less than 10 V. ▶ Have the alternator and battery checked.

⁷ Only on vehicles with steering wheel buttons.

Problem	Possible causes/consequences and ▶ Solutions
The auxiliary heating switches off automatically and/or cannot be switched on.	The fuse is blown. ▶ Replace the fuse; see the "Fuse allocation" supplement. ▶ Have the cause of the blown fuse determined at a qualified specialist workshop.
The auxiliary heating switches off automatically and/or cannot be switched on.	 A malfunction has occurred. ▶ Switch the ignition on and off twice. If the auxiliary heating still cannot be switched on, the heating device is faulty. ▶ Have the auxiliary heating checked at a qualified specialist workshop.
The auxiliary heating is overheated.	The coolant level is too low. ▶ Check the coolant level and add more coolant if necessary (> page 172).

Central locking system

⚠ WARNING

If service work is not carried out correctly, the operating safety of your vehicle may be affected. This could cause you to lose control of your vehicle and cause an accident. Moreover, the safety systems may no longer be able to protect you or others as they are designed to do.

Problem	Possible causes/consequences and ▶ Solutions
It is no longer possible to lock the vehicle using the remote control. The turn signals do not flash when the vehicle is locked.	The doors are not closed properly. ▶ Close the doors properly and lock the vehicle again.
It is no longer possible to lock the vehicle using the remote control. The turn signals do not flash when the vehicle is locked.	 The central locking system has malfunctioned. ▶ Lock the vehicle using the folding key (▷ page 56). ▶ Have the central locking system checked as soon as possible at a qualified specialist workshop.

Problem	Possible causes/consequences and ▶ Solutions
It is no longer possible to lock or unlock the vehicle using the remote control.	 The remote control batteries are weak or discharged. ▶ Point the remote control at the driver's door handle at close range and try again. If this does not work: ▶ Lock or unlock the vehicle with the folding key (▷ page 56). ▶ Check the batteries of the remote control (▷ page 55).
It is no longer possible to lock or unlock the vehicle using the remote control.	The remote control is faulty. ► Lock or unlock the vehicle with the folding key (> page 56). ► Have the central locking system checked as soon as possible at a qualified specialist workshop.
You have lost a key.	 ▶ Have the key deactivated at an authorized Sprinter Dealer. ▶ Report the loss immediately to the vehicle insurers. ▶ If necessary, have the mechanical locks replaced. Your qualified specialist workshop will be happy to provide you with a replacement.
The key cannot be turned in the ignition lock.	 The on-board voltage is too low. Switch off all non-essential consumers, such as interior lighting, and try to turn the key again. If this does not work: Check and, if necessary, replace the starter battery. or Jump-start the vehicle. or Consult a qualified specialist workshop.
The key cannot be turned in the ignition lock.	The steering lock has jammed mechanically. ▶ Remove the key and insert it again into the ignition lock. Turn the steering wheel from side to side while doing so.

Headlamps



⚠ WARNING

If service work is not carried out correctly, the operating safety of your vehicle may be affected. This could cause you to lose control of your vehicle and cause an accident. Moreover, the safety systems may no longer be able to protect you or others as they are designed to do.

Problem	Possible causes/consequences and ▶ Solutions
The headlamps are fogged up on the inside.	Air humidity is very high. ▶ Drive with the headlamps switched on. The headlamps are clear after a short distance.
The headlamps are fogged up on the inside.	The headlamp housing is not sealed and moisture has been able to enter. • Have the headlamps checked at a qualified specialist workshop.

Windshield wipers



⚠ WARNING

If service work is not carried out correctly, the operating safety of your vehicle may be affected. This could cause you to lose control of your vehicle and cause an accident. Moreover, the safety systems may no longer be able to protect you or others as they are designed to do. Always have service work carried out at a qualified specialist workshop.

Problem	Possible causes/consequences and ▶ Solutions
The windshield wipers are jammed.	The wiper movement is obstructed, e.g. by leaves or snow. The wiper motor has been deactivated.
	 ▶ Stop the vehicle as soon as possible. For safety reasons, remove the key from the ignition lock. ▶ Remove the cause of the obstruction. ▶ Switch on the windshield wipers again.
The windshield wipers have stopped working completely.	 There is a malfunction in the windshield wiper drive. ▶ Select another wiper speed on the combination switch. ▶ Have the windshield wipers checked at a qualified specialist workshop.

Fuel and fuel tank



MARNING

If service work is not carried out correctly, the operating safety of your vehicle may be affected. This could cause you to lose control of your vehicle and cause an accident. Moreover, the safety systems may no longer be able to protect you or others as they are designed to do. Always have service work carried out at a qualified specialist workshop.

Problem	Possible causes/consequences and ▶ Solutions
The fuel tank has run completely dry.	There is air in the fuel system. ▶ Bleed the fuel system (▷ page 224).
Fuel is leaking from the vehicle.	Risk of explosion The fuel line or the fuel tank is faulty. Leaking fuel creates a risk of fire or explosion. ► Switch off the ignition immediately. ► Remove the key from the ignition lock. ► Do not restart the engine under any circumstances. ► Consult a qualified specialist workshop.

Engine

Draining the fuel filter

If the indicator lamp lights up, you must drain the fuel filter.


When the pi indicator lamp lights up, drain the fuel filter with water separator immediately. Otherwise, the engine may be damaged.

⊕Environmental note

When handling, storing and disposing of diesel and diesel mixtures, please observe the relevant regulations.

To this end, have the fuel filter with water separator drained at a qualified specialist workshop.

The fuel filter with water separator is in the engine compartment.



- Apply the parking brake and move the automatic transmission selector lever to position P.
- ► Switch off the engine and open the hood (> page 171).
- ► Place a suitable receptacle under drain hose (1).
- ► Turn the key to position **2** in the ignition lock.
- ▶ Open drain plug ② immediately until liquid flows out of drain hose ①. Make sure that the liquid flows into the receptacle under drain hose ①.
- ► Close drain plug ② as soon as approximately 0.2 US qt (0.2 I) of liquid has been collected.
- After 30 seconds the electric fuel pump automatically stops the liquid from draining out.
- ► After draining, turn the key back to position **0** in the ignition lock.
- ➤ Dispose of the collected liquid in an environmentally responsible manner, e.g. at a qualified specialist workshop.
- ► Drain the fuel filter again if the indicator lamp remains lit.
- If the lindicator lamp does not go out after draining for the second time, have the

cause checked immediately at a qualified specialist workshop.

Bleeding the fuel system

If you have driven a vehicle until the fuel tank is empty, the engine may not be able to be started immediately after refueling, as there may still be air in the fuel system.

- 1 Too many attempts to start the engine could drain the battery.
- ► After refueling: turn the key to position 2 in the ignition lock for approximately 10
- ► Turn the starter motor for up to 60 seconds without interruption until the engine is running smoothly.

If the engine does not start:

- ► Wait approximately 2 minutes.
- ► Then turn the starter motor for up to 60 seconds again without interruption until the engine is running smoothly.

If this attempt is also unsuccessful, do not attempt to start the engine again. Consult a qualified specialist workshop.

Flat tire

General notes

The vehicle can be equipped either with a spare wheel or with Premium tire sealant. The spare wheel is under the vehicle at the rear (⊳ page 186). The Premium tire sealant is located in the stowage compartment in the right-hand door sill (⊳ page 186).

When you replace a tire, we recommend that you also replace the tire valve.

/ WARNING

Only for vehicles without a tire pressure monitor:

For safety reasons, we recommend that you only use tire valves manufactured by

Schrader. These have been tested for use on your vehicle.

Use only tire valves of type:

- TR 600 for the vehicle types 2500
- TR 418 for the vehicle types 3500

Using other tire inflation valves or valves made by other manufacturers can result in tire pressure loss and thereby impair the operating safety of the vehicle.

You will find safety-relevant information on tires and wheels in the "Tires and wheels" section (⊳ page 260).

Preparing the vehicle

- ▶ Stop the vehicle as far away as possible from traffic and on a level, firm and non-slip surface.
- ▶ Switch on the hazard warning lamps.
- ► Apply the parking brake.
- ▶ Move the selector lever of the automatic transmission to position **P**.
- ► Any passengers should leave the vehicle, ensuring that they are not endangered as they do so.
- ▶ Place the warning triangle or hazard warning lights at a suitable distance. Observe legal requirements.

Using tire sealant

You can use the Premium tire sealant to seal small punctures, particularly those in the tire tread. You can use tire sealant at an outside temperature down to -22 °F (-30 °C).



↑ WARNING

Smoking, fire and naked flames are prohibited when handling tire sealant. Avoid creating sparks. The tire sealant could otherwise ignite and cause a fire.

↑ WARNING

Your safety is at particular risk and the tire sealant is unable to repair a tire in the following situations:

- if there are cuts or punctures in the tire larger than 0.23 inches (6 mm)
- if the rim is damaged
- if you have driven with very low tire pressures or with flat tires

Do not drive any further. Consult a qualified specialist workshop which has the necessary specialist knowledge and tools to carry out the work required.

For this reason, we recommend an authorized Sprinter Dealer. In particular, work relevant to safety or on safety-related systems must be carried out at a qualified specialist workshop.

- ▶ Prepare the vehicle as described (> page 224).
- ▶ Before using Premium tire sealant, you should stop the vehicle so that the damage on the tire is at the bottom.
- ► It is beneficial to the sealing process if you remove the foreign body that has pierced the tire, e.g. a screw or a nail.
- ► Remove the Premium tire sealant, the accompanying "max 50 mph"("max80 km/h") sticker and the tire inflation compressor from the stowage compartment in the right-hand doorway (> page 186).
- ► Affix the sticker within the driver's field of vision.

↑ WARNING

It is essential to comply with the manufacturer's safety notice on the sticker on the electric air pump and the tire sealant bottle. You could otherwise fail to recognize dangers and injure yourself and others.


↑ WARNING

Tire sealant must not come into contact with your skin, eyes or clothing. Do not inhale the fumes.

- If tire sealant comes into contact with your eyes or skin, immediately rinse thoroughly with clean water.
- Immediately change out of clothing that has been in contact with tire sealant.
- If an allergic reaction occurs, consult a doctor immediately.

Keep tire sealant away from children.

- If tire sealant is swallowed, immediately rinse your mouth out thoroughly and drink plenty of water.
- Do not induce vomiting. Consult a doctor immediately.
- The tire sealant is water-soluble. If tire sealant escapes, you can wash it off with water.




Tire inflation compressor

- Switch
- ② Angled connecting piece
- (3) Tire inflation compressor hose
- (4) Flap
- ⑤ Pressure gauge with pressure release screw
- 6 Connector with cable
- ➤ Open flap ④ of the tire inflation compressor.
- ▶ Pull connector (a) and hose (a) with pressure gauge (b) from the housing.



Tire sealant bottle for single tires

- 7 Valve
- Tire sealant bottle with hook, hose and valve core extractor




Tire sealant bottle for twin tires

- (7) Valve
- Tire sealant bottle with hook, hose and angled connecting piece
- ► Shake tire sealant bottle (8).
- ► Unscrew and remove the cap from valve ⑦ of tire sealant bottle ⑧.
- ▶ Push angled connecting piece ② located on hose ③ of the tire inflation compressor as far as it will go onto valve ⑦ of tire sealant bottle ⑧ and fix in place.

The following steps differ depending on the vehicle tires.

- Single tire (> page 226)
- Twin tires, inner wheels (> page 227)
- Twin tires, outer wheels (> page 228)

Single tire



- Hook
- 10 Button
- (11) Lever
- (12) Valve core extractor
- (13) Tire valve
- ▶ Pull knob (10) out of valve core extractor(12) as far as it will go.
- ► Remove the cap from valve ③ on the defective tire.
- ► Hook tire sealant bottle (8) into the upper vent hole in the wheel using hook (9).
- ► Keep pressing lever ①, place valve core extractor ② firmly onto tire valve ③ and then release lever ①.
- ▶ Press knob ⑩ into the valve core of valve ③, turning it gently as you do so, until the shaft of valve core extractor ② engages.
- ► Turn knob ⑩ counter-clockwise until the valve core is unscrewed.
- ▶ Pull knob (10) out of valve core extractor(12) as far as it will go.

This pulls the valve core into the valve core extractor and seals it against the valve core extractor stop.

- ► Make sure that the pressure release screw on pressure gauge (5) is closed.
- ► Connect connector ⑥ to the 12 V socket (12 V, 25 A, 300 W) on the center console (▷ page 134).
- Only use the 12 V socket on the center console to connect the electric air pump.

You could otherwise damage the vehicle's electrics.

- ► Start the engine.
- ▶ Press I on tire inflation compressor switch (1).

The tire inflation compressor is activated. The tire sealant is then pumped into the tire and the tire pressure is increased. Run the tire inflation compressor for at least 10 minutes until tire sealant bottle (3) is completely empty and a minimum tire pressure of 43.5 psi (3.0 bar) has been reached.

Do not run the electric air pump for longer than 20 minutes without a break; otherwise it may overheat.

The air pump can be used again once it has cooled down.

- ▶ Inflate the tire using the tire inflation compressor until the recommended tire pressure (▷ page 288) is reached.
- ► Then, press **0** on tire inflation compressor switch (1).

The tire inflation compressor is deactivated.


- ► Slide knob (10) quickly to the stop in valve core extractor (12).
- ► Turn knob (10) clockwise until the valve core is firmly screwed into tire valve (13).
- 1 Do not pull the valve core extractor off the tire valve while the valve core is unscrewed from the tire valve. The tire sealant could otherwise run out and get on your skin or clothes.

The tire sealant is water-soluble. If tire sealant escapes, you can wash it off with water.


- ► Press lever (1) and pull valve core extractor (12) from tire valve (13).
- ► Screw the valve cap onto tire valve ③.

After filling with tire sealant, (⊳ page 230).

Twin tires, inner wheels



- Valve extension
- (ii) Valve core extractor
- ► Unscrew the valve cap from valve extension (9) of the defective tire.
- Screw valve core extractor (10) clockwise as far as it will go onto valve extension (9).
- ► Screw valve core extractor (10) approximately a further half turn to release the valve extension.
- ► Unscrew the valve extension and the valve core extractor counter-clockwise from the tire valve.
- ► Unscrew the valve extension from the valve core extractor.



- ① Valve core extractor
- 11) Hook
- 12) Button
- (3) Angled connecting piece
- (14) Tire valve

- ➤ Pull knob ② out of valve core extractor ③ as far as it will go.
- ► Screw valve core extractor (10) clockwise onto tire valve (14).
- Press knob ② into the valve core of valve ④, turning it gently as you do so, until the shaft of valve core extractor ⑩ engages.
- ► Turn knob ② counter-clockwise until the valve core is unscrewed.
- ► Pull knob ② out of valve core extractor ③ as far as it will go.
 - This pulls the valve core into the valve core extractor and seals it against the valve core extractor stop.
- ► Hook tire sealant bottle (8) into the upper vent hole in the wheel using hook (11).
- ▶ Push angled connecting piece ③ located on the hose of tire sealant filler bottle ⑧ as far as it will go on to valve core extractor ⑩ and fix it in place.
- ► Make sure that the pressure release screw on pressure gauge ⑤ is closed.
- ► Connect connector ⑥ to the 12 V socket (12 V, 25 A, 300 W) on the center console (▷ page 134).
- Only use the 12 V socket on the center console to connect the electric air pump. You could otherwise damage the vehicle's electrics.
- ▶ Start the engine.
- ▶ Press I on tire inflation compressor switch (1).

The tire inflation compressor is activated. The tire sealant is then pumped into the tire and the tire pressure is increased. Let the tire inflation compressor run for at least 10 minutes until tire sealant bottle (3) is completely empty and a minimum tire pressure of 43.5 psi (3.0 bar) has been reached.

Do not run the electric air pump for longer than 20 minutes without a break; otherwise it may overheat.

- The air pump can be used again once it has cooled down.
- ▶ Inflate the tire using the tire inflation compressor until the recommended tire pressure (▷ page 288) is reached.
- ► Then, press **0** on tire inflation compressor switch (1).
 - The tire inflation compressor is deactivated.
- ➤ Slide knob ② quickly to the stop in valve core extractor (10).
- ► Turn knob ② clockwise until the valve core is firmly screwed into tire valve ④.
- 1 Do not pull the valve core extractor off the tire valve while the valve core is unscrewed from the tire valve. The tire sealant could otherwise run out and get on your skin or clothes.


The tire sealant is water-soluble. If tire sealant escapes, you can wash it off with water.

- ▶ Pull knob ② out of valve core extractor③ as far as it will go.
- ► Unscrew valve core extractor (10) counterclockwise from tire valve (14).
- ► Screw valve extension ⑨ onto tire valve (4) and tighten it.
- Screw the valve cap onto valve extension②.

After filling with tire sealant, (⊳ page 230).

Twin tires, outer wheels


The tire valve is located on the inside of the outer wheel. It should be positioned horizontally on the left side of the wheel for the repair process.




Valve tool with handle and turning piece



- Handle
- 10 Turning piece
- ► Remove the cap from valve (11) on the defective tire.
- ► Guide the valve tool through the gap in the wheel and push it onto tire valve (1).
- ► Hold handle ③ of the valve tool with one hand and unscrew the valve core with the other hand using turning piece ⑩ of the valve tool.
- ► Remove the valve tool through the gap carefully, so that the valve core remains engaged in the valve tool.
- ilf the valve insert is damaged or lost when it is unscrewed, you can use the valve insert of the tire sealant bottle after you have used the tire sealant (▷ page 230).



- (11) Tire valve
- ② Angled connecting piece



- (12) Angled connecting piece
- (13) Hook
- ► Hook tire sealant bottle (8) into the upper vent hole in the wheel using hook (13).
- ▶ Push angled connecting piece ② located on the hose of tire sealant filler bottle ⑧ as far as it will go onto valve ① and fix it in place.
- ► Make sure that the pressure release screw on pressure gauge ⑤ is closed.
- ► Connect connector **(6)** to the 12 V socket (12 V, 25 A, 300 W) on the center console (▷ page 134).
- Only use the 12 V socket on the center console to connect the electric air pump. You could otherwise damage the vehicle's electrics.

- ▶ Start the engine.
- ► Press switch ① on the tire inflation compressor to position I.

The tire inflation compressor is activated. The tire sealant is then pumped into the tire and the tire pressure is increased. Run the tire inflation compressor until tire sealant bottle (8) is completely empty.

- ▶ Press switch ① on the tire inflation compressor to **0** after about 15 seconds.
- ► Loosen angled connecting piece ② from tire valve (1) and remove it.
- ► Screw in the valve core again using the valve tool and remove the valve tool through the opening.
- If the valve insert is damaged or lost when it is unscrewed, you can use the valve insert of the tire sealant bottle after you have used the tire sealant.
- Unscrew the valve insert from the valve of the tire sealant bottle using the valve extractor.
- Do not run the electric air pump for longer than 20 minutes without a break; otherwise it may overheat.

The air pump can be used again once it has cooled down.

- ▶ Push angled connecting piece ② located on tire inflation compressor hose ③ as far as it will go onto valve ⑪ and fix it in place.
- Push I on tire inflation compressor switch ① and inflate the tire to the recommended tire pressure (▷ page 288).

↑ WARNING

If the specified tire pressure is not reached, the tire is too severely damaged. The tire sealant cannot offer assistance with a flat tire in this case. Damaged tires as well as tire pressure that is too low can impair the braking and driving characteristics. There is a risk of an accident.

Do not drive any further. Notify a qualified specialist workshop.

- ► Then, press **0** on tire inflation compressor switch (1).
 - The tire inflation compressor is deactivated.
- 1 The tire sealant is water-soluble. If tire sealant escapes, you can wash it off with water.
- ► Screw the valve cap onto tire valve ①.

After filling with tire sealant, (⊳ page 230).

After filling with tire sealant

- ► Turn the pressure release screw on pressure gauge ⑤ counter-clockwise and bleed the system.
- ► Turn the key to position **0** in the ignition lock
- ▶ Pull the tire inflation compressor connector out of the 12 V socket.
- ► Stow the tire inflation compressor, tire sealant bottle (8) with the valve core extractor and/or valve tool, the warning triangle and hazard warning lights inside the vehicle.
- ▶ Remove angled connecting piece ② from valve ⑦ of tire sealant filler bottle ⑧ and screw the valve cap onto the valve.

↑ WARNING

Do not exceed a maximum speed of 50 mph (80 km/h).

The "max. 50 mph" (80 km/h) sticker must be affixed within the driver's field of vision.

The vehicle's handling characteristics may be affected.

- ▶ Pull away immediately. This enables the tire sealant to distribute inside the tire and create a more effective
- ► Stop driving after about 3 minutes and check the tire pressure, e.g. with the tire inflation compressor.
- You must connect the angled connecting piece on hose (3) of the tire inflation compressor directly to the tire valve on the
- ► Correct the tire pressure accordingly if it does not correspond to the recommended tire pressure (⊳ page 288).
- ► To increase the tire pressure: switch on the tire inflation compressor.
- ▶ To reduce the tire pressure: open the pressure release screw on pressure gauge (5).
- ▶ Drive to the nearest workshop and have the tire repaired or replaced.
- ► Clean the valve core extractor with clean
- ► Have tire sealant bottle (8) replaced as soon as possible at a qualified specialist workshop.

⊕Environmental note

Have the used tire sealant disposed of at a qualified specialist workshop.

Have the tire sealant bottle replaced every 8 years at a qualified specialist workshop.

Changing a wheel in the event of a flat tire

Important safety notes

↑ WARNING

To avoid the risk of serious or even fatal injury and to avoid damage to the vehicle, observe the following:

- the vehicle's jack is intended only to raise the vehicle for a short time when changing
- position the jack on the appropriate jacking point only. Make sure that the jack is correctly positioned under the jacking point before raising the vehicle.
- the jack must be placed on a firm, flat surface.
- before raising the vehicle, you should also secure it against rolling away, e.g. by placing chocks under the wheels. Never release the parking brake while the vehicle is raised.
- make sure that the distance between the underside of the tires and the ground does not exceed 1.2 in (3 cm). The vehicle could otherwise slip off the jack or tip over.
- never place your hands or feet under the raised vehicle.
- never start the engine, and prevent other jolts or vibrations while the vehicle is raised. The vehicle could otherwise slip off the jack.

Preparing to change a wheel

- ▶ Prepare the vehicle as described (⊳ page 224).
- ► Secure the vehicle against rolling away using wheel chocks or similar items. Use the wheel chock (⊳ page 185) to do so.




/ WARNING

The vehicle could slip off the jack on uphill and downhill gradients.

To avoid the risk of causing serious or even fatal injury or damage to the vehicle, do not change wheels on uphill and downhill gradients.

On a level road:

- ▶ Place wheel chocks in front of and behind the wheel which is diagonally opposite the wheel you wish to change.
- ➤ Take the vehicle tool kit and the jack from the footwell on the co-driver's side (> page 184).
- ► Remove the spare wheel from the spare wheel bracket (> page 186).
- ► On wheels with wheel bolts, remove the hub cap.
- ► Assemble the lug wrench extension using the middle rod and the rod with the largest diameter from the three-piece jack pump lever.
- Starting with the middle rod, slide the lug wrench extension as far as it will go onto the lug wrench.
- I Only use the jack pump lever middle rod and the rod with the largest diameter as a lug wrench extension. Only slide the middle rod as far as it will go onto the lug wrench. The rods may otherwise bend and be distorted to such an extent that they can no longer be used as a pump lever for the jack.



► Loosen the wheel nuts or wheel bolts on the wheel to be changed by about one turn using extended lug wrench (1). Do not unscrew the wheel bolts or wheel nuts completely.

Hydraulic jack

► Insert the third rod of the jack pump lever into the lug wrench extension.


The jack pump lever is assembled.



- ► Close pressure release screw ②.
- ► To do this, use the flattened section on pump lever ① to turn pressure release screw ② clockwise to the stop.
- 1 Never turn pressure release screw 2 more than 1 or 2 full turns. Hydraulic fluid could otherwise escape.
- ▶ Insert pump lever ① into the recess on the jack and secure by turning it clockwise.
- Make sure that the jack is positioned directly under the jacking points described below.
- ▶ Raise the vehicle by pumping the lever until the wheel is raised clear of the ground. Make sure that the distance between the underside of the tires and the ground does not exceed 1.2 in (3 mm).

Jacking point at the front axle

The vehicle jacking point is located under the longitudinal member in front of the front axle.



Jacking point at the rear axle

The jacking point is located under the longitudinal member in front of the rear axle.




Jacking point (example: vehicle type 2500)



Jacking point (example: vehicle type 3500)

Do not place the jack on the leaf spring or the differential case.

On the chassis version, the jacking point is located next to the front leaf spring support.



Jacking point (example: Cab Chassis)

Only position the jack on the jacking points intended for this purpose. You could otherwise damage the vehicle.

Removing a wheel

- ▶ Unscrew the wheel bolts or nuts.
- Do not place the wheel bolts or the wheel nuts in sand or dirt. The threads of the wheel bolts and wheel nuts could otherwise be damaged when being tightened.
- ► On front wheels with wheel nuts, remove the wheel nut cover.
- ▶ Remove the wheel.

Mounting a new wheel

↑ WARNING

Oiled or greased wheel bolts/wheel nuts and damaged wheel bolt/wheel nut/wheel hub threads can cause wheel bolts/wheel nuts to come loose. As a result, you could lose a wheel while driving. There is a risk of an accident.

Never oil or grease wheel bolts/wheel nuts. In the event of damage to the threads, contact a qualified specialist workshop immediately. Have the damaged wheel bolts/wheel nuts or hub threads replaced/renewed. Do not continue driving.

We therefore recommend that you use only the wheel bolts and wheel nuts approved for Sprinter vehicles for safety reasons. Other wheel bolts or wheel nuts could work loose.

- ► Clean the wheel and wheel hub contact surfaces.
- ▶ Push the wheel onto the wheel hub and press it on.
- On vehicles equipped with a tire pressure monitor, electronic components are located in the wheel.


Tire-mounting tools should not be used near the valve. This could damage the electronic components.

Only have tires changed at a qualified specialist workshop.

↑ WARNING

Do not tighten the wheel bolts and wheel nuts completely while the vehicle is still jacked up. The vehicle could otherwise tip.

Wheels with centering by wheel bolts:



- (1) Wheel bolt for alloy wheel
- (2) Wheel bolt for steel wheel
- For a steel wheel, only use the short wheel bolts to mount the steel spare wheel. Using other wheel bolts to mount the steel spare wheel could damage the brake system.
- ► Screw in the wheel bolts and tighten them lightly.
- 1 On vehicles with alloy wheels, you will find short wheel bolts suitable for the steel spare wheel in the vehicle tool kit.

For wheels with wheel nuts:


- ➤ On the front wheels, push the wheel nut cover onto the wheel bolts.
- ► Screw in three wheel nuts over the fixing discs of the wheel nut cover.
- ► Turn the wheel so that the wheel bolts are in the center of the holes.
- ▶ Screw on the rest of the wheel nuts.
- ► Slightly tighten all the wheel nuts.

Lowering the vehicle

- Open the pressure release screw on the jack with pump lever slowly by one turn (▷ page 232).
- ► Carefully lower the vehicle.
- ▶ Put the jack aside.
- ▶ Pull the rod with the smallest diameter off the pump lever.

The shortened pump lever serves as a lug wrench extension.

- Starting with the middle rod, slide the lug wrench extension as far as it will go onto the lug wrench.
- Only use the jack pump lever middle rod and the rod with the largest diameter as a lug wrench extension. Only slide the middle rod as far as it will go onto the lug wrench. The rods may otherwise bend and be distorted to such an extent that they can no longer be used as a pump lever for the jack.



Tightening torque pattern

1)-6) Wheel bolts or wheel nuts

- ▶ Tighten all the wheel bolts or wheel nuts evenly in the sequence indicated using the extended lug wrench.
- I The tightening torque is:
 - 177 lb-ft (240 Nm) (steel wheel) / 133 lb-ft (180 Nm) (light-alloy wheel) for wheel bolts
 - 133 lb-ft (180 Nm) for wheel nuts

You can now mount the hub caps on steel wheels with wheel bolts. The installing procedure depends on whether the hub cap acts as a trim that covers the whole wheel, or just covers the center.

- With a hub cap that covers the whole wheel, make sure the opening for the tire valve is positioned over the valve.
- ▶ Push the edge of the hub cap with both hands against the wheel until it clicks into place.
- With a hub cap for the middle of the wheel, make sure that the clamping lugs of the cover are positioned over the wheel bolts.
- ▶ Hit the middle of the hub cap to engage it on the wheel.
- ▶ Push the piston on the hydraulic jack in again and close the pressure release screw.
- ► Secure the faulty wheel in the spare wheel bracket (⊳ page 186).
- ▶ Stow the jack and the vehicle tool kit.
- ► Check the tire pressure and correct if necessary (⊳ page 288).
- ▶ Retighten the wheel bolts or wheel nuts to the specified tightening torque after the vehicle has been driven for 30 miles (50 km).

Retightening wheel nuts/wheel bolts



↑ WARNING

The wheels could work loose if the wheel nuts and bolts are not tightened to the specified tightening torque. There is a risk of accident. Have the tightening torque immediately checked at a qualified specialist workshop after a wheel is changed.

The tightening torque for wheel bolts is:

- 177 lb-ft (240 Nm) for steel wheels
- 133 lb-ft (180 Nm) for alloy wheels

The tightening torque for wheel nuts is 133 lb-ft (180 Nm).

When using newly painted rims, retighten additionally with the specified tightening torque after approximately 600 to 3000 miles (1000 to 5000 km).

Electrical system

Notes on changing bulbs

The bulbs and lamps are an essential component of vehicle safety. Therefore, make sure that each bulb is always working.



/ WARNING

Bulbs and lamps can become very hot. For this reason, allow them to cool down before changing them. Otherwise, you could burn yourself when you touch them.

Keep bulbs out of the reach of children. Otherwise, they could, for example, damage the bulbs and injure themselves.

Never use a bulb which has been dropped. Such a bulb may explode and injure you.

Halogen bulbs are pressurized and could explode when you change them, especially if they are very hot. You should therefore wear eye protection and gloves when you are changing them.

/ DANGER

Xenon bulbs are under high voltage. You could get an electric shock and be seriously or even fatally injured if you touch the electric contacts on Xenon bulbs. Therefore, do not remove the cover on Xenon bulbs.

Do not change the Xenon bulbs yourself, but have them replaced at a qualified specialist workshop.

- To prevent short circuits, switch off the lighting system before changing a bulb.
- Only touch new bulbs with a clean, lint-free cloth or similar item. Do not work with wet or greasy fingers.
- Only use 12 V bulbs of the same type and of the correct wattage.
- Have the headlamp setting checked regularly.
- If the new bulb still does not light up, consult a qualified specialist workshop.
- Have the following LEDs and bulbs changed at a qualified specialist workshop:
- the additional turn signals in the exterior mirrors
- the high-mounted brake lamp
- the Bi-Xenon bulbs
- the fog lamps
- Make sure the bulbs are always securely installed.

Changing bulbs

Front bulbs




N82.10-2747-31

	Lights	Bulb type
1	Additional turn signal lamps in the exterior mirrors	PY 16 W
2	Turn signal lamps	PY 21 W
3	Halogen headlamps: low-beam headlamps	H7 55 W
	Bi-Xenon headlamps: low-beam/high-beam headlamps	D1S-35 W
4	Halogen headlamps: high-beam headlamps	H7 55 W
	Cornering lamps	H7 55 W
(5)	Fog lamps	H11 55 W
6	Parking lamps/ standing lamps	WY 5 W

High-beam headlamps/cornering lamps, low-beam headlamps




- ► Switch off the lights.
- ▶ Open the hood (> page 171).
- ▶ Press catches (1) down.
- ► Lift housing cover ② in the direction of the arrow and remove it.



- (3) Low-beam headlamps
- (4) Halogen low-beam headlamp/Xenon cornering lamp headlamp
- ▶ Disconnect the connector from the bulb.
- ▶ Detach the retainer spring and remove the bulb.
- ► Insert the new bulb so the base fits into the recess of the socket.
- ► Attach the retainer spring and connect the plug to the bulb.
- ► Insert housing cover ② into the lower mounting points.


- ► Fold housing cover ② against the headlamp casing.
- ▶ Push catches ① up until you feel them engage.

Turn signal lamps



- ► Switch off the lights.
- ▶ Open the hood (▷ page 171).
- ► Turn bulb holder ① counterclockwise and remove it.
- ► Turn the bulb counterclockwise by pressing lightly and pull it out of bulb holder ①.
- ▶ Press a new bulb into bulb holder ① and screw in clockwise.
- ► Insert bulb holder ① into the lamp and turn it clockwise.


Parking lamps and standing lamps



- ► Switch off the lights.
- ▶ Open the hood (> page 171).
- ► Turn cap ① counterclockwise and remove it.
- ▶ Pull out the bulb holder with the bulb.


- ▶ Pull the bulb out of the bulb holder.
- ▶ Press a new bulb into the bulb holder.
- ▶ Insert the bulb holder into the reflector.
- ► Replace cap ① and turn it clockwise to the stop.

Rear bulbs



Cargo Van/Crew Van

	Lights	Bulb type
1	High-mounted brake lamp	LED
2	Brake lamps	P 21 W
3	Turn signal lamps	PY 21 W
4	Tail lamps/standing lamps	R 5 W
5	License plate lamp	W 5 W
6	Rear fog lamps (driver's side)	P 21 W
7	Backup lamps	P 21 W




Chassis (example: Cab Chassis)


	Lights	Bulb type
8	Perimeter lamp/ standing lamp	R 5 W
9	Turn signal lamps	PY 21 W
10	Brake lamps	P 21 W
11)	Backup lamps	P 21 W
12	Rear fog lamps (driver's side)	P 21 W
13	Tail lamps	R 5 W
14)	License plate lamp	R 5 W

Changing the rear bulbs (Cargo Van/Crew Van)

Rear light cluster




- ► Switch off the lights.
- ► Undo screws ① and remove the rear lamp lens in the direction of the arrow.
- ▶ Pull the connector off the bulb holder.



- ② Retaining lugs
- ③ Brake lamps
- 4 Standing lamp/tail lamp
- (5) Backup lamps
- (6) Turn signal lamps
- Rear fog lamp
- ► Release retaining lugs ② and take the bulb holder out of the rear lamp cluster.
- ► Turn the bulb counterclockwise by pressing lightly and pull it out of the bulb holder.
- ▶ Press a new bulb into the bulb holder and screw in clockwise.
- ▶ Press the connector into the bulb holder.
- ► Insert the lamp lens.


To do this, clip the bulb holder into the three holes provided at the side and tighten screws ①.

License plate lamp



- ► Switch off the lights.
- ► Insert a screwdriver or similar implement into recess ② and carefully pry off lamp lens ①.
- ▶ Pull the bulb out of the bulb holder.
- ► Insert a new bulb.
- ► Align lamp lens ① and clip it in so that it engages.

Changing the rear bulbs (chassis)




- ① Screws
- ② Lamp lens
- ③ Perimeter lamp/standing lamp
- 4 Turn signal lamps
- ⑤ Brake lamps
- 6 Tail lamps
- (7) Rear fog lamp
- (8) License plate lamp
- Backup lamps
- ► Switch off the lights.
- ▶ Undo screws (1) and remove lamp lens (2).

- ► Turn the bulb counterclockwise by pressing lightly and pull it out of the bulb holder.
- ► Press a new bulb into the bulb holder and screw in clockwise.
- ▶ Position lamp lens ② and tighten screws ① again.

Changing additional bulbs


Perimeter lamp W 5 W (Cab Chassis only)





- ► Switch off the lights.
- ▶ Undo screws (1) and remove the lamp unit.
- ► Turn bulb holder ② and remove it.
- ▶ Pull the bulb out of bulb holder ②.
- ▶ Press a new bulb into bulb holder ②.
- ▶ Screw bulb holder ② into the lamp unit.
- ► Carefully position the lamp housing and tighten screws (1) again.


Entry lamp W 5 W



- ► Switch off the lights.
- Press in the latching spring of lamp housing ① with a suitable implement, e.g. a screwdriver.
- ▶ Pry off lamp housing (1).
- ▶ Disconnect cable connector (3).
- ▶ Pull out bulb holder ②.
- ▶ Pull the bulb out of bulb holder ②.
- ▶ Press a new bulb into bulb holder ②.
- ► Screw bulb holder ② into lamp unit ①.
- ► Connect cable connector ③.

 The connector locking spring must engage.
- ▶ Align and engage lamp housing (1).


Front interior light K 18 W




- ► Switch off the lights.
- Press in the latching spring of lamp housing ① with a suitable implement, e.g. a screwdriver.
- ▶ Pry off lamp housing ①.
- ▶ Pull bulb ② out of the bulb holder.

- ▶ Insert new bulb ②.
- ▶ Align and engage lamp housing (1) on the right-hand side.
- Have the interior lights in the overhead control panel replaced at a qualified specialist workshop. You could otherwise damage the overhead control panel.

Rear interior lights K 15 W



Interior light with switch




Interior light without switch

- ▶ Switch off the lights.
- ▶ Press in the latching spring of lamp housing (1) with a suitable implement, e.g. a screwdriver.
- ▶ Pry off lamp housing (1).
- ► For interior lights without a switch, fold back protective cover (3).
- ▶ Pull bulb (2) out of the bulb holder.
- ▶ Insert new bulb ②.

- ► For interior lights without a switch, fold back protective cover (3).
- ► Align lamp housing ① on the left-hand side and engage.

Rear interior lights W 5 W



- ► Switch off the lights.
- ▶ Undo screws (1) and remove the lamp lens.
- ▶ Push bulb (2) into the bulb holder and remove by turning counterclockwise.
- ▶ Push new bulb ② into the bulb holder and screw in by turning clockwise.
- ▶ Position the lamp lens and tighten screws (1) again.

Fuses and relays

General safety notes

↑ WARNING


Only use fuses approved for Sprinter with the fuse rating specified for the respective systems. Do not repair or bypass defective fuses. A fire may otherwise result through overload. Have the problem assessed and resolved only at a qualified specialist workshop, e.g. an authorized Sprinter Dealer. Blown fuses must be replaced with fuses of the same rating and which have the amperage specified in the following overview. Fuses of the same rating can be recognized by the color and amperage. A qualified specialist workshop will be happy to advise you.

The fuses and relays for the standard equipment are located in the main fuse box in the footwell on the left-hand side of the vehicle.

Additional fuses and relays for the items of optional equipment are located in the fuse box under the left front seat and in its seat base. Always have the fuses in the seat base replaced at a qualified specialist workshop.

Switch off the ignition and the electrical consumers before changing a fuse.

Main fuse box



Fuse box in the footwell on the left-hand side of the vehicle.


- ► To open: unlock quick-release fastener

 1 and remove the cover.
- ➤ To close: attach the bottom edge of the cover and fold upwards.

The cover must engage.

► Lock quick-release fastener 2.

Arrangement



Fuses Fuse-relay box (SRB)

No.	Consumer	Fuse rating
1	Horn	15 A
2	ESTL (electric steering lock) ignition lock	25 A
3	Terminal 30 Z, vehicles with a gasoline engine/ignition lock/instrument cluster	10 A
4	Light switch/switch unit on center console	5 A
5	Windshield wipers	30 A
6	Fuel pump	15 A
7	MRM (jacket tube module)	5 A
8	Terminal 87 (2)	20 A
9	Terminal 87 (3), vehicles with a gasoline/diesel engine	20/25 A

No.	Consumer	Fuse rating
10	Terminal 87 (4)	10 A
11	Terminal 15 R vehicle	15 A
12	Air bag control unit	10 A
13	Cigarette lighter/glove box lamp/radio/loading tailgate/personal navigation device (PND) power socket	15 A
14	Diagnostics connection/light switch/instrument cluster	5 A
15	Headlamp range control/front-compartment heating	5 A
16	Terminal 87 (1)	10 A
17	Air bag control unit	10 A
18	Terminal 15 vehicle, brake light switch	7.5 A

No.	Consumer	Fuse rating
19	Interior lighting	7.5 A
20	Co-driver power window switch/terminal 30/2 SAM (signal acquisition and actuation module)	25 A
21	Engine control unit	5 A
22	Brake system (ABS)	5 A
23	Starter motor	20 A
24	Diesel engine, engine components/control unit, vehicles with a natural gas engine NGT ⁸	10 A
25	12 V socket in the center console	25 A


Fuse block F55/1

No.	Consumer	Fuse rating
1	Driver's door control unit	25 A
2	Diagnostics connection	10 A
3	Brake system (valves)	25 A
4	Brake system (delivery pump)	40 A
5	Terminal 87 (2a), engine	7.5/10 A
6	Terminal 87 (3a), engine	7.5/10 A
7	Headlamp cleaning system	30 A
8	Anti-theft alarm system (ATA)/beacon/beacon with siren	15 A
9	Additional turn signal module	10 A

Fuse block F55/2

	,	
No.	Consumer	Fuse rating
10	Radio	15/20 A
11	Mobile phone/ tachograph/additional recorder	7.5 A
12	Blower, front/auxiliary heating blower setting 1	30 A
13	Auxiliary heating system digital timer, radio receiver/DIN slot basic wiring/FleetBoard/antitheft protection with vehicle tracking	7.5 A
14	Seat heating	30 A
15	Brake system control unit	5 A
16	Heating, rear- compartment heating/ front-compartment air conditioning/CD player	10 A
17	Motion detector/ passenger compartment illumination (reading lamps or LED light strip)/ comfort illumination/ reading and cargo compartment lamp (courier vehicles)	7.5/10 A
18	Rear-compartment air conditioning	7.5 A


⁸ Natural Gas Technology



Pre-fuse box in the battery compartment in the footwell on the left-hand side of the vehicle F59


No.	Consumer	Fuse rating
1	Preglow relay/ secondary air pump	80/40 A
2	Air-conditioning system cooling fan, cab	60/40 A
3	SAM (signal acquisition and actuation module)/ fuse and relay box	80 A
4	Auxiliary battery/ retarder	150 A
5	Terminal 30 fuse box, SAM (signal acquisition and actuation module)/ fuse and relay box	150 A
6	Connection point on the base of the seat	Bridge
7	Passenger compartment air conditioning/PTC heater booster	80/150A

Relays in the main fuse box



No.	Relays	Description
R1	K40/9	Horn relay
R2	K40/9	Windshield wiper setting 1/2 relay
R3	K40/9	Fuel pump relay
R4	K40/9	Windshield wipers on/off relay
R5	K40/9	Starter relay, terminal 50
R6	K40/9	Relay, terminal 15 R (normally open contact)
R7	K40/9	Engine control unit relay, terminal 87
R8	K40/9	Relay, terminal 15 (reinforced relay)

Fuse box under the left front seat




Fuse box on the outside of the seat base

- ► **To open:** move the front seat to the highest position.
- ▶ Press both latching springs ① down and remove the cover.
- ► To close: install the bottom edge of the cover and fold upwards.

The cover must engage.

Arrangement



Fuses Fuse block F55/3

	•	
No.	Consumer	Fuse rating
1	Mirror setting/rear window defroster	5 A
2	Rear window wiper	30 A
3	Auxiliary heating, digital timer/rear view camera/neutral gate switch, starting-off aid and all-wheel drive/engine run-on/DIN slot basic wiring (roof)/FleetBoard/anti-theft protection with vehicle tracking/emergency hammer lighting in passenger compartment	5 A
4	Tachograph/ADR working speed governor/power take- off/AAG (trailer control unit)	7.5 A

No.	Consumer	Fuse rating
5	ECO Start/EGS control unit (electronic gearbox control)	5/10 A
6	Terminal 15 all-wheel drive, control unit	5 A
7	ESM (electronic selector module)	10 A
8	Passenger compartment emergency lighting/loading tailgate/tipper	5/10 A
9	Passenger compartment air conditioning, compressor clutch	7.5 A

Fuse block F55/4

No.	Consumer	Fuse rating
10	Terminal 30, body/ equipment manufacturer	25 A
11	Terminal 15, body/ equipment manufacturer	15 A
12	D+, body/equipment manufacturer	10 A
13	Fuel pump (FSCM)	20 A
14	Trailer power socket	20 A
15	Trailer recognition unit	25 A
16	Tire pressure monitor/ PARKTRONIC	7.5 A
17	PSM control unit	25 A
18	PSM control unit	25 A

Fuse block F55/5

No.	Consumer	Fuse rating
19	Overhead control panel	5 A
20	License plate lamp (courier vehicles)/ perimeter lamp/ entrance lighting (bus)	7.5 A
21	Terminal 30 body electrics (courier vehicles)/rear window defroster 1	15/30 A
22	Electrical step, co- driver's door (bus)/rear window defroster 2/ vehicle socket (courier vehicles)	10/15/ 20 A

⁸ Natural Gas Technology

No.	Consumer	Fuse rating
23	Non-MB body electrics/ 12V socket rear left, cargo compartment/ passenger compartment	10/15 A
24	12 V socket under the base of driver's seat	15 A
25	12 V socket rear right, cargo compartment/ passenger compartment	15 A
26	Hot-water auxiliary heating	25 A
27	Hot-air auxiliary heating/heater booster system	20/25 A

Fuse block F55/6

No.	Consumer	Fuse rating	
28	Start using additional battery	20 A	
29	Terminal 87 (7) gas system, vehicles with a natural gas engine (NGT) ⁸ /SCR ⁹ control module, vehicles with exhaust gas aftertreatment/terminal 30 all-wheel drive, control module	7.5/10/ 30 A	
30	Auxiliary heat exchanger fan/brake booster	15/30 A	
31	Sliding door closing assistance, left/electric sliding door, left/rear compartment heating blower	15/30 A	

⁹ Selective Catalytic Reduction

No.	Consumer	Fuse rating	
32	SCR ⁹ relay supply, vehicles with exhaust gas aftertreatment/ KEYLESS ENTRY	5/10 A	
33	Sliding door closing assistance, right/ electric sliding door, right/air suspension compressor	15/30 A	
34	SCR ⁹ heater 1 DEF supply reservoir, vehicles with exhaust gas aftertreatment	15 A	
35	SCR ⁹ heater 2 hose, vehicles with exhaust gas aftertreatment	15 A	
36	SCR ⁹ heater 3 delivery pump, vehicles with exhaust gas aftertreatment	10 A	

Fuse block F55/7

No.	Consumer	Fuse rating
37	Unassigned	_
38	Unassigned	
39	Body electrics (courier vehicles)/passenger compartment air conditioning/roof ventilator/siren	7.5/15 A
40	Unassigned	_
41	Unassigned	_
42	Rear-compartment air conditioning	30 A

⁹ Selective Catalytic Reduction

No.	Consumer	Fuse rating
43	Electrical step, sliding door, right	10 A
44	Electrical step, sliding door, left	10 A
45	Electrical step, control system	5 A


Fuses in the seat base of the left front seat

The following additional fuses are located in the seat base:

- for the passenger compartment or rear compartment air conditioning
- for the windshield heating
- for other vehicle components, such as power steering pumps, additional batteries and PTC heater boosters
- from the body manufacturers for retarders, loading tailgates and tippers

Always have the fuses in the seat base replaced at a qualified specialist workshop.

Relays in the seat base of the left front seat



No.	Relays	Description
R1	Unassigned	_
R2	K41	Load relief relay, terminal 15
R3	K41/3	Load relief relay, terminal 15 (2)
R4	K64 K110 K41/5	Air injection/SAP relay SCR ¹⁰ relay, vehicles with exhaust gas aftertreatment Starter relay, terminal 15
R5	K13/5	Rear window defroster relay 1
R6	K13/6	Rear window defroster relay 2
R7	K41/2	Load relief relay, terminal 15 R
R8	K6/1	Starter relay, additional battery
R9	K31/7	Windshield heating relay1
R10	K23/1	Blower relay, front, blower setting 1
R11	K117/3	Electrical step relay 1, sliding door, left
R12	K117/4	Electrical step relay 2, sliding door, left
R13	Unassigned	_
R14	Unassigned	-
R15	K88	Body manufacturer relay, terminal 15

¹⁰ Selective Catalytic Reduction

No.	Relays	Description
R16	K88/1	Body manufacturer relay, terminal 61 (D+)
R17	K95 K93	Loading tailgate relay Comfort illumination relay
R18	K2	Headlamp cleaning system relay
R19	K51/10	Beacon with siren relay
R20	K39/3	ATA (anti-theft alarm system) relay, horn
R21	K108 K116 K23/2	Perimeter lamp relay License plate lamp relay (courier vehicles) Blower relay, hot-air auxiliary heating, blower setting 1
R22	K23/3	Blower relay, hot-air auxiliary heating, blower setting 2
R23	K39/1 K124/1	Siren relay Relay, terminal 61 (D+), anti-theft protection with vehicle tracking
R24	K117/1	Electrical step relay 1, sliding door, right
R25	K117/2	Electrical step relay 2, sliding door, right
R26	K121 K124	Reverse warning device off relay Anti-theft protection with vehicle tracking relay

Other relays

No.	Relays	Description
-	K57	Battery cutoff relay, LHD
_	K57/4	Battery cutoff relay, RHD
_	К9	Auxiliary fan (at the radiator) relay
-	K9/5	Auxiliary fan (rear compartment air conditioning) relay

Batteries for the remote control

Notes on changing the batteries



MARNING

Batteries contain toxic substances.

Swallowing batteries can lead to serious health issues or death.

Keep batteries out of the reach of children. Seek medical attention immediately if a battery is swallowed.

⊕Environmental note




Batteries contain toxic substances. It is illegal to dispose of them with household waste. Batteries must be collected separately and be recycled in an environmentally responsible manner.




Dispose of old batteries in an environmentally responsible manner. Take discharged batteries to a qualified specialist workshop or to a collection point for used batteries.

Remote control with an integrated folding key

You need two CR 2025 3 V cell batteries. When changing the batteries, do not press any of the buttons on the remote control.



- 1 Battery cover
- ② Key release button
- ▶ Press key release button ②. The key folds out.
- ▶ Remove battery cover ① in the direction of the arrow.



- ▶ Remove old batteries from the battery tray.
- 1 When inserting the batteries, make sure that they are clean and lint-free.
- ► Insert the new batteries with the positive terminal facing upwards. Use a lint-free cloth to do so.
- ► Position battery cover ① and press down until it engages noticeably.
- ► Check the function of all the remote control buttons on the vehicle.

Opening/closing in an emergency

Electrical step

↑ WARNING


The step may cause injury to other road users if left extended when driving.

If the electrical step does not retract automatically, you will have to push it in and lock it into place manually before continuing your journey.


■ Driving with the step extended may result in it being damaged.

If the electrical step does not retract automatically, you will have to push it in and lock it into place manually before continuing your journey.


If a malfunction occurs, you can push the electrical step in and secure it manually for the onward journey.



- ▶ Pull R-clips ② on both rods ① on the underside of the step out of their respective pins.
- ► Remove washers ③ and detach both rods ①.



- ▶ Fold rods (1) into the housing in the step.
- ▶ Push the step into its housing.



► Insert R-clips ② into the step as far as they will go through the holes on both sides of the housing.


The step is secured in its housing.

Automatic transmission

In the event of a malfunction, it is possible to manually release the selector lever from the lock in parking position **P**, e.g. to have the vehicle towed away.



► Remove cover (1).



- ► Slide implement ② as far as it will go into the opening.
- ▶ Push the implement in and simultaneously move the selector lever out of position **P**.
- ► Remove implement ②.
- ► Refit cover (1).

Jump starting, tow-starting and towing away

Jump-starting

Important safety notes

If the vehicle battery is discharged, the engine can be started from another vehicle using jumper cables. For this purpose, the vehicle has a jump-starting connection point in the engine compartment.

The additional battery in the engine compartment is not suitable for jump-starting operations. If your vehicle requires jump-starting, or if you use it to jump-start another vehicle, use the jump-starting connection point in the engine compartment.

↑ WARNING

Explosive oxyhydrogen is produced when batteries are being charged. When working on batteries, always make sure that the work area is well ventilated.

Keep flames and naked lights away from the battery, and do not smoke.

Prevent the creation of sparks (e.g. when disconnecting the batteries). Sparks can ignite the oxyhydrogen gas and cause the batteries to explode. You and others could be seriously injured.

↑ WARNING

Due to the gases which escape from batteries, there is a risk of acid burns when jump-starting a vehicle. Do not lean over the battery while the engine is being jump-started.

Avoid repeated and lengthy starting attempts.

Do not use a rapid-charging device to start the engine.


Vehicle preparation

When jump-starting, observe the following points:


- jump-starting must only be performed when the engine and catalytic converter are cold.
- do not start the engine if the battery is frozen. Let the battery thaw first.
- when jump-starting, use only batteries with the same nominal voltage and a similar capacity.
- only use jumper cables protected against polarity reversal, with adequate cross-

- section and with insulated battery terminal clamps.
- ► Make sure that the two vehicles do not touch.
- ► Apply the parking brake.
- ► Move the selector lever of the automatic transmission to position **P**.
- ▶ Switch off all electrical consumers.
- ► Switch on the battery main switch (> page 90).
- ▶ Remove the key from the ignition lock.
- ▶ Open the hood (> page 171).

Connecting the jumper cable



Jump-starting connection point on the left of the air filter



Connection plan

- ► Remove the cover from positive terminal (2) of the donor battery.
- ► First connect one of the positive terminal clamps of the jumper cable to positive terminal ② of the donor battery.

- ▶ Then, use other positive terminal clamp ① of the jumper cable to turn the red protective cap of the jump-starting connection point clockwise and slide it back and connect positive terminal clamp ① to positive terminal ③ of the jump-starting connection point.
- 1 Do not connect the jumper cable to the additional battery in the engine compartment. The additional battery is not suitable for jump-starting operations.
- ► Run the donor vehicle's engine at idling speed.
- First, connect the negative terminal clamps of the jumper cable to negative terminal
 3 of the donor battery and then to ground contact (4) of your own vehicle.
- ► Start the engine.
- 1 You can now switch electrical consumers back on but do not switch on the lights.
- ► First, disconnect the negative terminal clamps of the jumper cable from ground contact ④ and then from negative terminal ③ of the donor battery.
- ► First disconnect the positive terminal clamps of the jumper cable from positive terminal ⑤ of the jump-starting connection point and then from positive terminal ② of the donor battery.
 - The red protective cap springs back to its initial position when positive terminal clamp ① is removed from the jump-starting connection point.
- ▶ Place the cover on positive terminal ② of the donor battery.
- 1 You can now switch the lights on.
- ► Have the battery checked at a qualified specialist workshop.

Tow-starting

You cannot tow-start your vehicle, as it has an automatic transmission.

Towing

General notes

MARNING

Tow the vehicle using a rigid towing bar if:

- the engine is not running.
- the voltage supply or the vehicle's electrical system is malfunctioning.

There is no power assistance for the steering and braking when the engine is not running. You must then use significantly greater force to steer the vehicle and brake.

Do not tow the vehicle if the key cannot be turned in the ignition lock. The steering is then locked and it will not be possible to steer the vehicle.

When towing another vehicle, its weight should not be greater than the permissible gross weight of your vehicle.

Observe national regulations when towing. It is preferable to have the vehicle transported on a transporter or trailer instead of towing it. When towing the vehicle, use a rigid towing bar.


- Only secure the tow cable or tow bar to the towing eyes. You could otherwise damage the vehicle.
- Before towing, deactivate the automatic locking while driving function (▷ page 57). You could otherwise lock yourself out of the vehicle when pushing or towing away the vehicle.
- Do not exceed a towing speed of 31 mph (50 km/h). You could otherwise damage the transmission.
- ► Turn the key to position 2 in the ignition lock
- ► For a towing distance of up to 30 miles (50 km), move the selector lever to position **N**.

WARNING

A propeller shaft could fall off as it is being removed and injure you. Secure the propeller shaft before removal to prevent it from falling down, e.g. with the aid of another person or by tying the propeller shaft up.

- ► For a towing distance of longer than 30 miles (50 km), remove the propeller shafts to the driven axles.
- Always use new bolts when installing the propeller shafts.

Front towing eye



The fixture for the front towing eye is located in the bumper.

► To install the towing eye: press on cover (1) in the direction of the arrow and remove cover (1).

You will see the fixture for the towing eye.

- ► Take the towing eye and lug wrench from the vehicle tool kit (⊳ page 184).
- ▶ Screw in the towing eye clockwise to the stop.
- ▶ Insert the lug wrench handle into the towing eye and tighten.
- ▶ To remove the towing eye: take the lug wrench from the vehicle tool kit.
- ▶ Insert the lug wrench handle into the towing eye and turn the wrench counterclockwise.
- ▶ Unscrew the towing eye.

- ▶ Insert cover (1) with the lug at the bottom and press it in at the top until it engages.
- ▶ Place the towing eye and lug wrench back in the vehicle tool kit.

Rear towing eye

If your vehicle is equipped with a rear towing eye, this is located at the rear of the chassis on the right-hand side when viewed in the direction of travel.

1 If your vehicle is equipped with a trailer tow hitch, use this as a towing device.

Recovering a vehicle that is stuck

If the drive wheels are dug in to loose or muddy ground, tow the vehicle with extreme care, particularly if it is laden.

When recovering the vehicle, do not use jerky movements and do not pull it at an angle. The chassis may otherwise be damaged.

Do not tow the vehicle out with a trailer attached.

Tow the vehicle out backwards in the tracks already made, if possible.

Towing the vehicle in the event of particular malfunctions

With transmission damage

↑ WARNING

A propeller shaft could fall off as it is being removed and injure you. Secure the propeller shaft before removal to prevent it from falling down, e.g. with the aid of another person or by tying the propeller shaft up.

- ► Always remove the propeller shafts leading to the driven axles.
- Always use new bolts when installing the propeller shafts.

With front axle damage

- ► Turn the key to position 1 in the ignition lock.
- ► Raise the front axle.

↑ WARNING

A propeller shaft could fall off as it is being removed and injure you. Secure the propeller shaft before removal to prevent it from falling down, e.g. with the aid of another person or by tying the propeller shaft up.

■ The ignition must be switched off if the vehicle is being towed with the front or rear axle raised. Otherwise, ESP® may intervene and damage the brake system.

With rear axle damage

- ► Turn the key to position 1 in the ignition lock.
- ▶ Raise the rear axle.

Malfunction in the electrical system

If the battery is defective, the automatic transmission will be locked in position \mathbf{P} . To shift the automatic transmission to position \mathbf{N} , you must provide power to the vehicle's electrical system in the same way as jump-starting (\triangleright page 253).

Have the vehicle transported on a transporter or trailer.

Transporting the vehicle

The towing eye can be used to pull the vehicle onto a special transporter or trailer for transportation.

- Only lash the vehicle down by the wheels or rims, not by vehicle parts such as axle or steering components. There is otherwise a risk of damage to the vehicle.
- ► Move the selector lever of the automatic transmission to position **N**.

Useful information	260
Important safety notes	260
Operation	26 1
Operation in winter	262
Tire pressure	263
Loading the vehicle	269
Maximum tire load	273
Tire labeling	274
Definition for tires and loading	276
Changing wheels	279

Useful information

This Operator's Manual describes all models as well as standard and optional equipment of your vehicle that were available at the time of going to print. Country-specific variations are possible. Note that your vehicle may not be equipped with all of the described functions. This also applies to systems and functions relevant to safety.

Read the information on qualified specialist workshops: (⊳ page 19).

Important safety notes

Contact an authorized Sprinter Dealer if you require information on tested and recommended tires and wheels for summer and winter driving. Advice on purchasing and caring for tires is also available there.

↑ WARNING

Replace rims or tires with the same designation, manufacturer and type as shown on the original part. For further information, contact an authorized Sprinter Dealer. If incorrectly sized rims and tires are mounted, the wheel brakes or suspension components can be damaged. Also, the operating clearance of the wheels and the tires may no longer be correct.

↑ WARNING

Worn, old tires can cause accidents. If the tire tread is worn to minimum tread depth, or if the tires have sustained damage, replace them.

When replacing rims, only use genuine Sprinter wheel bolts specified for the particular rim type. Failure to do so can result in the bolts loosening and possibly an accident.

Retreaded tires are not tested or recommended by the dealer named on the inside cover page, since previous damage cannot always be recognized on retreads. The operating safety of the vehicle cannot be assured when such tires are used.



MARNING

Only for vehicles without a tire pressure monitor:

For safety reasons, we recommend that you only use tire valves manufactured by Schrader. These have been tested for use on your vehicle.

Use only tire valves of type:

- TR 600 for the vehicle types 2500
- TR 418 for the vehicle types 3500

Using other tire inflation valves or valves made by other manufacturers can result in tire pressure loss and thereby impair the operating safety of the vehicle.

■ Do not screw additional weights (check) valves, etc.) onto the tire valves. The electronic components could thus be damaged.



♠ WARNING

If you feel a sudden significant vibration or ride disturbance, or you suspect that possible damage to your vehicle has occurred, you should turn on the hazard warning lamps, carefully slow down, and drive with caution to an area which is a safe distance from the road. Inspect the tires and the vehicle underbody for possible damage. If the vehicle appears unsafe, have the vehicle towed to the nearest authorized Sprinter Dealer for repairs.



♠ WARNING

Do not drive with a flat tire. A flat tire affects the ability to steer or brake the vehicle. You might lose control of the vehicle. Continued driving with a flat tire or driving at high speed with a flat tire will cause excessive heat buildup and possibly a fire.

Operation

Notes on driving

- If the vehicle is heavily laden, check the tire pressures, and correct them, if necessary.
- When parking your vehicle, make sure that the tires do not get deformed by the curb or other obstacles. If it is necessary to drive over curbs, speed bumps or similar elevations, try to do so slowly and at an obtuse angle. Otherwise, the tires, particularly the sidewalls, can get damaged.

Notes on regularly inspecting wheels and tires

⚠ WARNING

Regularly check the tires for damage. Damaged tires can cause tire inflation pressure loss. As a result, you could lose control of your vehicle.

Worn, old tires can cause accidents. If the tire tread is worn to minimum tread depth, or if the tires have sustained damage, replace them.

- Damaged wheels can cause a loss of tire pressure. Check regularly, at least once a month, for damages, e.g.:
 - cuts, punctures, tears, bulges on tires
 - deformation or severe corrosion on wheels

Check the wheels and tires, particularly after driving off-road or on bad roads.

- Regularly check the tire tread depth and the condition of the tread across the whole width of the tire (⊳ page 261). If necessary, turn the front wheels to full lock in order to inspect the inner side of the tire surface.
- All wheels must have a valve cap to protect the valve against dirt and moisture. Do not install anything onto the valve (such as tire pressure monitoring systems) other than the standard valve cap or other valve caps

- approved by the distributor named on the inside of the front cover.
- Regularly check the pressure of all the tires including the spare wheel, particularly prior to long trips, and correct the pressure (⊳ page 263).

Tire tread



↑ WARNING

Although the applicable federal motor vehicle safety laws consider a tire to be worn when the treadwear indicators (TWI) become visible at approximately 1/16 inches (1.6 mm), we recommend that you do not allow your tires to wear down to that level. As tread depth approaches 1/8 inches (3 mm) the adhesion properties on a wet road are sharply reduced. Depending upon the weather and/or road surface (conditions), the tire traction varies

widely.

Replace tires before they become excessively worn, as the tire traction on wet road surfaces decreases significantly when the tread depth is less than $\frac{1}{8}$ in (3mm).

Tread wear indicators (TWIs) are required by law. Six indicators are positioned over the tire tread. They are visible once the tread depth is approximately $\frac{1}{16}$ in (1.6mm). If this is the case, the tire is so worn that it must be replaced.

The recommended tread depth for summer tires is at least 1/8 in (3mm). The recommended tread depth for winter tires is at least 1/6 in(4mm).



Bar marking (1) for tread wear is integrated into the tire tread.

Notes on selecting, mounting and replacing tires

- Only mount tires and wheels of the same type and make.
- Only mount tires of the correct size onto the wheels.
- After mounting new tires, run them in at moderate speeds for the first 60 miles (100km) as they only reach their full performance after this distance.
- · Replace tires before they become excessively worn, as the tire traction on wet road surfaces decreases significantly when the tread depth is less than $\frac{1}{8}$ in (3mm).
- Replace the tires after six years at the latest, regardless of wear. This also applies to the spare wheel.

The service life of tires depends, among other things, on the following factors:

- · driving style
- tire pressure
- mileage

Permissible wheel/tire combinations and instructions for tires can be found under "Tires and wheels" in the "Technical data" section (⊳ page 288).

Operation in winter

Please bear the following in mind

Have your vehicle winterproofed at a qualified specialist workshop at the onset of winter. Observe the notes under "Winter driving" in the "Operation" section (▷ page 279).

Driving with summer tires

At temperatures below 45 °F (+7 °C), summer tires lose a significant degree of elasticity and therefore traction and braking capacity equip your vehicle with M+S tires. Summer tires can become torn when used in very cold temperatures. This will damage them permanently. We cannot accept responsibility for this type of damage.

M+S tires

At temperatures below 45 °F (+7 °C), use winter tires or all-season tires - both are marked M+S.

In wintry road conditions, only winter tires with the 🛕 snowflake symbol in addition to the M+S marking offer the best possible grip. Only these tires allow driving safety systems such as ABS and ESP® to continue to work optimally in winter, as these tires have been designed specifically for driving on snow.

For safe handling characteristics, use M+S tires of the same make and the same tread on all wheels.

⚠ WARNING

You must replace M+S tires with a tread depth below 1/6 inches (4 mm). These are no longer suitable for winter driving.

If M+S tires are mounted, you must observe the maximum permissible speed.

If you have mounted M+S tires:

- ► Check the tire pressure (> page 263).
- ▶ Restart the tire pressure monitor (▷ page 266).

↑ WARNING

If you mount the spare wheel when using M+S tires, you must be prepared for unstable cornering and impaired handling because of the different tire properties. Adjust your driving style accordingly.

Have the spare wheel replaced with a normal wheel with an M+S tire at the nearest qualified specialist workshop.

Snow chains

Snow chains increase traction on roads in wintry conditions.

For reasons of safety we only recommend using snow chains or traction aids that are approved for the Sprinter. The snow chains or traction aids must be of class U or meet the SAE type U specification. Information on snow chains is available at any qualified specialist workshop.

- Only use snow chains when the road is covered by a layer of snow. Do not exceed the maximum permissible speed of 30 mph (50 km/h). Remove the snow chains as soon as possible. Take them off before you travel on a snow-free road.
- The use of snow chains may be restricted by local regulations. Observe the relevant instructions when you want to mount snow chains.
- Manual Check the snow chains for damage before mounting them. Damaged or worn snow chains may break, causing damage to wheels, wheel arches or wheel suspension. For this reason, you must use only snow chains that are free of defects. Observe the manufacturer's mounting instructions.

If you intend to mount snow chains, please bear the following points in mind:

- You may not mount snow chains on all wheel/tire combinations. When mounting the snow chains, note the permissible tire and snow chain dimensions.
- Mount snow chains only in pairs and only to the rear wheels. Observe the manufacturer's mounting instructions.
- Check the chain tension after approximately 0.5 miles (1.0 km).
- 1 You can deactivate ASR (> page 51) when pulling away with snow chains mounted. This allows the wheels to spin in a controlled manner, achieving an increased driving force (cutting action).

Tire pressure

Tire pressure specifications

↑ WARNING

Follow recommended tire inflation pressures. Do not underinflate tires. Underinflated tires wear excessively and/or unevenly, adversely affect handling and fuel economy, and are more likely to fail from being overheated.

Do not overinflate tires. Overinflated tires can adversely affect handling and ride comfort, wear unevenly, increase stopping distance, and result in sudden deflation (blowout) because they are more likely to become punctured or damaged by road debris, potholes etc.

Do not overload the tires by exceeding the specified load limit as indicated on the Tire and Loading Information placard on the driver's door B-pillar. Overloading the tires can overheat them, possibly causing a blowout. Overloading the tires can also result in handling or steering problems, or brake failure.

A table of recommended tire pressures can be found on the Tire & Loading Information

placard¹¹ or the tire pressure plate on the B-pillar on the driver's side of the vehicle (> page 264).

Use a tire pressure gauge intended for this purpose. The outer appearance of a tire does not permit any reliable conclusion about the tire pressure. On vehicles equipped with the electronic tire pressure monitor, the tire pressure can be checked using the on-board computer.

MARNING

If the tire pressure drops repeatedly:

- check the tires for foreign objects
- check whether the wheel is losing air or the valve is leaking
- make sure that only a valve cap approved by the dealer listed on the inside of the cover page is on the tire valve


Underinflated tires have a negative effect on vehicle safety, which could lead you to cause an accident.

Correct the tire pressure only when the tires are cold. Tires are cold when the vehicle has been parked for at least three hours or has been driven less than 1 mile (1.6 km). Tire temperature changes depending on the ambient temperature, driving speed and tire load. If the tire temperature changes by 18 °F (10 °C), the tire pressure changes by approximately 10 kPa (0.1 bar/1.5 psi). Take this into consideration if you are checking tire pressure when the tires are warm, and correct the tire pressure only if it is too low for current operating conditions. If you check the tire pressure when the tires are warm, it results in a higher value than when the tires are cold. This is normal. Do not under any circumstances release the air in order to adjust the pressure to the prescribed value for cold tires. Tire pressure would then be too low.

Take note of the recommended tire pressure data for cold tires on the Tire & Loading

Information placard¹¹ or the tire pressure plate on the B-pillar on the driver's side of the vehicle.

i The data shown on the following tire data labels are examples. Tire pressure data are vehicle-specific and may deviate from the data illustrated here. The tire pressure data applicable to your vehicle can be found on the Tire & Loading Information placard or tire pressure plate of your vehicle.



N40.00-2031-31

Tire & Loading Information placard¹¹

TIRE INFLATION	PRESSURE/PRESSI	ON DES PNEUS
GVWR/PNBV 5003 KG (11030 LB)		
	FRONT/AVANT	REAR/ ARRIÈRE
GAWR/PNBE	2000 KG (4410 LB)	3502 KG (7720 LB)
TIRES/PNEUS	LT215/85R16	LT215/85R16
RIMS/JANTES	5.5Jx16"	5.5Jx16"
TIRE INFLATION PRESSURE/ PRESSION DES PNEUS	420 KPA (61 PSI) COLD SINGLE/ FROID SIMPLE	420 KPA (61 PSI) COLD DUAL/ FROID JUMELÉ
A906 584 27 38		

Tire pressure plate

You will find recommended tire pressure specifications ① for cold tires and for a fully loaded vehicle on the Tire & Loading Information placard or on the tire pressure plate. The tire pressure specifications apply to the factory-mounted tires.

¹¹ Only for vehicles with a gross weight of less than 10,000 lbs (4536 kg).

Underinflated or overinflated tires

Underinflated tires

/ WARNING

Follow recommended tire inflation pressures. Do not underinflate tires. Underinflated tires wear excessively and/or unevenly, adversely affect handling and fuel economy, and are more likely to fail from being overheated.

Underinflated tires can:

- wear excessively and/or unevenly
- · adversely affect fuel economy
- · fail from being overheated
- · adversely affect handling

Overinflated tires

⚠ WARNING

Follow recommended tire inflation pressures. Do not overinflate tires. Overinflated tires can adversely affect handling and ride comfort, wear unevenly, increase stopping distance, and result in sudden deflation (blowout) because they are more likely to become punctured or damaged by road debris, potholes etc.

Overinflated tires can:

- · adversely affect handling
- wear excessively and/or unevenly
- · be more likely to become damaged
- · adversely affect ride comfort
- · increase stopping distance

Maximum tire pressures



↑ WARNING

Never exceed the maximum tire inflation pressure. Follow recommended tire inflation pressures.

Do not underinflate tires. Underinflated tires wear excessively and/or unevenly, adversely affect handling and fuel economy, and are more likely to fail from being overheated.

Do not overinflate tires. Overinflated tires can adversely affect handling and ride comfort, wear unevenly, increase stopping distance, and result in sudden deflation (blowout) because they are more likely to become punctured or damaged by road debris, potholes etc.



- (1) Maximum permitted tire pressure (example)
- 1 The actual values for tires are specific to each vehicle and may deviate from the values in the illustration.

When adjusting the tire pressures always observe the recommended tire pressure for your vehicle (⊳ page 263).

Checking the tire pressure



♠ WARNING

potholes etc.

Follow recommended tire inflation pressures. Do not underinflate tires. Underinflated tires wear excessively and/or unevenly, adversely affect handling and fuel economy, and are more likely to fail from being overheated. Do not overinflate tires. Overinflated tires can adversely affect handling and ride comfort, wear unevenly, increase stopping distance, and result in sudden deflation (blowout) because they are more likely to become punctured or damaged by road debris,

Do not overload the tires by exceeding the specified load limit as indicated on the Tire and Loading Information placard on the driver's door B-pillar. Overloading the tires can overheat them, possibly causing a blowout. Overloading the tires can also result in handling or steering problems, or brake failure.

Check the tire pressure at least once a month.

Only check and correct tire pressures when
the tires are cold.

Checking the tire pressure manually

In order to determine and adjust the tire pressures, proceed as follows:

- ▶ Remove the valve cap of the tire you wish to check.
- ► Press the tire pressure gauge securely onto the valve.
- ► Read the tire pressure and compare it with the recommended value on the Tire and Loading Information placard ¹² or on the tire pressure plate on the B-pillar on the driver's side of the vehicle.
- ▶ If necessary, increase the tire pressure to the recommended value.
- ▶ If the tire pressure is too high, release air by pressing down the metal pin in the valve using the tip of a pen, for example. Then, check the tire pressure again using the tire pressure gauge.
- ► Screw the valve cap onto the valve.
- Repeat the steps for the other tires.

Tire pressure monitor

Important safety notes

If a tire pressure monitor is installed, the vehicle's wheels have sensors installed that monitor the tire pressures in all 4 tires. The tire pressure monitor warns you when the

pressure drops in one or more of the tires. The tire pressure monitor only functions if the correct wheel electronics units are installed on all wheels.

The tire pressure monitor has a yellow (!) warning lamp in the instrument cluster for indicating pressure loss/malfunctions (USA) or for pressure loss (Canada). Depending on how the warning lamp flashes or lights up, an underinflated tire or a malfunction in the tire pressure monitor is displayed:

- if the (!) warning lamp is lit continuously, the tire pressure on one or more tires is significantly too low. The tire pressure monitor is not malfunctioning.
- USA only: if the (!) warning lamp flashes for 60 seconds and then remains lit constantly, the tire pressure monitor is malfunctioning.

⚠ WARNING

Each tire, including the spare (if provided), should be checked at least once a month when cold and inflated to the pressure recommended by the vehicle manufacturer on the Tire and Loading Information placard on the driver's door B-pillar or the tire pressure label on the inside of the fuel filler flap. If your vehicle has tires of a different size than the size indicated on the Tire and Loading Information placard or the tire pressure label, you should determine the proper tire pressure for those tires.

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS) that illuminates a low tire pressure telltale when one or more of your tires are significantly underinflated.

Accordingly, when the low tire pressure telltale illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly underinflated tire causes the tire to overheat and can lead to tire failure. Underinflation also reduces fuel efficiency

¹² Only for vehicles with a gross vehicle weight rating of less than 10,000 lbs(4536 kg).

and tire tread life, and may affect the vehicle's handling and stopping ability.

Please note that the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if underinflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale.

USA only:

Your vehicle has also been equipped with a TPMS malfunction indicator to indicate when the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will be repeated every time the vehicle is started as long as the malfunction exists.

When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended. TPMS malfunctions may occur for a variety of reasons, including the installation of incompatible replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly. Always check the TPMS malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS to continue to function properly.

1 USA only:

If the tire pressure monitor is malfunctioning, it may take more than 10 minutes for the (!) tire pressure warning lamp to inform you of the malfunction by flashing for 60 seconds and then remaining lit.

When the malfunction has been rectified, the tire pressure warning lamp goes out after driving for a few minutes.

Information on tire pressures is displayed in the on-board computer. After a few minutes

of driving, the current tire pressure of each tire is shown in the on-board computer

- 1 The tire pressure values indicated by the on-board computer may differ from those measured at a gas station with a pressure gauge. The tire pressures shown by the on-board computer refer to those measured at sea level. At elevated locations, the tire pressure checker shows a higher tire pressure than the on-board computer. In this case, do not reduce the tire pressures.
- i If radio transmitting equipment (e.g. wireless headphones, two-way radios) is operated inside the vehicle or in the vicinity of the vehicle, this can interfere with the operation of the tire pressure monitor.

Calling up tire pressure using the onboard computer

Vehicles with steering wheel buttons

Using the steering wheel buttons

- ► Turn the key to position 2 in the ignition lock.
- ▶ Press the or button repeatedly until the standard display (> page 80) is shown.
- ▶ Press the △ or ▽ button repeatedly until the current tire pressure for the individual tires is displayed.



If the vehicle has been parked for more than 20 minutes or you have not then driven faster than 18mph (30km/h), you will see the following message:

tire press. displayed after driving for several minutes

1 The tire pressure values indicated by the on-board computer may differ from those measured at a gas station using a pressure gauge. The on-board computer will generally give you a more exact value.

Tire pressure loss warning system

Vehicles without steering wheel buttons

The <u>(!)</u> tire pressure warning lamp in the instrument cluster comes on if the pressure of one or more tires drops significantly.

1 US vehicles only:

If the ① tire pressure warning lamp flashes for just 60seconds and then is lit permanently, the tire pressure monitor is malfunctioning (> page 198).

If a malfunction of the tire pressure monitor is recognized, the <u>(!)</u> tire pressure warning lamp shows this at the latest after ten minutes.

Vehicles with steering wheel buttons

A message is displayed and the <u>(!)</u> tire pressure warning lamp in the instrument cluster comes on if the pressure of one or more tires drops significantly.

The tire pressure is shown in two red rectangles. The pressure of the tire concerned is shown in one of the two rectangles (⊳ page 201). A warning tone also sounds.

1 US vehicles only:

If the ① tire pressure warning lamp flashes for just 60seconds and then is lit permanently, the tire pressure monitor is malfunctioning (> page 198).

If a malfunction of the tire pressure monitor is recognized, the ① tire pressure warning lamp shows this at the latest after ten minutes.

Reactivating the tire pressure monitor

In most cases, the tire pressure monitor detects the new reference values automatically, e.g. after you have:

- · changed the tire pressure
- · changed wheels or tires
- · mounted new wheels or tires

If you wish to define new reference values manually:

▶ Refer to the table on the tire data labels (> page 264) to make sure that the pressure of all four tires is set correctly. Observe the notes on tire pressures in the "Tires and wheels" section (> page 288).

Vehicles without steering wheel buttons

- ► Turn the key to position 2 in the ignition lock.
- ▶ Press the M menu button on the instrument cluster repeatedly until the following message is displayed: +CAL - TPMS
- ▶ Press the → button on the instrument cluster.

The following message is displayed:

OK TPMS

The tire pressure monitor activation process has begun. The tire pressures measured for the individual wheels are stored as the new reference values, provided that the tire pressure monitor considers them to be plausible.

If you wish to cancel the activation process:

▶ Press the — button or the M menu button on the instrument cluster. The activation will be automatically canceled without warning after 30 seconds.

Vehicles with steering wheel buttons

- ► Turn the key to position 2 in the ignition
- ▶ Press the 🗊 or 🗐 button on the steering wheel repeatedly until the standard display (⊳ page 80) appears.
- ▶ Press the 🗘 or 🔯 button on the steering wheel repeatedly until the current pressure of the individual tires is displayed, or the display shows the following message:

tire press. displayed after driving for several minutes

▶ Press the (0) reset button on the instrument cluster.

The following message is displayed:

Monitor current tire pressure?

▶ Press the 🛨 button on the steering wheel.

The following message is displayed: tire press. monitor reactivated

The tire pressure monitor activation process has begun. The tire pressures measured for the individual wheels are stored as the new reference values. provided that the tire pressure monitor considers them to be plausible.

If you wish to cancel the activation process:

▶ Press the — button on the steering wheel.

Loading the vehicle

Instruction labels for tires and loads

/ WARNING

Do not overload the tires by exceeding the specified load limit as indicated on the Tire and Loading Information placard on the B-pillar on the driver's side or on the vehicle identification plate on the driver seat frame. Overloading the tires can overheat them, possibly causing a blowout. Overloading the tires can also result in handling or steering problems, or brake failure.



The Tire and Loading Information placard on the driver's door B-pillar

The following instruction labels on your vehicle show the maximum possible load.

- (1) Only for vehicles with a gross vehicle weight rating of less than 10,000 lbs(4536 kg):
 - Tire and Loading Information placard (1) is on the B-pillar on the driver's side. The Tire and Loading Information placard shows the permissible number of occupants and the maximum permissible vehicle load. It also contains details of the tire sizes and corresponding pressures for tires mounted at the factory.
- (2) The vehicle identification plate is located on the driver's seat frame. The vehicle identification plate informs you of the gross vehicle weight rating. It is made up of the vehicle weight, all vehicle occupants, the fuel and the cargo. You can also find information about the maximum gross axle weight rating of the front and rear axle.


The maximum gross axle weight rating is the maximum weight that can be carried by one axle (front or rear axle). Never exceed the maximum load or the maximum gross axle weight rating for the front or rear axle.

Tire and Loading Information placard

Only for vehicles with a gross vehicle weight rating of less than 10,000 lbs(4536 kg).

Maximum permissible gross vehicle weight rating

1 The details on the Tire and Loading Information placard illustration are only an example. The maximum permissible gross vehicle weight rating is vehicle-specific and may differ from that which is illustrated. You can find the valid maximum permissible gross vehicle weight rating for your vehicle on the Tire and Loading Information placard.




N40.00-2030-31

- 1) Maximum number of seats
- ② Maximum permissible gross vehicle weight rating
- ► The Tire and Loading Information placard gives you details on maximum permissible gross vehicle weight rating ②: "The gross weight of occupants and luggage must never exceed XXX kilograms or XXX pounds."

The gross weight of all vehicle occupants, cargo, luggage and trailer load/noseweight (if applicable) must not exceed the specified value.

Number of seats

1 The details on the Tire and Loading Information placard illustration are only an example. The number of seats is vehiclespecific and can differ from the details shown. The number of seats in your vehicle can be found on the Tire and Loading Information placard.



- ① Maximum number of seats
- ② Maximum permissible gross vehicle weight rating

Maximum number of seats ① determines the maximum number of occupants allowed to travel in the vehicle. This information can be found on the Tire and Loading Information placard.

Determining the maximum load

Individual steps

The following steps have been developed as required of all manufacturers under Title 49, Code of U.S. Federal Regulations, Part 575 pursuant to the "National Traffic and Motor Vehicle Safety Act of 1966".

- ➤ Step 1: Locate the statement "The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs." on your vehicle's Tire and Loading Information placard.
- Step 2: Determine the combined weight of the driver and passengers that will be traveling in your vehicle.
- Step 3: Subtract the combined weight of the driver and passengers from XXX kilograms or XXX lbs.
- ▶ Step 4: The resulting figure equals the available amount of cargo and luggage load capacity. For example, if the "XXX" amount equals 1400 lbs and there will be five

- 150 lb passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs $(1400 750 (5 \times 150) = 650 \text{ lbs})$.
- ▶ Step 5: Determine the combined weight of luggage and cargo being loaded on the vehicle. For reasons of safety, that weight must not exceed the available cargo and luggage cargo capacity calculated in step 4.
- ► Step 6 (if applicable): If you intend to tow a trailer behind your vehicle, the load on the trailer is transferred to your vehicle.

 Consult this Operator's Manual to determine how this reduces the available cargo and luggage load capacity of your vehicle (> page 273).

Example: Steps 1 to 3

The following table shows examples of how to calculate total load and cargo capacities with varying seating configurations and number and size of occupants. The following examples use a cargo limit of 1500 lbs (680 kg). **This is for illustration purposes only.** Make sure you always use the actual load limit for your vehicle stated on the vehicle's Tire and Loading Information placard (\triangleright page 270).

		Example 1	Example 2	Example 3
Step 1	Combined maximum weight of occupants and cargo (data from the Tire and Loading Information placard)	1500 lbs (680 kg)	1500 lbs (680 kg)	1500 lbs (680 kg)

		Example 1	Example 2	Example 3
Step 2	Number of people in the vehicle (driver and occupants)	5	3	1
	Distribution of the occupants	Front: 2 Rear: 3	Front: 1 Rear: 2	Front: 1
	Weight of the occupants	Occupant 1: 150 lbs (68 kg) Occupant 2: 180 lbs (82 kg) Occupant 3: 160 lbs (73 kg) Occupant 4: 140 lbs (63 kg) Occupant 5: 120 lbs (54 kg)	Occupant 1: 200 lbs (91 kg) Occupant 2: 190 lbs (86 kg) Occupant 3: 150 lbs (68 kg)	Occupant 1: 150 lbs (68 kg)
	Gross weight of all occupants	750 lbs (340 kg)	540 lbs (245 kg)	150 lbs (68 kg)

		Example 1	Example 2	Example 3
Step 3	Permissible cargo and trailer load/ noseweight (maximum gross vehicle weight rating from the Tire and Loading Information placard minus the gross weight of all occupants)	1500 lbs (680 kg) - 750 lbs (340 kg) = 750 lbs (340 kg)	1500 lbs (680 kg) - 540 lbs (245 kg) = 960 lbs (435 kg)	1500 lbs (680 kg) - 150 lbs (68 kg) = 1350 lbs (612 kg)

The greater the combined weight of the occupants, the lower the maximum luggage load. Further information can be found under "Towing a trailer" (▷ page 154).

Vehicle identification plate

Even if you have calculated the total cargo carefully, you should still make sure that the gross vehicle weight rating and the gross axle weight rating are not exceeded. Details about this can be found on the vehicle identification plate on the driver seat frame of your vehicle (⊳ page 285).

Gross vehicle weight: the gross weight of the vehicle, all passengers, cargo and trailer load/noseweight (if applicable) must not exceed the permissible gross vehicle weight.

Gross axle weight rating: the maximum permissible load that can be carried by one axle (front or rear axle).

To ensure that your vehicle does not exceed the maximum permissible values (gross vehicle weight and maximum gross axle weight rating), have your loaded vehicle (including driver, occupants, cargo, and full trailer load if applicable) weighed on a suitable vehicle weighbridge.

Trailer load/noseweight


The trailer load/noseweight affects the gross weight of the vehicle. If a trailer is attached, the trailer load/noseweight is included in the load along with occupants and luggage. The

trailer load/noseweight is usually approximately 10% of the gross weight of the trailer and its cargo.

Maximum tire load

⚠ WARNING

Do not overload the tires by exceeding the specified load limit as indicated on the Tire and Loading Information placard on the B-pillar on the driver's side or on the vehicle identification plate on the driver seat frame. Overloading the tires can overheat them, possibly causing a blowout. Overloading the tires can also result in handling or steering problems, or brake failure.



 The actual values for tires are specific to each vehicle and may deviate from the values in the illustration.


Maximum tire load ① is the maximum permitted weight for which the tire is approved.

Further information on tire loads (> page 274).

Tire labeling

Overview of tire labeling

The following markings are on the tire in addition to the tire name (sales designation) and the manufacturer's name:



- DOT, Tire Identification Number
 (▷ page 276)
- ② Maximum tire load (⊳ page 273)
- ③ Maximum tire pressure (⊳ page 265)
- (4) Manufacturer
- ⑤ Tire material (▷ page 276)
- ⑥ Tire size designation, load-bearing capacity and speed index (▷ page 274)
- (7) Tire name
- Tire data is vehicle-specific and may deviate from the data in the example.

Tire size designation, load bearing index and speed index



- Design standard
- ② Tire width
- ③ Nominal aspect ration in %
- (4) Tire code
- (5) Rim diameter
- 6 Load bearing index
- Speed index
- Tire data is vehicle-specific and may deviate from the data in the example. Instructions for tires can be found under "Tires and wheels" in the "Technical data" section (▷ page 288).

General: depending on the manufacturer's standards, the size imprinted in the tire wall may not contain any letters or may contain one letter ① that precedes the size description.

If "LT" precedes the size description (as shown above): these are light truck tires according to U.S. manufacturing standards.

If "C" precedes the size description: these are commercial motor vehicle tires according to European manufacturing standards.

Tire width: tire width ② shows the nominal tire width in millimeters.

Nominal aspect ratio: aspect ratio ③ is the size ratio between the tire height and the tire width and is shown in percent. The aspect ratio is calculated by dividing the tire width by the tire height.

Tire code: tire code (4) specifies the tire type. "R" represents radial tires. "D" represents diagonal tires, "B" represents diagonal radial tires.

Rim diameter: rim diameter (5) is the diameter of the bead seat, not the diameter of the rim flange. The rim diameter is specified in inches (in).

Load bearing index: load bearing index (6) is a numerical code which specifies the maximum load-bearing capacity of a tire.

/ WARNING

The tire load rating must always be at least half of the GAWR of your vehicle. Otherwise, sudden tire failure may be the result which could cause an accident and/or serious injury to you or others.

Always replace rims and tires with rims and tires having the same specifications (designation, manufacturer and type) as shown on the original part.

↑ WARNING

Do not overload the tires by exceeding the specified load limit as indicated on the Tire and Loading Information placard on the driver's door B-pillar. Overloading the tires can overheat them, possibly causing a blowout. Overloading the tires can also result in handling or steering problems, or brake failure.

Example:

The load bearing index 120 is equivalent to a maximum load of 3042lbs (1380kg) that the tire can carry. If two load-bearing capacity indices are specified (as shown above), the first number states the load-bearing capacity for single tires, the second number the loadbearing capacity for twin tires. For further information on the maximum tire load in kilograms and pounds, see (▷ page 273).

Speed index: speed index (7) specifies the approved maximum speed of the tire.

↑ WARNING

Even when permitted by law, never operate a vehicle at speeds greater than the maximum speed rating of the tires.

Exceeding the maximum speed for which tires are rated can lead to sudden tire failure, causing loss of vehicle control and possibly resulting in an accident and/or serious personal injury and possible death, for you and for others.

Regardless of the speed index always observe the speed limits. Drive carefully and adapt your driving style to the traffic conditions.

Index	Speed rating
F	up to 50mph (80 km/h)
G	up to 56mph (90 km/h)
J	up to 62mph (100 km/h)
K	up to 68mph (110 km/h)
L	up to 74mph (120 km/h)
М	up to 80mph (130 km/h)
N	up to 87mph (140 km/h)
Р	up to 93mph (150 km/h)
Q	up to 100mph (160 km/h)
R	above 106mph (170 km/h)

Not all tires that have the M+S identification offer the driving characteristics of winter tires. Winter tires have, in addition to the M+S identification, the A snow flake symbol on the tire sidewall. Tires with this identification fulfill the requirements of the Rubber Manufacturers Association (RMA) and the Rubber Association of Canada (RAC) regarding the tire traction on snow and have been especially developed for driving on snow.

Further information on the reading of tire information can be obtained at any qualified specialist workshop.

DOT, Tire Identification Number (TIN)

U.S. tire regulations prescribe that every new tire manufacturer or retreader has to imprint a TIN in or on the sidewall of each tire produced.



The TIN is a unique identification number. The TIN enables the tire manufacturers to inform purchasers of recalls and other safety-relevant matters. It makes it possible for the purchaser to easily identify the affected tires.

The TIN is made up of manufacturer identification code ②, tire size ③, tire type code ④ and date of manufacture ⑤.

1 Tire data is vehicle-specific and may deviate from the data in the example.

DOT (Department of Transportation): tire symbol ① marks that the tire complies with the requirements of the U.S. Department of Transportation.

Manufacturer identification code:

manufacturer identification code ② provides details on the tire manufacturer. New tires have a code with two symbols. Retreaded tires have a code with four symbols.

Further information about retreaded tires (> page 260).

Tire size: identifier (3) describes the tire size.

Tire type code: tire type code (4) can be used by the manufacturer as a code to describe specific characteristics of the tire.

Date of manufacture: date of manufacture (5) provides information about the age of a tire. The first and second positions represent the week of manufacture, starting with "01" for the first calendar week. Positions three and four represent the year of manufacture. For example, a tire that is marked with "3208", was manufactured in week 32 in 2008.

Tire characteristics



i Tire data is vehicle-specific and may deviate from the data in the example.

This information describes the tire cord and the number of layers in sidewall ① and under tire tread ②.

Definition for tires and loading

Tire structure and characteristics

Describes the number of layers or the number of rubber-coated belts in the tire tread and the tire wall. These consist of steel, nylon, polyester, and other materials.

Bar

Metric unit for tire pressure. 14.5038pounds per square inch (psi) and 100kilopascal (kPa) correspond to one bar.

DOT (Department of Transportation)

Tires with the DOT label fulfill the requirements of the U.S. Department of Transportation.

Average weight of vehicle occupants

The number of occupants for which the vehicle is designed multiplied by 68 kilograms (150lb).

Uniform Tire Quality Grading Standards

A uniform standard to grade the quality of tires with regard to tread quality, traction and temperature characteristics. The quality grading assessment is made by the manufacturer following specifications from the U.S. government. The quality grade of a tire is imprinted on the sidewall of the tire.

Recommended tire pressure

The recommended tire pressure for your vehicle for normal driving conditions for cold tires. The recommendation can be found on the Tire & Loading Information placard ¹³ or on the tire pressure plate on the B-pillar on the driver's side of the vehicle. The recommended tire pressure provides the best balance between handling characteristics, ride comfort and wear.

Increased vehicle weight due to optional equipment

The combined weight of all standard and optional equipment available for the vehicle, regardless of whether it is actually installed on the vehicle or not.

Wheel rim

The part of the wheel on which the tire is mounted.

GAWR (Gross Axle Weight Rating)

The GAWR is the maximum gross axle weight rating. The actual load on an axle must never exceed the gross axle weight rating. The Gross Axle Weight Rating can be found on the vehicle identification plate on the driver seat frame (▷ page 285).

Speed index

The speed index is part of the tire identification. It specifies the speed range for which the tire is approved.

GTW (Gross Trailer Weight)

GTW is the total of weight of a trailer and the weight of the load, accessories etc. on the trailer.

GVW (Gross Vehicle Weight)

The gross vehicle weight includes the weight of the vehicle including fuel, tools, spare wheel, accessories installed, occupants, luggage and the drawbar noseweight if applicable. The gross vehicle weight may not exceed the GVWR (Gross Vehicle Weight Rating) specified on the vehicle identification plate on the driver seat frame (▷ page 285).

GVWR (Gross Vehicle Weight Rating)

The GVWR is the maximum permissible gross weight of a fully loaded vehicle (the weight of the vehicle including all accessories, occupants, fuel, luggage and the drawbar noseweight if applicable). The Gross Vehicle

¹³ Only for vehicles with a gross weight of less than 10,000lbs (4536kg).

Weight Rating is specified on the vehicle identification plate on the driver seat frame (> page 285).

Maximum weight of the laden vehicle

The maximum weight is the sum of the curb weight of the vehicle, the weight of the accessories, the maximum load and the weight of the optional equipment installed at the factory.

Kilopascal (kPa)

Metric unit for tire pressure. 6.9kPa is equivalent to 1psi. Another tire pressure unit is bar. 100kilopascal (kPa) is equivalent to 1bar.

Load index

In addition to the load bearing index, a load index can be stamped onto the sidewall of the tire. It specifies the load-bearing capacity of the tire more precisely.

Curb weight

The weight of a vehicle with standard equipment including the maximum filling capacity of fuel, oil, and coolant. It also includes the air-conditioning system and optional equipment if these are installed on the vehicle, but does not include passengers or luggage.

Maximum tire load

The maximum tire load in kilograms or pounds is the maximum weight for which a tire is approved.

Maximum permissible tire pressure

Maximum permissible tire pressure for one tire.

Maximum load on one tire

Maximum load on one tire. This is calculated by dividing the maximum axle load of one axle by two.

PSI (Pounds per square inch)

Standard unit of measurement for tire pressure.

Aspect ratio

Relationship between tire height and width in percent.

Tire pressure

Pressure inside the tire applying an outward force to every square inch of the tire's surface. Tire pressure is specified in pounds per square inch (psi), in kilopascal (kPa) or in bar. Tire pressure should only be corrected when the tires are cold.

Tire pressure of cold tires

The tires are cold:

- if the vehicle has been parked for at least three hours without direct sunlight on the tires, and
- if the vehicle was driven less than 1 mile (1.6 km).

Tire tread

The part of the tire that comes into contact with the road.

Tire bead

The tire bead ensures that the tire sits securely on the wheel. There are several steel wires in the bead to prevent the tire from coming loose from the wheel rim.

Sidewall

The part of the tire between the tread and the tire bead.

Weight of optional extras

The combined weight of those optional extras that weigh more than the replaced standard part and more than 2.3 kg (5 lbs). These optional extras, such as a roof rack or a highcapacity battery, are not included in the curb weight and the weight of the accessories.

TIN (Tire Identification Number)

A unique identification number which can be used by a tire manufacturer to identify tires, for example for a product recall, and thus identify the purchasers. The TIN is composed of the manufacturer identification code, tire size, tire model code and manufacturing date.

Load bearing index

The load bearing index (also load index) is a code that contains the maximum load bearing capacity of a tire.

Traction

Traction is the result of friction between the tires and the road surface.

TWR (permissible trailer drawbar load)

The TWR is the maximum permissible weight that may act on the ball coupling of the trailer tow hitch.

Wear indicator

Narrow bars (tread wear bars) that are distributed over the tire tread. If the tire tread is level with the bars, the wear limit of $\frac{1}{16}$ in (1.6 mm) has been reached.

Distribution of the vehicle occupants

The distribution of vehicle occupants over designated seat positions in a vehicle.

Maximum permissible payload weight

Nominal load and cargo/luggage load plus 68 kg (150 lb) multiplied by the number of seats in the vehicle.

Changing wheels

Flat tire

The "Flat tire" section in the "Practical advice" chapter (⊳ page 224) contains information and notes on how to deal with a flat tire. It also provides instructions on changing a wheel or mounting the spare wheel.

Interchanging the wheels

Important safety notes



↑ WARNING

Rotate front and rear wheels only if the tires are of the same dimension.

If your vehicle is equipped with mixed-size tires (different tire dimensions front vs. rear), tire rotation is not possible.

↑ WARNING

After changing a wheel, for safety reasons you must:

- have the tightening torque checked. For wheel bolts, the tightening torque is 177 lb-ft (240 Nm) (steel wheel)/133 lb-ft (180 Nm) (alloy wheel). For wheel nuts, the tightening torque is 133 lb-ft (180 Nm). The wheels could otherwise work loose.
- check the tire pressure and correct it if necessary.
- have the wheel bolts/wheel nuts retightened after driving a distance of 30 miles (50 km). The tightening torque for wheel bolts is 177 lb-ft (240 Nm)(steel wheel)/133 lb-ft (180 Nm) (alloy wheel). The tightening torque for wheel nuts is 133 lb-ft (180 Nm).
- if using new or painted rims, have the wheel bolts and wheel nuts retightened at the specified tightening torque after the vehicle has been driven for approximately 600 to 3000 miles (1000 to 5000 km).
- have the direction of rotation corrected, if reversed, as soon as possible at a qualified specialist workshop, e.g. an authorized Sprinter Dealer. The vehicle handling characteristics could otherwise be affected.

Otherwise, the operating reliability and road safety of the vehicle could be jeopardized. This could cause you to lose control of your vehicle, resulting in an accident and injuring yourself or others.

The vehicle tires are an essential component in the overall performance and stability of the vehicle. The service life of tires is dependent upon and proportional to tire type, speed rating, environmental conditions, tire load, tire pressure, road quality and individual driving style.

For this reason, we recommend regularly checking wear and correct tire pressure as well as regularly rotating the tires, according

to the appropriate tire configuration of the vehicle.

The wear patterns on the front and rear tires differ, depending on the operating conditions. Rotate the wheels before a clear wear pattern has formed on the tires. Front tires typically wear more on the shoulders and the rear tires in the center.

If your vehicle's tire configuration allows, you can rotate the wheels according to the intervals in the tire manufacturer's warranty book in your vehicle documents. If no warranty book is available, the tires should be rotated every 3000 to 6000 miles (5000 to 10000km), or earlier if tire wear requires. Do not change the direction of rotation.

Clean the contact surfaces of the wheel and the brake disc thoroughly every time a wheel is rotated. Check the tire pressures.

If your vehicle is equipped with the tire pressure monitor, each wheel has an electronic component.

Tire-mounting tools should not be applied in the area of the valve. Otherwise, the electronic components could be damaged.

Only have tires replaced at a qualified specialist workshop.




Diagram for rotating single tires and twin tires

Single tires

If the tires have identical dimensions, you may rotate the tires at the front and rear axles in pairs so that the tires' original direction of rotation remains the same. On unidirectional

tires, an arrow on the sidewall shows the prescribed direction of rotation of the tire.

Twin rear tires

If the tires have identical dimensions, you may rotate the tires at the front axle and the inner wheels at the rear axle in pairs so that the tires' original direction of rotation remains the same. With unidirectional tires, you may rotate the outside wheels at the rear axle from one side to the other.

Information on changing wheels (⊳ page 231).

Direction of rotation

Tires with a specified direction of rotation have additional benefits, e.g. if there is a risk of hydroplaning. You will only gain these benefits if the correct direction of rotation is observed.

An arrow on the sidewall of the tire indicates its correct direction of rotation.

You may mount a spare wheel against the direction of rotation. Observe the time restriction on use as well as the speed limitation specified on the spare wheel.

Storing wheels

Store wheels that are not being used in a cool, dry and preferably dark place. Protect the tires from contact with oil, grease and fuel.

Cleaning the wheels



MARNING

Do not use power washers with circular jet nozzles (concentrated-power jets) to clean your vehicle, especially for cleaning tires. You could otherwise damage the tires and cause an accident.

Useful information	
Genuine Sprinter parts	284
Vehicle electronics	284
Identification plates	285
Operating data	287
Capacities	294

Useful information

This Operator's Manual describes all models as well as standard and optional equipment of your vehicle that were available at the time of going to print. Country-specific variations are possible. Note that your vehicle may not be equipped with all of the described functions. This also applies to systems and functions relevant to safety.

Read the information on qualified specialist workshops: (⊳ page 19).

Genuine Sprinter parts

We test genuine parts, conversion parts and accessories that have been specifically approved for your type of vehicle for:

- · reliability
- safety
- suitability

Despite ongoing market research, we are unable to assess other parts. We therefore accept no responsibility for the use of such parts in a Sprinter, even if they have been independently or officially approved.

In some countries, certain parts are only officially approved for installation or modification if they comply with legal requirements. All genuine Sprinter parts satisfy these requirements. Make sure that any replacement parts are suitable for your vehicle.

The use of non-approved parts could affect your vehicle's operating safety. Therefore, we recommend genuine Sprinter parts and conversion parts and accessories which have been authorized for your type of vehicle.

↓Environmental note

We supply reconditioned assemblies and parts which are of the same quality as new parts. The same New Vehicle Limited Warranty applies as for new parts.

Genuine Sprinter parts, as well as specifically approved conversion parts and accessories, can be obtained at an authorized Sprinter Dealer. Here you will receive advice about permissible technical modifications, and the parts will be professionally installed.

Always provide the vehicle's identification number and the engine number when ordering genuine Sprinter parts. The numbers can be found on the vehicle identification plate of your vehicle (⊳ page 285).

Vehicle electronics

Tampering with the engine electronics



↑ WARNING

For safety reasons, have all work on engine electronics and the relevant parts carried out only at a qualified specialist workshop. The vehicle's operating safety may otherwise be jeopardized.

I Only have engine electronics and the corresponding parts, such as control units, sensors or connector leads, serviced in a qualified specialist workshop. Otherwise, the vehicle parts may wear more quickly. This can lead to loss of the New Vehicle Limited Warranty.

Retrofitting electrical or electronic equipment

Electrical and electronic devices may have a detrimental effect on both the comfort and the operating safety of the vehicle. If equipment of this kind is retrofitted, its electromagnetic compatibility must be checked and verified.

If these devices are linked to functions associated with resistance to interference. they must have type approval. This applies to the device or its interfaces to the vehicle electronics, e.g. charging brackets.

If you wish to install telephones or two-way radios in the vehicle, you must obtain formal approval. Further information can be obtained from any Sprinter Dealer.

Damage or consequential damage arising from installing equipment which is not approved by the distributor named on the inside of the front cover is not covered by the New Vehicle Limited Warranty.

For operation of mobile phones and two-way radios, we recommend connection to an approved exterior antenna. This is the only way to ensure optimum reception quality inside the vehicle and to minimize mutual interference between the vehicle electronics, mobile phones and two-way radios.

⚠ WARNING

You and others may damage your health due to excessive electromagnetic radiation. By using an external antenna, the possible health risks of electromagnetic fields, which are under discussion among the scientific community, should be largely prevented.

The transmission output of the mobile phone or two-way radio must not exceed the maximum transmission outputs listed

Therefore, only have the exterior antenna installed at a qualified specialist workshop.

maximum transmission outputs listeu.			
Frequency range	Maximum transmission output (PEAK)		
Short wave (f < 50 MHz)	100 W		
4 m waveband	30 W		
2 m waveband	50 W		
Trunked radio/Tetra	35 W		
70 cm waveband	35 W		
GSM 900/AMPS	10 W		
GSM 1800	10 W		
UMTS	10 W		

Identification plates

Vehicle identification plates


The vehicle identification plate with the vehicle identification number (VIN), the paint code, and the specifications for the permissible weights is located on the base of the driver's seat.



Base of the driver's seat


 Vehicle identification plate with VIN for vehicle or chassis

The VIN is also stamped into the rear wall of the engine compartment (▷ page 286).



Example: vehicle identification plate (US vehicles)

- ② VIN
- ③ Paint code



Example: chassis identification plate (US vehicles)

- ② VIN
- ③ Paint code




Example: vehicle identification plate (vehicles for Canada)

- ② VIN
- ③ Paint code



Example: chassis identification plate (vehicles for Canada)

- ② VIN
- (3) Paint code



Engine compartment

- WIN (stamped on the rear wall of the engine compartment)
- Engine number (stamped on the crankcase)
- 6 Emission Control Information and engine oil 14 label



Example: Emission Control Information label

i The data shown in the pictures is for the purposes of illustration. Such data is vehicle-specific and may differ from that shown. Always observe the specifications on your vehicle's identification plate.

Tire plates

The Tire and Loading Information label ¹⁵ or the Tire Pressure label is on the B-pillar on the driver's side. You will find the required tire pressure values for the vehicle's original tires on the relevant tire labels.


 $^{^{14}}$ Note also the engine oil information for diesel engines under "Service products" in the "Operation" section.

¹⁵ Vehicles with a permissible gross weight of up to 10,000 lbs(4536 kg) only.


The Tire and Loading Information label also specifies the number of seats and the permissible load.



 Tire and Loading Information label or Tire Pressure label



Tire and Loading Information label



Tire Pressure label

- (2) Number of seats
- ③ Permissible load
- (4) Recommended pressure for cold tires
- 1 The data shown in the pictures is for the purposes of illustration. Such data is vehicle-specific and can differ from that

shown. Always observe the specifications on your vehicle's tire label.

The tire pressure information applies to all load levels up to the permissible gross weight and is only valid for original tires in their cold state.

Operating data

General notes

The following sections contain important technical data for your vehicle.

You can find vehicle-specific and equipmentdependent technical data in your vehicle registration papers, such as:

- Engine power output data
- Speeds
- · Vehicle dimensions
- Vehicle weights

Tires and wheels

Overview

Only use tire and rim sizes approved for your type of vehicle. These have been specially adapted for use with the control systems, such as ABS or ESP®.

Take note of the operating safety information on tires and wheels in the "Tires and wheels" section (> page 260).

1 In particular, please also observe the permissible tire specifications in your country.

These regulations may determine a specific type of tire for your vehicle or prohibit the use of certain types of tire which are permitted in other countries.

Observe the tire load rating and speed rating required for your vehicle.

Information on wheels and tires can be obtained at any authorized Sprinter Dealer. Data on the original tires can be found on the Tire and Loading Information placard on the B-pillar on the driver's side of your vehicle (\triangleright page 286).

Vehicle type	2500	3500
Rim size (steel wheel)	6.5 J x 16	5.5 J x 16
Rim size (alloy rim)	6.5 J x 16	-
Offset	2.13 in (54 mm)	-
Half distance from center to center	_	4.82 in (122.5 mm)
Wheel attachment	Wheel bolts	Wheel nuts
Tightening torque (steel wheel)	177 lb-ft (240 Nm)	133 lb-ft (180 Nm)
Tightening torque (alloy wheel)	133 lb-ft (180 Nm)	-
Summer tires	_	-
All-weather tires ¹⁶	LT 245/75 R16 120/116N	LT 215/85 R16 115/112N
		LT 215/85 R16 115/112Q
Winter tires ¹⁶	LT 245/75 R16 120/116N M+S 🛕	LT 215/85 R16 115/112N M+S 🛕

Tire pressure

Take note of the information on tire pressure in the "Wheels and tires" section (⊳ page 263).

¹⁶ Radial tires.

↑ WARNING

Underinflated tires:

- · jeopardize driving safety
- damage or destroy the tires
- may cause tire overheating or even spontaneous combustion

You could lose control of your vehicle and injure yourself and other persons.

For this reason, check the tire pressure regularly before starting a journey and correct it if necessary.

Correct the tire pressure before loading. If the vehicle is loaded, check the tire pressure, and correct it if necessary.

While driving, dependent on driving speeds and load, the tire temperature and with it, the tire pressure rise.

You should thus only correct tire pressures when the tires are cold. If the tires are warm, you may only correct tire pressures when:

- taking the respective tire temperatures into consideration with the vehicle laden, the values apparent from the tire pressure table are not exceeded.
- the levels fall below the values stated in the tire pressure table when the vehicle is unladen and the temperature of the tire is taken into account.

The tires can be deemed to be cold if the vehicle has been parked for at least 3 hours or if it has been driven for less than 1 mile (1.6 km) at an outside temperature of approximately 68 °F (20 °C).

1 The tire pressure changes by about 10 kPa (0.1 bar/1.5 psi) for each 18 °F (10 °C) change in the air temperature. Remember to allow for this when checking tire pressures inside, particularly in winter.

Example:

Room temperature = approximately 68 °F (20 °C)

Outside temperature = approximately 32 °F (0 °C)

Tire pressure to be set: prescribed tire pressure +20 kPa (+0.2 bar/+3 psi).

■ The pressure difference between tires on any one axle must be no greater than 10 kPa (0.1 bar/1.5 psi).

A tire pressure of less than 300 kPa (3.0 bar/43.6 psi) is not permissible.

The tire pressure values in the following table apply to all load conditions up to the maximum permissible gross vehicle weight and only to the specified original tires in cold condition. The values are determined by the permissible axle loads found on the vehicle identification plate on the driver seat frame (> page 285).

1 Additionally, you will find the stipulated tire pressure values on the tire data label on the B-pillar on the driver's side of your vehicle (▷ page 286).

Tire pressure table

Tires	Permissible axle loads (see vehicle identification plate)					
	Front axle			Rear axle		
	3970 lbs (1801 kg)	4080 lbs (1851 kg)	4410 lbs (2000 kg)	5360 lbs (2431 kg)	7060 lbs (3202 kg)	7720 lbs (3502 kg)
LT 215/85 R 115/112 N	-	380 kPa (3.8 bar/ 55 psi)	420 kPa (4.2 bar/ 61 psi)	-	380 kPa (3.8 bar/ 55 psi)	420 kPa (4.2 bar/ 61 psi)
LT 215/85 R 115/112 Q	-	380 kPa (3.8 bar/ 55 psi)	420 kPa (4.2 bar/ 61 psi)	-	380 kPa (3.8 bar/ 55 psi)	420 kPa (4.2 bar/ 61 psi)
LT 245/75 R 120/116 N	320 kPa (3.2 bar/ 47 psi)	-	-	480 kPa (4.8 bar/ 70 psi)	-	-

Cargo tie-down points and carrier systems

Lashing points

General notes

Observe the information on the maximum loading capacity of the lashing points.

If you use multiple lashing points to secure

a load, you should observe the maximum loading capacity of the weakest lashing point.

When you brake hard, for example, forces apply that can be far higher than the weight force of the transported load. Always use multiple lashing points to distribute these forces, and distribute the load equally among them.

You will find further information about lashing points and cargo tie-down rings in the "Operation" section (▷ page 147).

Cargo tie-down rings

The maximum tensile load of the cargo tiedown rings is:

Cargo tie-down rings	Permissible nominal tensile load
Passenger Van	786.5 lbf (3,500 N)
Cargo Van	1,124.0 lbf (5,000 N)

Load rails

The maximum tensile loads of the lashing points in the cargo compartment are:

Lashing point	Permissible nominal tensile load
Load rails on cargo compartment floor	1,124.0 lbf (5,000 N)
Lower load rail on sidewall	562.0 lbf (2,500 N)
Upper load rail on sidewall	337.0 lbf (1,500 N)

The values specified apply only to loads placed on the floor of the cargo compartment if:

- the load is secured to 2 lashing points on the rail and
- the distance to the next load securing point on the same rail is approximately 3 ft (1 m).

Roof carrier

↑ WARNING

If you have mounted a roof carrier, the vehicle's handling, steering and braking characteristics may change due to the higher center of gravity. This is the case particularly if the roof carrier is laden. Adapt your driving style according to the vehicle load.

Observe the manufacturer's installation instructions. An incorrectly secured roof carrier and/or load could come loose, fall off and thereby endanger you or others.

Observe the maximum roof load and maximum roof carrier load. Loads transported on the roof must always be secured with particular care.

Do not allow the load, including passengers, to exceed the permissible gross vehicle weight or the gross axle weight rating for your vehicle.

Maximum roof load and minimum number of pairs of roof carrier supports on vehicles with:

	Maximum roof load	Minimum number of pairs of supports
Standard roof	660 lbs (300 kg)	6
High roof	330 lbs (150 kg)	3

The data is valid for a load distributed evenly over the entire roof area.

■ The weight of any load carried on the roof, including the roof carrier, must not exceed the maximum permissible roof load.

The roof carrier supports must be mounted at equal distances.

We recommend that you have a stabilizer installed on the front axle.

Reduce the load on shorter roof carriers proportionately. The maximum load per pair of carrier supports is 110 lbs (50 kg).

For safety reasons, we recommend that you only use roof carrier systems that have been tested and approved for the Sprinter. This will help to avoid damage.

Loading directions and other information concerning load distribution and load securing can be found in the "Operation" section (> page 144).

Trailer tow hitch

General notes

We recommend that you have the trailer tow hitch mounted at an authorized Sprinter Dealer.

Use only a trailer tow hitch that has been tested and approved specially for your vehicle by the distributor named on the inside of the front cover. Only use a ball coupling that is

approved for your vehicle and Sprinter trailer tow hitch. You can also find information on the permitted dimensions of the ball coupling on the identification plate of the trailer tow hitch.

You can obtain advice from a qualified specialist workshop. Please also note the information on towing a trailer in the "Operation" section (▷ page 150).

The permitted weight and load values, which must not be exceeded, can be found in your vehicle's registration papers and on the type plates of the trailer tow hitch and the trailer as well as the vehicle identification plate (▷ page 285). You will find the basic values approved by the manufacturer in the following table. If the values vary, the lowest value always applies.

Make sure that you adhere to the weight restrictions by having the weight checked on a calibrated weighbridge.

On vehicles with a permissible gross vehicle weight of 11030 lbs (5003 kg), the permissible gross combination weight is less than the total of the permissible gross vehicle weight and the permissible trailer load. Exceeding the permissible gross combination weight can lead to damage to the drivetrain, to the transmission or to the trailer tow hitch.

If the vehicle or the trailer is fully laden, the relevant value for the permissible gross vehicle weight or the permissible trailer load is therefore lower. In this case, the trailer or the vehicle may only be partially loaded.

Maximum permitted weights and loads

Type of vehicle	Gross vehicle weight GVWR	Gross front axle load GAWR (FA)	Gross rear axle load GAWR (RA)	Gross combinati on weight ¹⁷ GCWR	Trailer load ¹⁸ GTW	Maximu m permiss. nose weight TWR
2500	8,550 lbs (3,878 kg)	3,970 lbs (1,801 kg)	5,360 lbs (2,431 kg)	13,550 lbs (6,146 kg)	5,000 lbs (2,268 kg)	500 lbs (227 kg)
3500	9,900 lbs (4,490 kg) Canada	4,080 lbs (1,851 kg)	7,060 lbs (3,202 kg)	14,900 lbs (6,759 kg)	5,000 lbs (2,268 kg)	500 lbs (227 kg) ¹⁹
	only	4,410 lbs (2,000 kg)		15,250 lbs (6,917 kg)	7,500 lbs (3,402 kg)	750 lbs (340 kg) ²⁰
	9990 lbs (4,531 kg) USA only	4,080 lbs (1,851 kg)	7,060 lbs (3,202 kg)	14,990 lbs (6,799 kg)	5,000 lbs (2,268 kg)	500 lbs (227 kg) ¹⁹
		4,410 lbs (2,000 kg)		15,250 lbs (6,917 kg)	7,500 lbs (3,402 kg)	750 lbs (340 kg) ²⁰
	11,030 lbs (5,003 kg)	4,080 lbs (1,851 kg)	7,720 lbs (3,502 kg)	15,250 lbs (6917 kg)	5,000 lbs (2,268 kg)	500 lbs (227 kg) ¹⁹
		4,410 lbs (2,000 kg)			7,500 lbs (3,402 kg)	750 lbs (340 kg) ²⁰

¹⁷ Maximum permissible gross weight of the vehicle and trailer.

¹⁸ Maximum permissible gross weight of the trailer.

¹⁹ Only for extra-long vehicles with an overall length of 289.2 in (7,344 mm).

²⁰ Only for extra-long vehicles with an overall length of 289.2 in (7,344 mm).

Capacities

Engine with oil filter	Fuel tank	DEF tank	Engine cooling system	Windshield/ headlamp cleaning system
Engine oil	ULTRA-LOW SULFUR DIESEL	Diesel Exhaust Fluid (DEF) ²¹	Coolant ²²	Washer fluid with windshield washer concentrate
13.21 US qt. (12.5 I)	26.4 US gal (100 I) ²³	3.2 US gal (12.0 l)/ 4.9 US gal (18.5 l)/ 5.8 US gal (22.0 l) ²⁴	10.75 US qt (10.0 l)	Approximately 6.3 US qt (6.0 l)

²¹ DEF according to ISO 22241. Observe the MB Specification for Service Products, Sheet No. 352.0.

²² If the coolant is renewed/replaced, the coolant should contain 50 % of antifreeze/corrosion inhibitor by volume. This is equivalent to antifreeze protection down to -34.6 °F (-37 °C). Do not exceed a proportion of 55% by volume (antifreeze protection of approximately -49.0 °F (-45 °C)). Otherwise heat will not be adequately dissipated. MB Specification for Service Products, Sheet No. 310.1.

²³ Including a reserve of 5.3 US gal(20 I).

²⁴ Only Cab Chassis.

Publication details

Internet

Further information on Mercedes-Benz vehicles can be obtained on the Internet at www.mercedes-benz.com www.mbusa.com (USA only) www.mercedes-benz.ca (Canada only)

Editorial office

You are welcome to forward any queries or suggestions you may have regarding this Operator's Manual to the technical documentation team at the address on the inside of the front cover.

- © Mercedes-Benz USA, LLC
- [©] Mercedes-Benz Canada, Inc.

Mercedes-Benz USA, LLC and Mercedes-Benz Canada Inc. are Daimler companies. Not to be reprinted, translated or otherwise reproduced, in whole or in part, without written permission.

Printed in the USA.



Order no. 6462 7487 13 Part no. 906 584 83 72 Edition C MY 2012 MB