Vehicle document wallet in the vehicle

Here you can find information on operation, service work and the warranty for your vehicle in printed form.

9075844414

Order no. T907 0566 13 Part no. 907 584 44 14 Edition C-2024



The new eSprinter

Operator's Manual

Mercedes-Benz



Front passenger air bag warning





Air bag warning sticker for USA and Canada

WARNING Risk of injury or fatal injuries if the front passenger air bag is enabled

If the front passenger air bag is enabled, a child on the front passenger seat may be struck by the front passenger air bag in the event of an accident.

NEVER use a rearward-facing child restraint system on a seat with an ENA-BLED FRONT AIR BAG. This can result in the DEATH of or SERIOUS INJURY to the CHILD.

Observe the chapter entitled "Children in the vehicle".

Publication details

Internet

Further information about Mercedes-Benz vehicles and about Mercedes-Benz AG can be found on the following websites:

https://www.mercedes-benz.com

https://www.mbusa.com (USA only)

https://www.mercedes-benz.ca (Canada only)

Editorial team

© Mercedes-Benz Vans, LLC

[®] Mercedes-Benz AG: Not to be reprinted, translated or otherwise reproduced, in whole or in part, without written permission from Mercedes-Benz AG.

Vehicle manufacturer

Mercedes-Benz AG

Mercedesstraße 120

70372 Stuttgart

Germany

Vehicle dealer Mercedes-Benz USA, LLC

One Mercedes-Benz Drive

Sandy Springs, GA 30328

https://www.mbusa.com (USA only)

http://www.mbsprinterusa.com

Customer Assistance Center:

1-877-762-8267

Mercedes-Benz Canada, Inc.

2680 Matheson Blvd E, Suite 400

Mississauga, ON L4W 0A5

https://www.mercedes-benz.ca (Canada only)

Customer Assistance Center:

1-800-387-0100

Mercedes-Benz USA, LLC and Mercedes-Benz Canada, Inc. are Mercedes-Benz Group AG enterprises.

Canada only: "Authorized Sprinter Dealer" is defined as an authorized Mercedes-Benz Sprinter Dealer.

As at 09.06.23

Welcome to the world of Mercedes-Benz

Before you first drive off, read this Operator's Manual carefully and familiarize yourself with your vehicle. For your own safety and a longer operating lifespan, follow the instructions and warning notices in this Operator's Manual. Disregarding them may result in damage to the vehicle or environment or in injuries to people.

Vehicle damage caused by failure to observe the instructions is not covered by the New Vehicle Limited Warranty.

The standard equipment and product description of your vehicle may vary, depending on the following factors:

- Model
- Order
- · National version
- Availability

Mercedes-Benz reserves the right to introduce changes in:

- Design
- Equipment
- · Technical features

Your vehicle may therefore differ, in individual cases, from that shown in the descriptions and illustrations.

The following documents are integral parts of the vehicle:

- · Printed Operator's Manual
- · Service booklet
- Equipment-dependent supplements

Always keep these documents in the vehicle. If you sell the vehicle, always pass all documents on to the new owner.

Mercedes-Benz Vans, LLC

Mercedes-Benz Canada, Inc.

A Mercedes-Benz Group AG Company

2 Contents

Symbols	. 4	Elec Rea Part
At a glance Cockpit Instrument cluster Overhead control panel Door operating unit Emergencies and breakdowns	. 6 . 7	Side Anti Sea Note tion
General notes Environmental protection Mercedes-Benz Genuine Parts Attachments, add-on equipment, installations and conversions Operator's Manual Service and vehicle operation Operating safety Declarations of conformity and notes on	13 13 13 14 15 15 16	Sea Stee Stov Info Cup Ash Soc Inst
driving in different countries	18 18 19 19 19	Ligh Ligh Adju Cha Win Mirr
cal aids	20 20 21 21 21 21 21 24	Clin Ove Ope Ope tion Pre-
Occupant safety Brief overview of most important points Information on the automatic functions of the restraint system Purpose and function of the restraint system Seat belts Airbags	26 26 29 29 33 33	Driv Driv Driv Trar Cha Park Driv Trail
Children in the vehicle	34 34 34 36	Inst pute Ove Fun
Opening and closing	38 38 40 43	Ove whe Ove Fun

Electric sliding door Rear-end doors Partition sliding door Side window Anti-theft prevention	44 47 49 50 52
Seats and stowage	55 55 55
Steering wheel	63 64 65 65
Light and vision Lighting Adjusting the interior lighting Changing bulbs Windshield wipers Mirrors	71 73 77
Climate control Overview of climate control systems Operating climate control systems Operating air vents Operating cargo compartment ventilation Pre-entry climate control	82 82 84 87 87
Driving and parking	90 99 100 102 110 113 125
Instrument cluster and on-board computer	131 131 131 132

Display of the available power	133 133 134
Mercedes me Mercedes me calls Mercedes me connect Mercedes me and apps	137 137 139 140
Audio system Notes on operating safety Overview and operation System settings Radio Media Telephone	141 141 142 143 143 144 145
Transporting	148 148 148 149 150 151
Maintenance and care	152 152 152 155 158
Breakdown assistance Emergency Emergency Call System Flat tire Battery Towing or tow-starting Electrical fuses Vehicle tool kit Hydraulic jack	163 163 165 165 167 170 171 172
Wheels and tires	174
Information on noise or unusual driving characteristics	174
and tires	174
Information on M+S tires	174 175 175 176

Loading the vehicle Tire labeling Information on definitions (tires and loading) Changing a wheel Spare wheel	181 183 186 188 194
Technical data	199 199 199 200 226 228 230 231 233
Display messages and warning and indicator lamps	235 235 252
Index	261

4 Symbols

In these Operating Instructions, you will find the following symbols:

WARNING Danger due to failure to observe the warning notices

Warning notices draw your attention to hazards that may endanger your health or life, or the health or life of others.

Observe the warning notices.

ENVIRONMENTAL NOTE Environmental damage due to failure to observe environmental notes

Environmental notes include information on environmentally responsible behavior or environmentally responsible disposal.

- Observe environmental notes.
- ! NOTE Damage to property due to failure to observe notes on material damage

Notes on material damage inform you of risks which may lead to your vehicle being damaged.

- Observe notes on material damage.
- These symbols indicate useful instructions or further information that could be helpful to you.
- Instructions
- (→ Further information on a topic page)


Display Messages on the display

Highest menu level to be selected in the multimedia/audio system

Corresponding submenus to be selected in the multimedia/audio system


Indicates a cause





High beam → 66 Windshield wipers → 7 Rear window wiper → 7 ② Steering-wheel buttons → 13 ③ DIRECT SELECT lever → 10 ④ Inside rear-view mirror → 8 Digital inside rear-view mirror → 8 Overhead control panel → 7 ⑤ Tachograph ② Sun visor ⑤ Front passenger window lifter → 5 ⑥ Central locking system → 4 ⑥ Stowage compartment cover → 17 ⑥ Radio ② Device installation frame	① Combination switch		
Windshield wipers → 7 Rear window wiper → 7 Rear window wiper → 7 ② Steering-wheel buttons → 13 ③ DIRECT SELECT lever → 10 ④ Inside rear-view mirror → 8 Digital inside rear-view mirror → 8 Overhead control panel → 7 ③ Tachograph ② Sun visor ⑤ Front passenger window lifter → 5 ② Central locking system → 4 ⑥ Stowage compartment cover → 17 ⑥ Radio ② Device installation frame	Turn signal indicators	\rightarrow	69
Rear window wiper → 7 ② Steering-wheel buttons → 13 ③ DIRECT SELECT lever → 10 ④ Inside rear-view mirror → 8 Digital inside rear-view mirror → 8 ⑤ Overhead control panel → 7 ⑥ Tachograph ② Sun visor ⑤ Front passenger window lifter → 5 ② Central locking system → 4 ⑥ Stowage compartment cover → 17 ① Radio ② Device installation frame	High beam	\rightarrow	69
② Steering-wheel buttons → 13 ③ DIRECT SELECT lever → 10 ④ Inside rear-view mirror → 8 Digital inside rear-view mirror → 8 ① Overhead control panel → 7 ④ Tachograph ⑦ Sun visor ⑤ Front passenger window lifter → 5 ② Central locking system → 4 ⑥ Stowage compartment cover → 17 ⑥ Radio ⑥ Device installation frame	Windshield wipers	\rightarrow	77
③ DIRECT SELECT lever → 10 ③ Inside rear-view mirror → 8 Digital inside rear-view mirror → 8 ⑤ Overhead control panel → 7 ⑥ Tachograph ⑦ Sun visor ⑤ Front passenger window lifter → 5 ⑥ Central locking system → 4 ⑥ Stowage compartment cover → 17 ① Radio ② Device installation frame	Rear window wiper	\rightarrow	77
 Inside rear-view mirror → 8 Digital inside rear-view mirror → 8 Overhead control panel → 7 Tachograph Sun visor Front passenger window lifter → 5 Central locking system → 4 Stowage compartment cover → 17 Radio Device installation frame 	② Steering-wheel buttons	\rightarrow	132
Digital inside rear-view mirror → 8 3 Overhead control panel → 7 3 Tachograph 7 Sun visor 8 Front passenger window lifter → 5 9 Central locking system → 4 10 Stowage compartment cover → 17 10 Radio 10 Device installation frame	3 DIRECT SELECT lever	\rightarrow	100
© Overhead control panel → 7 © Tachograph © Sun visor © Front passenger window lifter → 5 © Central locking system → 4 © Stowage compartment cover → 17 Radio © Device installation frame	4 Inside rear-view mirror	\rightarrow	81
 ③ Tachograph ② Sun visor ③ Front passenger window lifter → 5 ④ Central locking system → 4 ⑥ Stowage compartment cover → 17 ⑪ Radio ⑫ Device installation frame 	Digital inside rear-view mirror	\rightarrow	80
 ② Sun visor ③ Front passenger window lifter → 5 ④ Central locking system → 4 ⑥ Stowage compartment cover → 17 ⑪ Radio ⑫ Device installation frame 	(5) Overhead control panel	\rightarrow	71
 ⑤ Front passenger window lifter → 5 ⑥ Central locking system → 4 ⑥ Stowage compartment cover → 17 ⑥ Radio ⑥ Device installation frame 	Tachograph		
 ② Central locking system → 4 ⑥ Stowage compartment cover → 17 ① Radio ② Device installation frame 	Sun visor		
 (a) Stowage compartment cover → 17 (b) Radio (c) Device installation frame 	Front passenger window lifter	\rightarrow	50
Stowage compartment cover Radio Device installation frame	Central locking system	\rightarrow	41
Device installation frame	Stowage compartment cover	\rightarrow	171
	Radio		
♠ Ol'	Device installation frame		
Ulimate control system 8	(ii) Climate control system	\rightarrow	82

(4) Cup holder	\rightarrow	64
115 V socket	\rightarrow	66
6 Key slot for KEYLESS-START	\rightarrow	93
12 V socket	\rightarrow	66
® USB port	\rightarrow	64
Opens and closes the electric sliding door	\rightarrow	45
Start/stop button	\rightarrow	93
Right-hand switch panel		
Activates/deactivates cargo compartment ventilation	\rightarrow	87
② Opens the hood	\rightarrow	155
3 Light switch	\rightarrow	68
Headlamp range adjuster	\rightarrow	69
Adjusts the driver's seat	\rightarrow	58
3 Seat heating	\rightarrow	63
Central locking system	\rightarrow	41
Driver's window lifter	\rightarrow	51




Instrument cluster (example)

i The functions of the existing indicator and warning lamps depend on the equipment.

1 Speedometer	\rightarrow	131
② ₽ ESP®	\rightarrow	253
3 A Distance warning	\rightarrow	259
Seat belt not fastened	\rightarrow	258
5 🗘 🗘 Turn signal light	\rightarrow	69
Display of indicator and warning lamps		
READY Operational readiness of drive system	\rightarrow	93
Condition of charge display for high-voltage battery	\rightarrow	132
Power availability display	\rightarrow	131
Reduced power	\rightarrow	259
Parking brake applied (red)	\rightarrow	253
Brake malfunction	\rightarrow	253
Electrical malfunction	\rightarrow	243
Maximum available output of the drive system	\rightarrow	133
System error	\rightarrow	259

RBS Regenerative brake system	\rightarrow	91
(yellow) Electric parking brake	\rightarrow	253
Tco Tachograph		
🕡 👺 Restraint system	\rightarrow	253
Power steering malfunction	\rightarrow	259
⊕ ☐ High beam	\rightarrow	69
	\rightarrow	68
② → Side lights	\rightarrow	68
High-voltage battery reserve	\rightarrow	259
Fog light	\rightarrow	68
	\rightarrow	68
② (!) Tire pressure monitoring system	\rightarrow	260
(4) ABS malfunction	\rightarrow	253
② Spr ESP® deactivated	\rightarrow	253




53

- me button for service or information calls (breakdown assistance call)
- ② Activates/deactivates → interior protection
- ③ [Yes and the second second
- Switches automatic light control on/off
- Switches the front interior lighting on/off
- Switches rear interior lighting on/off (unassigned, depending on equipment)

- 137 Switches the right-hand reading light on/off
 - (a) Switches the tow-away \rightarrow 53 alarm on/off


 - Sos SOS emergency call but on cover
 137
 - (III) Glasses compartment




Version 2 of the overhead control panel

- 1 Sun visors
- ② X Switches the left-hand reading light on/off
- Switches automatic light control on/off
- Switches the front interior lighting on/off
- Switches rear interior lighting on/off (unassigned, depending on equipment)
- Switches the right-hand reading light on/off

Door operating unit of vehicles with	electrical	ly adj	ustable seat		
Adjusts the outside mirrors	\rightarrow	79	5 M 1 2 3 Operates the mem-	\rightarrow	60
2 🔐 🔒 Unlocks/locks the	\rightarrow	41	ory function		
central locking system			Opens the door	\rightarrow	40
	\rightarrow	63	Opens/closes the right-hand side window	\rightarrow	50
 Adjusts the front seats electronically 	. →	58	Opens/closes the left- hand side window	\rightarrow	50





Checking and topping up operating fluids	\rightarrow	228
High-voltage disconnect device	\rightarrow	90
② Buttons for the SOS emergency call system and Mercedes me connect	\rightarrow	164
3 High-voltage disconnect device at the front in the engine com- partment	\rightarrow	90
4 Hazard warning light system	\rightarrow	70
(5) Vehicle tool kit	\rightarrow	190
6 Jack	\rightarrow	172
• QR code for accessing the rescue card below the lock strikers of the doors on both driver's and front passenger sides	\rightarrow	21

Information label for tire pressure	\rightarrow	176
Warning triangle and emergency medical kit		
Safety vest	\rightarrow	163
First-aid kit (soft-sided)	\rightarrow	163
Flat tire	\rightarrow	165
Further emergency and breakdown devices:		
Spare wheel	\rightarrow	194

Environmental protection

ENVIRONMENTAL NOTE Environmental damage due to operating conditions and personal driving style

Operate your vehicle in an environmentally responsible manner to help protect the environment. Please observe the following recommendations on operating conditions and personal driving style.

Operating conditions:

- Make sure that the tire pressures are correct.
- Do not carry any unnecessary weight (e.g. roof luggage racks once you no longer need them).
- Monitor energy consumption.
- Adhere to the service intervals. A regularly serviced vehicle will contribute to environmental protection.
- Always have maintenance work carried out at a qualified specialist workshop.

Personal driving style:

- Drive carefully and maintain a suitable distance from the vehicle in front.
- Avoid frequent, sudden acceleration and braking.
- Drive in a way that conserves energy. Pay attention to the ECO display for an economical driving style.

ENVIRONMENTAL NOTE Environmental pollution caused by irresponsible disposal of the high-voltage battery

A high-voltage battery contains materials which are harmful to the environment.

Dispose of defective high-voltage batteries at a qualified specialist workshop.

Environmental issues and recommendations

It is recommended that you re-use or recycle materials instead of simply disposing of them.

The relevant environmental guidelines and regulations serve to protect the environment and should be followed carefully.

Mercedes-Benz Genuine Parts

ENVIRONMENTAL NOTE Environmental damage due to not using recycled reconditioned components

Mercedes-Benz AG offers recycled reconditioned components and parts with the same quality as new parts. The same entitlement from the Limited Warranty is valid as for new parts.

- Use recycled reconditioned components and parts from Mercedes-Benz AG.
- NOTE Impairment of the operating efficiency of the restraint systems due to the installation of accessory parts or due to repairs or welding

Air bags and seat belt tensioners as well as control units and sensors for the restraint systems may be installed in the following areas of your vehicle:

- Door frame
- Roof frame
- Doors
- Door pillars
- Door |Sill
- Seats
- Cockpit
- Instrument cluster
- · Center console
- Do not install accessory parts such as audio systems in these areas.
- Do not carry out repairs or welding.
- Have accessories retrofitted at a qualified specialist workshop.

If you use parts, tires, wheels or safety-relevant accessories that have not been approved by Mercedes-Benz, the operating safety of the vehicle may be jeopardized. Safety-relevant systems such as the brake system may malfunction. Only use Mercedes-Benz Genuine Parts or parts of equal quality. Only use tires, wheels and accessory parts that are approved for your vehicle model.

Mercedes-Benz tests original parts, conversion parts and accessory parts that have been approved for your vehicle model for reliability, safety and suitability. Despite ongoing market research, we are unable to assess other parts. We therefore accept no responsibility for the use of such parts in Mercedes-Benz vehicles, even if they have been officially approved or independently approved by a testing center.

In some other countries, certain parts are officially approved for installation or modification only if they comply with legal requirements. All Mercedes-Benz Genuine Parts satisfy these requirements. Make sure that all parts are suitable for your vehicle.

Always specify the vehicle identification number (VIN) and the engine number when ordering Mercedes-Benz Genuine Parts (\rightarrow page 226).

Attachments, add-on equipment, installations and conversions

Notes on body/equipment mounting directives

For safety reasons, have add-on equipment produced and installed in accordance with the valid Mercedes-Benz body/equipment mounting directives. These body/equipment mounting directives ensure that the chassis and add-on equipment form one unit and that the greatest possible level of operational and driving safety is achieved.

Both vehicle manufacturers and body manufacturers must always ensure that the products they manufacture come into circulation only in a safe state and do not pose any risks to people. Otherwise, there may be consequences under civil, criminal or public law. All manufacturers are responsible for the products that they have manufactured. Manufacturers of attachments, add-on equipment, installations and conversions must guarantee compliance with Directive 2001/95/EC on general product safety.

The body manufacturer must also ensure compliance with standards concerning operational reliability (in accordance with ISO 26262) and cyber security (in accordance with ISO 21434 and UN R155).

Mercedes-Benz recommends the following procedure for safety reasons:

- Do not make any other changes to the vehicle.
- Obtain approval from the dealer named on the inside title page in the event of deviations from the approved body/equipment mounting directives.

Acceptance tests performed by public test bodies or official approvals do not rule out safety risks.

Observe the information about Mercedes-Benz Genuine Parts (\rightarrow page 13).

- (i) You can obtain further information at a qualified specialist workshop.
- (i) You can find further information on requesting a check for compatibility with the basic vehicle in the body/equipment mounting directives.
- (i) Structural changes to high-voltage components, high-voltage lines and equipotential bonding lines are not permitted.
- If work is carried out on a vehicle with an electric drive, the country-specific requirements concerning statutory occupational safety and accident prevention regulations must be observed.

★ WARNING Risk of accident and injury in the event of improper conversions or changes to the vehicle

Conversions or changes to the vehicle can prevent systems or components from functioning properly and/or jeopardize the vehicle's operational safety.

 Always have conversions or changes to the vehicle carried out at a qualified workshop.

If you intend to make changes to your vehicle, Mercedes-Benz strongly recommends that you contact the dealer. They will give you all the information you need. There may be a charge for this service.

If body manufacturers and dealers make modifications that affect the final inspection of the engine, vehicle or equipment, they must accept sole responsibility for the vehicle. This also applies to marking and documenting the vehicle parts affected by the changes that they make.

You are responsible for ensuring and providing evidence that the following conditions are met:

- The vehicle complies with all relevant standards and regulations that are affected by the modification.
- The modified vehicle still meets vehicle safety standards and emissions laws and regulations.
- The modification does not impair the safety of the vehicle.

Mercedes-Benz is not responsible for the final inspection, product liability or warranty claims resulting from modification. This applies to the following points:

- · The modified components or systems
- The resultant violation of emissions laws and regulations or vehicle safety standards
- All consequences resulting from the modified, less safe or even faulty vehicle

Mercedes-Benz accepts no responsibility as final manufacturer or for the resultant product liability.

Notes on the cargo floor

The factory equips the vehicle with a wooden or plastic cargo floor; this is an integral part of the vehicle structure. If you have the cargo floor removed, the vehicle body may be damaged. Load securing will then be impaired and the maximum loading capacity of the tie-down points will no longer be guaranteed. Therefore, do not have the cargo floor removed.

Notes on the partition

Without a partition, vehicles that are approved as commercial vehicles (N1, N2) do not fulfill ISO 27956, which describes the equipment for properly securing a load in delivery vehicles. If the vehicle is used to transport goods, retrofitting the partition is strongly recommended, as properly securing the load in vehicles without a partition will always be complex.

Operator's Manual

This Operator's Manual describes all models, as well as standard and optional equipment of your vehicle that was available at the time of going to press. Country-specific differences are possible. Note that your vehicle may not be equipped with all the functions described. This is also the case for systems and functions relevant to safety. Therefore, your vehicle's equipment may differ from that in the descriptions and illustrations.

The original purchase agreement for your vehicle contains a list of all the systems in your vehicle.

Should you have any questions concerning equipment and operation, consult an authorized Mercedes-Benz Center.

 Please bear in mind that all the speed values stated in this Operator's Manual are approximate and are subject to a certain tolerance. The Operator's Manual and Service Booklet are important documents and should be kept in the vehicle.

Note on vehicles that are equipped by body manufacturers

Always observe the body manufacturer's operating instructions. You could otherwise fail to recognize dangers.

Service and vehicle operation

Warranty

The limited warranty for your vehicle is in accordance with the warranty terms and conditions in the Service and Warranty Information booklet.

Your Mercedes-Benz will replace and repair all factory-installed parts in accordance with the terms of the following warranty terms and conditions:

- · New Vehicle Limited Warranty
- State Warranty Enforcement Laws ("Lemon Laws")

Replacement parts and accessories are covered by the Mercedes-Benz Parts and Accessories Warranties.

These are available at any Mercedes-Benz.

(i) Should you lose your Service and Warranty Information booklet, have an Mercedes-Benz arrange for a replacement. The new Service and Warranty Information booklet will be posted to you.

Vehicle operation outside the USA or Canada

If you drive your vehicle abroad, service points or replacement parts may not be available immediately.

Certain Mercedes-Benz models are available in Europe through the European Delivery Program. Please consult a Mercedes-Benz service center for further information, or write to one of the following addresses:

In the USA:

Mercedes-Benz USA, LLC One Mercedes-Benz Drive Sandy Springs, GA 30328

In Canada:

Mercedes-Benz Canada, Inc. 2680 Matheson Blvd E, Suite 400 Mississauga, ON L4W 0A5

Maintenance

Your customer service advisor will record every service for you in the Service and Warranty Information booklet.

Roadside Assistance

Roadside Assistance offers technical help in the event of a breakdown. Your calls to the toll-free Roadside Assistance Hotline are answered by our agents 24 hours a day, 365 days a year.

1-877-762-8267 (USA)

1-800-387-0100 (Canada)

You can find further information in the Roadside Assistance brochure (USA) or the "Roadside Assistance" section in the Service and Warranty Information booklet (Canada). You will find both in the vehicle document wallet.

Change of address or change of ownership

In the event of a change of address, please send us the "Notification of Address Change" in the Service and Warranty Information booklet, or simply call the Customer Assistance Center (USA) on the hotline number 1-877-762-8267 or Customer Service (Canada) on 1-800-387-0100. This will give us the opportunity to get in touch with you as soon as possible when necessary.

If you sell your Mercedes, please leave the entire literature in the vehicle so that it is available to the next owner. If you have purchased a used vehicle, please send us the "Notice of Purchase of Used Car" in the Service and Warranty Information booklet or call the Customer Assistance Center (USA) on the hotline number 1-877-762-8267 or Customer Service (Canada) on 1-800-387-0100.

Possible danger due to substances hazardous to health

In compliance with Proposition 65 ("Prop65"), the following detachable label has been added to each vehicle sold in California:

\triangle

WARNING



Operating, servicing and maintaining a passenger vehicle, pickup truck, van or off-road motor vehicle can expose you to chemicals including engine exhaust, carbon monoxide, phthalates, and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure, avoid breathing exhaust, do not idle the engine except as necessary, service your vehicle in a well-wentilated area and wear gloves or wash your hands frequently when servicing your vehicle. For more information go to www.P65Warnings.ca.gov/passenger-vehicle

Operating safety



WARNING Risk of accident due to malfunctions or system failures

If you do not have the prescribed service/ maintenance work or any required repairs carried out, this could result in malfunctions or system failures.

Always have the prescribed service and maintenance work or any required repairs carried out in a qualified specialist workshop.



WARNING Risk of accident or injury due to incorrect modifications on electronic component parts

Modification of electronic components, their software or wiring could impair their function and/or the function of other networked component parts or safety-relevant systems.

This can endanger the operating safety of the vehicle.

- Never tamper with the wiring and electronic component parts or their software.
- You should have all work on electrical and electronic components carried out at a qualified specialist workshop.

Please observe the "Vehicle electronics" section in the "Technical data".

NOTE Damage to the vehicle caused by driving too fast and by blows to the underbody and chassis parts

The vehicle can be damaged in the following cases in particular:

- The underside of the vehicle makes contact with the ground, e.g. on a high curb or an unpaved road.
- The vehicle drives too quickly over an obstacle, e.g. a curb, a speed bump or a pothole.
- A heavy object hits the underbody or chassis components.

In these or similar situations, the vehicle body, the underbody, chassis components, wheels or tires and parts of the high-voltage battery could be damaged even if this is not visible. Components that have been damaged in this way can fail unexpectedly or, in the event of an accident, may not absorb the loads that arise as intended.

Have the vehicle checked and repaired immediately at a qualified specialist workshop.

or

If driving safety is impaired during the rest of the journey, stop immediately paying attention to the traffic situation and notify a qualified specialist workshop.

An electric vehicle has an electric motor. The electric motor's power supply is provided by the high-voltage on-board electrical system.


▲ DANGER Risk of death and fire due to modified and/or damaged components of the high-voltage on-board electrical system

The vehicle's high-voltage on-board electrical system is under high voltage. If you modify component parts in the vehicle's high-voltage on-board electrical system or touch damaged component parts, you may be electrocuted. In addition, modified and/or damaged components may cause a fire.

In the event of an accident or impact to the underbody, components of the high-voltage electrical system may be damaged although the damage is not visible.

- Never make any modifications to the high-voltage on-board electrical system.
- Do not switch on or use the vehicle if its high-voltage on-board electrical system components have been modified or damaged.
- Never touch damaged components of the high-voltage on-board electrical system.
- After an accident, do not touch any components of the high-voltage on-board electrical system.
- After an accident, have the vehicle transported away.
- Have the components of the high-voltage on-board electrical system checked at a qualified specialist workshop and replaced if necessary.

The components of the vehicle's high-voltage onboard electrical system are marked with yellow warning stickers. The cables of the vehicle's highvoltage on-board electrical system are orange.



Example

High-voltage components that may become very hot are marked with separate warning labels:



Example

Vehicles with an electric motor generate significantly less noise than vehicles with internal combustion engines. As a result, your vehicle may not be heard by other road users in certain situations. This can occur, for example, when you are parking and your vehicle cannot be seen by other road users. In order to allow for the possibility that other road users may behave incorrectly, adopt a particularly anticipatory driving style.

The vehicle is additionally equipped with a sound generator, which serves as an Acoustic Vehicle Alerting System (AVAS) (→ page 90). This safety system is prescribed by law.

The outside sound produced by the sound generator (AVAS) can be heard in the passenger compartment at low speeds and it is not a malfunction.

Declarations of conformity and notes on driving in different countries

Country-specific information for regulatory radio components

Notes when crossing national borders

You must observe the regulatory provisions concerning radio for the country in which you are currently driving when operating the vehicle.



USA: "The wireless devices of this vehicle comply with Part 15 of the FCC Rules. Operation is subject to the following two conditions: 1) These devices may not cause harmful interference, and 2) These devices must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment."

Canada: "The wireless devices of this vehicle comply with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) These devices may not cause interference, and (2) These devices must accept any interference, including interference that may cause undesired operation of the device".

USA: "Wireless charging system for mobile devices (Model: WMI3.5 Wireless Mobile Interface): This Device complies with Part 18 of the FCC Rules."

The name and address of the responsible party is:

Molex CVS

Mizarstraße 3 12529 Schönefeld

Germany

Diagnostics connection

The diagnostics connection is a technical interface in the vehicle. It is used, for example, during repair and maintenance work or for issuing readouts of vehicle data in a specialist workshop. Diagnostic devices should therefore be connected only in a qualified specialist workshop.



WARNING Risk of accident due to connecting devices to the diagnostics connection

If you connect devices to the diagnostics connection of the vehicle, the function of vehicle systems and operating safety may be impaired.

For safety reasons, we recommend that you use and connect only products approved by an authorized Mercedes-Benz Service Center.

A

WARNING Risk of accident due to objects in the driver's footwell

Objects in the driver's footwell may impede pedal travel or block a depressed pedal.


This will jeopardize the operating- and road safety of the vehicle.

- Stow all objects in the vehicle securely so that they cannot get into the driver's footwell.
- Make sure that there is always sufficient clearance for the pedals.
- Always install the floor mats securely and as prescribed.
- Do not use loose floor mats and do not place floor mats on top of one another.
- NOTE Battery discharging from using devices connected to the diagnostics connection

Using devices at the diagnostics connection drains the battery.

- Check the charge level of the battery.
- If the charge level is low, charge the battery.

19



The connection and use of another device on the diagnostics connection can have the following effects:

- · Malfunctions in the vehicle system
- Permanent damage to vehicle components

Please refer to the warranty terms and conditions regarding this.

Qualified specialist workshop

A qualified specialist workshop has the necessary special skills, tools and qualifications to correctly carry out any necessary work on your vehicle. This particularly applies to work relevant to safety.

Always have the following work on the vehicle carried out at a qualified specialist workshop:

- · Safety-relevant works
- Service and maintenance work
- Repair work
- · Modifications as well as installations and conversions
- Work on electronic components
- Work on high-voltage components

Mercedes-Benz recommends that you use an Mercedes-Benz for this purpose.

Vehicle registration

Mercedes-Benz may ask its service centers to carry out technical inspections on certain vehicles. The quality or safety of the vehicles is improved as a result of the inspection.

Mercedes-Benz can only inform you about vehicle checks if itMercedes-Benz has your registration data.

In the following cases, your vehicle may not be registered to you yet:

- · you did not purchase your vehicle at an authorized specialist dealer.
- your vehicle has not yet been inspected at a Mercedes-Benz Service Center.

It is advisable to register your vehicle with a Mercedes-Benz Service Center.

Inform Mercedes-Benz as soon as possible about any change in address or vehicle ownership.

You can do this at a Mercedes-Benz Service Center, for example.

Correct use of the vehicle

If you remove warning stickers, you or others may fail to recognize the dangers. Leave warning stickers in position.

Observe the following information in particular when operating the vehicle:

- Safety notes in these operating instructions
- Technical data for the vehicle
- Traffic rules and regulations of the country in which you are currently located
- Laws pertaining to motor vehicles and safety standards of the country in which you are currently located
- Radio regulations of the country in which you are currently located

Multi-purpose vehicle

WARNING Risk of accident when the center of gravity is too high

The vehicle may start to skid and rollover in the event of sudden steering maneuvers and/or when the vehicle's speed is not adapted to the road conditions.

Always adapt your speed and driving style to the vehicle's driving characteristics and to the prevailing road and weather conditions.



USA



Canada

Utility vehicles have a significantly higher rollover rate than other types of vehicles.

Unsafe operation of the vehicle can result in an accident or rollover, as well as serious or even fatal injuries.

In a rollover crash, an unbelted person is significantly more likely to die than a person wearing a seat belt.

You and all vehicle occupants should always wear seat belts.

Notes for persons with electronic medical aids

Despite meticulous development of their vehicle systems, -Mercedes-Benz AG cannot completely rule out the interaction of vehicle systems with electronic medical aids, suchas cardiac pacemakers.

In addition, there are components built into the vehicle that, regardless of the operating status of your vehicle, can generate magnetic fields on a par with permanent magnets. These fields can be found, forexample, in the area around the multimedia and sound system or also in the seating area, depending on the vehicle equipment.

It is therefore possible for the following to occur in isolated cases, depending on the aids used:

- · medical aids malfunctioning
- adverse health effects

Observe the notes and warnings of the manufacturer of the medical aids; if in doubt, contact the device manufacturer and/or your doctor. If there is continuing uncertainty concerning the possibility of medical aids malfunctioning,-Mercedes-Benz AG recommends using only few electrical vehicle systems and/or maintaining a distance from the components.

When charging the high-voltage battery, keep a distance of at least an arm's length between the medical aid and the following components:

- the power supply equipment
 This includes charging stations in the form of a wallbox or a public charging point, forexample.
- vehicle components carrying live voltage
 This includes the charging cable and the charging control box, forexample.

Have repairs and maintenance work in close proximity to the following components carried out only by a qualified specialist workshop:

- vehicle components carrying live voltage
- transmission aerials
- · multimedia system and sound system

If you have any queries or suggestions, consult a qualified specialist workshop.

Problems with your vehicle

If you experience a problem with your vehicle, particularly one that you believe may affect vehicle safety, please contact a Mercedes-Benz immediately to have the problem diagnosed and rectified.

If the problem is not resolved to your satisfaction, please contact a Mercedes-Benz again or write to one of the following addresses.

In the USA:

Mercedes-Benz USA, LLC Customer Assistance Center One Mercedes-Benz Drive Sandy Springs, GA 30328

In Canada:

Mercedes-Benz Canada, Inc. Customer Assistance Center 2680 Matheson Blvd E, Suite 400 Mississauga, Ontario L4W 0A5

"Reporting safety defects"

For USA only:

The following text is published as required of manufacturers under Title 49, Code of U.S. Federal Regulations, Part 575 pursuant to the "National Traffic and Motor Vehicle Safety Act of 1966".

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Mercedes-Benz Vans, LLC.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Mercedes-Benz Vans, LLC.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to https://www.safe-rcar.gov; or write to: Administrator, NHTSA, 400 Seventh Street, SW., Washington, DC 20590, USA.

You can find more information on vehicle safety on https://www.safercar.gov

For Canada only:

The following text is published as required of manufacturers under subsection 18.4 (4) of the Motor Vehicle Safety Regulations.

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform Transport Canada in addition to notifying Mercedes-Benz Canada Inc.

If Transport Canada received similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, Transport Canada cannot become involved in individual problems between you, your dealer, or Mercedes-Benz Canada Inc.

To contact Transport Canada, you may call the Defect Investigations and Recalls Division toll-free in Canada at 1-800-333-0510 or 819-994-3328 in the Gatineau-Ottawa area or internationally; may also go to the following websites for more information:

• English: www.tc.gc.ca/recalls

• French: www.tc.gc.ca/rappels

Limited Warranty



NOTE Damage to the vehicle arising from violation of these operating instructions.

Damage to the vehicle can arise from violation of these operating instructions.

Such damage is not covered by either the Limited Warranty or the new or used-vehicle warranty.

Observe the instructions in these operating instructions on proper operation of your vehicle as well as regarding possible vehicle damage.

QR codes for rescue card

The QR code stickers are affixed to the B-pillar on the driver's and front passenger side. In the event of an accident, emergency services can use the QR code to quickly determine the corresponding rescue card for your vehicle. The current rescue card contains the most important information about your vehicle in a compact form, e.g. the routing of the electric lines.

Further information is available at: https://rk.mb-gr.com/de/#rescue-sticker

Data storage

Data processing in the vehicle

Electronic control units

Electronic control units are installed in your vehicle. Control units process data they receive from vehicle sensors, forexample, generate themselves or exchange between themselves. Some control units are required for the safe operation of your vehicle. For example, some assist you when driving, suchas driver assistance systems, while others enable functions serving comfort or infotainment.

The following provides you with general information regarding data processing in the vehicle. Additional information regarding which data in your vehicle is collected, saved and transmitted to third parties and for what purpose can be found in the information directly related to the functional characteristics in question in the respective Operator's Manual. This information is available both online and digitally, depending on the vehicle's equipment.

Personal data

A unique vehicle identification number identifies every vehicle. Depending on the country, this vehicle identification number can be used by, forexample, governmental authorities to determine the owner's identity. There are other possibilities for using data collected from the vehicle to identify the owner or driver, suchas the license plate number

Therefore, data generated or processed by control units may be attributable to a person or, under certain conditions, become attributable to a person. Depending on which vehicle data are available, it may be possible to make inferences about, forexample, your driving behaviour, location, route or use patterns.

Legal requirements regarding the disclosure of data

If legally required to do so, manufacturers are legally obliged on a case-by-case basis to provide data stored by the manufacturer to governmental entities, upon request and to the extent required. For example, this may come into effect during the investigation of a criminal offense.

Governmental entities are themselves authorised to read out data from the vehicle in individual cases and within the applicable legal framework. Following an accident, information that can help with an investigation can be taken from the air bag control unit, forexample.

Operational data in the vehicle

Data processed by control units for operation of the vehicle.

This includes the following data, for example:

- Vehicle status information suchas the speed, longitudinal acceleration, lateral acceleration, number of wheel revolutions or the fastened seat belts display
- Ambient conditions, suchas temperature, rain sensor or distance sensor

Generally, these are short-term data and will not be stored beyond the period of operation, and is processed only within the vehicle itself. Control units, forexample vehicle keys, often contain data memories. Their use permits the temporary or permanent documentation of technical information regarding the vehicle's operating state, component loads, maintenance requirements and technical events or malfunctions.

Depending on the technical equipment, the following data are stored:

- Operating status of system components, suchas fill levels, tire pressure or battery status
- Malfunctions or defects in important system components, such as lights or brakes
- System reactions in special driving situations, suchas air bag deployment or the intervention of stability control systems
- Information on events leading to vehicle damage
- State of charge for the high-voltage battery, estimated range

In certain cases, storing data that would have otherwise been temporary may be required. This may be the case if the vehicle has detected a malfunction, forexample.

If you use services suchas repair services and maintenance work, stored operational data and the vehicle identification number can be read out and used as required. They can be read out from the vehicle by service network employees, suchas those working for workshops, manufacturers or third parties (e.g. breakdown services). The same applies for warranty claims and quality assurance measures.

In general, the readout is performed via the legally prescribed port for the diagnostics connection in the vehicle. The operating data read out documents the vehicle's or individual components' technical condition and help to diagnose faults, ensure compliance with warranty obligations and bring about improvements in quality. To that end, this data, and in particular information pertaining to component loads, technical events, malfunctions and other faults may be transmitted along with the vehicle identification number to the manufacturer. Furthermore, the manufacturer is subject to product liability. For this reason, the manufacturer also uses operational data from the vehicle. forexample, for recalls. These data can also be used to examine the customer's warranty and legal guarantee claims.

Fault memories in the vehicle can be reset by a service outlet or at your request as part of repair or maintenance work.

Functions serving comfort and infotainment

You can store the vehicle's settings for comfort and customisations, and can change or reset them at any time.

Depending on the vehicle equipment, this includes the following settings, forexample:

- · Seat and steering wheel positions
- · Suspension tuning and climate control settings
- · Customisation settings, such as interior lighting

Depending on the selected equipment, you can import data into vehicle infotainment functions yourself.

Depending on the vehicle equipment, this includes the following data, forexample:

- Multimedia data, suchas music, films or photos for playback in an integrated multimedia system
- address book data for use in connection with an integrated hands-free system or an integrated navigation system
- · entered navigation destinations
- · data for the use of Internet services

These data for functions serving comfort and infotainment may be saved locally in the vehicle or on a device connected to the vehicle, suchas a smartphone, USB flash drive or MP3 player. Data that you have entered yourself can be deleted at any time.

These data are transmitted only from the vehicle to third parties at your request. This applies in particular when using online services from your own selected settings.

Smartphone integration (e.g. Android Auto or Apple CarPlay®)

If your vehicle is equipped accordingly, you can connect your smartphone or another mobile end device to the vehicle. You can then control them through the control elements integrated into the vehicle. Images and audio from the smartphone can be relayed through the multimedia system. Certain information is simultaneously transferred to your smartphone. Depending on the type of integration, thisincludes position data, day/night mode and other general vehicle statuses. For more information, please consult the Operator's Manual for the vehicle or in the infotainment system.

This integration allows the use of selected smartphone apps, suchas navigation or music player apps. There is no further interaction between the smartphone and the vehicle; in particular effective access to vehicle data. The type of additional data processing is determined by the provider of the app being used. Permissible settings, if any, will depend on the specific app and your smartphone's operating system.

Online services

Wireless network connection

If your vehicle has a wireless network connection, data can be exchanged between your vehicle and other systems. The wireless network connection is made possible by the vehicle's own transmitter and receiver or by a mobile end device that you have brought into the vehicle, forexample, a smartphone. Online functions can be used via this wireless network connection. This includes online services and applications/apps provided to you by the manufacturer or by other providers.

Manufacturer's own services

Regarding the manufacturer's online services, the individual functions are described by the manufacturer in a suitable place, forexample, in the Operator's Manual or on the manufacturer's website, where the relevant data protection information is also given. Personal identification data may be used to provide online services. Data is exchanged via a secure connection, e.g. the manufacturer's designated IT systems. Any personal data which are collected, processed and used, other than for the provision of services, is done so exclusively on the basis of legal permission. This is the case, forexample, for a legally prescribed emergency call system, a contractual agreement or when consent has been given.

You can have services and functions, some of which are subject to a fee, activated or deactivated. This excludes legally prescribed functions and services, such as an emergency call system.

Services of third parties

If you use online services from other providers (third parties), these services are the responsibility of the provider in question and subject to that provider's data protection conditions and terms of use. As a general rule, the manufacturer has no influence on the content exchanged.

For this reason, when services are provided by third parties, please ask the service provider in question for information about the type, extent and purpose of the collection and use of personal data.

Onboard Logic Unit (OLU)

The Onboard Logic Unit (OLU) is available to commercial customers.

It contains control units, including antennas for connection via wireless networks, that permit the

exchange of data between your vehicle and other systems. The control units can be used in conjunction with service provided by a third party. Under certaincircumstances, these services may alter the basic configuration of the vehicle and could affect the performance of certain vehicle functions.

For further information about specific services, read the Operator's Manual of the third-party provider. For further information about the Onboard Logic Unit, consult an authorized Mercedes-Benz Center.

If you, yourself, do not own and are not responsible for the vehicle, you may notknow the current status of the Onboard Logic Unit. For further information concerning the services which are currently active, including any data which may be being processed as defined by the GDPR, please contact the person responsible for the vehicle.

Data protection rights

Depending on the country, the equipment and functions of your vehicle, and the services and service offerings used, you are entitled to different data protection rights. Further information on data protection and your data protection rights can either be found on the manufacturer's website or you will receive this information as part of the various services and service offers. There, you will also find the contact information for the manufacturer and its data protection officer.

At a workshop, for example, with the support of a specialist and possibly for a fee, you can have data read out which is stored only locally in the vehicle.

Event Data Recorders

USA only:

This vehicle is equipped with an event data recorder (EDR). The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an air bag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less.

The EDR in this vehicle is designed to record such data as:

- How various systems in your vehicle were operating:
- Whether or not the driver and passenger safety belts were buckled/fastened;

- How far (if at all) the driver was depressing the accelerator and/or brake pedal; and,
- · How fast the vehicle was traveling.

These data can help provide a better understanding of the circumstances in which crashes and injuries occur. NOTE: EDR data are recorded by your vehicle only if a non-trivial crash situation occurs; no data are recorded by the EDR under normal driving conditions and no personal data (e.g., name, gender, age, and crash location) are recorded. However, other parties, such as law enforcement could combine the EDR data with the type of personally identifying data routinely acquired during a crash investigation.

Access to the vehicle and/or the EDR is needed to read data that is recorded by an EDR, and special equipment is required. In addition to the vehicle manufacturer, other parties that have the special equipment, such as law enforcement, can read the information by accessing the vehicle or the EDR.

EDR data may be used in civil and criminal matters as a tool in accident reconstruction, accident claims, and vehicle safety. Since the Crash Data Retrieval CDR tool that is used to extract data from the EDR is commercially available, Mercedes-Benz Vans, LLC ("MBV") expressly disclaims any and all liability arising from the extraction of this information by unauthorized Mercedes-Benz personnel.

MBV will not share EDR data with others without the consent of the vehicle owners or, if the vehicle is leased, without the consent of the lessee. Exceptions to this representation include responses to subpoenas by law enforcement; by federal, state or local government; in connection with or arising out of litigation involving MBV or its subsidiaries and affiliates; or, as required by law.

Warning: The EDR is a component of the Restraint System Module. Tampering with, altering, modifying or removing the EDR component may result in a malfunction of the Restraint System Module and other systems.

State laws or regulations regarding EDRs that conflict with federal regulation are pre\-empted. This means that in the event of such conflict, the federal regulation governs. As of February 2013, 13 states have enacted laws relating to EDRs.

Copyright

Free and open source software

Information on licenses for free and open-source software used in your vehicle can be found on the

data storage medium in your vehicle document wallet and with latest updates on the following website:

https://www.mercedes-benz.com/opensource

Registered trademarks

- Bluetooth® is a registered trademark of Bluetooth SIG Inc.
- DTS™ is a registered trademark of DTS, Inc.
- Dolby[®] and MLP™ are registered trademarks of DOLBY Laboratories.
- ESP® and PRE-SAFE® are registered trademarks of Mercedes-Benz Group AG.
- HomeLink[®] is a registered trademark of Gentex Corporation.
- iPod[®] and iTunes[®] are registered trademarks of Apple Inc.
- Burmester® is a registered trademark of Burmester Audiosysteme GmbH.
- Microsoft[®] and Windows Media[®] are registered trademarks of Microsoft Corporation.
- SiriusXM[®] is a registered trademark of Sirius XM Radio Inc.
- HD Radio[™] is a registered trademark of iBiquity Digital Corporation.
- Gracenote[®] is a registered trademark of Gracenote, Inc.
- ZAGAT Survey[®] and related brands are registered trademarks of Zagat Survey, LLC.

Brief overview of most important points

Basic information

Make sure that the following prerequisites in particular have been met, so that the components of the restraint system are able to provide the intended level of protection:

- Sit correctly (→ page 26).
- Fasten the seat belt correctly (\rightarrow page 27).
 - Function of the $\boxed{\clubsuit}$ seat belt warning lamp (\rightarrow page 28).
- The prestraint system warning lamp has not gone out after the self-test (→ page 28).

For clear understanding

The chapter "Occupant safety" includes information on equipment, functions and behaviors that contribute directly to safety of vehicle occupants.

The information is structured as follows:

- The most important information in brief: in this chapter, you are provided with an overview of the relationship between the restraint system and the correct behavior of all vehicle occupants.
- Specific information: in further sections of the chapter "Occupant safety", you can find specific information on the equipment and functions of the restraint system.
- Keyword directory: you can also find certain subjects in this Operator's Manual using the keyword directory.

Information on the following subjects, amongothers, is not provided in the chapter "Occupant safety":

- Children in the vehicle (→ page 34)
- Driving and driving safety systems (→ page 113)
- Stowage areas (→ page 148)

Defining generic terms clearly

In this Operator's Manual, the following generic terms are used:

- Occupant safety: comprises the components and system functions which help to minimize, as much as possible, the stresses on and consequences for vehicle occupants during an accident.
- Restraint system: comprises those components which, along with the vehicle structure, help prevent vehicle occupants from potentially

- coming into contact with parts of the vehicle interior. The seat belts and air bags, for example, are components of the restraint system.
- Child restraint system: you can find all information on this subject in the chapter "Children in the vehicle" (→ page 34).

Be diligent

For the components of the restraint system to provide the intended level of protection, it is essential that you are seated correctly and that the seat belt is correctly secured.

Bear in mind that negligence when adjusting your sitting position and fastening the seat belt can have serious consequences. Be diligent and make sure before starting every journey that all vehicle occupants are sitting correctly and have fastened their seat belts properly.

Information on the correct seat position

The seat position must be correct in order for the components of the restraint system to provide the intended level of protection.

The seat position influences both the protection provided by the seat belt and the additional protection provided by the air bag.

A correct seat position in which the seat is nearly perfectly upright and a correctly fastened seat belt reduce the risks posed by the air bag when it is deployed.



WARNING Risk of injury or death due to an incorrect seat position

If you deviate from the correct seat position, the air bag cannot provide its intended protective function.

Each vehicle occupant must make sure of the following.

- ▶ Put the seat in the correct position.
- ➤ Fasten seat belts correctly. Pregnant women must take particular care to ensure that the lap belt never lies across the abdomen.
- Observe the following information.

In order for the restraint system to provide the intended level of protection, observe the following information:

 Before starting your journey, adjust your seat correctly (→ page 55). When doing so, make sure you are able to fasten your seat belt correctly. The shoulder belt strap must be routed forward from the seat belt outlet over the center of your shoulder.

- Keep your distance from the air bags, especially the front air bags. Set the driver's seat and co-driver seat as far back as possible while making sure the seat belt is fastened correctly.
- Make sure there are no people, animals or objects between the vehicle occupants and an air bag.
- If you are the driver, observe the following information on the correct position of the driver's seat (→ page 55).
 - Hold the steering wheel only by the steering wheel rim. This allows the driver's air bag to fully deploy.
- Assume a nearly upright sitting posture, with your buttocks positioned as far back as possible in the gap between the seat cushion and the seat backrest.
 - Your back must lie as flatly and as firmly as possible against the seat backrest.
- While driving, do not lean forward and do not lean against the door or side window. You may otherwise be in the deployment area of the air bags.
- Sit with their feet resting on the floor, if possible. Your thighs are slightly supported by the seat cushion.
 - Do not put your feet on the cockpit, for example. Your feet may otherwise be in the deployment area of the air bag.
- · Fasten the seat belt correctly.

Notes on wearing the seat belt correctly

Always fasten your seat belt correctly before starting a journey. Only a seat belt that is worn correctly can provide the intended level of protection.

WARNING Risk of injury or death due to incorrectly fastened seat belt

If the seat belt is not worn correctly, it cannot perform its intended protective function.

In addition, an incorrectly fastened seat belt can also cause injuries, for example, in the event of an accident or when braking or changing direction suddenly. Always ensure that all vehicle occupants have their seat belts fastened correctly and are sitting properly.

WARNING Risk of injury or death when additional restraint systems are not used for persons with a smaller stature

Persons under 5 ft (1.50 m) tall cannot wear the seat belt correctly without a suitable additional restraint system.

 Always secure persons under 5 ft (1.50 m) tall in a suitable restraint system.

Each vehicle occupant must observe the following notes in particular:

- · The seat belt must not be twisted.
- The shoulder belt strap must be routed forward from the seat belt outlet over the center of your shoulder.
- The shoulder belt strap should neither touch your neck nor be routed under your arm or behind your back.
- The lap belt must be routed as low down across the hips as possible.
 - In addition, push the lap belt down as far as possible across your hips and pull tight with the shoulder belt strap. Never route the lap belt across your abdomen.
 - Pregnant women must also take particular care with this.
- After being tightened, the shoulder belt strap and lap belt must fit snugly against the body.
- Avoid wearing bulky clothing, e.g. a winter coat.
- Never route the seat belt across sharp, pointed, abrasive or fragile objects.
- Only one person should use each seat belt at any one time.
- Never secure objects with a seat belt if the seat belt is being used by one of the vehicle's occupants.

Also ensure that no objects, e.g. a cushion, are ever placed between a person and the seat.

Fastening and adjusting seat belts

If the seat belt is pulled quickly or sharply, the seat belt retractor locks. The seat belt strap cannot be pulled out any further.



- Always engage the seat belt tongue ① of the seat belt into the seat belt buckle ② of the corresponding seat.
- ➤ To adjust the seat belt height: press button ③
 on the seat belt outlet and slide the seat belt
 outlet to the desired position.
- NOTE Deployment of components of the restraint system when the front passenger seat is unoccupied and a seat belt is buckled

When the front passenger seat is unoccupied and the seat belt tongue of the seat belt is engaged in the seat belt buckle, components of the restraint system may deploy unnecessarily on the front passenger side, e.g. the Emergency Tensioning Device.

- Only buckle the seat belts as intended.
- (i) Observe the information on the special seat belt retractor of the seat belt (→ page 36).

Function of the restraint system warning lamp

When the vehicle is switched on, a self-test is performed, during which the restraint system warning lamp [37] lights up. It goes out no later than a few seconds after the vehicle is started. The components of the restraint system are then functional.

A malfunction has occurred in the restraint system in the following cases:

- The restraint system warning lamp does not light up or lights up continuously when the vehicle is switched on.
- The restraint system warning lamp lights up continuously or repeatedly during a journey.

If components of the restraint system have been deployed, the restraint system warning lamp [37] lights up continuously.

WARNING Risk of injury due to malfunctions in the restraint system

Components in the restraint system may be activated unintentionally or not deploy as planned in an accident.

Have the restraint system checked and repaired immediately at a qualified specialist workshop.

If the restraint system is malfunctioning, the automatic high-voltage emergency shutoff may not function.

▲ DANGER Risk of fatal injuries due to malfunctions of the automatic high-voltage emergency shutoff

In the event of an accident, the high-voltage on-board electrical system may not be deactivated as intended.

You may be electrocuted if you touch the damaged component parts of the high-voltage onboard electrical system.

- Have the automatic high-voltage emergency shutoff checked and repaired immediately at a qualified specialist workshop.
- After an accident, switch off the vehicle immediately.

Mercedes-Benz recommends that you have the vehicle towed to a qualified specialist workshop.

Function of the seat belt warning lamp

The seat belt warning lamp in the instrument cluster display reminds you that all vehicle occupants must fasten their seat belts correctly.

The _______ seat belt warning lamp lights up for six seconds each time the vehicle is switched on.

A warning tone may also sound.

After the vehicle is started, the seat belt warning goes out as soon as the driver's and the front passenger's seat belts are fastened.

While driving, the seat belt warning lights up in the following cases:

- if the vehicle's speed is higher than 15 mph (25 km/h) and the driver's or front passenger's seat belt is not fastened
- if the driver or front passenger unfastens their seat belt during the journey

Information on the child restraint system

When installing a child restraint system, observe the notes in "Children in the vehicle" $(\rightarrow page 34)$.

Notes on the child restraint system on the front passenger seat

A

WARNING Risk of injury or fatal injuries if the front passenger air bag is enabled

If the front passenger air bag is enabled, a child on the front passenger seat may be struck by the front passenger air bag in the event of an accident.

NEVER use a rearward-facing child restraint system on a seat with an ENA-BLED FRONT AIR BAG. This can result in the DEATH of or SERIOUS INJURY to the CHILD.

Also pay particular attention to the notes on rearward-facing or forward-facing child restraint systems on the front passenger seat (\rightarrow page 36).

Information on the automatic functions of the restraint system

Overview of the automatic measures after an accident

Depending on the type and severity of the accident, and depending on the vehicle's equipment, the following measures can be implemented, for example:

- · automatic braking (post-collision brake)
- · activating the hazard warning lights
- triggering an automatic emergency call
 (→ page 163)
- switching off the drive system and high-voltage on-board electrical system

- · unlocking the vehicle doors
- · lowering the front side windows
- · switching on the interior lighting

Function of the post-collision brake after an accident

Function of the post-collision brake

Depending on the accident situation, the post-collision brake can minimize the severity of a further collision or even avoid it.

If an accident has been detected, the post-collision brake can implement automatic braking. When the vehicle has come to a standstill, the electric parking brake is automatically applied.

The driver can cancel automatic braking by taking the following actions:

- · braking more strongly than automatic braking
- fully depressing the accelerator pedal with force

Purpose and function of the restraint system Overview of deployment situations (restraint system)

Make sure that the following prerequisites in particular have been met, so that the components of the restraint system are able to provide the intended level of protection:

- Sit correctly (→ page 26).
- Fasten the seat belt correctly (→ page 27).
 - Function of the seat belt warning lamp $(\rightarrow page 28)$.
- The page 28).

Depending on the detected deployment situation, the components of the restraint system can be activated or deployed independently of one another:

- Emergency Tensioning Device: frontal impact, rear impact, side impact, overturning, rollover
- Driver's air bag, front passenger air bag: frontal impact
- · Side air bag: side impact
- Window air bag: side impact, overturning, rollover, frontal impact

The installation location of an air bag is identified by the symbol AIRBAG (\rightarrow page 33).

Observe the information on the function of the restraint system (\rightarrow page 30).

Information on how the restraint system works

How the restraint system functions depends on the severity of the impact detected and the apparent type of accident.

For more information about types of accidents, see "Overview of deployment situations" $(\rightarrow page 29)$.

The activation thresholds for the components of the restraint system are determined based on the evaluation of the sensor values measured at various points in the vehicle. This process is pre-emptive in nature. The triggering/deployment of the components of the restraint system must take place in good time at the start of the collision.

Factors that can be seen and measured only after a collision has occurred do not play a decisive role in the deployment of an air bag, nor do they provide an indication of air bag deployment.

The vehicle may be deformed significantly without an air bag being deployed. This is the case if only parts that are relatively easily deformed are affected and the rate of vehicle deceleration is not high. Conversely, an air bag may be deployed even though the vehicle suffers only minor deformation. If very rigid vehicle parts, such as longitudinal members, are hit, the vehicle deceleration may be high enough for this to happen.

Depending on the apparent type of accident and the detected deployment situation, Emergency Tensioning Devices and/or air bags supplement the protection offered by a correctly worn seat belt.

Vehicles with a front passenger bench seat: the Emergency Tensioning Device on the front passenger seat is triggered whether or not the seat belt tongue is engaged in the seat belt buckle.

When enabled, an air bag can provide additional protection for the respective vehicle occupant.

Possible protection per air bag:

- Driver's air bag, front passenger air bag: head and ribcage
- Window curtain air bag: head
- · Side impact air bag: ribcage and pelvis

However, no system available today can completely eliminate injuries and fatalities in every accident situation. In particular, the seat belt and air bag generally do not protect against objects penetrat-

ing the vehicle from the outside. It is also not possible to completely rule out the risk of injury caused by the air bag deploying.

Mercedes-Benz recommends that you have the vehicle towed to a qualified specialist workshop after an accident. Take this into account, particularly if a Emergency Tensioning Device is triggered or an air bag deployed.

If the Emergency Tensioning Devices are triggered or an air bag is deployed, you will hear a bang, and a small amount of powder may also be released:

- The bang will not generally affect your hearing.
- In general, the powder released is not hazardous to health but may cause short-term breathing difficulties to persons suffering from asthma or other pulmonary conditions.

Provided it is safe to do so, leave the vehicle immediately or open the window in order to prevent breathing difficulties.

Air bags and pyrotechnic Emergency Tensioning Devices contain perchlorate material, which may require special handling or environmental protection measures. National guidelines regarding waste disposal must be observed. In California see https://dtsc.ca.gov/. You can use the search function to find information on perchlorate, for example.

Information on the limited protection provided by the restraint system

Risk due to incorrect behavior by vehicle occupants

Every vehicle occupant must make sure of the following in particular:

- They observe the information on the correct seat position (→ page 26).
- There are no heavy, sharp-edged or fragile objects in the pockets of their clothing. Store such objects in a suitable place.

WARNING Risk of injury or death due to an incorrect seat position

The seat belt does not offer the intended level of protection if you have not moved the seat backrest to an almost vertical position.

In particular, you could slip beneath the seatbelt and become injured.

Adjust the seat properly before beginning your journey.

Always ensure that the seat backrest is in an almost vertical position and that the shoulder belt is routed across the center of your shoulder.

Risk due to objects in the vehicle interior

Every vehicle occupant must make sure of the following in particular:

- They observe the information on the correct seat position (→ page 26).
- There are no objects between the seat, door and door pillar (B-pillar).
- There are no hard objects, e.g. coat hangers, hanging on the grab handles or coat hooks.
- There are no heavy, sharp-edged or fragile objects in the pockets of your clothing. Store such objects in a suitable place.

▲ WARNING Risk of injury or death due to blocked seat belt buckle or seat belt anchorage

Objects next to the front seat that block the seat belt buckle or the moving seat belt anchorage on the front seat impair the function of the Emergency Tensioning Devices.

Before starting the journey, make sure that there are no objects around the seat belt buckle or between the front seat and door.

WARNING Risk of injury from objects in the deployment area of an airbag

Objects in the deployment area of an airbag can hinder or prevent the correct deployment of the airbag.

The airbag may then deploy in an uncontrolled manner and may even cause additional injuries to the vehicle occupants by deploying. This may be the case in particular if the airbag is integrated into the seat.

- Always stow and secure objects correctly.
- Before commencing your journey, make sure that no objects are stowed in the deployment area of an airbag.

The installation location of an air bag is identified by the AIRBAG symbol (\rightarrow page 33).

Risk due to installation of accessories

Do not attach accessories such as mobile navigation devices, mobile phones or cup holders within the deployment area of an air bag, e.g. on the cockpit, on the door, on the side window or on the side trim.

In addition, no connecting cables, tensioning straps or retaining straps may be routed or attached to the vehicle within the deployment area of an air bag. Always comply with the accessory manufacturer's installation instructions and, in particular, the notes on suitable places for installation.

WARNING Risk of injury or death due to unsuitable protective covers

Unsuitable protective covers mean that air bags can no longer protect vehicle occupants as they are designed to do.

Use only protective covers approved by Mercedes-Benz for the seat in question.

Risk due to pets in the vehicle interior

WARNING Risk of accident and injury due to animals left unsecured or unattended in the vehicle

If you leave animals in the vehicle unattended or unsecured, they could possibly press buttons or switches.

An animal may:

- Activate vehicle equipment and become trapped, for example
- Switch systems on or off and endanger other road users

Unsecured animals may be thrown around in the vehicle in the event of an accident or sudden steering and braking maneuvers and injure vehicle occupants in the process.

- Never leave animals in the vehicle unattended.
- Always correctly secure animals while driving, e.g. using a suitable animal carrier.

Risk due to modification, damage or wear to the components of the restraint system

A

WARNING Risk of injury or death due to modifications to the restraint system

Vehicle occupants may no longer be protected as intended if alterations are made to the restraint system.

- Never alter the parts of the restraint system
- Never tamper with the wiring or any electronic component parts or their software.

If it is necessary to adjust the vehicle to accommodate a person with physical disabilities, contact an authorized Mercedes-Benz Center for details.

USA only: for further information contact our Customer Assistance Center at 1-800-FOR-MERCedes (1-800-367-6372).

A

WARNING Risk of injury or death due to damaged or modified seat belts

Seat belts cannot provide protection in the following situations:

- The seat belt is damaged, has been modified, is extremely dirty, bleached or dyed
- The seat belt buckle is damaged or extremely dirty
- Modifications have been made to the Emergency Tensioning Device, seat belt anchorage or seat belt retractor

Seat belts may sustain non-visible damage in an accident, e.g. due to glass splinters.

Modified or damaged seat belts could tear or fail in the event of an accident, for example.

Modified Emergency Tensioning Devices could accidentally trigger or fail to function as intended.

- Never modify the seat belt system, for example the seat belt, seat belt buckle, Emergency Tensioning Device, seat belt anchorage and seat belt retractor.
- Make sure that the seat belts are undamaged, not worn and clean.
- Always have the seat belts checked immediately after an accident at a qualified specialist workshop.

Only use seat belts which have been approved for your vehicle by Mercedes-Benz.

A

WARNING Risk of injury due to modifications to the cover of an airbag

If you change the cover of an airbag or attach objects, e.g. even stickers, to it, the airbag may no longer function as intended.

- Never modify the cover of an airbag.
- ▶ Do not attach any objects to the cover.

The installation location of an air bag is identified by the air bag symbol (\rightarrow page 33).



WARNING Risk of injury due to malfunctioning sensors in the door

The function of the airbags can be impaired due to modifications or incorrect work performed on the doors or door trim, or if the doors are damaged.

- Never modify the doors or parts of the
- Always have work on the doors or door trim carried out at a qualified specialist workshop.

Risk due to components of the restraint system that have already been deployed

Mercedes-Benz recommends that you have the vehicle towed to a qualified specialist workshop after an accident.



WARNING Risk of burns from hot air bag components

The air bag parts are hot after an air bag has been deployed.

- Do not touch the air bag parts.
- Have a deployed air bag replaced at a qualified specialist workshop as soon as possible.



WARNING Risk of injury due to deployed airbag

A deployed airbag no longer offers any protection.

Have the vehicle towed to a qualified specialist workshop in order to have the deployed airbag replaced.

Have deployed air bags replaced immediately.

WARNING Risk of injury or death from deployed pyrotechnic Emergency Tensioning Devices

Pyrotechnic Emergency Tensioning Devices that have been deployed are no longer operational and are unable to perform their intended protective function.

Therefore, have deployed pyrotechnic Emergency Tensioning Devices immediately replaced at a qualified specialist workshop.

Seat belts

Unfastening the seat belts


- Press the release button on the seat belt buckle and guide the seat belt back with the seat belt tongue.
- ! NOTE Damage caused by trapping the seat belt

If an unused seat belt is not fully retracted, it may become trapped in the door or in the seat mechanism.

Always ensure that an unused seat belt is fully retracted.

Airbags

Overview of air bags



- Oriver's air bag
- Window curtain air bag
- 3 Co-driver air bag
- Side impact air bag

The installation location of an air bag is identified by the AIRBAG symbol.

Observe the information in "Overview of deployment situations" (\rightarrow page 29).

Brief overview of most important points

Carrying children safely in the vehicle

Always observe the following when carrying chil-

- · Never leave children unattended in the vehicle $(\rightarrow page 34)$.
- Secure children of less than 5 ft (1.50 m) in height or under 12 years of age properly in the appropriate seat with a suitable and approved child restraint system and secure infants in a rear-facing child restraint system.
- · Observe the child restraint system manufacturer's installation instructions.

Front passenger seat

Attachment system:



Seat belt on vehicle seat (\rightarrow page 37)

Important safety notes

Basic information

Be diligent

Bear in mind that negligence when securing a child in the child restraint system can have serious consequences. Always be diligent and secure a child carefully before each journey.

Infants and children must never travel sitting on the lap of a vehicle occupant.

To improve protection for children under 12 years of age or less than 5 ft (1.50 m) in height, Mercedes-Benz recommends that you make sure you observe the following information:

- Always secure the child in a child restraint system suitable for this Mercedes-Benz vehicle.
- The child restraint system must be appropriate to the age, weight and size of the child.
- . The vehicle seat must be suitable for the child restraint system to be installed:
 - ISOFIX mounting bracket
 - Securing with the seat belt on the vehicle

The generic term child restraint system

The generic term child restraint system is used in this Operator's Manual. A child restraint system can be e.g.:

- · an infant carrier
- a rear-facing child seat

- · a front-facing child seat
- a child booster seat Mercedes-Benz recommends using a child booster seat with a seat backrest and seat belt guide

Observe laws and regulations

Always observe the legal requirements when using a child restraint system in the vehicle.

Securing systems for child restraint systems in the vehicle

Only use the following securing systems for child restraint systems:

· the seat belt system of the vehicle

A booster seat may be necessary to achieve proper seat belt positioning for children over 40 lbs (18 kg) in weight or until they reach a height where a three-point seat belt can be installed properly without a booster seat.

Mercedes-Benz recommends a child booster seat with a backrest and seat belt guides.

Observe standards for child restraint systems

All child restraint systems must meet the following standards:

- U.S. Federal Motor Vehicle Safety Standards
- Canadian Motor Vehicle Safety Standards 213

Confirmation that the child restraint system complies with the standards can be found on an information label on the child restraint system. This confirmation can also be found in the installation instructions that are included with the child restraint system.

Important warning notices

Always secure a child restraint system correctly

WARNING Risk of injury or death due to incorrect installation of the child restraint system

The child can then not be protected or restrained as intended.

- Be sure to comply with the manufacturer's installation instructions for the child restraint system and its correct use.
- Make sure that the entire base of the child restraint system always rests on the sitting surface of the seat.

- Never place objects (e.g. cushions) under or behind the child restraint system.
- Use child restraint systems only with the original cover designed for them.
- Always replace damaged covers with genuine covers.
- Always observe the vehicle-specific information.
 - Securing a child restraint system with the seat belt (→ page 37).
- Observe the warning labels in the vehicle interior and on the child restraint system.

▲ WARNING Risk of injury or death due to unsecured child restraint systems in the vehicle

If the child restraint system is incorrectly mounted or unsecured, it may come loose.

The child can then not be protected or restrained as intended.

Unused child restraint systems could be flung around and hit vehicle occupants.

- Always comply with the manufacturer's installation instructions for the child restraint system and its correct use.
- Always fit child restraint systems correctly, even if they are transported in the vehicle unused.

Do not modify the child restraint system

WARNING Risk of injury due to modifications to the child restraint system

The child restraint system can no longer function properly. This poses an increased risk of injury.

- Never modify a child restraint system.
- Only affix accessories which have been specially approved for this child restraint system by the child restraint system's manufacturer.

Only use child restraint systems which are in proper working condition

A

WARNING Risk of injury or death caused by the use of damaged child restraint systems.

Child restraint systems or their retaining systems that have been subjected to stress in an accident may not be able to perform their intended protective function.

It may be the case that the child cannot be properly restrained.

- Always immediately replace child restraint systems that have been damaged or involved in an accident.
- Have the securing systems for the child restraint systems checked at a qualified specialist workshop before installing a child restraint system again.

Avoid direct sunlight

A WADNING Diek o

WARNING Risk of burns when the child seat is exposed to direct sunlight

If the child restraint system is exposed to direct sunlight or heat, parts could heat up excessively.

Children could suffer burns from these parts, particularly the metallic parts of the child restraint system.

- Always make sure that the child restraint system is not exposed to direct sunlight.
- Cover the child restraint system with a blanket, for example.
- If the child restraint system has been exposed to direct sunlight, allow it to cool before securing a child into it.
- Never leave children unattended in the vehicle.

Observe when stopping or parking

WARNING Risk of fatal injury due to exposure to extreme heat or cold in the vehicle

If persons, particularly children, are subjected to prolonged exposure to intense heat or cold, there is a risk of severe injury or even death.

Never leave persons, particularly children, unattended in the vehicle.

WARNING Risk of accident and injury due to children left unattended in the vehicle

If you leave children unattended in the vehicle, they could, in particular:

- open doors, thereby endangering other persons or road users.
- · get out and be struck by oncoming traffic.
- operate vehicle equipment and become trapped, for example.

In addition, the children could also set the vehicle in motion by, for example:

- · releasing the parking brake.
- · changing the gearbox position.
- · starting the vehicle.
- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the key with you and lock the vehicle.
- ► Keep the key out of reach of children.

Notes on rearward-facing child restraint systems on the front passenger seat

The front passenger air bag cannot be deactivated. Never install a rearward-facing child restraint system on the front passenger seat. Observe the manufacturer's installation and operating instructions for the child restraint system.

Securing the child restraint system

Adjusting the seat correctly

- Depending on the vehicle equipment, always observe the following when installing a belt-secured child restraint system on the front passenger seat:
- When using a front-facing child restraint system with integrated child seat belt: remove the head restraint from the respective seat, if possible. After the child restraint system has been removed, immediately replace the head restraint and adjust correctly.
- The backrest of the front-facing child restraint system must, as far as possible, be resting against the seat backrest of the front passenger seat.

- Do not wedge the child restraint system between the roof and the seat surface and/or install it facing the wrong direction.
- Adjust the vehicle head restraints so that the child restraint system is not put under strain by the head restraint.
- Never place objects (e.g. cushions) under or behind the child restraint system.
- Set the front passenger seat as far back as possible and move the seat into the highest position possible. Always make sure that the shoulder belt strap is correctly routed from the seat belt outlet of the vehicle to the shoulder belt guide on the child restraint system. The shoulder belt strap must be routed forwards from the seat belt outlet and, where possible, downwards to the child restraint system.
- Fully retract the seat cushion length adjustment
- Set the seat cushion inclination in such a way that the front edge of the seat cushion is in the highest position and the rear edge of the seat cushion is in the lowest position.
- Set the seat backrest to the most vertical position possible.

Activating or deactivating the special seat belt retractor



WARNING Risk of injury or death if a seat belt is unfastened while the vehicle is in motion

If the seat belt is released while the vehicle is in motion, the special seat belt retractor is deactivated and the child restraint system is no longer correctly secured. The seat belt is drawn in slightly by the inertia reel and cannot be immediately closed again.

- Stop the vehicle immediately in accordance with the traffic conditions.
- Activate the special seat belt retractor again and correctly secure the child restraint system.

When activated, the special seat belt retractor ensures that the seat belts of the front passenger seat do not slacken once the child restraint system is secured.

Installing a child restraint system

When installing a child restraint system, always observe the manufacturer's installation and

- operating instructions for the child restraint system used, as well as the notes in this Operator's Manual.
- Pull the seat belt smoothly from the seat belt
- Engage the seat belt tongue in the seat belt buckle.

Activating the special seat belt retractor

- Extend the seat belt fully and then allow the inertia reel to retract the belt. When the special seat belt retractor is activated, you should hear a ratcheting sound.
- Push the child restraint system down until the seat belt is tight.

Deactivating the special seat belt retractor

- Press the release button of the seat belt buckle.
- Hold the seat belt tongue and guide it back to the seat belt outlet.

Securing the child restraint system with the seat helt

The seat belts on the following seats are equipped with a child seat safety feature:

· Front passenger seat

When enabled, the child seat safety feature ensures that the seat belts of the front passenger seat do not slacken once the child restraint system is secured.

- Install the child restraint system. The entire base of the child restraint system must always rest on the sitting surface of the seat.
- Always make sure that the shoulder belt strap is correctly routed from the seat belt outlet of the vehicle to the shoulder belt guide on the child restraint system.
 - The shoulder belt strap must be routed forwards from the seat belt outlet and, where possible, downwards to the child restraint system.
- If necessary, adjust the seat belt outlet and the front passenger seat as appropriate.

SmartKey

Notes on radio connections of the key

▲ DANGER Risk of fatal injury to persons with medical devices due to electromagnetic radiation when using the start/stop button


Persons with medical devices, e.g. pacemakers or defibrillators:

There is a radio connection between the key and the vehicle.

The function of a medical device can be impaired.

Before operating the vehicle, consult your doctor or the manufacturer of the medical device about any possible effects from such systems.

Detection range of the KEYLESS-START function antenna



Position of the key holder when the detection range of the antenna is reduced

Overview of SmartKey functions


WARNING Risk of accident and injury if children are left unattended in the vehicle

If children are left unattended in the vehicle, they could in particular:

- open doors, thereby endangering other persons or road users.
- get out and be struck by oncoming traffic.
- operate vehicle equipment and become trapped, for example.

In addition, the children could also set the vehicle in motion, for example by:

- · releasing the parking brake.
- changing gear.
- · starting the vehicle.
- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- ► Keep the SmartKey out of the reach of children.
- I NOTE Damage to the SmartKey caused by magnetic fields
- Keep the SmartKey away from strong magnetic fields.



- 1 To lock
- Battery indicator light
- To unlock
- To unlock the cargo compartment (sliding doors and rear-end doors)/to unlock and open/close the electric sliding doors
- 6 Emergency key

The SmartKey's factory setting enables you to centrally lock and unlock the following components:

- The driver's and front passenger door
- · The sliding doors
- The rear-end doors
- i If you do not open the vehicle within approximately 40 seconds of unlocking it, the vehicle will lock again and anti-theft protection will be armed again.

Do not keep the SmartKey together with electronic devices or metallic objects. This can affect the SmartKey's functionality.

i) If the indicator lamp does not light up when you press the o button, the battery is discharged.

Replace the SmartKey battery (\rightarrow page 39).

Changing the unlocking settings

The key has the following adjustable unlocking functions:

- unlock the vehicle centrally
- unlock the driver's door (vehicles without partition or with cab)
- unlock the driver's door and front passenger door (vehicles with partition)
- ➤ To switch between settings: press and hold the and buttons at the same time for approximately six seconds until the indicator lamp flashes twice.
- ➤ To unlock the vehicle centrally when the unlocking function is selected for the driver's door or the driver's and front passenger door: press the → button a second time.

Reducing the energy consumption of the SmartKey

Deactivating SmartKey function

If you do not use the vehicle or a SmartKey for an extended period of time, you can also deactivate the function of the SmartKey to reduce its energy consumption.

- Press and hold the button on the Smart-Key.
- With the button held down, immediately press the button on the SmartKey twice in quick succession.


The SmartKey's indicator light will light up once briefly and once for a long time.

Deactivating SmartKey function

- Press any button on the SmartKey.
- The SmartKey function will automatically be activated when the vehicle is started with the SmartKey in the gearshift console slot (→ page 93).

Removing and inserting the mechanical key

Removing



- Press release button ②.
 Emergency key ① is pushed slightly out.
- ▶ Pull mechanical key ① out completely.

Inserting

- Press release button 2.
- ► Slide the mechanical key (1) in completely until it engages.

Replacing the key battery

A DANGER Risk of fatal injury due to swallowing batteries

Batteries contain toxic and corrosive substances. If batteries are swallowed or otherwise enter the body, severe internal burns can occur within two hours.

There is a risk of fatal injury!

- Keep the batteries out of the reach of children.
- If the lid and/or the battery compartment do not close securely, stop using the key and keep it away from children.
- If batteries are swallowed or otherwise enter the body, seek immediate medical attention.



Batteries contain pollutants. It is illegal to dispose of them with the household rubbish.



Dispose of batteries in an environmentally responsible manner. Take discharged batteries to a qualified specialist workshop or to a collection point for used batteries.

Requirements:

• One CR 2032 3 V cell battery

Mercedes-Benz recommends that you have the battery replaced by a qualified specialist workshop.

 \triangleright Removing the emergency key (\rightarrow page 39).



Example image

- Press release button ② down fully and slide cover ① forward.
- Remove battery compartment (3) and remove the discharged battery.
- Insert the new battery into battery compartment (a). Observe the positive pole marking in the battery compartment and on the battery.
- Insert battery compartment 3.
- Replace cover ① so that it engages.
- Slide the emergency key in completely until it engages (→ page 39).

Rectifying problems with the key

You can no longer lock or unlock the vehicle

Possible causes:

- The key battery is weak or discharged.
- There is interference from a powerful radio signal source.
- · The key is faulty.
- Check the battery with the indicator lamp and replace if necessary (\rightarrow page 39).


- Use the mechanical key to unlock and lock the vehicle (\rightarrow page 39).
- Have the key checked at a qualified specialist workshop.

You have lost a key

- Have the key deactivated at a qualified specialist workshop.
- If necessary, have the mechanical locks replaced.


Doors

Unlocking and opening the door from inside



To unlock and open the front door: pull door handle 2.

Safety pin **1** pops up when the door is unlocked.



The symbol indicates that the rear door is unlocked.

➤ To unlock and open the rear door: pull opening lever and open the rear door. When the door unlocks, latch moves forward.

The symbol is visible.

- To close: pull the rear door closed by the door handle.
- To lock: slide latch 2 back.
 The symbol is visible.

Centrally locking and unlocking the door from the inside

WARNING Risk of accident and injury if children are left unattended in the vehicle

If children are left unattended in the vehicle, they could in particular:

- open doors, thereby endangering other persons or road users.
- get out and be struck by oncoming traffic.
- operate vehicle equipment and become trapped, for example.

In addition, the children could also set the vehicle in motion, for example by:

- · releasing the parking brake.
- · changing gear.
- · starting the vehicle.
- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- Keep the SmartKey out of the reach of children.


WARNING Risk of fatal injury due to exposure to extreme heat or cold in the vehicle

If persons, particularly children, are subjected to prolonged exposure to intense heat or cold, there is a risk of severe injury or even death.


Never leave persons, particularly children, unattended in the vehicle.

You can use the central locking buttons to centrally lock and unlock the entire vehicle from the inside.

The central locking buttons are located in the driver's and front passenger door.



Central locking buttons (vehicles with electrically adjustable front seats)



Central locking buttons (vehicles with manually adjustable front seats)

- To unlock: with the doors closed, press button

 1.
- To lock: with the doors closed, press button


 2.

Activating/deactivating the automatic locking mechanism


Requirements:

- The power supply or the vehicle has been switched on.
- The doors are closed.

When the automatic locking mechanism is activated and the vehicle is traveling at a speed above 9 mph (15 km/h), the vehicle is locked automatically.



Central locking buttons (vehicles with electrically adjustable front seats)



Central locking buttons (vehicles with manually adjustable front seats)

If the vehicle is being tow-started, push-started or tested on a roller dynamometer, there is a risk of being locked out when the function is activated.

- ➤ To activate: press and hold button ② until you hear a tone.
- ➤ To deactivate: press and hold button ① until you hear a tone.

Automatic locking after closing the last door

WARNING Risk of fatal injury due to exposure to extreme heat or cold in the vehicle

If persons, particularly children, are subjected to prolonged exposure to intense heat or cold, there is a risk of severe injury or even death.

- Never leave persons, particularly children, unattended in the vehicle.
- **WARNING** Risk of accident and injury if children are left unattended in the vehicle

If children are left unattended in the vehicle, they could in particular:

- open doors, thereby endangering other persons or road users.
- get out and be struck by oncoming traffic.
- operate vehicle equipment and become trapped, for example.

In addition, the children could also set the vehicle in motion, for example by:

- releasing the parking brake.
- changing gear.
- · starting the vehicle.
- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- Keep the SmartKey out of the reach of children.
- WARNING Accident- and risk of injury with unsecured or unattended animals in parked vehicle

If you leave animals in the vehicle unattended or unsecured, they could possiblypress buttons or switches.

An animal may:

- Activate vehicle equipment and become trapped, for example.
- Switch systems on or- off and endanger other road users
- Never leave animals in the vehicle unattended.
- Always secure animals properly, e.g. with a suitable animal transport box.

After leaving the vehicle and closing the last door, the vehicle is automatically locked. This also applies if the SmartKey is still in the vehicle.

There is a danger of locking oneself out. The vehicle can only be opened again with a SmartKey for the vehicle.


- Always carry the SmartKey for the vehicle with you when leaving the vehicle.
- If the vehicle is locked and the only available SmartKey is in the vehicle, notify a qualified specialist workshop.



Warning notice, depending on the equipment on the driver's door, the partition wall, the sliding door or the Speed Delivery Door

Unlocking and locking the driver's door with the mechanical key

i If you want to lock the vehicle completely with the mechanical key, press the button for the locking mechanism from inside first with the driver's door open. Then lock the driver's door with the mechanical key.




- To unlock: turn the mechanical key counterclockwise to position 1.
- To lock: turn the mechanical key clockwise to position 1.
- i Right-hand drive vehicles: turn the mechanical key in the opposite direction for each case.

Using the grab handles when getting into and out of the vehicle

The entrances may be equipped with grab handles and steps. The grab handles to enter and exit the vehicle are at the front door and the sliding door.

- (i) To avoid risks:
 - When getting into and out of the vehicle, always use the grab handles and steps.
 These are specifically designed to withstand such loads.
 - Keep steps and entrances free from dirt, e.g. mud, clay, snow and ice.



- When getting into and out of the vehicle, use the grab handles (1) and steps.
- (i) The grab handles on the sliding door are provided as an easy entry and exit feature and can hold up to a maximum of 176 lbs (80 kg). Do not use the grab handle on the sliding door to secure a load (lashing). Do not secure any objects to the easy entry and exit features.

Sliding door

Opening and closing the sliding door

▲ WARNING Risk of becoming trapped due to an open sliding door which is not engaged in place

On an incline, the sliding door can move by itself.

This can cause you or other people to become trapped.

Always make sure that the open sliding door is engaged. To do so, open the sliding door to the stop.


A

WARNING Risk of becoming trapped due to sliding door opening towards the rear

When you open the sliding door, the sliding door could hit other people as it moves towards the rear of the vehicle.


Only open the sliding door when traffic conditions permit.

To unlock



Pull safety pin (a) upwards manually or use the central locking button to unlock the sliding door (→ page 41).

Opening



i Your vehicle may be equipped with a long sliding door with an intermediate catch. You can also lock the sliding door in place around halfway when opening and closing. This means you do not always have to open the door fully when getting in or out. The sliding door is not fully engaged when in the intermediate catch position.

- Press in the button (1) and pull the door (2) handle.
- Push back the sliding door fully using the door handle until it engages.
- Check the sliding door catch.

Closing

- Press in the button (1) and pull the door (2) handle.
- Slide the sliding door firmly forwards using the door handle until it closes.

To lock

Notes on electrical closing assist

If your vehicle is fitted with electrical closing assist, you will require less force to close the sliding door.

Electric sliding door

Function of the electric sliding door

Your vehicle may be equipped with an electric sliding door on the left and/or right-hand side.

You can operate the electric sliding door in the following ways:

- by pressing the sliding door buttons on the center console
- by pressing the sliding door button on the door sill (B-pillar)
- using the door handle (inside or outside)
- using the key

If the electric sliding door is obstructed while opening, it will move a few centimeters in the opposite direction and then stop.

If the sliding door is obstructed during the closing procedure, it will open fully again.

If the electric motor of the sliding door is in danger of overheating, e.g. due to frequent opening and closing within a short period, the sliding door will open fully. The sliding door will then be locked in place. The sliding door will be operational again after approximately 30 seconds.

If there has been a malfunction or the battery has been disconnected, you can use the release catch to disconnect the sliding door from the electric motor. You will then be able to open or close the door manually (\rightarrow page 46).

Opening/closing the electric sliding door with the button

WARNING Risk of becoming trapped due to sliding door opening towards the rear

When you open the sliding door, the sliding door could hit other people as it moves towards the rear of the vehicle.

Only open the sliding door when traffic conditions permit.


WARNING Risk of injury despite the object detection function

The object detection function does not react to soft, light and thin objects, such as fingers. The object detection function cannot prevent someone from becoming trapped in these situations.


- When opening and closing the electric sliding door, make sure that no parts of the body are within the operating range of the sliding door.
- If someone becomes trapped, press the button again to stop the sliding door.

Object detection:


If an object obstructs the sliding door as it closes, the sliding door will be stopped. Object detection is only an aid. It is not a substitute for your attentiveness.



- Opens and closes the sliding door on the left side of the vehicle
- Opens and closes the sliding door on the right side of the vehicle



In vehicles with a partition, button **(3)** is located on the partition next to the door entrance at the height of the inside door handle.



- To unlock: pull locking pin up manually or use the central locking button to unlock the sliding door (→ page 41).
- ► To open: briefly press button ①, ② or ③.

 The sliding door will open automatically.

When you open the door using button ① or ②, you will hear two acoustic signals.

The indicator lamp at the top of button ① or ② will flash, and button ③ will flash.

When the sliding door is completely open, the indicator lamp at the top of button ① or ② will light up.

► To close: briefly press button ①, ② or ③. The sliding door will close automatically.

When you close the door using button ① or ②, you will also hear two acoustic signals.

The indicator lamp at the top of button ① or ② will flash, and button ③ will flash.

When the sliding door is completely closed, the indicator lamp at the top of button ① or ② will go out.

To stop automatic operation: briefly press button n or 2.

The sliding door will stop moving.


- i When you stop automatic operation during opening, the door will close when you press the button again.
- i In unfavorable operating conditions, e.g. frost or ice, or if the vehicle is very dirty, you can press and hold the corresponding button. The electric sliding door will then move with increased force. Note that, in such circumstances, the object detection function is less sensitive. To stop the movement, release the button.


Opening/closing the electric sliding door with the key

- To unlock: briefly press the or button on the key.
- To open: press and hold the or button on the key for longer than 0.5 seconds. You will hear two acoustic signals and the sliding door will open automatically.
- ➤ To close: press and hold the property or button on the key for longer than 0.5 seconds. You will hear two acoustic signals and the sliding door will close automatically.
- ➤ To interrupt automatic operation: briefly press the ☑ or ☑ button on the key. The sliding door stops moving.

i When you stop automatic operation upon opening the door, the door closes when you press the button again.

Opening/closing the electric sliding door with the door handle





- Press button (1) or pull outside door handle
 - The sliding door will open or close.
- Press button 1 again or pull outside door handle 2.
 - The sliding door will stop moving.

Unlocking the electric sliding door manually

Disconnecting the sliding door from the electric motor

- Insert the emergency key into opening (1) of disconnect switch (2) in the "AUTO" position.
- Turn the emergency key 180° clockwise. The "MAN" position will be set.

Open or close the sliding door with the outside or inside door handle.

Establishing the connection between the sliding door and electric motor

- Insert the emergency key into opening ① of disconnect switch ② in the "MAN" position.
- Turn the emergency key 180° counter-clockwise.
 - The "AUTO" position will be set.
- Adjust the sliding door (→ page 47).


Unlocking

- Press release button ①.
- Open or close the sliding door with the outside or inside door handle.

Establishing the connection between the sliding door and electric motor

- Turn disconnect switch ② 180° counterclockwise. The "AUTO" position will be set.
- \blacktriangleright Adjust the sliding door (\rightarrow page 47).
- If it is not possible to rectify the malfunction, visit a qualified specialist workshop.

Resetting the electric sliding door



Sliding door buttons on the center console



Sliding door button on the door frame (B-pillar)

You must reset the sliding door if there has been a malfunction or a voltage supply interruption.

If the sliding door is open: press button ① or ② on the center console or sliding door button ③ on the door frame (B-pillar) and hold it until the door is closed.

or

- Close the sliding door with the door handle (→ page 46).
- Then briefly press button (1) or (2) on the center console or sliding door button (3) on the door frame (B-pillar) once, or pull the door handle (→ page 46) to open the sliding door completely.

The sliding door will be operational.

Rear-end doors

Opening and closing the rear-end doors from outside

WARNING Risk of injury due to the rearend door swinging open

When you open a rear-end door, the following can occur:

- You or another person can be injured.
- A person may be struck by oncoming traffic

This is particularly the case if you open the rear-end door more than 90° or if it opens in an uncontrolled manner.

Even rear-end doors which are properly closed can swing open when the vehicle parked is on an incline or it is windy.


- Only open a rear-end door when the traffic conditions and surroundings permit.
- Always make sure that the rear-end doors are properly closed.

NOTE Damage to the rear-end doors due to objects obstructing their range of movement

When the rear-end doors are opened, any objects obstructing the range of movement of the rear-end doors can be damaged as well as the vehicle.

Make sure that there is sufficient clearance when opening the rear-end doors.

Opening the right rear-end door



- Pull handle ①.
- Swing the rear-end door out to the side until it engages.

Opening the left rear-end door



- Ensure that the right rear-end door is open and engaged.
- Pull release handle (1) in the direction of the arrow.

Swing the rear-end door out to the side until it engages.

Opening the rear-end doors fully

- Open the respective rear-end door beyond the first detent (90°).
- Open the rear-end door fully. The rear-end door will be retained in the stop position.

Closing the rear-end doors from outside

- Close the left rear-end door firmly from outside.
- Close the right rear-end door firmly from outside.

Opening rear-end doors with door retainer more than 90°

WARNING Risk of injury due to the rearend door swinging open

When you open a rear-end door, the following can occur:

- You or another person can be injured.
- A person may be struck by oncoming traffic.


This is particularly the case if you open the rear-end door more than 90° or if it opens in an uncontrolled manner.

Even rear-end doors which are properly closed can swing open when the vehicle parked is on an incline or it is windy.

- Only open a rear-end door when the traffic conditions and surroundings permit.
- Always make sure that the rear-end doors are properly closed.
- NOTE Damage to the rear-end doors due to objects obstructing their range of movement

When the rear-end doors are opened, any objects obstructing the range of movement of the rear-end doors can be damaged as well as the vehicle.

Make sure that there is sufficient clearance when opening the rear-end doors.



- Open the rear-end door approximately 45°.
- Pull and hold the door retainer in the direction of the arrow.
- Open the rear-end door at an angle greater than 90° so that the door retainer is no longer locked in place.
- Release the door check and open the tailgate to the steering limit.

Opening/closing the rear-end doors from the inside

WARNING Risk of injury due to the rearend door swinging open

When you open a rear-end door, the following can occur:

- You or another person can be injured.
- A person may be struck by oncoming traffic.

This is particularly the case if you open the rear-end door more than 90° or if it opens in an uncontrolled manner.


Even rear-end doors which are properly closed can swing open when the vehicle parked is on an incline or it is windy.

- Only open a rear-end door when the traffic conditions and surroundings permit.
- Always make sure that the rear-end doors are properly closed.

NOTE Damage to the rear-end doors due to objects obstructing their range of movement

When the rear-end doors are opened, any objects obstructing the range of movement of the rear-end doors can be damaged as well as the vehicle.

Make sure that there is sufficient clearance when opening the rear-end doors.



The symbol indicates that the rear-end door is unlocked.

- To unlock: slide latch ② to the left.
 The → symbol is visible.
- ➤ To open: pull opening lever and open the rear-end door. Swing the rear-end door to the side until it engages.
- ➤ To close: make sure that the left rear-end door is closed. Pull the rear right door firmly to by the door handle.
- To lock: slide latch 2 to the right. The symbol is visible.

Partition sliding door


Opening and closing the partition sliding door

WARNING Risk of becoming trapped if the partition sliding door is not engaged


The partition sliding door may move on its own while the vehicle is in motion.

This can cause you or other people to become trapped.

Before every journey, close the partition sliding door and ensure that it is engaged.



Partition from the cab



Partition from the cargo compartment

- ➤ To open: turn the key to the left <a>® from the cab or push the lever to the right <a>® from the cargo compartment.

 The sliding door will be unlocked.
- Push the sliding door as far as it will go to the right from the cab or to the left from the cargo compartment.
- ➤ To close: push the sliding door to the left from the cab or to the right from the cargo compartment until it engages.
 You can lock the sliding door from the cab with the key.

Side window

Opening and closing the side windows

WARNING Risk of entrapment when opening a side window

When opening a side window, parts of the body could be drawn in or become trapped between the side window and window frame.

- When opening, make sure that nobody is touching the side window.
- If someone is trapped, release the button immediately or pull it in order to close the side window again.
- **WARNING** Risk of becoming trapped when closing a side window

When closing a side window, body parts could be trapped in the closing area in the process.


- When closing, make sure that no body parts are in the closing area.
- If someone is trapped, release the button immediately or press the button in order to reopen the side window.
- ▲ WARNING Risk of becoming trapped when children operate the side windows

Children could become trapped if they operate the side windows, particularly when unattended.

- Activate the child safety lock for the rear passenger compartment side windows.
- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- Never leave children unattended in the vehicle.
- **WARNING** Risk of fatal injury due to exposure to extreme heat or cold in the vehicle

If persons, particularly children, are subjected to prolonged exposure to intense heat or cold, there is a risk of severe injury or even death.

Never leave persons, particularly children, unattended in the vehicle.



- To open manually: press and hold button
 or
- To close manually: pull and hold button (1) or (2).

The windows in the front doors can also be operated automatically.

- To open completely: briefly press button or beyond the pressure point. Automatic operation will start.
- To close completely: briefly pull button or beyond the pressure point.
 Automatic operation will start.
- ► To interrupt automatic operation: briefly press or pull button ① or ② again.
- i If an object blocks a side window during the automatic closing process, the side window will open again automatically. The automatic reversing function is only an aid and is not a substitute for your attentiveness.
- (i) If automatic operation of the side window does not work, there will also be no automatic reversing function.

Automatic reversing function of the side windows If an object blocks a side window during the closing process, the side window will open again automatically. The automatic reversing function is only an aid and is not a substitute for your attentiveness.

During the closing process, make sure that no body parts are in the closing area. ▲ WARNING Risk of becoming trapped despite there being reversing protection on the side window

The reversing function will not react:

- to soft, light and thin objects, e.g. fingers
- over the last ½ in (4 mm) of the closing path
- during resetting
- when the side window is closed again manually immediately after automatic reversing

The reversing function cannot prevent someone from becoming trapped in these situations.

- During the closing process, make sure that no body parts are in the closing area.

Adjusting the side windows

The side windows must be readjusted after a malfunction or a voltage supply interruption.

- Switch on the power supply (\rightarrow page 92).
- Push both buttons on the power window and hold for approximately one second after the side window has closed.

Rectifying problems with the side windows

A side window cannot be closed and you cannot see the cause

Check to see if there are any objects in the window guide.

▲ WARNING Risk of becoming trapped or fatally injured if reversing protection is not activated

If you close a side window again immediately after it has been blocked, the side window will close with increased or maximum force. The reversing function is then not active and body parts may become trapped.

Make sure that no parts of the body are in the closing area.

To stop the closing process, release the button or press the button again to reopen the side window.

If a side window is obstructed during closing and reopens again slightly, you can proceed as follows:

Immediately after the window is obstructed, pull the corresponding button again until the side window has closed. Then pull and hold the button for another second.

The side window will be closed with increased force.

If the side window is obstructed again and reopens slightly, you can proceed as follows:

- Repeat the previous step. The side window will be closed without the automatic reversing function.
- If a side window is obstructed again during closing and reopens again slightly, consult a qualified specialist workshop.

Anti-theft prevention

Function of immobilizer

The immobilizer prevents your vehicle from being started without the correct key.

The immobilizer is automatically activated when the vehicle is switched off, and deactivated when the vehicle is switched on.

When leaving the vehicle, always take the key with you and lock the vehicle. If the key is left inside the vehicle, anyone can start the vehicle.

i In the event the engine does not start despite the vehicle's starter battery having sufficient charge, the immobilizer is faulty. Contact a qualified specialist workshop or call 1-800-367-6372 (in the USA) or 1-800-387-0100 (in Canada).

ATA (Anti-Theft Alarm system)

■ Function of ATA (Anti-Theft Alarm system)

If the ATA system is armed, a visual and audible alarm is triggered in the following situations:

- · a side door is opened
- the rear-end door is opened
- · the hood is opened


- the interior protection is triggered
 (→ page 53)
- the tow-away alarm is triggered (\rightarrow page 53)

The alarm will not be deactivated, even if the door which was opened to trigger the alarm is immediately closed again, for example.

Canceling a triggered alarm (\rightarrow page 52).

The ATA is activated automatically after approximately ten seconds in the following instance:

· after the vehicle has been locked with the key



When the ATA system is armed, an indicator lamp


1 flashes in the overhead control panel.

ATA is automatically deactivated in the following situations:

- after unlocking the vehicle with the key
- after pressing the start/stop button with the key inside the vehicle.

Arms/deactivates ATA (anti-theft alarm system)

Arming



- Close all the doors.
- Close the side window or deactivate the interior protection (→ page 53) to prevent a false alarm.
- Lock the vehicle with the key. Indicator lamp in the overhead control panel flashes.

Deactivating

- Unlock the vehicle with the key. Indicator lamp (i) in the overhead control panel goes out.
- (i) The vehicle locks again automatically if you do not open a door within 40 seconds after unlocking the vehicle.

Stopping the alarm

Press the or button on the key.

or

Press the Start/Stop button with the key inside the vehicle. The alarm stops.

Function of the tow-away alarm

When the tow-away alarm is armed, a visual and audible alarm is triggered if the vehicle's inclination changes. This may be the case, forexample, if the vehicle is lifted on one side.

Arming or deactivating the tow-away alarm


Arming/deactivating

- Lock the vehicle with the key.
 The tow-away alarm is automatically armed after about 40 seconds:
- Open the vehicle with the key.
 The tow-away alarm is deactivated.

The tow-away alarm is activated if the following condition is met:

· All the doors are closed.

Deactivating



Switch off the vehicle (→ page 92).

- Press the ① button.
 - When the button is released, the indicator lamp ② in the button lights up for approximately three seconds.
- Lock the vehicle with the key.
 The tow-away alarm is deactivated.

The tow-away alarm is activated again in the following instances:

- · the vehicle is unlocked again.
- · a door is opened
- · the vehicle is locked again.

Deactivate the tow-away alarm when locking your vehicle in the following situations:

- when loading and/or transporting the vehicle on a ferry or car transporter, for example
- when parking the vehicle on a movable surface, such as a split-level garage

False alarms will thus be prevented.

Interior protection

Function

A visual and acoustic alarm is triggered if the armed interior protection detects motion in the vehicle interior.

Arming/deactivating the interior protection

Arming

- Close the side windows.
- Ensure that no objects (suchas mascots or clothes hangers) are hanging on the inside mirror or on the grab handles. False alarms will thus be prevented.
- Lock the vehicle with the key. The interior protection is armed after approximately 40 seconds.


The interior protection is activated if the following condition is met:

· All the doors are closed.

Switching off

Unlock the vehicle with the key. The interior protection automatically switches off.

Deactivating



- \triangleright Switch off the vehicle (\rightarrow page 92).
- Press the button. When the button is released, indicator lamp in the button lights up for approximately three seconds.
- Lock the vehicle with the key.
 The interior protection is deactivated.

The interior protection is activated again in the following instances:

- · the vehicle is unlocked again.
- a door is opened
- the vehicle is locked again.

Deactivate the interior protection when locking your vehicle in the following situations:

- people or animals remain inside the vehicle
- if the side windows remain open
- when transporting the vehicle, for example on a ferry or car transporter.


False alarms will thus be prevented.

Notes on the correct driver's seat position

WARNING Risk of accident due to adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations in particular:

- If you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
- If you fasten your seat belt while the vehicle is in motion
- Before starting the vehicle: in particular, adjust the driver's seat, head restraint, steering wheel and mirror, and fasten your seat belt.



Ensure the following when adjusting steering wheel (a), seat belt (2) or driver's seat (1):

- You are sitting as far away from the driver's air bag as possible.
- · You are sitting in an upright position.
- Your thighs are gently supported by the seat cushion.
- Your legs are not fully extended and you can reach the pedals easily.
- The back of your head is supported at eye level by the middle part of the head restraint.
- You can hold the steering wheel with your arms slightly bent.
- You can move your legs without any restrictions.
- You can see all of the instrument cluster displays well.

- You have a good overview of the traffic conditions.
- Your seat belt sits snugly against your body and passes across the center of your shoulder and across your hips in the pelvic area.

Notes on grab handles

WARNING Risk of injury due to excessive load on the grab handles

If you apply your full body weight to the grab handle or pull it abruptly, the grab handle may be damaged or come loose from its anchorage. This may result in injuries.

Use the grab handles only to stabilize the seating position or to assist in getting in and out of the seat.

Seats

Adjusting the front seats manually (without Seat Comfort Package)

WARNING Risk of becoming trapped if the seat is adjusted by children

Children could become trapped if they adjust the seats, particularly if they are unattended.

- When leaving the vehicle, always take the key with you and lock the vehicle.
- Never leave children unattended in the vehicle.

WARNING Risk of becoming trapped when adjusting the seat

When you adjust a seat, you or other vehicle occupants could become trapped, e.g. on the seat guide rail.

When adjusting a seat, make sure that no one has any part of their body within the sweep of the seat.

Observe the safety notes on "Air bags" and "Children in the vehicle".

WARNING Risk of accident due to the driver's seat not being engaged

The driver's seat may move unexpectedly while driving.

This could cause you to lose control of the vehicle.

Always make sure that the driver's seat is engaged before starting the vehicle.

WARNING Risk of accident due to adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations in particular:

- If you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
- If you fasten your seat belt while the vehicle is in motion
- Before starting the vehicle: in particular, adjust the driver's seat, head restraint, steering wheel and mirror, and fasten your seat belt.

WARNING Risk of becoming trapped if the seat height is adjusted carelessly

If you adjust the seat height carelessly, you or other vehicle occupants could be trapped and thereby injured.

Children in particular could accidentally press the electrical seat adjustment buttons and become trapped.

While moving the seats, make sure that hands or other body parts do not get under the lever assembly of the seat adjustment system.

★ WARNING Risk of injury due to head restraints not being installed or being adjusted incorrectly

If head restraints have not been installed or have not been adjusted correctly, there is an increased risk of injury in the head and neck area, e.g. in the event of an accident or when braking.

- Always drive with the head restraints installed.
- Before driving off, make sure for every vehicle occupant that the center of the head restraint supports the back of the head at about eye level.

Using the head restraint fore-and-aft adjustment, adjust the head restraint so that it is as close to the back of your head as possible.

A

WARNING Risk of injury or death due to an incorrect seat position


The seat belt does not offer the intended level of protection if you have not moved the seat backrest to an almost vertical position.

In particular, you could slip beneath the seatbelt and become injured.

- Adjust the seat properly before beginning your journey.
- Always ensure that the seat backrest is in an almost vertical position and that the shoulder belt is routed across the center of your shoulder.
- NOTE Damage to the seats when moving the seats back

The seats may be damaged by objects when moving the seats back.

When moving the seats back, make sure that there are no objects in the footwell, under or behind the seats.



- Seat fore-and-aft position
- Seat height
- Seat backrest inclination
- To adjust the seat fore-and-aft position: lift lever and slide the seat into the desired position. Ensure that the seat is engaged.
- ➤ To adjust the seat height: keep on pressing or pulling lever ② until the required seat height has been reached.

➤ To adjust the seat backrest inclination: rotate handwheel ⑤ forwards and backwards until the desired position has been reached.

Adjusting the front seats manually (with Seat Comfort Package)

WARNING Risk of becoming trapped if the seat is adjusted by children

Children could become trapped if they adjust the seats, particularly if they are unattended.

- When leaving the vehicle, always take the key with you and lock the vehicle.
- Never leave children unattended in the vehicle.

WARNING Risk of becoming trapped when adjusting the seat

When you adjust a seat, you or other vehicle occupants could become trapped, e.g. on the seat guide rail.

When adjusting a seat, make sure that no one has any part of their body within the sweep of the seat.

Observe the safety notes on "Air bags" and "Children in the vehicle".

WARNING Risk of accident due to the driver's seat not being engaged

The driver's seat may move unexpectedly while driving.

This could cause you to lose control of the vehicle.

- Always make sure that the driver's seat is engaged before starting the vehicle.
- ▲ WARNING Risk of accident due to adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations in particular:

- If you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
- If you fasten your seat belt while the vehicle is in motion
- Before starting the vehicle: in particular, adjust the driver's seat, head restraint,

steering wheel and mirror, and fasten your seat belt.

WARNING Risk of becoming trapped if the seat height is adjusted carelessly

If you adjust the seat height carelessly, you or other vehicle occupants could be trapped and thereby injured.

Children in particular could accidentally press the electrical seat adjustment buttons and become trapped.

While moving the seats, make sure that hands or other body parts do not get under the lever assembly of the seat adjustment system.

▲ WARNING Risk of injury due to head restraints not being installed or being adjusted incorrectly

If head restraints have not been installed or have not been adjusted correctly, there is an increased risk of injury in the head and neck area, e.g. in the event of an accident or when braking.

- Always drive with the head restraints installed.
- Before driving off, make sure for every vehicle occupant that the center of the head restraint supports the back of the head at about eye level.

Using the head restraint fore-and-aft adjustment, adjust the head restraint so that it is as close to the back of your head as possible.

WARNING Risk of injury or death due to an incorrect seat position

The seat belt does not offer the intended level of protection if you have not moved the seat backrest to an almost vertical position.

In particular, you could slip beneath the seatbelt and become injured.

- Adjust the seat properly before beginning your journey.
- Always ensure that the seat backrest is in an almost vertical position and that the shoulder belt is routed across the center of your shoulder.

NOTE Damage to the seats when moving the seats back

The seats may be damaged by objects when moving the seats back.

When moving the seats back, make sure that there are no objects in the footwell. under or behind the seats.



Example image of comfort suspension seat

- Seat cushion length
- Seat backrest inclination
- Seat height
- Seat cushion inclination
- Seat fore-and-aft position
- Seat suspension
- Seat suspension lock
- To adjust the seat cushion length: lift lever 1 and slide the front part of the seat cushion forwards or backwards.
- To adjust the seat backrest inclination: rotate handwheel 2 forwards and backwards until the desired position has been reached.
- To adjust the seat height: pull or push lever (3) until the desired position has been reached.
- To adjust the seat cushion inclination: rotate handwheel (4) forwards and backwards until the desired position has been reached.
- To adjust the seat fore-and-aft position: lift lever (5) and slide the seat into the desired position.
- To check for safety: ensure that the seat is engaged.
- To adjust the seat suspension: take your weight off the seat.

- Using handwheel 6, set the body weight (88 lb (40 kg) to 265 lb (120 kg)) so that the seat suspension works optimally. If you set a higher weight, the seat suspension will become firmer. The seat will then not vibrate as much. If the seat vibrates often and significantly, you can engage it in the lower area.
- To engage the seat suspension lock: turn lever upwards.

The next time the seat vibrates, it will engage.

To release the seat suspension lock: turn lever to the right.

The seat will then be able to vibrate.

Adjusting the front seat electrically

WARNING Risk of becoming trapped if the seat is adjusted by children

Children could become trapped if they adjust the seats, particularly if they are unattended.

- When leaving the vehicle, always take the kev with you and lock the vehicle.
- Never leave children unattended in the vehicle.

The seats can be adjusted when the vehicle is switched off.



WARNING Risk of becoming trapped when adjusting the seat

When you adjust a seat, you or other vehicle occupants could become trapped, e.g. on the seat guide rail.

When adjusting a seat, make sure that no one has any part of their body within the sweep of the seat.

Observe the safety notes on "Air bags" and "Children in the vehicle".



WARNING Risk of accident due to the driver's seat not being engaged

The driver's seat may move unexpectedly while driving.

This could cause you to lose control of the vehicle.



Always make sure that the driver's seat is engaged before starting the vehicle.

▲ WARNING Risk of accident due to adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations in particular:

- If you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
- If you fasten your seat belt while the vehicle is in motion
- Before starting the vehicle: in particular, adjust the driver's seat, head restraint, steering wheel and mirror, and fasten your seat belt.

WARNING Risk of becoming trapped if the seat height is adjusted carelessly

If you adjust the seat height carelessly, you or other vehicle occupants could be trapped and thereby injured.

Children in particular could accidentally press the electrical seat adjustment buttons and become trapped.

While moving the seats, make sure that hands or other body parts do not get under the lever assembly of the seat adjustment system.

▲ WARNING Risk of injury due to head restraints not being installed or being adjusted incorrectly

If head restraints have not been installed or have not been adjusted correctly, there is an increased risk of injury in the head and neck area, e.g. in the event of an accident or when braking.

- Always drive with the head restraints installed.
- Before driving off, make sure for every vehicle occupant that the center of the head restraint supports the back of the head at about eye level.

Do not interchange the head restraints of the front and rear seats. Otherwise, you will not be able to set the height and inclination of the head restraints to the correct position.

Using the head restraint fore-and-aft adjustment, adjust the head restraint so that it is as close to the back of your head as possible.

WARNING Risk of injury or death due to an incorrect seat position

The seat belt does not offer the intended level of protection if you have not moved the seat backrest to an almost vertical position.


In particular, you could slip beneath the seatbelt and become injured.

- Adjust the seat properly before beginning your journey.
- Always ensure that the seat backrest is in an almost vertical position and that the shoulder belt is routed across the center of your shoulder.

I NOTE Damage to the seats when moving the seats back


The seats may be damaged by objects when moving the seats back.

When moving the seats back, make sure that there are no objects in the footwell, under or behind the seats.



- Seat backrest inclination
- Seat height
- Seat cushion inclination
- Seat fore-and-aft position
- Save the settings with the memory function (→ page 60).

Setting 4-way lumbar support



- Higher
- Softer
- 3 Lower
- Firmer
- Use buttons (1) to (2) adjust the backrest contour individually to your spine.

Operating the memory function

WARNING Risk of an accident if the memory function is used while driving

If you use the memory function on the driver's side while driving, you could lose control of the vehicle as a result of the adjustments being

- Only use the memory function on the driver's side when the vehicle is stationary.
- **WARNING** Risk of entrapment when adjusting the seat with the memory function

When the memory function adjusts the seat, you and other vehicle occupants – particularly children – could become trapped.

- During the adjustment process of the memory function, make sure that no one has any body parts in the sweep of the seat.
- If somebody becomes trapped, immediately release the memory function position button.

The adjustment process is stopped.

WARNING Danger of entrapment when memory function is activated by children


When children activate the memory function, they can get trapped, especially if they are unsupervised.

- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the key with you and lock the vehicle.

The memory function can be used when the vehicle is switched off.

Storing seat adjustments

Seat adjustments for up to three people can be stored and called up using the memory function. You can adjust the seat and the backrest.



- Adjust the seat to the desired position.
- Press memory button M together with one of preset position buttons 1, 2 or 3. An acoustic signal will sound. The settings are stored.
- ➤ To call up: press and hold preset position button 1, 2 or 3 until the front seat is in the stored position.

Rotating the front seats

★ WARNING Risk of injury or fatal injuries if the driver's seat and front passenger seat are not engaged

In this situation, the restraint systems cannot perform their intended protective function.

- Engage the driver's seat and front passenger seat in the direction of travel before you start the vehicle.
- ▲ WARNING Risk of accident due to adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations in particular:

- If you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
- If you fasten your seat belt while the vehicle is in motion
- Before starting the vehicle: in particular, adjust the driver's seat, head restraint, steering wheel and mirror, and fasten your seat belt.
- **WARNING** Risk of injury when the seat is pushed backwards

If the seat has been pushed backwards, you may injure yourself on the seat guide rails protruding at the front.

Make sure that you do not touch the seat guide rails.



You can rotate the driver's and front passenger seats by 50° and 180°. The seats engage both in and opposite to the direction of travel as well as at 50° towards the exit.

Ensure that the parking brake is applied and the brake lever (if applicable) is down as far as it will go (→ page 112).

- When rotating the seat, open the respective front door in order to avoid a collision with the door trim.
- Adjust the steering wheel in such a way that there is sufficient clearance to rotate and adjust the driver's seat (→ page 63).
- Slide the front passenger seat forward before rotating it (→ page 55).
- ➤ To rotate the seat: push lever towards the door and rotate the seat slightly inwards.

 The turning device will be unlocked.
- ▶ Release lever (1) again.
- Rotate the seat outwards or inwards into the required position.

Folding the co-driver bench seat cushion forwards and backwards




- To fold the seat surface forward: lift seat surface out of front anchorage ①.
- Pull the seat surface out of rear anchorage 2 and move it slightly forwards.
- Fold the rear edge of the seat surface upwards.
- You can stow individual objects in the stowage compartment beneath the co-driver bench seat.
- To fold back the seat surface: fold the rear edge of the seat surface downwards.
- Slide the seat surface under the seat backrest into rear anchorage ②.
- Push the front seat surface downwards until it engages in front anchorage (1).

Folding the folding seat up or down

WARNING Risk of injury when using the folding seat due to inserted key

The key in the lock of the partition wall sliding door may come into contact with the person on the folding seat.

Always remove the key before a person sits on the folding seat.



- Remove key 1 from the partition sliding door.
- Press the push button on catch ② and fold seat cushion ③ up or down.
- Release push button on catch ② when seat cushion ③ reaches its end position.
- Move seat cushion (a) until it has locked. The push button on catch (a) must be completely flush with the seat frame.

Head restraints

Adjusting the head restraint manually

▲ WARNING Risk of accident due to adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations in particular:

- If you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
- If you fasten your seat belt while the vehicle is in motion
- Before starting the vehicle: in particular, adjust the driver's seat, head restraint,


steering wheel and mirror, and fasten your seat belt.

WARNING Risk of injury due to head restraints not being installed or being adjusted incorrectly

If head restraints have not been installed or have not been adjusted correctly, there is an increased risk of injury in the head and neck area, e.g. in the event of an accident or when braking.

- Always drive with the head restraints installed.
- Before driving off, make sure for every vehicle occupant that the center of the head restraint supports the back of the head at about eye level.

Using the head restraint fore-and-aft adjustment, adjust the head restraint so that it is as close to the back of your head as possible.



Head restraint (example of luxury head restraint on the driver's seat)

- To raise: pull the head restraint upwards into the desired position and ensure that it engages.
- i Use the head restraint only when it is engaged.
- To lower: press release button ①, slide the head restraint downwards into the desired position and ensure that it engages.
- i Use the head restraint only when it is engaged.

- ➤ To move forwards: press release button and pull the head restraint forwards until it engages in the desired position.
- To move backwards: press release button and slide the head restraint backwards into the desired position.
- To remove: press release button
 and pull the head restraint up and out.
- To install: press the head restraint with detent on the left-hand side when viewed in the direction of travel into the holes until it engages.

Switching the seat heating on/off

WARNING Risk of burns due to repeatedly switching on the seat heating

Repeatedly switching on the seat heating can cause the seat cushion and seat backrest padding to become very hot.

In particular, the health of persons with limited temperature sensitivity or a limited ability to react to high temperatures may be affected or they may even suffer burn-like injuries.

Do not repeatedly switch on the seat heating.

To protect against overheating, the seat heating may be temporarily deactivated after it is switched on repeatedly.


NOTE Damage to the seats caused by objects or documents when the seat heating is switched on

When the seat heating is switched on, overheating may occur due to objects or documents placed on the seats, e.g. seat cushions or child seats. This could cause damage to the seat surface.

Make sure that no objects or documents are on the seats when the seat heating is switched on.

Requirements:

• The power supply is switched on.



- To switch on: press the button.

 All indicator lamps on the button light up.
- ➤ To lower the level: press button until the required heating level is reached.
 Depending on the heating level, one to three indicator lamps will light up.
- To switch off: press button (1) until all indicator lamps are off.
- i The seat heater automatically switches back out of the three heating levels after 8, 10 and 20 minutes until the seat heater switches off.

Steering wheel

Adjusting the steering wheel

WARNING Risk of accident due to adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations in particular:

- If you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
- If you fasten your seat belt while the vehicle is in motion
- Before starting the vehicle: in particular, adjust the driver's seat, head restraint, steering wheel and mirror, and fasten your seat belt.

WARNING Risk of accident due to unlocked steering wheel


The steering wheel may move unexpectedly if it is unlocked while the vehicle is in motion.

- Make sure that the steering wheel is locked before driving off.
- Never unlock the steering wheel when the vehicle is in motion.
- **WARNING** Risk of entrapment for children when adjusting the steering wheel

Children could injure themselves if they adjust the steering wheel.

- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.

Adjusting the steering wheel



- Lever
- Steering column height
- Steering column fore-and-aft adjustment
- To unlock: swing lever odown as far as it will go.

The steering wheel is unlocked.


To lock: pull lever up as far as it will go. The steering wheel is locked.

Switching the steering wheel heater on/off

Requirements:

• The vehicle is switched on.

The steering wheel heater is switched on and off via a switch below the steering wheel.



- ➤ To switch on: push the switch into position 1.


 If indicator lamp ③ lights up, the steering wheel heater is switched on.
- To switch off: push the switch into position 2.

When you switch the vehicle off, the steering wheel heater will switch off.

Stowage areas

Overview of the front stowage compartments


Overview of the front storage compartments
Observe the notes on loading the vehicle
(→ page 148).



- Lockable compartment above windshield (subject to a maximum load of 4 lb (2 kg))
- Windshield storage compartment with two cup holders / ashtray stowage space Storage compartment with cover, depending on specification

- © Center console storage compartment with USB port, charging interface, NFC interface and 12 V socket
- Storage compartment above windshield (subject to a maximum load of 5 lb (2.5 kg))
- Front passenger side storage compartment (subject to a maximum load of 11 lb (5 kg))
- 6 Cup holder (→ page 65)
- Storage compartment in the doors

Information about the bottle holder



Bottle holder in the front doors (example: front passenger door)

Cup holders

Overview of cup holders in the center console

WARNING - Risk of accident or injury
when using the cup holder while the vehicle is moving

The cup holder cannot secure containers while the vehicle is moving.

If you use a cup holder while the vehicle is moving, the container may be flung around and liquids may be spilled. The vehicle occupants may come into contact with the liquid and if it is hot, they could be scalded. You could be distracted from traffic conditions and you may lose control of the vehicle.

- Only use the cup holder when the vehicle is stationary.
- Only use the cup holder for containers of the right size.

Close the container, particularly if the liquid is hot.



The cup holders for the driver and front passenger are in the center console.

Key holder **()** for vehicles with a reduced antenna detection range (KEYLESS-START) is located in the driver's cup holder.

Ashtray and cigarette lighter

Using ashtrays

- Place the closed ashtray in a cup holder in the windshield stowage compartments.
- Check that the ashtray is seated securely.
- i Do not place the ashtray in the center console cup holders. It cannot sit securely here.

Using the cigarette lighter in the center console

WARNING Risk of fire and injury from hot cigarette lighter

You can suffer burns if you touch the hot heating element or the hot socket of the cigarette lighter.


In addition, flammable materials can catch fire if:

- you drop the hot cigarette lighter.
- children e.g. hold the hot cigarette lighter to objects.
- Always hold the cigarette lighter by the knob.
- Always make sure that the cigarette lighter is out of the reach of children.

Never leave children unattended in the vehicle.

Requirements:

• The vehicle is switched on.



Press in cigarette lighter
The cigarette lighter will pop out when the heating element is red-hot.


Sockets

Using 12 V sockets

Requirements:

Only devices with a maximum power consumption of 180 W (15 A) may be connected.

12 V socket in the storage compartment



- Open the lid of the storage compartment in the center console.
- Fold up cover (1) of the socket.
- Insert the plug of the device.

- (i) Depending on the vehicle equipment, the vehicle has additional 12 V sockets:
 - in the lower control panel in the front center console
 - · in the driver's seat
 - in the cargo compartment

Notes on the 115 V socket

! NOTE Damage to the auxiliary battery due to full discharge

The auxiliary battery may become damaged if a device with too high a power output is connected when you leave the vehicle, or the auxiliary battery's charge level is low.

- Only connect devices up to a maximum of 150 W.
- Do not leave devices connected for longer than four hours.

Vehicles with an auxiliary battery have a run-on function. If you leave the vehicle, you can charge devices over a period of up to four hours. If the vehicle is switched on and off again during the run-on period, the run-on function starts again for another four hours.

Using the 115 V socket in the center console

A

DANGER Risk of fatal injuries due to a damaged connecting cable or a damaged socket

You could receive an electric shock if the connecting cable or the 115 V power socket is pulled out of the trim or is damaged or wet.

- Use only connecting cables that are dry and free of damage.
- When the vehicle is switched off, make sure that the 115 V power socket is dry.
- Immediately have the 115 V power socket checked or replaced at a qualified specialized workshop if it is damaged or has been pulled out of the trim.
- Never plug the connecting cable into a 115 V power socket that is damaged or has been pulled out of the trim.

DANGER Risk of death due to using the socket incorrectly

In particular, you could receive an electric shock:

- If you touch the inside of the socket
- If you insert unsuitable devices or objects into the socket
- Do not touch the inside of the socket.
- Only connect suitable devices to the socket.

▲ DANGER Risk of fatal injuries due to electric shock

If you clean the 115 V socket with a wet cloth, you can get an electric shock.

There is a risk of fatal injury!

Avoid the area around the 115 V socket when cleaning.

Requirements

- Only connect devices with a suitable plug which conforms to the standards specific to the country you are in.
- Only connect devices up to a maximum of 150 W.
- · Do not use multiple socket outlets.



- Open flap (3).
- Insert the plug of the device into 115 V socket

 .

When the on-board electrical system voltage is sufficient, indicator lamp ② lights up.

If you will not be using the 115 V power socket, keep the flap ③ closed.

Installing and removing the floor mats


WARNING Risk of accident due to objects in the driver's footwell

Objects in the driver's footwell may impede pedal travel or block a depressed pedal.

This will jeopardize the operating- and road safety of the vehicle.

- Stow all objects in the vehicle securely so that they cannot get into the driver's footwell.
- Make sure that there is always sufficient clearance for the pedals.
- Always install the floor mats securely and as prescribed.
- Do not use loose floor mats and do not place floor mats on top of one another.

Installing



- Slide the seat backwards.
- Position the floor mat in the footwell so that it fits flush.
- Press studs ① onto holders ②, if applicable.
- Connect the installed driver and passenger footwell floor mats at the contact area.
- Adjust the seat.

Removing

- Slide the corresponding seat backwards and pull the floor mat off holders ②, if applicable.
- Remove the floor mat.

Lighting

Notes on adjusting the lights when driving abroad


Vehicles with halogen or static LED headlamps: Changing the headlamps is not necessary. The legal requirements will also be fulfilled in countries with left- and right-hand traffic.

Information about lighting systems and your responsibility

The vehicle's various lighting systems are only aids. The vehicle driver is responsible for adjusting the vehicle's lighting to the prevailing light, visibility, statutory conditions and traffic conditions.

Light switch

Operating the light switch



- 1 2005 Activates or deactivates parking lamps and license plate and instrument lighting.
- 2 Auro Activates or deactivates automatic driving lights/daytime running lamps (preferred light switch position).
- Activates or deactivates low beam/high beam.
- Activates or deactivates the front fog light.
- ① * Activates or deactivates the rear fog light.
- ▶ ⑥ Applies or releases the electric parking brake (→ page 111).
- (i) If you hear a warning tone when exiting the vehicle, the lights may still be on.

- The turn signal light, the high beam and the headlamp flasher are operated with the combination switch (→ page 69).
- Leaving the parking lamps on for several hours drains the battery.

 If the battery is heavily discharged, the parking lamps will switch off automatically to enable the next vehicle start.

Automatic driving lights function

WARNING Risk of accident when the low beam is switched off in poor visibility

When the light switch is set to AUTO, the low beam may not be switched on automatically if there is fog, snow or other causes of poor visibility such as spray.

In such cases, turn the light switch to

The automatic driving lights are only an aid. Responsibility for vehicle lighting rests with you. Turn the light switch from AUTO to D immediately in the event of fog, snow or spray. Otherwise, the driving lights will be temporarily interrupted.

To switch the automatic driving lights on:

Turn the light switch to the AUTO position.
 Switch the power supply on: the side lights will automatically switch on or off depending on the brightness of the ambient light.


The daytime running lights will be switched on when the vehicle is started. The side lights and the low beam will also switch on or off depending on the brightness of the ambient light.

When the low beam is switched on, the pindicator lamp on the instrument cluster will also switch on.

Activating/deactivating the fog lights

Requirements:

- The light switch is in the ☑ or ▲UTO position.
- The vehicle has been switched on or started.



- To switch the front fog light on or off: press button 4.
- To switch the rear fog light on or off: press button (6).

Comply with the country-specific regulations for using the rear fog lamp.


Adjusting headlamp range

Requirements:

• The vehicle has been started.


You can use the headlamp range adjuster to adjust the light cone of the headlamps to the vehicle's load condition. As the seats are occupied or the cargo compartment is loaded or unloaded, the light cone will change. This may cause visibility conditions to deteriorate and you could glare oncoming traffic.

in vehicles with LED headlamps, the headlamp range is adjusted automatically.



- Driver's seat and front passenger seat occupied
- 1 Driver's seat and front passenger seat occupied
- 2 Driver's seat and front passenger seat occupied, cargo compartment or loading area laden
- 3 Driver's seat and front passenger seat occupied and maximum permitted rear axle load being used
- Turn the headlamp range adjuster to the corresponding position.
 The road illumination should be 131.2 ft (40 m) to 328.1 ft (100 m) and the low beam must not glare oncoming traffic.
- If the vehicle is unladen, select position [0].

Operating the combination light switch



- High beam
- Right turn signal light

- Headlamp flashing
- 4 Left turn signal light
- Use the combination switch to select the desired function.

Switching on high beam

- \triangleright Switch on the low beam (\rightarrow page 68).
- ➤ Push the combination switch forwards ①.

 The ② indicator lamp on the instrument cluster will light up. The combination switch will return to its starting position.
- (i) In the AUTO position, the high beam switches on only in darkness and when the vehicle is switched on.
- To switch off: push the combination switch forwards or briefly pull it in the direction of arrow (s) (the action for headlamp flashing switches high beam off).
 - The 📆 indicator lamp on the instrument cluster will go out. The combination switch will return to its starting position.
- Vehicles with Highbeam Assist: when Highbeam Assist is active, it controls the activation and deactivation of the high beam
 (→ page 71).


Headlamp flashing

Briefly pull the combination switch in the direction of arrow <a>(a).

Turn signal light

- ➤ To indicate: push the combination switch in the required direction ② or ③ until it engages. When significant steering movements are made, the combination switch will automatically reset itself.
- ➤ To indicate briefly: tap the combination switch briefly in the required direction ② or ③. The corresponding turn signal lamp will flash three times.

Switching the hazard warning light system on/off




Press button ①.

If you operate a turn signal indicator while the hazard warning light system is switched on, only the turn signal lamps on the relevant side of the vehicle will light up.

i The hazard warning light system will work even when the vehicle has been switched off.

Cornering light function



The cornering light improves the illumination of the road over a wide angle in the turning direction, e.g. enabling better visibility in tight bends.

The function is active under the following conditions:

- The speed is less than 37 mph (60 km/h) and the indicator has been switched on or the steering wheel is turned.
- The speed is between 37 mph (60 km/h) and 50 mph (80 km/h) and the steering wheel is turned.

The cornering light may still light up for a short time but will be switched off automatically after a maximum of three minutes.

(i) When reverse gear is engaged, the lighting switches to the opposite side.

Highbeam Assist

Adaptive Highbeam Assist function

WARNING Risk of accident despite Adaptive Highbeam Assist

Adaptive Highbeam Assist does not react to:

- Road users without lights, e.g. pedestrians
- Road users with poor lighting, e.g. cyclists
- Road users whose lighting is obstructed, e.g. by a barrier

On very rare occasions, Adaptive Highbeam Assist may fail to recognize other road users with their own lighting, or may recognize them too late.

In these, or in similar situations, the automatic high beam will not be deactivated or will be activated despite the presence of other road users.

Always observe the road and traffic conditions carefully and switch off the high beam in good time.

Adaptive Highbeam Assist automatically switches between the following settings:

- · Low beam
- · High beam

The system detects that vehicle lights are approaching in the opposite direction or driving ahead of the vehicle.

At speeds greater than 19 mph (30 km/h), the system will switch to the following setting:

• If no other road users are detected, high beam will switch on automatically.

At speeds lower than 16 mph (25 km/h) or if there is sufficient street lighting, the system will switch to the following setting:

· High beam will automatically switch off.

System limits

Adaptive Highbeam Assist cannot take the road, weather or traffic conditions into consideration.

The detection of obstacles may be restricted if:

- · visibility is poor, e.g. in fog, heavy rain or snow.
- · the sensors are dirty or obscured.

Adaptive Highbeam Assist is only an aid. You are responsible for ensuring correct vehicle lighting in accordance with the prevailing light, visibility and traffic conditions.

The system's optical sensor is located behind the windshield near the overhead control panel.

Switching Highbeam Assist on/off


Requirements:

- The light switch is in the AUTO position.
- To switch on: switch on high beam using the combination switch.

When the high beam is switched on automatically in the dark, the high indicator lamp will light up on the instrument cluster display.

To switch off: switch off high beam using the combination switch.

Adjusting the interior lighting Adjusting the interior lighting



Versions 1 to 4


- Switches the front-left reading lamp on/off
- To switch off the automatic interior lighting control: press the button.

The interior lighting will switch on automatically if you:

- Unlock the vehicle
- Open a door
- Switches the (front) interior lighting on/off.
- Switches the rear passenger compartment / cargo compartment lamp on/off

- (not assigned depending on the vehicle equipment).
- ▶ ⑥ 盃 Switches the front-right reading lamp on/off

Adjusting the interior lighting for body manufacturer add-on equipment




- To switch the front left reading lamp on/off: press button (1).
- To deactivate automatic interior lighting control: press button 2.

Interior lighting control will switch on automatically if you do the following, for example:

- · Unlock the vehicle
- Open a door
- To switch the front interior lighting on/off: press button 3.
- ➤ To switch body manufacturer lamps on/off: press button ⑥ (not assigned depending on the vehicle equipment).
 - Your vehicle may be equipped with a functional feedback system: will light up in red if the body manufacturer lamps are switched on.
 - If the body manufacturer lamps have been switched on manually, they will also remain switched on for an extended period of time after locking.
- i This period of time is shortened if there is undervoltage in the starter battery.
- If the body manufacturer lamps have been switched off automatically to protect the battery, restart the vehicle before switching them on again.

- (i) The body manufacturer lamps can be switched on only when the battery voltage is stable.
- To switch the front right reading lamp on/off: press button (§).

Switching the rear passenger compartment interior lighting on/off



 Switches rear passenger compartment/ cargo compartment lamp on or off

Motion detector


WARNING Risk of injury due to laser beam of the motion detector

The motion detector emits non-visible radiation from LEDs that are classified as class 1 M lasers.

This may damage the retina in the following situations:

- If you look directly into the unfiltered laser beam of the motion detector for an extended period.
- If you look directly into the laser beam of the motion detector with optical instruments, such as glasses or magnifying glasses.
- Never look directly into the motion detector.

The motion detector is located in the cargo compartment behind the partition, in the middle of the roof.



Position of motion detector

If the vehicle is equipped with a motion detector, the cargo compartment lamp is also activated via the motion detector.

If the motion detector detects movement in the cargo compartment while the vehicle is stationary, the cargo compartment lamp will switch on for approximately two minutes.

The cargo compartment lamp will be switched on via the motion detector in the following situations:

- The vehicle is stationary, the parking brake is applied and you are not depressing the brake pedal.
- The selector lever is in position **P** and you are not depressing the brake pedal.
- The vehicle has not been locked from the outside using the key.

If no change to the vehicle (e.g. a door opening) is detected over several hours, the motion detector will automatically switch off. This prevents the battery from discharging.

Changing bulbs

Instructions for replacing illuminants

WARNING Risk of burns from hot component parts whilst replacing a bulb

Bulbs, lamps and plug connectors can become very hot during operation.

When replacing a bulb, you could burn yourself on these component parts.

Allow the component parts to cool down before replacing the bulbs.

Important safety notes

- Before changing the bulbs, switch off the vehicle's lighting system. This will prevent a short circuit.
- Use only spare bulbs of the same type and with the correct voltage.
- Use bulbs only in enclosed lamps that have been designed for them.
- Do not use any illuminant that has been dropped or has scratches on its glass tube. Otherwise, the illuminant may explode.
- The illuminant may explode under the following conditions:
 - if it is hot and you touch it
 - if you drop it
 - if you scratch it
- Stains on the glass tube will reduce the service life of the illuminant. Do not touch the glass tube with your bare hands. If necessary, clean the glass tube with alcohol or spirits while it is cold and wipe it down with a lint-free cloth.
- Protect light bulbs from humidity and do not bring them into contact with liquids.

Always ensure the bulbs are firmly secured.

If your vehicle is equipped with LED modules, you can check this as follows: the light cone will move from top to bottom and back again when the vehicle starts. For this to work, low beam needs to have been switched on before the vehicle is started


Bulbs and lamps are major elements in vehicle safety. Therefore, ensure that they are always working. Have the headlamp setting checked regularly.

If the new light source also does not light up, consult a qualified specialist workshop.

Replacing front light bulbs (vehicles with halogen headlamps)

Overview of illuminant types

You can replace the following light sources.




Halogen headlamps

- High beam/daytime running lights: H15 55 W/15 W
- Low beam/perimeter light: H7 55 W/W 5 W
- 3 Turn signal light: 3457 NAK 28 W

Replacing halogen headlamps

Requirements

- Low beam: light source type H7 55 W
- High beam/daytime running lights: light source type H15 55 W/15 W
- Perimeter lights: light source type W 5 W
- Turn signal lights: light source type 3457 NAK 28 W




- Low beam/perimeter light housing cover.
- A High beam/daytime running lights housing cover
- Turn signal light socket
- Switch off the lighting system.

- Low beam/perimeter light: pull housing cover
 - nearward to remove it.
- Pull the socket rearward to remove it.
- Remove the light source from the socket.
- Insert the new light source into the socket such that the base of the bulb rests fully against the base of the socket.
- Align and insert the socket.
- Attach housing cover 1.
- High beam/daytime running lights: pull housing cover 2 rearward to remove it.
- Turn the socket counter-clockwise and pull it out.
- Remove the light source from the socket.
- Insert the new light source into the socket such that the base of the bulb rests fully against the base of the socket.
- Insert the socket and turn it clockwise.
- Attach housing cover 2.
- Turn signal light:
- Turn socket (3) counter-clockwise and remove
- Gently turn the illuminant counter-clockwise and take it out of the socket.
- Insert the new illuminant into the socket and turn it clockwise.
- Insert socket (3) and turn it clockwise.

Replacing rear bulbs

Overview of rear illuminant types


You can replace the following light sources.





- Brake lights/tail lamps/perimeter lights: P 21 W
- Backup lamp: P 21 W
- 3 License plate lamp: W 5 W
- Rear fog light: P 21 W

You can replace the following light sources.



Vehicles with partial LED tail lamps

- Backup lamp: P 21 W
- License plate lamp: W 5 W
- Rear fog light: P 21 W


Changing the tail lamp


Requirements:

- Brake light/tail light/perimeter light: light source type P 21 W
- Backup lamps: light source type P 21 W
- Rear fog lights: light source type P 21 W



- Brake light/tail light/perimeter light
- 2 Backup lamp
- Rear fog light
- Switch off the lighting system.
- Open the rear-end door.





Removing

- Remove screws
 and pull out the tail lamp in the direction of the arrow.
- Remove the plug from bulb mount 3.
- Remove the screws ② and remove the bulb mount ③ from the tail lamp.
- Gently turn the light source counter-clockwise and take it out of the socket.
- Insert the new light source into the socket and turn it clockwise.

Installing

- Set bulb mount (a) on the tail lamp and screw in screws (a).
- Press the plug into the bulb mount 3.
- Insert the tail lamp and screw in the screws

 1.

License plate lamp

Requirements:

· License plate lamp: light bulb type W 5 W




- Switch off the lighting system.
- Place a screwdriver, for example, at opening ② between lamp ③ and panel ① and carefully pry off the lamp ③.
- Remove lamp (3) from panel (1).
- Rotate the bulb holder by around 45° and detach it from the lamp.
- Remove the light bulb.
- Insert the new bulb into the bulb holder.
- Insert the bulb holder into the lamp and rotate it by around 45°.
- Insert the lamp into the panel opening until it engages.

Replacing interior light bulbs

Replacing rear interior lamps

Requirements

(i) For the standard bulb failure indicator function to work correctly, only light bulbs that are the same type and power as those installed during production may be used.




- Switch off the interior lighting.
- Press in the catch spring of lens with a suitable object, e.g. a screwdriver, and then lever off the lens with the lamp housing.
- To remove the lens from the lamp housing: press the lugs of lens ② inwards.
- Remove light bulbs (3) from the lamp housing.
- Insert the new light bulb.
- Position the lens on the lamp housing and engage it.
- Align the lens with the lamp housing and engage it.

Windshield wipers

Switching the windshield wipers on and off


Requirements:

• The power supply is switched on.



- Single wipe/wiping with washer fluid
- 1 0 Windshield wipers off
- The intermittent wiping, normal
 Vehicles with rain sensors: automatic wiping, normal
- 3 F... Intermittent wiping, frequent Vehicles with rain sensors: automatic wiping, frequent
- 4 Continuous wiping, slow
- 5 Continuous wiping, fast
- Turn the combination switch to the corresponding position 1 5.
- Single wipe: press the button on the combination switch in the direction of arrow (a) as far as the first pressure point.
- Washing: press the button on the combination switch in the direction of arrow ⊚ as far as the second pressure point.

Switching the rear window wiper on and off



- 2 Intermittent wiping
- Single wipe: press button
 to the pressure point.
- Wiping with washer fluid: press button
 beyond the pressure point.
- To switch intermittent wiping on or off: press button 2.
 - The symbol will appear on the instrument cluster when the rear window wiper is switched on.

Replacing the windshield wiper blades

WARNING Risk of becoming trapped if the windshield wipers are switched on while wiper blades are being replaced

If the windshield wipers begin to move while you are changing the wiper blades, you can be trapped by the wiper arm.

Always switch off the windshield wipers and vehicle before changing the wiper blades.


WARNING Risk of injury from using the windshield wipers when the hood is open

If the windshield wipers start moving when the hood is open, you could be trapped by the wiper linkage.

Always switch off the windshield wipers and vehicle before opening the hood.

Replacing the wiper blades

 If the wiper blades are worn out, they will no longer wipe the windshield properly. Replace the wiper blades twice a year, preferably in spring and fall.



- Fold wiper arm 3 away from the windshield.
- Hold wiper arm (a) and turn the wiper blade away from wiper arm (b) in the direction of the arrow as far as it will go.
- Slide catch ② upwards in the direction of the arrow until it engages.
- Fold the wiper blade back onto the wiper arm.
- Remove the wiper blade from the wiper arm.
- Insert new wiper blade
 in the holder on wiper arm
 .

When doing so, take into account the different lengths of the wiper blades:

- Driver's side: long wiper blade
- Front passenger side: short wiper blade
- Slide catch ② downwards until it engages.
- Fold wiper arm 3 back onto the windshield.

Replacing the windshield wiper blades (WET WIPER SYSTEM)

▲ WARNING Risk of becoming trapped if the windshield wipers are switched on while wiper blades are being replaced

If the windshield wipers begin to move while you are changing the wiper blades, you can be trapped by the wiper arm.


- Always switch off the windshield wipers and vehicle before changing the wiper blades.
- **WARNING** Risk of injury from using the windshield wipers when the hood is open

If the windshield wipers start moving when the hood is open, you could be trapped by the wiper linkage.

Always switch off the windshield wipers and vehicle before opening the hood.

Replacing the wiper blades

i If the wiper blades are worn out, they will no longer wipe the windshield properly. Replace the wiper blades twice a year, preferably in spring and fall.




- Fold wiper arm (3) away from the windshield.
- ► Hold wiper arm ⑤ and turn the wiper blade away from wiper arm ⑥ in the direction of the arrow as far as it will go.
- Slide catch ② upwards in the direction of the arrow until it engages.
- Remove wiper blade **1** from the wiper arm in the direction of arrow **2**.
- Carefully remove hose 5 from the wiper blade.
- Attach hose 6 to the new wiper blade.
- Insert new wiper blade 1 in the holder on wiper arm 3.

When doing so, take into account the different lengths of the wiper blades:

- Driver's side: long wiper blade
- · Front passenger side: short wiper blade

- Slide catch ② downwards until it engages.
- Fold the wiper blade back onto the wiper arm.
- Fold wiper arm (3) back onto the windshield.

Replacing the rear window wiper blades



- Fold wiper arm 3 away from the rear window.
- Press both retaining clips ② together in the direction of the arrow and swivel the wiper blade away from the wiper arm.
- Pull wiper blade 1 upwards out of the holder on wiper arm 3.
- Insert new wiper blade (1) in the holder on wiper arm (3).
- Push new wiper blade 1 onto wiper arm 3 until the retaining clips engage.
- Fold wiper arm (3) back onto the rear window.

Mirrors

Operating the outside mirrors

▲ WARNING Risk of accident due to adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations in particular:

- If you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
- If you fasten your seat belt while the vehicle is in motion
- Before starting the vehicle: in particular, adjust the driver's seat, head restraint,

steering wheel and mirror, and fasten your seat belt.

★ WARNING Risk of accident due to misjudgment of distance when using the front-passenger mirror


The outside mirror on the front passenger side reflects objects on a smaller scale. The objects in view are in fact closer than they appear.

Therefore, always look over your shoulder to check the actual distance between you and the road users traveling behind you.

Adjusting the outside mirrors manually

- Adjust the outside mirrors to the correct position manually.
- To engage an outside mirror that has been pushed out of position: push the outside mirror into position manually.

Adjusting the outside mirrors electrically



Example image

! NOTE Damage to the electric outside mirrors due to folding in by hand or by force

If the electric outside mirrors are folded in or out manually, the outside mirrors may be damaged and will not engage properly.

If the outside mirrors are not folded when you have the vehicle washed at an automatic car wash, the washing brushes may forcibly fold in and damage the outside mirrors.

Fold the outside mirrors in and out electrically only.

- Fold in the outside mirrors before having the vehicle washed at an automatic car wash.
- Before setting off, switch on the power supply or the vehicle.
- To fold in or out: briefly press button 2.
- To select: use button o or so to select the outside mirror to be adjusted.
- To adjust: use button (4) to set the position of the mirror glass.
- To engage an outside mirror that has been pushed out of position: press and hold button

You will hear a click and the mirror will audibly engage in position. The outside mirror will be set to the correct position.

Resetting the outside mirrors

- i If the battery has been disconnected or completely discharged, the outside mirrors must be reset. Only then will the automatic mirror folding function work properly.
- Switch on the power supply or the vehicle.
- Briefly press button ②.


Heating the outside mirrors

- Vehicles without a rear window heater: at low temperatures, the mirror heater will switch on automatically once the vehicle has been started
- Vehicles with a rear window heater: at low temperatures, the mirror heater will switch on automatically once the vehicle has been started. The mirror heater can also be switched on together with the rear window heater using the rear window heater button.

Using the digital inside rearview mirror

The vehicle may be equipped with a digital inside rearview mirror. This uses a camera on top of the roof at the rear to provide a better view to the rear. The inside rearview mirror can be used either as a standard inside rearview mirror or as a display.

To prevent glare from the digital inside rearview mirror, first set the digital inside rearview mirror as the standard inside rearview mirror.



Digital image noise may occur on the display under certain circumstances in unfavorable ambient light.

Certain types of sunlight, e.g. sun low on the horizon or light from another intense light source, can reduce the display's contrast and cause it to become too bright. In such situations, objects on the display may be obscured or difficult to see. In these cases, be particularly careful and adapt your driving style accordingly.

Drivers must always wear the necessary personal visual aids required for them to drive a vehicle. Drivers with presbyopia (age-related long-sightedness) should, if necessary, wear visual aids with multifocal lenses to be sufficiently able to see traffic including via the displays.

- (i) If the camera on top of the roof at the rear is dirty, the image may be impaired. In this case, clean the camera manually with a damp cloth. Observe the notes on cleaning the digital inside rearview mirror (→ page 160).
- To use the standard inside rearview mirror: move the switch to position 1.
- To use the display: move the switch to position 2.

Adjusting the display brightness

- (i) The digital inside rearview mirror is equipped with light sensors on the front and back and automatically adjusts the brightness of the display to the ambient light. Do not cover the light sensors, e.g. with a sticker.
- Press menu button (3) once.
- Press button (4) to reduce the display brightness.

or

Press button (5) to increase the display brightness

Adjusting the angle of the camera

Press menu button (3) twice.

Press button (a) to move the angle downwards.

or

Press button 6 to move the angle upwards.

Activating and deactivating the rear view camera image

The vehicle may be equipped with a rear view camera with image in the inside rearview mirror.

- To activate, put the vehicle in reverse gear or press button .
- To deactivate, take the vehicle out of reverse gear or press button (5) again.

Error mode of the digital inside rearview mirror


If a system error occurs, e.g. if the camera fails, a crossed-out camera will appear at the top left of the display and no camera image will be visible in the mirror.

Switch to the standard inside rearview mirror if there is a system error.

If the vehicle is equipped with a rear view camera with image in the inside rearview mirror and a system error occurs, a crossed out camera with the number 2 will appear on the left side of the display.

In this case, no camera image is available for maneuvering.


Dimming the inside rearview mirror



Fold anti-glare lever in the direction of the arrow.


Overview of climate control systems

Heating system overview




- Sets the temperature
- ② ☐ Switches the rear window defroster on/off (→ page 87)
- 3 Switches footwell air distribution on/off
- Switches windshield defrosting on/off (→ page 86)
- Wehicle switched on: Max Comfort mode cut-in; Vehicle switched off: Pre-entry climate control
- Sets the airflow
- (i) The indicator lamps on the buttons signal that the functions in question have been activated.

TEMPMATIC overview



- ② Display
- 3 Sets the airflow
- Wehicle switched on: Max Comfort mode cut-in; Vehicle switched off: Pre-entry climate control
- Vehicles with rear window defrosters: switches the rear window defroster on/off (→ page 87)
- Switches air-recirculation mode on/off (→ page 86)
- Switches windshield defrosting on/off (→ page 86)
- Sets the air distribution (→ page 86)
- (i) The indicator lamps on the buttons signal that the functions in question have been activated.

THERMOTRONIC overview



- ② Display
- 3 Sets the airflow
- Symbol Wehicle switched on: Max Comfort mode cut-in; Vehicle switched off: Pre-entry climate control
- Switches air-recirculation mode on/off
 (→ page 86)
- Switches windshield defrosting on/off
 (→ page 86)
- \odot Sets the air distribution (\rightarrow page 86)
- Switches the A/C function on/off
 (→ page 85)
- (i) The indicator lamps on the buttons signal that the functions in question have been activated.

Operating climate control systems

Notes on energy-saving air-conditioning

Using the heating and climate control functions has a direct effect on the vehicle's range. For this reason, depending on the selected drive program,

 $(\longrightarrow \text{page 99})$ the heating/air-conditioning output will automatically be reduced.

Drive pro- gram	Vehicle characteristics
c (Com- fort)	Normal heating and air-conditioning output
E (ECO)	Reduced heating and air-conditioning output
MR (MAX Range)	Heavily reduced heating and airconditioning output

Depending on the vehicle's equipment, you can use MaxComfort mode to set an increased heating and air-conditioning output.

 To cool the high-voltage battery in very high outside temperatures, the cooling of the vehicle interior can be automatically reduced or switched off for a short time.

In drive program [], the best possible heating output is achieved in Auto mode (THERMOTRONIC) or with a low to moderate blower setting.

In drive programs \blacksquare and \blacksquare , there may be an increased risk of fogging up. If the windows fog up, you should increase the blower setting and select drive program \blacksquare if necessary. Switch on the "demist windshield" \blacksquare function as well if you need to (\rightarrow) page 87).

A reduction in the heating/air-conditioning output may mean that it will take longer than usual to

reach the desired vehicle interior temperature or that it cannot be reached at all.

MaxComfort mode

Depending on its equipment, your vehicle may have a MaxComfort mode.

When the vehicle is switched on, you can activate MaxComfort in all drive programs by pressing the button on the air-conditioning control panel. The maximum output of the heating/air-conditioning system will be activated in this mode. This makes it possible to heat the vehicle more quickly, but can have a negative impact on range. The function is switched on when the indicator lamp on the

Energy-saving mode (Cargo Van)

Depending on the vehicle's equipment, it may have an energy-saving mode to reduce energy consumption when the vehicle is switched on.

When energy-saving mode is activated, the output of the heating/air-conditioning system will be significantly reduced. The display on the instrument cluster will show a message reading Heating/Climate Control Energy-saving Active briefly and the symbol will be displayed permanently.

Energy-saving mode will be activated in drive programs and mr if:

- Front doors are opened immediately after the vehicle stops
- The front windows or doors are open for an extended period of time
- (i) Energy-saving mode will remain active for a few minutes even after the front doors have closed

By briefly switching on the "demist windshield" function (\rightarrow page 86), you can deactivate energy-saving mode for a certain period of time. When the "demist windshield" function is switched on, energy-saving mode will always be deactivated.

Energy-saving mode will automatically be deactivated:

- at speeds above approximately 43 mph (70 km/h)
- when the interior temperature falls below a certain level

In addition, comply with the following air-conditioning instructions in order to minimize energy consumption:

- · Select as low a blower setting as possible.
- Use the "demist windshield" function only for a brief period until the windshield is clear again.
- Vehicles with an air-conditioning system: ventilate the vehicle for a short time in warm
 weather. To achieve quicker cooling, briefly
 switch the climate control to air-recirculation
 mode. This will accelerate the cooling process
 and the desired vehicle interior temperature
 will be reached more quickly.
- Vehicles with seat heating: using the seat heating in conjunction with a medium vehicle interior temperature will result in lower fuel consumption than selecting a high vehicle interior temperature.

Switching the climate control system on/off

- To switch on: set the airflow to 1 or higher.
- To switch off: set the airflow to 0 or OFF. OFF will appear on the climate control system display.
- When the climate control system is switched off, the windows may fog up more quickly. Switch the climate control system off only briefly.

Switching the A/C function on/off

Requirements:

 The climate control system has been switched on (→ page 85).

The A/C function controls the climate and dries the air inside the vehicle.

- Press the A/c button.
- i Switch off the A/C function only briefly. Otherwise, the windows could fog up more quickly.
- Condensation may leak from the underside of the vehicle in cooling mode. This is not a sign of a defect.

Automatically regulating climate control

Requirements:

 The climate control system has been switched on (→ page 85).

Switching on automatic climate control

In automatic mode, the temperature, airflow and air distribution are regulated and kept constant.

Press the AUTO button. The display will show the temperature. The air-flow and air distribution will disappear from the display.

Switching off automatic climate control

Use the ∰ rocker switch to change the airflow setting or the ⇒ button to change the air distribution (→ page 86). The other setting will remain unaffected by the change.

Information on the air distribution settings

The symbols on the display indicate the vents through which the air is being directed.

Heating system

Directs air to the footwell vents

TEMPMATIC

Defroster and center air vent

All vents نخ

Center vents نح

Center and footwell vents

THERMOTRONIC

₩ Defroster vent

Defroster and center air vent

All vents نخۃ

Defroster and footwell vents

∀ Center vents

Center and footwell vents

Footwell vents

Setting the air distribution

Requirements:

- The climate control system is switched on.
- Press the juilton repeatedly until the desired air distribution appears in the air conditioning system display.

Defrosting the windows

Windows fogged up on the inside Vehicles with heating system

- Press the www button.
 When windshield defrosting is switched on, the temperature and airflow cannot be adjusted.
- \triangleright Close the front air vents (\rightarrow page 87).

Vehicles with TEMPMATIC or THERMOTRONIC

- Press the wo button and, if necessary, use the button to direct air onto the windshield wi.
- Increase the airflow as necessary and close the front air vents (→ page 87).
- If the windows remain fogged up: press the windows remain fogged up: press

When windshield defrosting is switched on, the temperature and airflow cannot be adjusted.

will appear on the climate control system display.

Vehicles with a windshield heater: press the 😰 button.

Depending on operation, you can achieve faster defrosting and drying of the windshield with the following settings:

- Use the نرج button to direct air onto the windshield المراكة
- Close the front air vents (→ page 87).
- Vehicles with windshield heater: switch on the

 \widetilde{\omega} windshield heater (→ page 87).

Windows fogged up on the outside

Switch on the windshield wiper (\rightarrow page 77).

Switching air-recirculation mode on/off

Press the Dutton.
The interior air will be recirculated.

Air-recirculation mode will switch off automatically.

i When air-recirculation mode is switched on, the windows may fog up more quickly. Switch on air-recirculation mode only briefly. Air-recirculation mode will automatically switch on in the following cases:

- in high outside temperatures
- while the vehicle is driving through a tunnel (vehicles with THERMOTRONIC automatic climate control only)
- when the wiping with washer fluid function is switched on (→ page 77)

The indicator lamp on the Dutton will not light up in this case. After a maximum of 30 minutes, outside air will automatically be introduced again.

Switching the windshield heater on and off

- in the event of high outside temperatures, the windshield heater may not switch on.
- ➤ Press the <a> button.
 If the indicator lamp on the button lights up, the windshield heater has switched on.
- (i) The windshield heater switches off automatically after a few minutes.
- i If the battery voltage is too low, it may not be possible to switch the windshield heater on. If the battery voltage becomes too low while the windshield heater is in operation, the windshield heater will switch off automatically.

Switching the rear window heater on or off

Press the button.

If the indicator lamp lights up, the rear window heater is switched on.


Operating air vents

Adjusting the front-compartment air vents

WARNING Risk of burns or frostbite due to being too close to the air vents


Very hot or very cold air can flow from the air vents.

- Make sure that all vehicle occupants always maintain a sufficient distance from the air vents.
- If necessary, direct the airflow to another area of the vehicle interior.



- To open or close: hold center ② of air vent ① and turn it to the left or right as far as it will go.
- ➤ To set the airflow direction: hold center ② of air vent ③ and move it up or down or to the left or right.

Operating cargo compartment ventilation



If your vehicle is equipped with a roof ventilator, you can admit fresh air to the cargo compartment, and extract air from it as well.

- Switch on the vehicle.
- ➤ To switch on and extract: press the top section of switch ①.

The roof ventilator will remove used air from the cargo compartment.

- ➤ To switch on and admit fresh air: press the bottom section of switch ②.
 - The roof ventilator will feed fresh air into the cargo compartment.
- To switch off: place the switch in the center position.

Pre-entry climate control

Notes on pre-entry climate control

WARNING Risk of fatal injury due to exposure to extreme heat or cold in the vehicle

If persons, particularly children, are subjected to prolonged exposure to intense heat or cold, there is a risk of severe injury or even death.

Never leave persons, particularly children, unattended in the vehicle.



WARNING Risk of burns due to repeatedly switching on the seat heating

Repeatedly switching on the seat heating can cause the seat cushion and seat backrest padding to become very hot.

In particular, the health of persons with limited temperature sensitivity or a limited ability to react to high temperatures may be affected or they may even suffer burn-like injuries.



Do not repeatedly switch on the seat heating.

To protect against overheating, the seat heating may be temporarily deactivated after it is switched on repeatedly.

Depending on the vehicle equipment, the following functions can be activated as needed during preentry climate control:

- Automatic climate control
- Blower
- Seat heating
- Steering wheel heater
- Mirror heater
- Rear window defroster
- Windshield heater

Setting pre-entry climate control when the vehicle is unlocked

On-board computer:

→ Settings → eSprinter >> Pre-entry Climate Control

With this function, the seats can be briefly prewarmed or pre-cooled before you get into the vehicle.

Activate or deactivate the function.

Selecting seats

Use the Driver's Seat Only setting to specify whether only the driver's seat or also the front passenger seat is air-conditioned. The seat-specific functions of pre-entry climate control, such as seat heating, will be performed for the selected seats.

If pre-entry climate control is enabled, an LED on the climate bar of the air-conditioning control panel will light up blue for a cooled vehicle and red for a heated vehicle.

Activating/deactivating pre-entry climate control when the vehicle is unlocked

Requirements:

- · The high-voltage battery is charged sufficiently.
- The function is activated on the on-board computer.
- To activate: unlock the vehicle. The climate control functions will be activated for up to five minutes for pre-heating and precooling.
- To switch off:
- Press the button on the air-conditioning control panel.
- · Locking by key (if the vehicle is parked for fewer than 15 minutes).
- (i) Pre-entry climate control will not be terminated via the automatic locking mechanism.
- (i) Seat heating will also remain switched on after the vehicle has been started.

Setting pre-entry climate control at departure time

On-board computer:

→ Settings → eSprinter >> Pre-entry Climate Control

Setting the departure time

The air inside the vehicle can be heated, ventilated or cooled to the set temperature when the vehicle is parked.

When the vehicle is connected to power supply equipment, priority will be given to charging the high-voltage battery to a specified minimum state of charge.

With active pre-entry climate control, the state of charge of the high-voltage battery may be reduced, even if the charging cable connector is inserted.

When the set temperature is changed, climate control mode will automatically be updated.

- The set departure times are used for the vehicle's pre-entry climate control system and to predict the state of charge at the time selected. Additional information on the charging settings (→ page 104).
- (i) If the Range Assistant function is active, it automatically determines, during a charging stop, the approximate time at which the desired state of charge will be attained. This is used as an approximate departure time for pre-entry climate control and is set automatically. Previously set departure times cannot be changed when the function is active. The automatically determined departure time can be activated or deactivated via the eSprinter menu.
- ➤ To select a seat: use the Driver's Seat Only setting to specify whether only the driver's seat or also the front passenger seat is air-conditioned.

Pre-entry climate control will take place for the selected seats.

If a departure time is set, a yellow LED will appear on the air-conditioning control panel. In addition, an LED on the air-conditioning control panel will indicate when pre-entry climate control is activated. It will light up blue when the vehicle is being cooled and red when it is being heated

Activating/deactivating pre-entry climate control at departure time

Requirements:

- The high-voltage battery is charged sufficiently.
- · The vehicle is switched off.
- The windows are closed.
- The doors to the passenger compartment are closed.
- The date and time are set correctly.
- To activate: set the departure time (→ page 104).
 Pre-entry climate control at departure time will switch on a maximum of 60 minutes before the

Pre-entry climate control at departure time will switch on a maximum of 60 minutes before the selected departure time. It will remain active for another ten minutes if departure is delayed.

To deactivate the pre-entry climate control at departure time early: press the with button on the air-conditioning control panel or switch off the preselection of the time in the eSprinter menu.

(i) Seat heating will also remain switched on after the vehicle has been started.

Operating immediate pre-entry climate control via the air conditioning control panel

Requirements

- The vehicle must be switched off.
- · The high-voltage battery is charged sufficiently.

Air conditioning of the vehicle interior can continue for up to 30 minutes, e.g. if the journey is interrupted.

- Press the w button on the air conditioning control panel.
- Set the temperature on the air conditioning control panel.

An LED will indicate when pre-entry climate control is activated. It will light up blue when the vehicle is being cooled and red when it is being heated.

Driving

Notes on electric mode



▲ DANGER Risk of fire and explosion from excessive internal pressure of the highvoltage battery

In the event of a vehicle fire, flammable gas can escape and ignite.

- If there is an unusual smell, smoke or burn marks, stop the charging process immediately.
- Leave the danger zone immediately. Secure the danger area at a sufficient distance.
- Call the fire service.



WARNING Risk of chemical burns and poisoning from damaged high-voltage battery

If the housing of the high-voltage battery has been damaged, electrolyte and gases may leak out.

- Avoid contact with the skin, eyes or clothing.
- Immediately rinse electrolyte splashes off with water and seek medical attention straight away.

Observe the following notes on vehicle noise emissions and the acoustic vehicle alerting system:

• The vehicle is equipped with a purely electric drive system and develops considerably lower vehicle noise emissions than vehicles with a combustion engine.

This is why the vehicle is equipped with a sound generator, which serves as an acoustic vehicle alerting system (AVAS). This safety system is prescribed by law.

The external noise of the sound generator is perceptible in the vehicle interior at low speeds and does not represent a malfunction.

· The sound generator generates speed-dependent vehicle noise emissions when the vehicle is driving forwards or backing up at a speed of up to around 20 mph (30 km/h).

This helps other road users - especially pedestrians and cyclists - to hear your vehicle better.

• From a speed of 12 mph (20 km/h), the acoustic vehicle alerting system gradually switches off.

- Despite the sound generator, the vehicle still may not be heard by other road users. Adapt your driving style accordingly.
- The sound generator is off when the vehicle is stationary.

Manually disconnecting the high-voltage on-board electrical system



DANGER Risk of death and fire due to modified and/or damaged components of the high-voltage on-board electrical sys-

The vehicle's high-voltage on-board electrical system is under high voltage. If you modify component parts in the vehicle's high-voltage on-board electrical system or touch damaged component parts, you may be electrocuted. In addition, modified and/or damaged components may cause a fire.

In the event of an accident or impact to the underbody, components of the high-voltage electrical system may be damaged although the damage is not visible.

- Never make any modifications to the high-voltage on-board electrical system.
- Do not switch on or use the vehicle if its high-voltage on-board electrical system components have been modified or dam-
- Never touch damaged components of the high-voltage on-board electrical system.
- After an accident, do not touch any components of the high-voltage on-board electrical system.
- After an accident, have the vehicle transported away.
- Have the components of the high-voltage on-board electrical system checked at a qualified specialist workshop and replaced if necessary.


Requirements:

- The prestraint system warning lamp lights up in the instrument cluster, e.g. after an acci-
- The vehicle is badly damaged, e.g. after an accident, and the restraint system components have not been triggered.
- The vehicle has not been started.
- The vehicle is secured against rolling away.

Using the high-voltage disconnect device in the engine compartment

Disconnect the drive system manually only under the prerequisites in the specified situations.

Proper the hood (→ page 155).




- Press release tab
 in the direction of the arrow and pull it out.
- Pull high-voltage disconnect device ② in the direction of the arrow until it engages. The drive system has been disconnected. The capacitors of the vehicle's high-voltage electrical system are completely discharged after one minute at the earliest.

All work on the drive system may be carried out only at a qualified specialist workshop, even if it has been deactivated manually.

Using the high-voltage rescue separation point in the seat base of the driver's seat

Disconnect the drive system manually only under the prerequisites specified in the above-mentioned situations.

The high-voltage rescue separation point should be used only in an emergency and only by rescue personnel. The high-voltage rescue separation point is located in the seat base of the driver's seat.



- Open the fuse box in the seat base of the driver's seat (→ page 171).
- Sever the orange cable at marked position with a suitable tool. The drive system has been disconnected. The capacitors of the vehicle's high-voltage electrical system are completely discharged after one minute at the earliest.

All work on the drive system may be carried out only at a qualified specialist workshop, even if it has been deactivated manually.

Regenerative brake system

Function of the regenerative brake system

To charge the high-voltage battery while driving, the electric motor is operated as a alternator, depending on the selected recuperation level, in overrun mode and during braking. As soon as you release the accelerator pedal when the vehicle is in motion, recuperation in overrun mode is initiated. This does not apply if you have selected the recuperation level |D|+|+| (no recuperation).

The regenerative brake system has the following characteristics:

- it supports braking with electronically controlled brake force boosting
- it converts the kinetic energy of the vehicle into electric energy

You can use the steering wheel paddle shifters to manually adjust the intensity of recuperation in overrun mode (\rightarrow page 92).


System limits

The braking effect of the electric motor during recuperation in overrun mode may be reduced or may not be available at all in the following situations:

- with increasing state of charge of the high-voltage battery
- if the high-voltage battery has not yet reached operating temperature
- when driving at very slow speeds (near standstill)
- in drive range N
- during and after ESP[®] intervenes

Manually setting recuperative deceleration

You can use the steering wheel paddle shifters to manually adjust the intensity of recuperation in overrun mode.



The higher the recuperation, the more sharply the vehicle is braked when coasting and the more electric energy is fed into the high-voltage battery.

- (i) Recuperation level **D** is automatically set after restarting the vehicle.
- To increase recuperation: briefly pull steering wheel paddle shifter (1).
- ➤ To decrease recuperation: briefly pull steering wheel paddle shifter ②.
- D AUTO To select: pull and hold steering wheel paddle shifter 1 or 2.

The following recuperation levels are available:

• DAUTO Radar-supported recuperation taking road and traffic conditions into account, or

- intelligent and anticipatory recuperation with ECO Assist
- **D** + + No recuperation: the vehicle coasts, rolls freely, e.g. for driving on highways
- D + Decreased recuperation: slight deceleration in overrun mode
- D Normal recuperation
- D Increased recuperation: maximum deceleration in overrun mode, e.g. for driving in the city

(i) In addition to radar detection, ECO Assist analyze other data for the expected route. This allows ECO Assist to help optimally adjust the driving style for the route ahead, use minimal energy and recuperate.

Switching on the power supply or drive system using the start/stop button

WARNING Risk of accident and injury due to children left unattended in the vehicle

If you leave children unattended in the vehicle, they could, in particular:


- open doors, thereby endangering other persons or road users.
- get out and be struck by oncoming traffic.
- operate vehicle equipment and become trapped, for example.

In addition, the children could also set the vehicle in motion by, for example:

- releasing the parking brake.
- changing the gearbox position.
- · starting the vehicle.
- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the key with you and lock the vehicle.
- Keep the key out of reach of children.

Requirements:

- the key is in the detection range of the antenna
 (→ page 38) and the key battery is not flat
- · the brake pedal is not depressed



To switch on the power supply: press button once.

You can, for example, activate the windshield wipers.

The power supply will be switched off again when one of the following conditions is met:

- · you open the driver's door
- you press button 1 twice more
- To switch on the drive system: press button twice.

The indicator lamps on the instrument cluster will light up.

The drive system will be switched off again if one of the following conditions is met:


- You do not start the vehicle within 15 minutes.
- You press button (1) once.

Starting the engine

Starting the vehicle with the start/stop button

Requirements:

 the key is in detection range of the antenna (→ page 38) and the key battery is not discharged.



- Shift the transmission to position P or N.
- Depress the brake pedal and press button once.


 The vehicle will start. Once the vehicle can be driven, the READY display will appear on the

instrument cluster.

- If the vehicle does not start: switch off any unnecessary consumers and press button
- If the vehicle still does not start and the display message Place Key in Marked Space See Operator's Manual appears in the instrument cluster: start the vehicle in emergency operation mode.
- (i) If you leave the driver's seat after starting the vehicle, the instrument cluster will show a display message reading \(\text{\text{N}} \) Vehicle Operational Switch the Ignition Off Before Exiting. If you do not sit in the driver's seat within the next minute, the vehicle will automatically switch off.

Starting the vehicle in emergency operation mode

If the vehicle does not start and the display message Place Key in Marked Space See Operator's Manual appears on the instrument cluster, you can start the vehicle in emergency operation mode



- Remove key ① from your key ring.
- Insert key (1) into the slot. The vehicle is started after a brief time.
- Leave the key inserted during the entire jour-
- (i) When you remove key (1) from the slot, the vehicle stays switched on.
- Have key (1) checked at a qualified specialist workshop.

If the vehicle does not start:

- Leave key 1 in the slot.
- Depress the brake pedal.
- Start the vehicle with the start/stop button.
- (i) You can also switch on the power supply or the drive system with the start/stop button.

Breaking-in notes

After the vehicle has been delivered or after repairs, the sensor system of some driving systems and driving safety systems will adjust itself automatically after the vehicle has been driven a certain distance. Full system effectiveness will not be reached until the end of this teach-in process.

New or replaced brake pads, brake discs and tires will provide optimal braking and grip only after several hundred kilometers. Until then, compensate for the reduced braking effect by depressing the brake pedal with greater force.

Driving tips

Notes on driving

WARNING Risk of accident due to objects in the driver's footwell

Objects in the driver's footwell may impede pedal travel or block a depressed pedal.

This will jeopardize the operating and road safety of the vehicle.

- Stow all objects in the vehicle securely so that they cannot get into the driver's footwell.
- Make sure that there is always sufficient clearance for the pedals.
- Ensure there are non-slip attachments for floor mats and carpets.
- Do not lay multiple floor mats or carpets on top of one another.



WARNING Risk of accident due to incorrect footwear

Incorrect footwear includes, for example:

- Shoes with platform soles
- Shoes with high heels
- Slippers

There is a risk of an accident.

Always wear suitable footwear so that you can operate the pedals safely.

WARNING Risk of accident if the vehicle is switched off while driving

If you switch off the vehicle while driving, safety functions are restricted or no longer available.

This may affect the power steering system and the brake force boosting, for example.

You will need to use considerably more force to steer and brake, for example.

Do not switch off the vehicle while driving.



WARNING Risk of skidding and accident if recuperation level is increased on a slippery road surface

If the recuperation level is increased on a slippery road surface, the drive wheels may lose grip.

- Do not increase the recuperation level on a slippery road surface.
- ▲ WARNING Risk of accident and injury due to being under the influence of alcohol and drugs while driving

Drinking and driving and/or taking drugs and driving are very dangerous combinations. Even a small amount of alcohol or drugs can affect your reflexes, perceptions and judgment.

The possibility of a serious or even fatal accident are greatly increased when you drink or take drugs and drive.

Do not drink or take drugs and drive or allow anyone to drive who has been drinking or taking drugs.

★ WARNING Risk of accident and injury from operating mobile communications equipment

If you operate mobile communication equipment when driving, you will be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

The probability of a serious or even fatal accident increases greatly if you operate mobile communication equipment when driving.

Only operate mobile communication equipment when the vehicle is stationary.

For your own safety, observe the following points when operating mobile communications equipment:

- Please observe the legal requirements for the country in which you are driving.
- While driving, only operate mobile communications equipment when the traffic conditions permit it. You could otherwise be distracted from traffic, cause an accident and injure yourself and others.
- NOTE Vehicle damage due to failure to observe the maximum permissible clearance height

If the vehicle height exceeds the maximum permissible clearance height, the roof and other vehicle parts may be damaged.

Please observe the maximum clearance height indicated.

- If the vehicle exceeds the permissible clearance height, do not drive in.
- Take the modified vehicle height into account in the case of roof superstructures or other carrier systems.
- (i) Please bear in mind that all the speeds indicated in this Operator's Manual are approximate and are subject to a certain tolerance.

Notes on speed limitation

▲ WARNING Risk of injury through exceeding the specified tire load-bearing capacity or the permissible speed rating

Exceeding the specified tire load rating or the permissible speed rating may lead to tire damage and to the tires bursting.

- Therefore, only use tire types and sizes approved for your vehicle model.
- Observe the tire load rating and speed rating required for your vehicle.

Find out about the maximum permissible speed resulting from the tires, i.e. tires and tire pressure. Please observe the legal requirements for tires for the country you are in.

(i) Vehicles with tachograph: due to the different certification requirements for the tachograph and instrument cluster, the displayed speeds may differ. Please keep to the speed display on the instrument cluster.

You can permanently limit the speed of your vehicle.

Mercedes-Benz recommends a qualified specialist workshop for programming the speed limitation.

Note that you cannot exceed a programmed speed limitation when overtaking.

On downhill gradients, the speed limitation may be exceeded. Apply the brakes if necessary.

Display messages will warn you that you are approaching the speed limitation.

(i) For bus-equipped vehicles, the ex-works speed limitation for your vehicle is 60 mph (100 km/h) When overtaking, bear in mind that the speed limitation cannot be exceeded.

Information about transport by rail

Transporting your vehicle by rail may be subject to certain restrictions or require special measures to be taken in some countries due to varying tunnel heights and loading standards.

You can obtain information about this from any authorized Mercedes-Benz Center.

Information on braking

Heavy and light loads

If the brakes have been subjected to heavy use, do not park the vehicle immediately. Drive on for a short while. The brakes cool down more quickly in the airflow.

If you only make moderate use of the brakes, you should occasionally test their effectiveness. To do this, brake more firmly from a higher speed while paying attention to the traffic conditions. The brakes will grip better as a result.

Wet road surfaces

If you have been driving for a long time in heavy rain without braking, there may be a delayed response when you first apply the brakes. This may also occur after driving through a car wash or deep water. You must depress the brake pedal more firmly. Maintain a greater distance from the vehicle in front.

While paying attention to the traffic conditions, you should brake the vehicle firmly after driving on a wet road surface or through a car wash. This heats the brake discs so that they dry more quickly, which protects them against corrosion.

Impaired braking effect on roads treated with deicing salt:

- · a layer of salt on the brake discs or brake linings can increase braking distances considerably, or braking may only be one-sided
- · maintain an especially large safety distance from the vehicle in front

To remove the layer of salt:

- · apply the brakes from time to time, paying attention to traffic conditions
- depress the brake pedal gently at the end of a journey and when starting a new journey

Checking the brake lining thickness

In addition to monitoring by the brake lining wear sensor, you can regularly monitor and check all of the brake linings by a visual inspection for material wear.

If you are unable to check the brake lining wear on the inside of the wheels, remove the wheels if you possess the required skills. Otherwise visit a qualified specialist workshop.

If the brake lining material thickness is less than 0.12 in (3 mm), have the brake linings checked and if necessary replaced at a qualified specialist workshop.

Do not rely solely on the brake lining wear sensor. It is also strongly recommended that you have the brake linings checked at a qualified specialist workshop, and not only during every service prompted by the service interval display. Also check the brake linings before long journeys, and whenever the wheels are removed.

Check the brake linings in the following situations:

- during every service according to the service interval
- before long journeys
- every time a tire is replaced
- make regular visual inspections for your own safety

New brake discs and brake linings

New brake linings and brake discs only reach their optimal braking effect after a few hundred miles (a few hundred kilometres).

Until then, compensate for the reduced braking effect by pressing the brake pedal with greater force. For safety reasons, Mercedes-Benz recommends that you only have brake linings and brake discs which are approved by Mercedes-Benz installed in your vehicle.

Other brake discs or brake linings may compromise the safety of your vehicle.

Always replace all brake discs and brake linings on an axle at the same time. Always fit new brake linings when replacing brake discs.

Information about driving on wet roads

Hydroplaning



WARNING Risk of hydroplaning due to insufficient tire tread

Depending on the level of water on the road surface, hydroplaning may occur.

Avoid tire ruts and brake carefully.

Change tires that do not have sufficient tire tread.

Therefore, in heavy rain or other conditions in which hydroplaning can occur, drive as follows:

- reduce your speed.
- avoid tire ruts.
- brake carefully.

Driving on flooded roads

Bear in mind that vehicles traveling in front or in the opposite direction create waves. This may cause the maximum permissible water depth to be exceeded. These notes must be observed under all circumstances. Otherwise, you could damage the drive system, electrics and transmission.

If you have to drive on stretches of road on which water has collected, please bear in mind the following:

- the level of standing water must not be above the lower edge of the front bumper
- · you must drive no faster than walking pace.

Information about driving in winter

Drive particularly carefully on slippery roads. Avoid sudden acceleration, steering and braking maneuvers.

Have your vehicle winterproofed at a qualified specialist workshop in good time at the onset of winter.

Please observe the notes on snow chains $(\rightarrow page 175)$.

Regularly check the vehicle and remove snow or ice when traveling in wintry conditions.

An accumulation of snow and ice, particularly when frozen, in the area around the air intake, moving parts, the axles and the wheel wells may cause the following problems:

- · obstruction of the air intake
- · damage to vehicle parts
- Malfunctions due to restriction of the movement intended by the design (e.g. reduced steering movement)

If there is any damage, inform a qualified specialist workshop.

Information about driving off road

A WADNING Dick of oo

WARNING Risk of accident if you do not keep to line of fall on inclines

If you drive at an angle or turn on an incline, the vehicle could slip sideways, tip and rollover.

Always drive on inclines in the line of fall (straight up or down) and do not turn.

WARNING Risk of injury from acceleration forces during off-road driving

You could be thrown from your seat, for example.

Always wear your seat belt even when driving off-road.

WARNING Risk of injury to the hands when driving over obstacles

If you drive over obstacles or in tire ruts, the steering wheel may whip around.

- The steering wheel must always be held securely with both hands.
- Always hold the steering wheel so that your thumbs are on the outer rim of the steering wheel.
- When driving over obstacles, expect increased steering forces at short notice.

! NOTE Damage to the vehicle after driving off-road

Foreign bodies, such as stones and branches, could become trapped on the vehicle underside or on wheels and tires while you are driving and cause damage to the vehicle.

Foreign bodies could cause the following damage:

- Damage to the suspension, the high-voltage battery on the vehicle underside or the brake system
- Cause imbalances and thus vibrations
- Regularly remove any trapped foreign bodies, e.g. stones and branches.
- After driving off-road, check carefully whether there is any damage to the vehicle.
- If there is damage, have the vehicle checked at a qualified specialist workshop.

When driving off road or on unpaved surfaces, check the vehicle underside, wheels and tires at regular intervals. In particular, remove any trapped foreign bodies, e.g. stones and branches.

Please observe the following notes regarding foreign bodies of this kind:

- They could damage the suspension, the highvoltage battery in the underbody or the brake system.
- They could cause imbalances and thus vibrations
- They could be ejected from the vehicle when you continue driving.

If there is any damage, inform a qualified specialist workshop.

When you drive off road and on construction sites, sand, mud and water, for example, possibly mixed with oil, may get into the brakes. This may lead to a reduction in braking performance or total brake failure, including as a result of increased wear. The braking characteristics will vary depending on the material that has infiltrated the system. Clean the brakes after driving off road. If you then notice reduced braking performance or hear scraping noises, have the brake system checked immediately at a qualified specialist workshop. Adapt your driving style to the changed braking characteristics.

Driving off road or on construction sites increases the possibility of vehicle damage, which could in turn lead to the failure of certain major assemblies or systems. Adapt your driving style to the off-road driving conditions. Drive carefully. Have any vehicle damage repaired at a qualified specialist workshop as soon as possible.

When driving on rough terrain, do not shift the transmission to neutral. You could lose control when attempting to slow the vehicle with the service brake. If your vehicle cannot manage an uphill incline, drive back down in reverse gear.

When loading your vehicle for driving off road or on a construction site, keep the vehicle's center of gravity as low as possible.

Checklist before driving off road

- Vehicle tool kit: check that the jack is working (→ page 190).
- Make sure that a wheel wrench (→ page 190), a wooden underlay for the jack, a sturdy tow rope, a folding spade and a wheel chock (will be present, depending on equipment) are carried in the vehicle.
- Tires and wheels: check the tire tread depth
 (→ page 174) and the tire pressure
 (→ page 179).

Rules for off-road driving

Always be aware of the vehicle's ground clearance and avoid obstacles such as deep tire ruts.

Obstacles may damage the following parts of the vehicle, for example:

- Suspension
- Drivetrain
- The high-voltage battery in the underbody

Therefore, always drive slowly off road. If you must drive over obstacles, have the front passenger guide you.

- (i) Mercedes-Benz recommends that you additionally carry a shovel and a recovery rope with a shackle in the vehicle.
- Make sure that loads and items of luggage are securely stowed or lashed down (→ page 148).
- If the surface requires, temporarily deactivate ESP[®] when starting off (→ page 115).
- Drive slowly and smoothly. It may often be necessary to drive at walking pace.
- Avoid spinning the wheels.
- Ensure that the wheels remain in contact with the ground.
- As a precaution, get out of the vehicle to take a look at the route ahead. Exercise the utmost caution when driving across unfamiliar, unpredictable terrain.
- Look out for obstacles (e.g. rocks, holes, tree stumps and tire ruts).
- Avoid edges where the ground could crumble or break away.

Checklist after driving off road

Driving off road places greater demands on your vehicle than driving on normal roads. Check your vehicle after driving over rough terrain. By doing so, you will notice any damage in good time and reduce the risk of an accident for yourself and other road users. Clean your vehicle thoroughly before driving on public roads.

If you find damage to the vehicle after off-road driving, have the vehicle checked at a qualified specialist workshop immediately.


Please note the following points after driving off road or on construction sites and before driving on public roads:

- Activate ESP[®] (→ page 115).
- Clean the exterior lighting, particularly the headlamps and tail lamps, and check them for damage.
- Clean the front and rear license plates.
- Clean the windshield, windows and outside mirrors.
- Clean the steps, entrances and grab handles. This will make your footing safer.
- Clean the wheels and tires, wheel wells and the underbody of the vehicle with a jet of

water. This will increase traction, especially on wet road surfaces.

- Check the wheels and tires and wheel wells for trapped foreign objects and remove them.
 Trapped foreign objects can damage the wheels and tires or could be ejected from the vehicle when you continue the journey.
- Check the underbody for trapped branches or other vegetation and remove them.
- Clean the brake disks, brake pads and axle joints, particularly after operation in sand, mud, grit and gravel, water or similarly dirty conditions.
- Check the entire floor assembly, the tires, wheels, bodywork structure, brakes, steering and suspension for damage.
- Check the service brake for operating safety, e.g. carry out a brake test.
- If you notice significant vibrations after driving off road, check the wheels and drivetrain for foreign objects again. Remove any foreign objects that could lead to imbalances and thus cause vibrations. In the event of damage to the wheels and the drivetrain, visit a qualified specialist workshop immediately.

Function of the ECO display



The ECO display shows an evaluation of your driving style on the driver display depending on the situation. This enables you to check the efficiency of your driving style and adjust it if necessary. The ECO Display menu shows a ball ② that will roll forwards or backwards in the direction of travel on a stylized road according to the driving characteristics.

Above and below the road, lines mark the area for an efficient driving style ③. Ball ② will light up in green if it is rolling within these lines. Outside the lines, the ball will light up in orange.

The ECO display assesses the following criteria for an economical driving style:


- Coasting at the right times
- Consistent speed
- Moderate acceleration

The overall assessment of your driving style "from start" is indicated using stars ①. It starts with five empty stars, which you can fill one after the other if you drive efficiently. When all five stars are filled, a glow will appear in the background.

(i) You can call up the ECO Display function via the Trip menu.

Drive programs

Function of the program selector button



Use program selector button **(1)** to switch between the following drive programs:

(Comfort)

E (Eco)

MR (MAX Range)

Depending on the drive program selected, the following vehicle characteristics will change:

- The performance of heating or air conditioning
- · Output of the drive system
- Acceleration

The available power of the drive system is shown on the instrument cluster display and can be reduced, e. g. when the high-voltage battery has a very low state of charge (\rightarrow page 133).

Characteristics per drive program:

Drive program	Vehicle characteristics
© (Comfort)	 Comfortable driving style Full heating and air-conditioning output Maximum power availability of the drive system
(Eco)	Efficient and economical driving style Reduced heating and air conditioning output for increased range Reduced power of the drive system
(MAX Range)	Maximum range and consumption optimization Heavily reduced heating and air-conditioning output Reduced torque and severely reduced drive system output

i If you depress the accelerator pedal beyond the point of resistance (kickdown), the maximum power will also be available in drive programs and MR.

Selecting a drive program

Press the program selector button. The drive program selected will appear on the instrument cluster display next to the transmission position display.

Depending on the selected energy content of the high-voltage battery, the **E** or **C** drive program will be automatically selected after a drive system start.

Transmission

DIRECT SELECT lever

■ Function of the DIRECT SELECT lever

WARNING Risk of accident and injury if children are left unattended in the vehicle


If children are left unattended in the vehicle, they could in particular:

- open doors, thereby endangering other persons or road users.
- get out and be struck by oncoming traffic.
- operate vehicle equipment and become trapped, for example.

In addition, the children could also set the vehicle in motion, for example by:

- · releasing the parking brake.
- changing gear.
- starting the vehicle.
- Never leave children unattended in the vehicle.
- ► When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- Keep the SmartKey out of the reach of children.

You use the DIRECT SELECT lever to switch the drive range. The current drive range will appear on the display on the instrument cluster.



- P Park position
- R Reverse gear
- N Neutral
- **D** Drive position

Engaging reverse gear R

Depress the brake pedal and push the DIRECT SELECT lever upwards past the first point of resistance.

Transmission position display R will be shown on the instrument cluster display.

Selecting neutral N

WARNING Risk of accident and injury when neutral position is engaged

If you park the vehicle with the transmission in neutral position N and the parking brake is not engaged, the vehicle may roll away.

There is a risk of accident and injury.

- Before parking the vehicle, apply the parking brake.
- Press the brake pedal and the DIRECT SELECT lever upwards or downwards to the first point of resistance.

Transmission position display N will be shown on the instrument cluster display.

Subsequently releasing the brake pedal will allow you to move the vehicle freely, e.g. to push it or tow it away.

If the transmission is also to stay in neutral N when the vehicle is switched off, proceed as follows:

- Start the vehicle.
- Depress the brake pedal and engage neutral
- Release the brake pedal.
- Switch off the vehicle.
- (i) If you then exit the vehicle leaving the key in the vehicle, the transmission will remain in neutral N.

Engaging park position P

NOTE Damage due to engaging park position P while the vehicle is rolling

If you shift the transmission into park position **P** while the vehicle is rolling, the transmission may be damaged.

- If the vehicle is rolling, do not open a
- Only engage park position P when the vehicle is stationary.

- Observe the notes on parking the vehicle $(\rightarrow page 110)$.
- Depress the brake pedal until the vehicle is stationary.
- When the vehicle is stationary, press button

When the transmission position \mathbf{P} is shown. park position is engaged. If the transmission position **P** is not shown, apply the parking brake. Secure the vehicle against rolling away with a wheel chock or a non-sharp-edged object.

Park position **P** will be engaged automatically when one of the following conditions is met:

- · You switch the stationary vehicle off in transmission position **D** or **R**.
- You open the fully closed driver's door when the vehicle is stationary in transmission position **D** or **R**.
- When the vehicle is rolling, you switch it off in transmission position **D** or **R** and bring it to a standstill.
- When the HOLD function is active or the Active Distance Assist DISTRONIC system is active (vehicle stationary), the driver leaves the seat or the driver's seat belt buckle is unfastened.
- When the vehicle is rolling, you shift to transmission position \mathbb{N} , bring the vehicle to a standstill and open the fully closed driver's door when the vehicle is stationary.
- Engaging park position P automatically is required by the vehicle.
- (i) To maneuver with an open driver's door, open the fully closed driver's door while the vehicle is stationary and engage transmission position **D** or **R** again.

Engaging drive position D

Depress the brake pedal and push the DIRECT SELECT lever downwards past the first point of resistance.

Transmission position display **D** will be shown on the instrument cluster display.

Charging the high-voltage battery

Notes on charging the high-voltage battery

NOTE High-voltage battery damage due to leaving the vehicle idle for lengthy periods of time

Lithium-ion batteries experience a natural selfdischarge.

Exhaustive discharging can therefore occur if the vehicle is idle for several months. This can damage the high-voltage battery.

To avoid damage, please observe the following recommendations when handling the high-voltage battery.

! NOTE Accelerated aging of the high-voltage battery may occur if the following recommendations are not observed.

As a result of its basic characteristics, the storage capacity of and the amount of energy available from the high-voltage battery decreases over the course of its life. Therefore, both the maximum electrical range that can be achieved by the vehicle and its maximum electrical output can be impaired.

The following factors can accelerate the aging of the high-voltage battery:

- Frequent rapid charging with direct current (mode 4)
- · Leaving the vehicle non-operational for long periods at high ambient temperatures
- To avoid accelerated aging, please observe the following recommendations when handling the high-voltage battery.
- NOTE Damage to the vehicle socket or the charge port due to incorrect handling

Do not use excessive force (maximum 67.4 lbf (300 N)) to insert the charge port into the vehicle socket to the stop. You may otherwise damage the vehicle socket, the charge port or their contacts.

If you feel there is increased resistance, pull the charge port out of the socket and reinsert it.

NOTE Damage to the drive system when charging the high-voltage battery at extreme elevations

The drive system may be damaged if the highvoltage battery is charged at elevations greater than 13,123.36 ft (4,000 m) above sea level.

It may then no longer be possible to continue the journey.

Avoid charging processes at extreme elevations.

Information on charging times can be found in the technical data (\rightarrow page 230).

Recommendations for handling the high-voltage battery:

- · Only use direct current (mode 4) to guickcharge the high-voltage battery if necessary.
- · Charge the high-voltage battery on average to a state of charge of 80%. Beyond a state of charge of 80%, the charging time is significantly increased.
- If leaving the vehicle non-operational for lengthy periods, park it with a high-voltage battery state of charge of between 30% and 50%. Do not keep the high-voltage battery continuously connected to power supply equipment.
- · If leaving the vehicle non-operational for lengthy periods of time avoid, if possible, high ambient temperatures.
- Check the high-voltage battery's state of charge every six weeks (\rightarrow page 103).
- If the state of charge is below 20%, recharge the high-voltage battery.
- Do not disconnect the 12 V battery even if the vehicle is left non-operational for a lengthy period. Otherwise the condition of the vehicle's high-voltage battery will not be moni-

You can contribute to reducing the vehicle's energy consumption in the following ways:

- an anticipatory driving style (→ page 99)
- reduced use of electrical consumers
- regular servicing of the vehicle

The charging time of the high-voltage battery may change over the course of its life.

You can charge the high-voltage battery with both alternating current (mode 2 or 3) and direct current (mode 4).



Vehicle socket in the radiator grille

- Socket for charging with alternating current
- Socket extension for charging with direct current
- (i) When using a CCS (Combined Charging System) charging cable to charge with direct current, both areas of the vehicle socket are covered by the charge port.

Charging options for the high-voltage battery:

- · Charging through recuperation while the vehicle is in motion
- · Stationary charging with alternating current
 - mains socket (mode 2)
 - wallbox (mode 3)
 - charging station (mode 3)
- · Stationary charging with direct current via:
 - charging station (mode 4)

The charging current for single-phase charging is determined by the country-specific equipment installed in the vehicle.

Observe any possible different local mains requirements at your current location when charging. Consult a qualified electrician or your local distribution network operator if you have any questions concerning grid requirements.

It is recommended that you charge the high-voltage battery at a wallbox or charging station owing to the higher charging power and better charging efficiency offered.

System limits

The charging time of the high-voltage battery may be increased by the following:


- · high or low outside temperatures
- the vehicle remaining non-operational for an extended period without charge
- the maximum available charging current of the wallbox or power supply
- the settings for the charging process in the onboard computer
- · you have consented to a calibration of the high-voltage battery (\rightarrow page 152)

The power output of the high-voltage battery may be impaired by the following:

- high or low outside temperatures
- electrical auxiliary consumers in the vehicle being switched on, e.g. operating the climate control system
- the vehicle remaining non-operational for an extended period without charge

Function of the charge level display

(i) The data shown in the illustration are sample data.



- Time remaining until fully charged (until the selected maximum state of charge is reached)
- Maximum state of charge (depending on the setting)
- State of charge recommended by Range Assistant to reach the next destination
- Dynamic charge level display
- Current charging power

- 6 State of charge at next set departure time
- Remaining range at current state of charge
- Current state of charge of the high-voltage battery
- Set "Standard" charging program
- Pre-entry climate control active (automatic if departure time is set)
- Departure time symbol: one-time departure time set
- ECO charging activated
- i Indicated remaining range nay vary due to different factors, e.g. driving style or topography.
- (i) The value of the current charging power (s) can differ from the display on the charging station. At a charging power of 10 kW or higher, the value in the charge level display is rounded up or down and shown without a decimal place.

The value in ① varies depending on the setting of the charging process. It displays a prediction for the time until the maximum state of charge is reached. If Range Assistant is active, it displays a prediction for the time until the continuation of the journey is recommended.

The value in **(6)** varies depending on the setting of the charging process. It displays the expected state of charge at the next set departure time. This may be a single event or the next element in the weekly profile.

In place of the symbol for the earl "Standard" charging program, the following symbols may also be displayed:

- The Home charging program is set.
- The Work charging program is set.
- (i) An orange plug symbolizes a charging prompt. In addition to the symbol for the "One-time departure time" setting, the following symbols may also be displayed:
- □ No departure time is set.
- The weekly profile is active.

Configuring the charging settings

On-board computer:

¬→ Settings → eSprinter

For fleet vehicles, the eSprinter menu or its menu items may not be available.

Adjust the settings in the fleet management system, if possible.

Setting the charging program

Select Standard, Home or Work.

Setting the maximum state of charge

You can set the maximum state of charge in increments of 10 % between 50% and 100%.

- Observe the notes on charging the high-voltage battery (→ page 102).
- Select Standard, Home or Work.
- Set the maximum state of charge to the desired value, for example 80%.
- (i) For the high-voltage battery used in this vehicle, we advise against continually limiting the maximum state of charge, but recommend charging the high-voltage battery fully at regular intervals.

Unlocking the charging cable (mode 3 or 4)

- (i) When the function is active, the charging cable is unlocked once the maximum state of charge is reached.
- Select Home or Work.
- Activate or deactivate Unlock Charging Cable.

Switching on or off ECO Charging ICON_Eco_Charging_small

- Select Standard, Home or Work.
- Activate or deactivate the function.

The ECO Charging ICON_Eco_Charging_small function reduces the strain placed on the high-voltage battery during the charging process, thus helping to slow the natural aging process. The vehicle is charged using alternating current (AC) to a defined state of charge. It then takes the departure time into account when determining the rest of the charging process. This ensures that the high-voltage battery is optimally charged and still reaches the desired state of charge.

Setting the departure time

The set departure times are used for the vehicle's pre-entry climate control system and to predict the state of charge at the time selected.

As long as ECO Charging ICON_Eco_Charging_small is not activated, the charging process always starts immediately, irrespective of the next departure time.

- (i) If the Range Assistant function is active, it automatically determines, during a charging stop, the approximate time at which the desired state of charge will be attained. This is used as an approximate departure time for pre-entry climate control and is set automatically. Previously set departure times cannot be changed when the function is active.
- Select Departure Time.

The following charging times can be set:

- · individual charging times
- a Week Profile ICON_DepartureTimeWeekly

Setting an individual departure time

Select Add New Time and set a new departure time.

Select and adjust an existing departure time.


Setting the repeat days

Set the weekly profile via "Mercedes me connect".

Further information may be found in the "Mercedes me connect" Supplement.

Functions of the indicator lamps on the vehicle socket

The charge socket flap with the Mercedes star in the radiator grill is centrally locked and unlocked together with the vehicle.



Vehicle socket in the radiator trim

- Status indicator
- Charging process indicator lamp
- Locking status indicator lamp

Status display 1 flashes or lights up as with indicator lamps (2) and (3).

Overview of locking status

Locking sta- tus ③	Display	Meaning
U	Lights up white	Vehicle socket unlocked, insert or remove charg- ing cable
U	Flashes white	Malfunction during locking or unlocking

Overview of the charging process status

	• • •	
Status of charging process 2	Display	Meaning
	Flashes orange	Connection is being estab- lished
	Flashes green	Active energy flow
- 1	Lights up orange	Interruption in charging
- •	Lights up green	Charging process completed
<u></u>	Flashes red (for approx. 90 s)	Malfunction when charg- ing

Notes on charging the high-voltage battery at the mains socket (mode 2)

DANGER Risk of fatal injury from incorrectly installed component parts

Connecting the charging cable to a mains socket using incorrectly installed component parts could cause a fire or an electric shock, for example.

Only connect the charging cable to a mains socket that:

- has been properly installed and
- has been inspected by a qualified electrician
- For safety reasons, only use the charging cable supplied with the vehicle or an original Mercedes-Benz charging cable.
- Purchase these parts at an authorized Mercedes-Benz Center and obtain advice there.

Mercedes-Benz thoroughly tests these original charging cables for their suitability for high-voltage charging of your vehicle.

- Never use a damaged charging cable.
- Do not use:
- extension cables
- extension reels
- multiple sockets
- Never use socket adapters to connect the charging cable to the mains socket. The only exception being if the adapter has been tested and approved by the manufacturer for charging the high-voltage battery of an electric vehicle.
- Observe the safety notes in the operating instructions for the socket adapter.
- ! NOTE Overloading the mains socket due to excessive charging current

If the charging current is too high, the fuse could be tripped or the external mains supply could overheat.

- Make sure that the external mains supply has been designed for the charging current on the vehicle side.
- Use a different, suitable mains socket.

Before charging at a mains outlet, have the maximum permissible charging current for the relevant mains outlet or the building inspected by a qualified electrician.

The charging cable can be set to a country-specific maximum charging current value. When charging abroad, the maximum value may exceed the permitted value for that country.

When abroad, observe the country-specific laws when charging.

Only charging cables that fulfill the local grid requirements of your location and are approved for your vehicle may be used.

If you have questions concerning charging cables or if there is a malfunction, please contact a qualified specialist workshop.

The charging process can vary depending on the power supply equipment.

Short charging times can be achieved:

- · charging at a wallbox
- · charging at a charging station

When doing so, always observe the local information.

Notes on charging the high-voltage battery at a wallbox (mode 3)

DANGER Risk of fatal injury from incorrectly installed component parts

Connecting the charging cable to a wallbox using incorrectly installed component parts could cause a fire or an electric shock, for example.

- Only connect the charging cable to a wallbox that:
- · Has been properly installed and
- Has been inspected by a qualified electrician
- For safety reasons, only use charging cables that have been tested and approved by the manufacturer for charging the high-voltage battery in an electric vehicle.
- Never use damaged charging cables.
- Do not extend the charging cable.
- Do not use adapters.
- Observe the safety notes in the operating instructions for the wallbox.

Observe the local grid requirements of your current location when charging. When charging at a wallbox without a preinstalled cable, use only approved charging cables that conform to these grid requirements. Consult a qualified electrician or your local distribution grid operator if you have any questions concerning grid requirements.

Driving and parking 107

Notes on charging the high-voltage battery at a charging station (mode 3/4)

DANGER Risk of fatal injury due to damaged components

Connecting the vehicle to a charging station using damaged component parts could cause a fire or an electric shock, for example,

- Perform a visual check of the charging station for obvious defects, for example damage to the housing or charging cable connection.
- Never use damaged charging cables.
- Do not use an extension for the charging cable.
- Do not use adapters.
- Always observe the safety instructions on the charging station.

DANGER Risk of fatal injuries when carrying out maintenance work during the charging process

During the charging process, the high-voltage on-board electrical system is under high voltage.

Do not perform any maintenance work during the charging process.

Observe the local network requirements at your current location when charging. When charging with alternating current at a charging station without a pre-installed cable, only use approved charging cables which conform to these network requirements. Consult a qualified electrician or your local distribution network operator if you have any questions concerning grid requirements.

Most charging stations need to be activated before the charging process, e.g. by using an RFID card or via Plug-and-Charge. Observe the on-site operator's instructions for the charging station and the notes on Mercedes me Charge (see the Digital Operator's Manual for the vehicle).

Due to legal regulations in the individual countries, the charging cable to the vehicle must be no longer than 98.5 ft (30 m). This is to prevent the interference of signals being received by radio communication devices in the vehicle or in close proximity to the charging station. Be aware that parts of the charging cable may be routed underground. If in doubt, ask the charging station operator if this is the case before charging the high-voltage battery.

Starting the charging process

DANGER Risk of death when charging at a damaged socket

The charging process uses high voltage.

If the charging cable, the vehicle socket or the mains socket are damaged, you could receive an electric shock.

- Only use an undamaged charging cable.
- Avoid mechanical damage such as crushing, abrading or driving over the cable.
- Have a damaged vehicle socket replaced at a qualified specialist workshop as soon as possible.
- Never connect the charging cable to a damaged vehicle socket.

NOTE Damage to the vehicle due to overvoltage in the mains supply

The vehicle is equipped with an electrical fuse which protects it against overvoltage in the mains supply. This electrical fuse may trip during severe thunderstorms, for example, and may cause the fuse in the building to trip or may interrupt the charging process. These functions protect the vehicle.

After the fuse in the building is switched on again, the charging process resumes automatically.

Following an interruption in the power supply without the fuse in the building being tripped, it may take up to ten minutes for charging to resume automatically.

NOTE Damage due to overheating of charging cable and charge port

Charging cable and charge port may generate heat within the permissible limiting values during the charging process.


The heat generated by the charging cable and charge port is influenced by the following factors:

- The power supply of the mains and the charging cable are intact.
- The notes on handling the charging cable and operating unit on the charging cable were observed.

- If the charging cable or the charge port generate too much heat, have the power supply of the mains supply checked.
- I NOTE Damaged or dirty vehicle socket when the socket flap is open
- Always keep the socket cover and the socket flap closed when there is no charging cable connected. This protects the vehicle socket from dirt and damage.
- Make sure that the socket cover is closed properly before closing the socket flap. This can otherwise result in damage which may prevent the socket flap from being opened again.

Requirements

- The transmission is in position P.
- The drive system has not been started.
- The vehicle is unlocked, or the distance of the key to the vehicle socket is no greater than 3 ft (1 m). In addition, the battery of the key must be sufficiently charged.
- The hood is closed (only applies to mode 4).
- The charging cable is not under tension.



Vehicle socket in the radiator shell

- Press the top left of the socket flap for up to 1 second until it opens.
 - The socket flap
 opens slightly. If the vehicle is not unlocked, the socket flap opens after a brief delay.
 - The indicator lamp ② 🕡 and status display ③ light up white.
- Open socket flap (1) completely.

- i If the drive system has been started (the READY display lights up in the instrument cluster), the socket flap (1) cannot be opened.
- To charge with alternating current, press the upper catch, and to charge with direct current, press both catches to the left.

 The respective socket cover si sopened.
- (i) For the charging process with alternating current (mode 2 or 3), only connection (ii) is required.

Charging via mains socket (mode 2):

- Insert the mains plug into the mains socket of the external power source as far as it will go.
- Insert the charge port into connection (a) of the vehicle socket as far as it will go. Connection (b) remains free and should remain covered by the lower part of socket cover (a). The indicator lamp (a) (b) and status display (a) initially flash orange, and then green as soon as the high-voltage battery is charged.

Charging at a wallbox or charging station (mode 3)

Insert the charge port into connection (a) of the vehicle socket as far as it will go. Connection (a) remains free and should remain covered by the lower part of socket cover (a). If the wallbox or charging station is not equipped with a charging cable, insert the plug of the optional charging cable into the wallbox or charging station socket as far as it will go. The indicator lamp (a) and status display (a) initially flash orange, and then green as soon as the high-voltage battery is charged.

Charging at a charging station (mode 4):

When the charging cable is connected to the vehicle, the drive system cannot be started and the vehicle cannot be moved.

The charging process is aborted if the hood is opened during this process (only applies to mode 4).

When the charging process is started, the estimated charging time is displayed in the instrument cluster. The charging prediction shows the predicted state of charge at the set departure time or the

time at which the high-voltage battery will be fully charged.

The charging prediction may display the following information:

- · the predicted state of charge at a set departure time
- · the time at which the high-voltage battery will be fully charged
- · the time at which the high-voltage battery will reach the preset maximum state of charge


Observe any information displayed in the instrument cluster:

- Charging prediction (→ page 103)
- Display messages (→ page 235)
- (i) Depending on the temperature, the fan and battery cooling system may audibly switch on during the charging process.
- i) If the vehicle is connected to the alternating current mains supply (mode 2 or 3), the highvoltage battery will be recharged automatically as needed or when electrical consumers such as the pre-entry climate control are activated.

Ending the charging process

Requirements:

. The distance of the key to the vehicle socket is no greater than 3 ft (1 m) or the vehicle is unlocked.



Press charging interruption button 2. The charging process is ended after a short time. If indicator lamp 🕡 🕦 then lights up white, the vehicle socket is unlocked.

- (i) Instead of pressing charging interruption button 2, you can press the central locking button on the key four times within 2 seconds.
- Remove the charge port from the vehicle socket within 30 seconds. Only after charging with alternating current (mode 2/3) does the vehicle socket lock again after a period of 30 seconds, and the charging process resumes.
- (i) If you cannot remove the charge port, repeat the unlocking procedure. If the charge port remains locked, unlock the charge port with the emergency release (\rightarrow page 109).
- Close it, or close the socket cover and the socket flap.
- Remove the charge port from the mains socket, or from the socket on the wallbox/ charging station, and stow the vehicle charging cable safely in the vehicle.
- (i) After the charge port has been disconnected, the left indicator lamp on the vehicle socket remains lit for some time before going out.

Unlocking the charge port with the emergency release

WARNING Risk of burns from hot components in the engine compartment

Certain components in the engine compartment can be very hot, e.g. the drive system and the cooler.

Allow the drive system to cool down and touch only the components described below.


If you must unlock the charge port mechanically, touch only the following components:

- hood
- emergency release cable
- NOTE Damaged or dirty vehicle socket when the socket flap is open
- Always keep the socket cover and the socket flap closed when there is no charging cable connected. This protects the vehicle socket from dirt and damage.
- Make sure that the socket cover is closed properly before closing the socket flap. This can otherwise result in damage

which may prevent the socket flap from being opened again.

Requirements:

- The charge port cannot be disconnected.
- The distance of the key to the vehicle socket is no greater than 3 ft (1 m) or the vehicle is unlocked.



- \triangleright Open the hood (\rightarrow page 155).
- Press the charging interruption button on the vehicle socket and check the indicator lamps to ensure that the charging process has ended (→ page 109).
- Pull cable ① upward and disconnect the charge port from the vehicle socket within 30 seconds.
- Close the socket cover and the charge socket flap of the vehicle socket.
- Have the vehicle socket checked at a qualified specialist workshop.

Parking

Parking the vehicle

WARNING Risk of accident and injury due to children left unattended in the vehicle

If you leave children unattended in the vehicle, they could, in particular:


- open doors, thereby endangering other persons or road users.
- get out and be struck by oncoming traffic.
- operate vehicle equipment and become trapped, for example.

In addition, the children could also set the vehicle in motion by, for example:

- · releasing the parking brake.
- changing the gearbox position.
- · starting the vehicle.
- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the key with you and lock the vehicle.
- ► Keep the key out of reach of children.
- ★ WARNING Risk of accident and injury caused by an insufficiently secured vehicle rolling away

If the vehicle is not securely parked sufficiently, it can roll away in an uncontrolled way even at a slight downhill gradient.

- On uphill or downhill gradients, turn the front wheels so that the vehicle rolls towards the curb if it starts moving.
- Apply the parking brake.
- Switch the transmission to position **P**.
- ! NOTE Damage to the vehicle or the drivetrain due to rolling away
- Always park your vehicle safely and according to legal requirements.
- Always properly secure the vehicle against rolling away.



To ensure that the vehicle is properly secured against rolling away unintentionally, observe the following points.

- Always apply the parking brake.
- On uphill or downhill gradients: turn the front wheels towards the curb.
- Shift the transmission to position **P**.
- Switch off the vehicle by pressing button 1.
- Get out of the vehicle and lock it.
- On uphill or downhill gradients: secure the rear axle with a chock or an object without any sharp edges.

Electric parking brake

Information on the electric parking brake

WARNING Risk of accident and injury if children are left unattended in the vehicle

If children are left unattended in the vehicle. they could in particular:

- · open doors, thereby endangering other persons or road users.
- get out and be struck by oncoming traffic.
- operate vehicle equipment and become trapped, for example.

In addition, the children could also set the vehicle in motion, for example by:

- · releasing the parking brake.
- changing gear.
- starting the vehicle.
- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- Keep the SmartKey out of the reach of children.

Observe the note on transporting animals in the vehicle (\rightarrow page 31).

For the automatic functions to work correctly, the driver must be seated in the correct seat position $(\rightarrow page 55)$.

The function of the electric parking brake is dependent on the on-board electrical system voltage. If the on-board electrical system voltage is low or there is a malfunction in the system, the electric parking brake may not be able to be applied. In this case, the yellow indicator lamp lights up.

In this case, park the vehicle in the following way:

- Park the vehicle on level ground and secure it to prevent it from rolling away.
- Shift the transmission to position P.
- (i) The electric parking brake is only actually applied when the red PARK and (D) (USA) indicator lamps or the red (Canada) indicator lamps light up continuously.

It may not be possible to release a parking brake if the on-board electrical system voltage is low or if there is a malfunction in the system. Inform a qualified specialist workshop.

When the vehicle is stationary, the electric parking brake carries out a function test at regular intervals. Noises are normal in this process.


The automatic application of the parking brake only works after a previous journey.

Function of the electric parking brake

When the vehicle is switched off after a journey and the transmission is in position [P], the electric parking brake is automatically applied.

In addition, at least one of the following conditions must be fulfilled:

- the driver is not sitting in the driver's seat
- the belt buckle is undone



The electric parking brake is also automatically applied when the transmission is not in position P, but the following situations occur:

- · there is a system malfunction
- · the power supply is insufficient
- the vehicle is stationary for a long time

The red PARK and (P) (USA) or (P) (Canada) indicator lamps in the instrument cluster light up. The electric parking brake is only actually applied when the red PARK and ((USA) or ((Canada) indicator lamps light up continuously.

(i) To prevent the electric parking brake from applying automatically, pull switch (i).

Releasing the electric parking brake automatically

The electric parking brake of your vehicle is released when all of the following conditions are fulfilled:

- The driver is sitting in the driver's seat.
- · The driver is belted.
- The vehicle has been started.
- **D** or **R** is engaged and you depress the accelerator pedal.

or

You shift out of P into D or R. You must also depress the accelerator if traveling on steep uphill gradients.

• When $\overline{\mathbf{R}}$ is engaged, the rear-end doors must be closed.

Applying/releasing the electric parking brake manually

WARNING Risk of accident and injury if children are left unattended in the vehicle

If children are left unattended in the vehicle, they could in particular:

- open doors, thereby endangering other persons or road users.
- · get out and be struck by oncoming traffic.
- operate vehicle equipment and become trapped, for example.

In addition, the children could also set the vehicle in motion, for example by:

- · releasing the parking brake.
- · changing gear.
- starting the vehicle.
- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- Keep the SmartKey out of the reach of children.

- Observe "Notes on pets in the vehicle" (→ page 31).
- To apply: press the switch when the vehicle is stationary.

When the electric parking brake is applied, the red PARK and (M) (USA) or (M) (Canada) indicator lamps light up in the instrument cluster. The electric parking brake is only actually applied when the red PARK and (M) (USA) or (M) (Canada) indicator lamps light up continuously.

It is also possible to apply the electric parking brake when the vehicle is switched off.

➤ To release: pull the (switch.

The red PARK and (USA) or (Canada) indicator lamps in the instrument cluster go out.

You may only release the electric parking brake if the vehicle is switched on with the start/ stop button.

Emergency braking

In the event of an emergency, you can brake the vehicle while it is in motion with the electric parking brake.

While driving, press the switch of the electric parking brake.

The vehicle's brake lights light up.

The longer the **((())** switch of the electric parking brake is depressed, the greater the braking force.

During the braking procedure, you will receive the following feedback from the vehicle:

- · A warning tone sounds.
- The Release Parking Brake message appears in the instrument cluster.
- The red PARK and (D) (USA) indicator lamps flash in the instrument cluster or the red (C) (Canada) indicator lamp flashes in the instrument cluster.

When the vehicle has been braked to a standstill, the electric parking brake is applied.

Parking up the vehicle

Measures for the 12 V on-board electrical system battery if the vehicle is idle for lengthy periods


- Seek advice from a qualified specialist workshop to avoid damage to the 12 V on-board electrical system battery due to deep discharge.
- If the 12 V on-board battery has been disconnected and is reconnected, fully charge the high-voltage battery. This will enable an optimized display of the range and an optimized charging time forecast.

Measures for the high-voltage battery if the vehicle is idle for lengthy periods

- Park up the vehicle with the high-voltage battery at a state of charge between 30% and
- Do not keep the high-voltage battery continuously connected to power supply equipment.
- Check the state of charge of the high-voltage battery every two to three months. If the 12 V power supply is switched on, you can check the state of charge of the high-voltage battery with the on-board computer.
- If the charge level is insufficient, recharge the high-voltage battery (\rightarrow page 102).
- (i) The on-board computer displays the state of charge of the high-voltage battery on the instrument cluster display (\rightarrow page 132).

Using the chock

Use the chock to provide additional safety to prevent the vehicle from rolling away, e.g. when parking or changing a wheel.



Chock in load/passenger compartment

- To remove the chock: pull holding rope 1 slightly downwards and then remove it from holder 2.
- Remove the chock.
- (i) When stowing it away, ensure that the chock is secured in the holder by holding rope 1.

Driving and driving safety systems

Notes on driving systems and your responsibility

Your vehicle is equipped with driving systems that assist you in driving, parking and maneuvering the vehicle. The driving systems are only aids. They are not a substitute for you paying attention to your surroundings and do not relieve you of your responsibility pertaining to road traffic law. The driver is always responsible for maintaining a safe distance to the vehicle in front, for vehicle speed, for braking in good time and for staying in lane. Always pay attention to the traffic and intervene if necessary. Be aware of the limitations regarding the safe use of these systems.

Driving systems can neither reduce the risk of accident if you fail to adapt your driving style nor override the laws of physics. They cannot always take into account road, weather or traffic conditions.

(i) Some driving systems can regulate or limit the speed to a previously set value. If there is a change of drivers, make sure that you inform the new driver about the set cruise speed.

Function of driving systems and driving safety systems

In this section, you will find information about the following driving systems and driving safety systems:

- ABS (Anti-lock Braking System) (→ page 114)
- ASR (Acceleration Skid Control) (→ page 114)
- BAS (Brake Assist System) (→ page 114)
- ESP[®] (Electronic Stability Program)
 (→ page 115)
- EBD (Electronic Brakeforce Distribution)
 (→ page 116)
- Active Brake Assist (→ page 116)
- Cruise control (→ page 118)
- Hill Start Assist (→ page 120)
- HOLD function (→ page 120)
- · Rear-view camera
- Rear-view camera with inside rear-view mirror display (→ page 121)
- ATTENTION ASSIST (→ page 122)
- Blind Spot Assist (→ page 123)
- Lane Keeping Assist (→ page 124)

Functions of ABS (anti-lock braking system)

Observe the important safety guidelines for the driving safety system.

ABS controls the brake pressure in critical situations:

- During braking, for instance, at maximum fullstop braking or if there is insufficient tire traction, the wheels are prevented from locking.
- The steerability of the vehicle in terms of physical possibilities is ensured when you are braking.
- ABS is active at speeds above approximately 3 mph (5 km/h). On a slippery road surface, ABS will intervene even if you brake only gently.

System limits

ABS may be impaired or may not function if a malfunction has occurred and the yellow ABS warning lamp lights up continuously on the instrument cluster after the vehicle is started.

If ABS intervenes, you will feel pulsations in the brake pedal. The pulsating brake pedal may be an

indication of hazardous road conditions and functions as a reminder to take extra care while driving.

If ABS intervenes: keep the brake pedal firmly depressed until the braking situation has passed.

To carry out maximum full-stop braking: fully depress the brake pedal.

Function of BAS (Brake Assist System)

A

WARNING Risk of an accident caused by a malfunction in BAS (Brake Assist System)

If BAS is malfunctioning, the braking distance in an emergency braking situation is increased.

Depress the brake pedal with full force in emergency braking situations. ABS prevents the wheels from locking.

BAS helps you by providing additional brake force in an emergency braking situation.

If you depress the brake pedal quickly, BAS will be activated:

- BAS will automatically boost the brake force of the brakes
- · BAS can shorten the braking distance
- · ABS will prevent the wheels from locking

When you release the brake pedal, the brakes will function as usual again. BAS will be deactivated.

Functions of ASR (anti-slip control)

ASR can neither reduce the risk of an accident nor override the laws of physics if the driver does not pay attention when pulling away or accelerating. ASR is only an aid. Always adapt your driving style to suit the prevailing road and weather conditions.

Vehicles without steering-wheel buttons: if ASR is malfunctioning, the [] indicator lamp will light up and the drive system performance may be reduced.

If ASR is malfunctioning, the [] indicator lamp will light up in the instrument cluster and the drive system performance may be reduced.

ASR improves traction, i.e. the transfer of power from the tires to the road surface, for a sustained period and therefore also improves the driving stability of the vehicle. If the drive axle wheels start to spin, ASR will brake individual wheels on the drive axle and limit the output of the drive system. ASR thus assists you significantly when pulling away

and accelerating, especially on wet or slippery roads.

If traction on the road surface is not sufficient, even ASR will not allow you to pull away without difficulty. The type of tires and total weight of the vehicle as well as the gradient of the road also play a crucial role.

If ASR intervenes, the 👩 warning lamp in the instrument cluster will flash.

Function of ESP® (Electronic Stability Program)

WARNING Risk of skidding if ESP® is malfunctioning

If ESP® is malfunctioning, ESP® cannot carry out vehicle stabilization. In addition, other driving safety systems are switched off.

- Drive on carefully.
- Have ESP® checked at a qualified specialist workshop.

WARNING Risk of skidding if ESP® is deac-

If you deactivate ESP®, ESP® cannot carry out vehicle stabilization.

ESP® should only be deactivated in the following situations.

If the surface requires, temporarily deactivate $ESP^{\mathbb{R}}$ when pulling away (\rightarrow page 115).

Do not operate the vehicle on a roller dynamometer (e.g. for a performance test). If you have to operate the vehicle on a roller dynamometer, consult a qualified specialist workshop beforehand.

If ESP® is malfunctioning or automatically deactivated, the 🛐 warning lamp will light up yellow in the instrument cluster and the drive system output may be reduced.

(i) Only use wheels with the recommended tire size. Only then will ESP® function properly.

ESP® can, within physical limits, monitor and improve driving stability and traction in the following situations:

- When pulling away on wet or slippery road surfaces
- When braking
- · If you are driving faster than 50 mph (80 km/h) in strong crosswinds

If the vehicle is deviating from the direction desired by the driver, ESP® can stabilize the vehicle by performing the following actions:

- · One or more wheels are braked
- The drive system performance is adapted depending on the situation

When ESP® is deactivated by the driver, the warning lamp in the instrument cluster lights up continuously.

- · Vehicle stabilization may be delayed
- · Crosswind Assist is still active
- · The wheels may start to spin
- ASR traction control is no longer active

If ESP® is deactivated by the driver, ESP® will continue to support you when braking.

If the 🙀 warning lamp in the instrument cluster flashes, one or more tires have reached their grip

- Adapt your driving style to suit the prevailing road and weather conditions
- · Do not deactivate ESP® under any circumstan-

Activating/deactivating ESP® (Electronic Stability Program)

On-board computer:

→ Settings → DriveAssist → ESP (ESP)

Function of ESP® Crosswind Assist

Crosswind Assist does not react under the following conditions:

- · The vehicle is subjected to severe jolts and vibrations, e.g. as a result of uneven surfaces or potholes.
- The vehicle loses traction, e.g. on snow or ice or when hydroplaning.
- · The driver is performing sudden and large steering movements.

Crosswind Assist is operational again as soon as the driving conditions return to normal.

Crosswind Assist detects strong crosswind gusts that can impair the ability of your vehicle to drive straight ahead. Crosswind Assist intervenes

depending on the direction and strength of the crosswind.

A stabilizing brake application helps you to keep the vehicle on track.

Information is shown on the instrument cluster in the event of a clearly perceptible intervention by Crosswind Assist.

Crosswind Assist is active above a vehicle speed of 50 mph (80 km/h) when driving straight or during slight cornering.

Function of ESP® trailer stabilization



WARNING Risk of accident in poor road and weather conditions

In poor road and weather conditions, the trailer stabilization cannot prevent lurching of the vehicle/trailer combination. Trailers with a high center of gravity may tip over before ESP® detects this.



Always adapt your driving style to suit the current road and weather conditions.

ESP® trailer stabilization counteracts critical driving situations in good time and thereby provides considerable assistance when driving with a trailer. Trailer stabilization is part of ESP®.

If the sensor system and evaluation logic detect trailer swinging movements, ESP® trailer stabilization initially brakes individual vehicle wheels in a targeted manner. It thus counteracts swinging movements. If the swinging movements do not stop, the vehicle is braked until the vehicle/trailer combination is stabilized. If necessary, the vehicle's engine output is limited.

If your vehicle with trailer (vehicle/trailer combination) starts to swerve, you are able to stabilize the vehicle/trailer combination only by braking. ESP® trailer stabilization helps you to stabilize the vehicle/trailer combination in this situation.

ESP® trailer stabilization is active at speeds above approx. 40 mph (65 km/h).

If ESP® is deactivated because of a malfunction. trailer stabilization will not function.

Function of EBD (Electronic Brakeforce Distribution)

EBD has the following characteristics:

- · monitoring and controlling the brake pressure on the rear wheels
- improving driving stability when braking, especially on bends

Functions of Active Brake Assist

Active Brake Assist consists of the following functions:

- Distance warning function
- Autonomous braking function
- Situation-dependent brake force boosting

Active Brake Assist can help you to minimize the risk of a collision with vehicles or pedestrians or to reduce the effects of such a collision.

If Active Brake Assist has detected a risk of collision, you will be warned visually and acoustically.

If you do not react to the visual warning or warning tone, autonomous braking may be initiated in critical situations.

If there are pedestrians and cyclists crossing: in especially critical situations, Active Brake Assist may initiate autonomous braking directly. In this case, the visual warning and warning tone will occur at the same time as the brakes are applied.

If you apply the brakes yourself in a critical situation or depress the brake pedal during autonomous braking, situation-dependent brake force boosting will occur. The brake pressure will increase up to maximum full-stop braking if necessary. Situationdependent brake force boosting will intervene only when the brakes are applied firmly; otherwise, it will remain within the autonomous braking process.



WARNING Risk of accident in case of limited detection performance of Active Brake Assist

Active Brake Assist cannot always clearly identify objects and complex traffic situations.

Due to the system, unjustified interventions or non-interventions by Brake Assist may occur in complex driving situations. In these cases, as well as in the event of malfunctions of Active Brake Assist, the brake system continues to be available with full brake force boosting and

- Always keep a close eye on the traffic situation and do not rely solely on Active Brake Assist. Active Brake Assist is only an aid. The driver of the vehicle is responsible for maintaining a safe distance to the vehicle in front, for vehicle speed and for braking in good time.
- Be ready to brake and take evasive action if necessary.

Also observe the system limits of Active Brake Assist.

The individual subfunctions are available in the following speed ranges:

Distance warning function

The distance warning function will warn you at speeds greater than approximately 4 mph (7 km/h) if your vehicle is critically close to a vehicle or pedestrian.

An intermittent warning tone will sound and the distance warning lamp will light up on the instrument cluster.

Brake immediately or take evasive action, provided it is safe to do so and the traffic situation allows it.

The distance warning function can assist you with an intermittent warning tone and warning lamps in the following situations:

Vehicles traveling in front	Stationary vehi- cles	Crossing vehicles	Crossing pedes- trians/cyclists	Stationary pedes- trians
Up to approx. 155 mph (250 km/h)	Up to approx. 124 mph (200 km/h)	No reaction	Up to approx. 37 mph (60 km/h)	No reaction

Autonomous braking function

The autonomous braking function may intervene at speeds starting from approximately 4 mph (7 km/h) in the following situations:

Vehicles traveling in front	Stationary vehi- cles	Crossing vehicles	Crossing pedes- trians/cyclists	Stationary pedes- trians
Up to approx. 155 mph (250 km/h)	Up to approx. 124 mph (200 km/h)	No reaction	Up to approx. 37 mph (60 km/h)	No reaction

Situation-dependent brake force boosting

Situation-dependent brake force boosting may intervene at speeds starting from approximately 4 mph (7 km/h) in the following situations:

Vehicles traveling in front	Stationary vehi- cles	Crossing vehicles	Crossing pedes- trians/cyclists	Stationary pedes- trians
Up to approx. 155 mph (250 km/h)	Up to approx. 50 mph (80 km/h)	No reaction	Up to approx. 37 mph (60 km/h)	No reaction

Canceling brake application by Active Brake Assist

You can cancel brake application by Active Brake Assist at any time by:

- Fully depressing the accelerator pedal or with kickdown.
- Fully releasing the brake pedal (only during situation-dependent brake force boosting).

Active Brake Assist may cancel brake application if one of the following conditions is fulfilled:

- · You maneuver to avoid the obstacle.
- There is no longer a risk of collision.
- An obstacle is no longer detected in front of your vehicle.

System limits

The system may be impaired or may not function in the following situations:

- The sensors are affected by snow, rain, fog or heavy spray.
- The sensors are dirty, fogged up, damaged or obscured.
- The sensors are affected by interference from other radar sources, e.g. intense radar reflections in parking garages.
- If a loss of tire pressure or a defective tire has been detected and displayed.
- Full system performance is not yet available for a few seconds after you start the vehicle or drive off.

The system may not react correctly in the following situations:

- In complex traffic situations, objects may not always be clearly detected.
- Pedestrians or vehicles move quickly into the detection range of the sensors.
- · Pedestrians are obscured by other objects.
- Narrow-radius bends may hamper the system's ability to react correctly.

Setting Active Brake Assist

Requirements:

· The vehicle has been started.

On-board computer:

→ Settings → DriveAssist

>> Active Brake Assist (Active Brake Assist)

The following settings are available:

- Early
- Medium
- Late
- Active Brake Assist is deactivated by removing the tick next to the Early, Medium or Late setting.
- (i) It is recommended that Active Brake Assist is always left activated.
- Select a setting.

The last active setting is selected automatically every time the vehicle is started.

Exception: if the last setting was Off, the Medium setting will be automatically activated the next time the vehicle is started.

Deactivating Active Brake Assist

- (i) It is recommended that Active Brake Assist is always left activated.
- Remove the tick next to the Early, Medium or Late setting.

The distance warning function and the autonomous braking function are deactivated.

i If Active Brake Assist is deactivated, the symbol appears in the status bar of the instrument cluster display.

Cruise control

Function of cruise control

To maintain a previously stored speed, cruise control accelerates and brakes the vehicle independently.

If you accelerate to overtake, for example, the stored speed will not be deleted. If you remove your foot from the accelerator pedal after overtaking, cruise control will resume speed regulation back to the stored speed.

Cruise control is operated using the corresponding steering wheel buttons. You can set any speed from 12 mph (rounded) (20 km/h).

If you fail to adapt your driving style, cruise control can neither reduce the risk of an accident nor override the laws of physics. It cannot take into account road, weather or traffic conditions. Cruise control serves solely as an aid. You are responsible for the distance to the vehicle in front, for vehicle speed, braking in good time and for staying in your lane.

The status of cruise control and the stored speed are shown on the instrument cluster.



Instrument cluster display (color display)

- Cruise control is selected.
- Set speed gray: speed is stored, cruise control is deactivated.
- 3 Set speed green: speed is stored, cruise control is activated.

System limits

Cruise control may be unable to maintain the stored speed on uphill gradients. The stored speed will be resumed when the gradient levels out.

Do not use cruise control in the following situa-

- In the event of frequent changes in speed, e.g. in heavy traffic or winding roads
- · On slippery roads. The wheels on the drive axle may lose traction upon acceleration, causing the vehicle to begin skidding.
- · When visibility is poor

Operating cruise control


WARNING Risk of accident due to stored speed

If you call up the stored speed and this is lower than your current speed, the vehicle deceler-

Take into account the traffic situation before calling up the stored speed.

Requirements:

- · Cruise control is selected.
- ESP® must be activated but not intervening.
- The vehicle speed is at least 15 mph (20 km/h).
- The transmission is in position **D**.



Switching on cruise control:

▶ Press 📆 .

Activating cruise control:

Press **SET/+** or **SET/-** on switch panel **①**. The current speed will be stored and maintained by the vehicle.

or

Press RES/9.

The last stored speed will be called up and maintained by the vehicle.

The current vehicle speed will be stored if the last stored speed has been deleted.

(i) When you switch off the vehicle, the last speed stored will be deleted.

Increasing/reducing the stored speed:

- To increase the stored speed: swipe over switch panel 1 from the bottom up.
 - The stored speed will be increased by 1 mph (1 km/h).
- To reduce the stored speed: swipe over switch panel 1 from the top down.
 - The stored speed will be reduced by 1 mph (1 km/h).

or

Press SET/+ or SET/- briefly on the switch panel

1.

The stored speed will be increased or reduced to the following values depending on the unit:

- mph: the next value ending in 5 or 0
- km/h: the next value ending in 0

or

- Accelerate the vehicle to the desired speed.
- Press **SET/+** on the switch panel ①.

Deactivating cruise control:

► Press CANCEL.

Switching off cruise control:

- Press Core.
- i If you brake, deactivate ESP®, or if ESP® intervenes, cruise control will be deactivated.

Setting the limit speed for winter tires On-board computer


- → Settings → Vehicle → Winter Tires Limit
- Select a speed or deactivate the function.

Information on Hill Start Assist

Hill Start Assist holds the vehicle for a short time when pulling away on a hill under the following conditions:

- The transmission is in position **D** or **R**.
- The parking brake has been released.

This gives you enough time to move your foot from the brake pedal to the accelerator pedal and depress it before the vehicle begins to roll.



After a short time, Hill Start Assist no longer holds the vehicle.

Swiftly move your foot from the brake pedal to the accelerator pedal. Do not leave the vehicle when it is being held by Hill Start Assist.

HOLD function

Notes on the HOLD function

Requirement

The seat occupancy recognition on the driver's seat has detected that the driver has fastened the seat helf.

Function

The HOLD function holds the vehicle at a standstill without requiring you to depress the brake pedal, e.g. when you are pulling away on steep slopes or waiting in traffic. When you depress the accelerator pedal to pull away, the braking effect will be canceled and the HOLD function deactivated.

The HOLD function is only an aid. The responsibility for the vehicle safely standing still remains with the driver.

System limits

The HOLD function is intended only to provide assistance when you are driving and is not a sufficient means of safeguarding the vehicle against rolling away when stationary.

The incline cannot be greater than 30%.

Activating/deactivating the HOLD function

Requirements:

- The driver is seated and their seat belt is fastened
- . The vehicle is switched on.
- The electric parking brake has been released.
- The transmission is in position $\boxed{\mathbf{D}}$, $\boxed{\mathbf{R}}$ or $\boxed{\mathbf{N}}$.

Activating the HOLD function

WARNING Risk of an accident due to the HOLD function being active when you leave the vehicle

If the vehicle is only braked with the HOLD function it could, in the following situations, roll away:

- If there is a malfunction in the system or in the power supply.
- If the HOLD function is deactivated by depressing the accelerator pedal or brake pedal, e.g. by a vehicle occupant.
- Always secure the vehicle against rolling away before you leave it.

NOTE Damage due to automatic braking

When Active Brake Assist or the HOLD function is activated, the vehicle brakes automatically in certain situations.

To avoid damage to the vehicle, deactivate these systems in the following or similar situa-

- When towing
- In a car wash
- Make sure that the activation conditions are
- Depress the brake pedal until the HOLD display appears on the instrument cluster display. The HOLD function is activated. You can release the brake pedal.
- (i) If depressing the brake pedal the first time does not activate the HOLD function, wait briefly and then try again.

Deactivating the HOLD function

Depress the accelerator pedal to pull away.

- Depress the brake pedal until the HOLD display disappears from the display on the instrument cluster.
- (i) After a while, the transmission will shift to position $\boxed{\mathbf{P}}$ to relieve the load on the service brake.

When the HOLD function is activated, the transmission will automatically shift to position [P] in the following situations:

- . The driver leaves the driver's seat.
- The driver's door is opened.
- The vehicle is switched off.

Rear-view camera with inside rear-view mirror display

Function of the rear-view camera with inside rear-view mirror display

The rear-view camera is connected to the vehicle's inside rear-view mirror. When you engage reverse gear, the rear-view camera's image will appear in the left area of the inside rear-view mirror. This will allow you to see what is behind the vehicle when backing up.

The rear-view camera with an inside rear-view mirror display is only an aid. It is not a substitute for your attention to your surroundings. You are always responsible for safe maneuvering and parking. Ensure that there are no persons, animals or objects etc. in the maneuvering area while maneuvering and parking.

The rear-view camera with an inside rear-view mirror display may show a distorted view of obstacles or may show them incorrectly or not at all. It cannot show all objects very near to or under the rear bumper. It will not warn you of a collision, people or objects.

The area behind the vehicle is displayed as a mirror image.

System limits

The rear-view camera with an inside rear-view mirror display will not function, or will function only partially, in the following situations:

- · If there is heavy rain, snow or fog.
- · If the ambient light is poor, e.g. at night
- · If the area is illuminated with fluorescent lighting, the inside rear-view mirror display may flicker
- If there is a rapid change in temperature, e.g. if, in the winter, you drive out of the cold into a heated garage
- · If the ambient temperature is very high
- If the camera lens is obstructed, dirty or fogged up. Observe the notes on cleaning the rear-view camera (\rightarrow page 159).
- · If the camera or rear of your vehicle is damaged. In this case, check the camera's position and setting at a qualified specialist workshop.

The field of vision and other functions of the rearview camera may be restricted due to additional accessories on the rear of the vehicle (e.g. license plate bracket or bicycle rack).

- The inside rear-view mirror display contrast may be impaired due to incident sunlight or other light sources. In this case, pay particular attention.
- (i) Have the inside rear-view mirror repaired or replaced if its use is considerably restricted due to pixel errors, for example.
- (i) Objects that are not at ground level will appear further away than they are.

Examples of such objects:

- · the bumper of a vehicle parked behind
- · the drawbar of a trailer
- the ball neck of a trailer hitch

- · the tail-end of a truck
- · slanted posts

Displaying and hiding the inside rearview mirror display

Displaying

- Engage reverse gear.
 The image from the rear view camera appears on the left side of the inside rearview mirror.
- (i) Observe the system limits of the rear view camera with an inside rearview mirror display.

Hiding

Select another drive range.

or

- Switch off the drive system.
- The display will be hidden after a short time.

ATTENTION ASSIST

■ Function of ATTENTION ASSIST

ATTENTION ASSIST can assist you on long, monotonous journeys, e.g. on highways and trunk roads. If ATTENTION ASSIST detects indicators of fatigue or increasing lapses in concentration on the driver's part, it suggests taking a break.

ATTENTION ASSIST serves solely as an aid. It cannot always promptly detect fatigue or lapses in concentration. The system is not a substitute for a well-rested and attentive driver. On long journeys, take regular, timely breaks to allow for adequate recovery.

You can choose between two settings:

- · Standard: normal system sensitivity.
- Sensitive: higher system sensitivity. The driver is warned at an earlier stage, and the attention level detected by the system is adapted accordingly.

If fatigue or increased lapses in concentration are detected, the Attention Assist: Take a Break! warning appears in the instrument cluster. You can acknowledge the message and take a break if necessary. If you do not take a break and ATTENTION ASSIST continues to detect increasing lapses in concentration, you will be warned again after a minimum of 15 minutes.



Display of attention level in the instrument cluster (example)

You can have the following status information for ATTENTION ASSIST displayed in the Assistance menu of the on-board computer:

- · journey time since the last break
- The more segments of the circle displayed, the higher the detected attention level. Fewer segments are displayed in the circle as the attention level decreases, with the color of the diminishing circle segments changing from green, to orange, to red accordingly.

If the ATTENTION ASSIST cannot calculate the attention level and cannot issue a warning, the Attention Level message appears.

If ATTENTION ASSIST is deactivated, the symbol appears in the assistance graphic in the instrument cluster when the vehicle is running. ATTENTION ASSIST is activated automatically when the vehicle is restarted. The last selected sensitivity level remains stored.

System limits

ATTENTION ASSIST is active in the 37 mph (60 km/h) to 124 mph (200 km/h) speed range.

The functionality of ATTENTION ASSIST is restricted, and warnings may be delayed or not issued at all in the following situations:

- The journey is less than approximately 30 minutes
- Road conditions are poor (uneven road surface or potholes)
- The vehicle is subjected to a strong crosswind
- You have a sporty driving style (high cornering speeds or high rates of acceleration)

- . The time is set incorrectly
- You change lanes and vary your speed frequently in active driving situations

The ATTENTION ASSIST drowsiness or attentiveness assessment is deleted and restarted when continuing the journey in the following situations:

- · You switch off the vehicle.
- If you unfasten your seat belt and open the driver's door (e.g. to change drivers or take a

Setting ATTENTION ASSIST

On-board computer:

→ Settings → DriveAssist

>> Attention Assist (Attention Assist)

Setting options

The following settings are available:

- Standard
- Sensitive
- Off
- Select a setting.

Blind Spot Assist

Function of Blind Spot Assist with exit warning

Blind Spot Assist uses two lateral, rear-facing radar sensors to monitor the area directly next to and at the side behind the vehicle.

(i) USA only:

This device has been approved by the FCC as a "Vehicular Radar System". The radar sensor is intended for use in an automotive radar system only. Removal, tampering, or altering of the device will void any warranties, and is not permitted by the FCC. Do not tamper with, alter or use in any non-approved way. Any unauthorized modification to this device could void the user's authority to operate the equipment.

WARNING Risk of accident despite Blind Spot Assist

Blind Spot Assist does not react to either stationary objects or vehicles approaching and overtaking you at a greatly different speed.

Blind Spot Assist cannot warn drivers in these situations.

Always pay careful attention to the traffic situation and maintain a safe distance at the side of the vehicle.

Blind Spot Assist is only an aid. It may fail to detect some vehicles and is no substitute for attentive driving. Ensure that there is sufficient distance to the side from other road users and obstacles. If a vehicle is detected above speeds of approximately 7.5 mph (12 km/h) and this vehicle subsequently enters the detection range directly next to your vehicle, the warning lamp in the outside mirror lights up red.

(i) When a trailer is connected, the radar sensor's field of vision may be impaired, thereby making limited monitoring possible. Always pay careful attention to the traffic situation and maintain a safe distance at the side of the vehicle.

If a vehicle is detected close to your vehicle in the lateral detection range and you switch on the turn signal indicator in the corresponding direction, a warning tone sounds. The red warning lamp in the outside mirror flashes. If the turn signal indicator remains switched on, all other detected vehicles are indicated only by the flashing of the red warning lamp.

If you overtake a vehicle quickly, no warning is given.

Exit warning

The exit warning is an additional function of Blind Spot Assist and warns vehicle occupants when leaving the vehicle about any approaching vehicles.

WARNING Risk of accident despite exit warning

The exit warning neither reacts to stationary objects nor to persons or road users approaching you at a greatly differing speed.

The exit warning cannot warn drivers in these situations.

Always pay particular attention to the traffic situation when opening the doors and make sure there is sufficient clearance.

(i) An exit warning is not issued for sliding doors and rear-end doors.

Overview			
When the vehicle is stationary, an object is detected from behind in the detection range.	Red warning lamp in the outside mirror		
When the vehicle is stationary, a door on the relevant side of the vehicle is opened. An object which is close to your vehicle is detected in the detection range.	Collision warning		

This additional function is only available when Blind Spot Assist is activated and up to a maximum of three minutes after the drive system has been switched off. The end of the availability of the exit warning function is indicated by a series of flashes in the outside mirror.

The exit warning function is only an aid and is no substitute for the attentiveness of the vehicle occupants. Responsibility lies with the vehicle occupants when opening doors and leaving the vehicle.

System limits

Blind Spot Assist and the exit warning function may be limited in the following situations:

- if there is dirt on the sensors or the sensors are obscured
- if there is poor visibility, e.g. due to fog, heavy rain, snow or spray
- if narrow vehicles are within the detection range, e.g. bicycles
- · if lanes are very wide
- · if lanes are very narrow
- if vehicles are not driving in the middle of their lane
- i Stationary or slow-moving objects are not displayed.

Warnings may be issued in error when driving close to crash barriers or similar solid lane borders. Warnings may be interrupted when driving alongside long vehicles such as trucks for a prolonged time.

Blind Spot Assist is not operational when reverse gear is engaged.

The exit warning function may be limited in the following situations:

- when the sensor is blocked by adjacent vehicles in narrow parking spaces
- when people are approaching


Activating/deactivating Blind Spot Assist On-board computer:

¬→ Settings

Activate or deactivate Blind Spot Assist.

Lane Keeping Assist

■ Function of Lane Keeping Assist



Lane Keeping Assist monitors the area in front of your vehicle with multifunction camera ①. It serves to protect you against unintentionally leaving your lane. You may also be warned by a noticeable vibration in the steering wheel or by a warning tone and by the status symbol flashing on the instrument cluster.

The function is available in the speed range between approximately 40 mph (60 km/h) and 100 mph (160 km/h).

The warning will be issued when the following conditions are met at the same time:

- If Lane Keeping Assist detects lane markings.
- If a front wheel drives over lane markings.

You can activate and deactivate the Lane Keeping Assist warning.

If you fail to adapt your driving style, Lane Keeping Assist can neither reduce the risk of accident nor override the laws of physics. It cannot take into account road, weather or traffic conditions. Lane Keeping Assist is only an aid and is not intended to

keep the vehicle in the lane without the driver's cooperation. You are responsible for the distance to the vehicle in front, for vehicle speed, braking in good time and for staying in your lane.

System limits

The system may be impaired or may not function in the following situations:

- If there is poor visibility, e.g. due to insufficient illumination of the road, if there are highly variable shade conditions or in rain, snow, fog or
- Glare from oncoming traffic, direct sunlight or reflections.
- · There is dirt on the windshield in the vicinity of the multifunction camera or the camera is fogged up, damaged or obscured.
- · Lane markings for one lane are absent or unclear, e.g. in a construction area.
- If the lane markings are worn away, dark or covered up.
- If the distance to the vehicle in front is too short and thus the lane markings cannot be detected.
- The lane markings change quickly, e.g. lanes branch off, cross one another or merge.
- · The road is very narrow and winding.

Activating/deactivating Lane Keeping Assist and Active Lane Keeping Assist

On-board computer:

→ Settings → DriveAssist

Depending on vehicle equipment, select Active Lane Keeping Assist or Lane Keeping Assist (Lane Keeping Assist).

The driving system is activated or deactivated, depending on its previous status.

Trailer operation

Notes on trailer operation

WARNING Risk of accident and injury if the tongue weight is exceeded

The carrier system may detach from the vehicle, thereby endangering other road users.

Always comply with the permissible tongue weight when using a carrier.

WARNING Risk of accident due to unsuitable ball neck

If you install an unsuitable ball neck, the trailer hitch and the rear axle may be overloaded.

This can significantly impair the driving characteristics and the trailer may become loose. There is a risk of fatal injury.

- Only install a ball neck that complies with the permissible dimensions and is designed for the requirements of trailer operation.
- Do not modify the ball neck or the trailer hitch.

You can find specifications regarding the ball neck on the trailer's identification plate. You can find specifications regarding the trailer on the towing vehicle's identification plate and in the Technical Data (\rightarrow page 231).



WARNING Risk of accident and injury due to incorrectly installed ball neck

If the ball neck is not properly mounted and secured, it may come loose along with the trailer while the vehicle is in motion and endanger other road users. There is a risk of fatal injuries.

- Mount and secure the ball neck as described in the installation instructions of the ball neck manufacturer.
- ► With the ball neck mounted, always make sure it is properly secured before commencing a journey.



WARNING Risk of accident due to a ball neck that is not correctly installed or secured

If the ball neck is not correctly installed and secured, the trailer may come loose.

- Install and secure the ball neck as described in the ball neck manufacturer's installation instructions.
- If a ball neck is installed, ensure sure that it is properly secured before every journey.

NOTE The operating permit may be invalidated due to the illegal installation of trailer hitches

The installation – including retrofitting – of a non-folding or non-removable trailer hitch that even partially conceals the license plate or the lighting system is prohibited.

Observe the applicable legal regulations for the installation of trailer hitches.

Be sure to comply with the Operator's Manual of the manufacturer of the trailer coupling and the ball neck.

Place your vehicle/trailer combination on a surface that is as even as possible and secure it against rolling away (→ page 110). Couple and uncouple the trailer carefully.

When backing up the towing vehicle, ensure that there is no one between the vehicle and the trailer.

If you do not couple the trailer to the towing vehicle correctly, the trailer may become detached. Once it has been coupled and is roadworthy, the trailer must be in a horizontal position behind the towing vehicle.

Note the following regarding the tongue weight:

- Make full use of the maximum tongue weight, where possible.
- Never allow the tongue weight to fall below a legally prescribed minimum; the tongue weight must always be positive.
- Do not exceed or fall below the permissible tongue weights – this must be observed during loading and unloading of the trailer.

Do not exceed the following values:

- Permitted braked or unbraked towing capacity
 The maximum permissible towing capacity for unbraked trailers is 1,653 lbs (750 kg).
- · Permissible rear axle load of the towing vehicle
- Gross vehicle weight rating of the towing vehicle
- Gross vehicle weight rating of the trailer
- · Permissible gross combination weight
- · Maximum permissible speed of the trailer

The relevant permitted values, which must not be exceeded, can be found in the following places:

- in your vehicle documents
- on the identification plate of the trailer hitch

- on the trailer identification plate
- · on the vehicle identification plate

If there are discrepancies between the values, the lowest one shall apply.

Before driving off, ensure the following:

- The tire pressure on the rear axle of the towing vehicle has been set for the maximum load.
- The headlamps have been set correctly.

Values approved by the manufacturer can be found on the identification plates and in the section for the towing vehicle (\rightarrow page 177).

Your vehicle will behave differently with a trailer relative to without a trailer:

- The vehicle/trailer combination will be heavier.
- The vehicle/trailer combination will be restricted in its acceleration and gradeability.
- The vehicle/trailer combination will have an increased braking distance.
- The vehicle/trailer combination will be more susceptible to crosswind gusts.
- The vehicle/trailer combination will require more sensitive steering.
- The vehicle/trailer combination will have a larger turning circle.

This may impair the vehicle's driving characteristics.

When driving with a vehicle/trailer combination, always adapt your speed to the current road and weather conditions. Drive carefully. Keep a sufficient safe distance.

Comply with the maximum permissible speed of 50 mph (80 km/h) or 62 mph (100 km/h), even in countries in which higher speeds are permitted for vehicle/trailer combinations.

Attach only an approved trailer hitch to your vehicle. Use only a ball neck that has been approved for your vehicle. Further information about availability and installation – including that of the trailer electrics – is available from a qualified specialist workshop.

The trailer hitch is one of the most important vehicle parts for road safety. Comply with the instructions on operation, maintenance and servicing in the manufacturer's Operator's Manual.

(i) Your vehicle's bumpers are not suitable for installing detachable trailer hitches.

Do not attach any rented trailer hitches or any other detachable trailer hitches to the bumpers.

- (i) During trailer operation, remember that PARKTRONIC is available only to a limited extent, if at all.
- (i) The height of the ball head will change depending on the vehicle's load. In this case. use a trailer with a height-adjustable drawbar.

Driving notes

The maximum permissible speed for vehicle/trailer combinations depends on the type of trailer. Before setting off, consult the trailer's vehicle documents to find out the maximum permissible speed.

Your vehicle will behave differently with a trailer relative to without a trailer and the high-voltage battery will need to be recharged more quickly.

Observe the notes on ESP® trailer stabilization $(\rightarrow page 116)$.

Driving tips

If the trailer starts to sway, remember the following points:

- · Do not accelerate under any circumstances.
- · Do not countersteer.
- · If necessary, apply the brakes.
- (i) You can reduce the risk of the trailer swaying and rocking by retrofitting stabilizer bar or trailer stability programs. You can obtain further information from an authorized Mercedes-Benz Center.

When you are driving with a trailer, observe the following points:

- Maintain a greater distance from the vehicle in front than when driving without a trailer.
- Avoid braking abruptly. If possible, brake gently first of all so that the trailer closes up behind your vehicle. Then, increase the braking force rapidly.

Coupling/uncoupling a trailer

Coupling a trailer

NOTE Damage to the starter battery due to full discharge

Charging the trailer battery using the power supply of the trailer can damage the starter battery.

Do not use the vehicle's power supply to charge the trailer battery.

- Shift the selector lever to position **P**.
- Apply the vehicle's parking brake.
- Close all the doors.
- Position the trailer on a level surface behind the vehicle.
- (i) The height of the ball head will change depending on the vehicle's load. In this case. use a trailer with a height-adjustable drawbar.
- Couple up the trailer.
- Establish all electrical and other connections to the trailer.
- Remove objects or devices that are preventing the trailer from rolling, e.g.chocks.
- Release the trailer's parking brake.
- i The vehicle subharness has a cable connection to the brake light indicator lamp.

Observe the maximum permissible trailer dimensions (width and length).

Most US states and all Canadian provinces prescribe the following points, and you are urgently recommended to comply with these:

- · Safety chains between the towing vehicle and the trailer. The chains should be routed in a criss-cross pattern under the drawbar. They must be connected to the trailer hitch and not to the bumper or to the vehicle's axle.
 - Leave sufficient slack in the chains. This also allows for sharp cornering.
- A separate brake system is required for certain
- A safety feature is required for braked trailers. Determine the specific requirements according to the relevant laws.

If the trailer becomes detached from the towing vehicle, the safety feature triggers the trailer brakes and can thus reduce the danger.

Uncoupling a trailer

WARNING Risk of being crushed and becoming trapped when uncoupling a trailer

When uncoupling a trailer with an engaged inertia-activated brake, your hand may become trapped between the vehicle and the trailer drawbar.

Do not uncouple trailers with an engaged overrun brake.

I NOTE Damage during uncoupling with an engaged overrun brake

The vehicle may be damaged if you uncouple with an engaged overrun brake.

- Do not uncouple trailers with an engaged overrun brake.
- Shift the selector lever to position P.
- Apply the vehicle's parking brake.
- Close all the doors.
- Apply the trailer's parking brake.
- Further secure the trailer against rolling away with a wheel chock or similar object.
- Remove the trailer cables and safety chains.
- Uncouple the trailer.

Configuring settings for trailer operation

On-board computer:

¬→ Settings → eSprinter → Trailer Settings

Making settings for a trailer

The settings in this menu enable the energy forecast at the start of the trip to be calculated more accurately. The amount of energy, charging station scheduling, charging time and arrival time will thus be calculated to a greater degree of precision.

The selected trailer type influences:

- · Navigation with Electric Intelligence
- ECO Assist
- · The load spectrum
- Select the desired trailer type.
- Select the maximum permissible speed of the selected trailer.
- Confirm the changes.
- When contact with the trailer socket is established (trailer/rear bicycle rack), a menu will automatically appear on the display.

The following selections are available:

- · Rear Luggage Rack
- Small trailer
- Large trailer

Calibrating a trailer coupling

 Select Trailer coupling replaced Start calibration? to begin calibration for the new ball head position.

- Confirm the changes.
- Activate Trailer Maneuvering Assist and follow the corresponding instructions on the central display of the instrument cluster.
 When the Activated: Trailer Maneuvering Assist message is displayed, calibration is complete and Trailer Maneuvering Assist can be used.

Information about towing a trailer

Operating a trailer is subject to many statutory regulations such as maximum permissible speeds.

Many German states require a separate braking system for a trailer when a certain weight limit is exceeded. For your safety, it is recommended to use a separate functional braking system on any towed vehicle.

Make sure that your trailer combination meets local regulations. This not only applies to your place of residence, but also to your destination. Information on this can be obtained from the police and local authorities.

Comply with the following when driving with a trailer:

- Practice cornering, stopping and backing up in a traffic-free location. In this way, you will gain driving experience and become accustomed to the new handling characteristics.
- · Before driving, check the following:
 - that the trailer hitch and ball neck are
 - that the safety switch for braked trailers is functioning correctly
 - that the safety chains are secure and undamaged
 - that the electrical connections are secure
 - that the lights are functioning correctly
 - the wheels for damage and correct tire pressure (→ page 174)
- Adjust the outside mirrors so that you have a clear view of the rear section of the trailer.
- If the trailer is equipped with an individual braking system, check before each journey whether the brakes are functioning correctly.
- If the trailer has electronically controlled brakes, pull away carefully with the vehicle/ trailer combination. Brake manually using the brake controller and check whether the brakes are functioning correctly.

- Secure the load on the trailer in line with the requirements and rules for load-securing meth-
- · When driving with a trailer, check at regular intervals that the load is secure and that the lights and brakes are functioning correctly.
- Bear in mind that the handling characteristics are more unstable when towing a trailer than when driving without a trailer. Avoid sudden steering movements.
- The vehicle/trailer combination is heavier, accelerates more slowly, has a reduced gradeability and an increased braking distance. It is more susceptible to side winds and requires careful steering.
- If possible, do not brake suddenly, but rather moderately at first so that the trailer can activate its brakes. Then increase the pressure on the brake pedal.
- · Avoid constant braking, as this could cause the vehicle brakes and possibly also the trailer brakes to overheat.
- If the coolant temperature increases significantly when the air conditioning system is switched on, switch the air conditioning system

Coolant heat will also be dissipated if you switch the airflow and the temperature of the heating or air conditioning system to the maximum level. Open the windows if necessary.

When overtaking, pay particular attention to the increased overtaking distance of your vehicle/trailer combination.

Due to the length of your vehicle/trailer combination, you will require a longer stretch of road before switching back to the original lane.

Permissible trailer loads and tongue weights

Weight information

▲ WARNING Risk of accident due to an unbraked trailer with an excessive gross weight

If you pull an unbraked trailer with a gross trailer weight (GTW) of more than 1,653 lbs (750 kg), the vehicle's brake system may over-

This increases the braking distance and may even cause the brake system to fail.

Always use a trailer with a separate braking system if you are pulling a gross trailer weight (GTW) of more than 1,653 lbs (750 kg).

NOTE Damage to the drive train, transmission or trailer tow hitch due to excess gross combination weight

The permissible gross combination weight is exceeded.

The drive train, the transmission or the trailer tow hitch may be damaged.

Comply with the permissible gross combination weight.

In vehicles with a permissible gross vehicle weight of 11030 lbs (5003 kg), the permissible gross combination weight is less than the sum of the permissible gross vehicle weight plus the permissible trailer load. If either the vehicle or the trailer is fully laden, the permitted gross vehicle weight or the permitted trailer load values will be reduced accordingly. In this case, you may only partially load the trailer or the vehicle.

The gross trailer weight (GTW) is calculated on the basis of the weight of the trailer plus the weight of its load and equipment. If the trailer is equipped with a separate braking system, then the maximum gross trailer weight is 5000 lbs (2268 kg) or 7500 lbs (3402 kg).

The maximum permissible drawbar tongue weight on the ball head is 500 lbs (227 kg) or 750 lbs (340 kg). However, the actual tongue weight must not exceed the value given on the trailer hitch or trailer identification plates. Where the values differ, the lowest shall always apply.

The gross combined weight rating (GCWR) is calculated on the basis of the gross trailer weight plus the gross vehicle weight, including a driver's weight of approximately 150 lbs (68 kg). The maximum permissible gross combination weight is vehicle-specific and equipment-dependent. When driving with a trailer, you should not exceed the maximum permissible gross combination weight rating (GCWR).

The permissible values, which must not be exceeded, can be found in your vehicle documents and on the identification plates of the trailer hitch, the trailer and the vehicle. The values approved by the manufacturer can also be found in the "Technical data" section. Where the values differ, the lowest shall always apply.

Loading the trailer

Use a tongue weight that is as close as possible to the maximum permissible tongue weight. Do not allow the weight to fall below the minimum permissible tongue weight. Otherwise, the trailer may become detached.

- Distribute the load over the vehicle and the trailer so as not to exceed either the maximum permissible values for the gross vehicle weight rating (GVWR) and gross trailer weight (GTW), the gross combination weight rating (GCWR), or the maximum permissible gross axle weight rating (GAWR) and tongue weight (TWR) of your vehicle.
- Add the drawbar tongue weight (TWR) on the ball head to the rear axle load. This will ensure that you do not exceed the permissible gross axle weight rating (GAWR).
- Add the vehicle load to the drawbar tongue weight (TWR) on the ball head. This will ensure that you do not exceed the permissible gross vehicle weight rating (GVWR).

Checking vehicle and trailer weight

- Make sure that the weights of the towing vehicle and the trailer comply with the maximum permissible values. Have the vehicle/trailer combination weighed on a calibrated weighing machine. The vehicle/trailer combination comprises the towing vehicle including driver, passengers and load as well as the laden trailer.
- Check the maximum permissible gross axle weight rating of the front and rear axles (GAWR), the gross trailer weight (GTW), the gross combination weight rating (GCWR) and the drawbar tongue weight (TWR).

Trailer power supply

Incorrect cabling of the connector plug may interfere with other electronic systems in the vehicle. Mercedes-Benz therefore recommends that you have the cabling of the connector plug carried out at a qualified specialist workshop.

You can connect accessories up to a maximum of 240 W to the permanent power supply. Do not charge a trailer battery using the power supply.

Your vehicle may be equipped with a range of electrical equipment for trailer operation. Depending on your trailer, you may need an adapter for the electrical connection between the trailer and your vehicle.

The trailer socket of your vehicle is equipped with a permanent power supply at the factory.

The permanent power supply is supplied via trailer socket pin 4.

Note that the trailer's permanent power supply is not switched off when the vehicle's on-board electrical system voltage is low. This could completely discharge your vehicle's starter battery.

Further information on the electrical equipment currently installed on your vehicle and on installing the trailer electrics can be obtained at a qualified specialist workshop.

Overview of the instrument cluster

WARNING Risk of accident due to an instrument cluster malfunction

In the event of a failure or malfunction of the instrument cluster, you will not recognize limitations in the functions of systems relevant to safety. This may impair operating safety.


Park the vehicle safely as soon as possible and notify a qualified specialist work-

If you are uncertain regarding the operational safety of your vehicle, park the vehicle safely as soon as possible. Inform a qualified specialist workshop.



- Speedometer
- ② Instrument cluster display (→ page 132)
- Power availability display (→ page 131)
- Maximum available output of the drive system
- State of charge of the high-voltage battery (\rightarrow page 259)

Function of the power availability display



Power availability display (example)

The power availability display 1 includes two areas:

- In the area below $\boxed{\mathbf{0}}$, the recovered power of the vehicle during recuperation is displayed.
- In the area above $\boxed{\mathbf{0}}$, the current amount of power that the drive system is feeding to the wheels is displayed.

If the needle for the power availability display is in the OFF position, the vehicle is not ready to drive.

The vehicle is not ready to drive in the following situations:


- · The drive system has not yet started.
- There is still a charging cable connected to the vehicle socket.
- There is insufficient high-voltage battery power available.
- · There is a malfunction in the high-voltage onboard electrical system.

Once the vehicle is ready to drive, the needle moves to the **0** position and the display READY appears on the instrument cluster.

The braking effect of the electric motor using recuperation is either reduced or not effective in the following operating statuses:

- The high-voltage battery is not yet at normal operating temperature.
- · The road speed is close to vehicle standstill.
- The transmission is in position N.
- During or after an ESP® control intervention.


Overview of the buttons on the steering wheel



命 OK Switch panel, left

Calls up the main menu. Confirms a selection/hides

display messages



arrow (navigate).

(C) Activates cruise control. OFF Deactivates cruise control.

SET/+ SET/- RES/ CANCEL

Operates cruise control.

命 OK

Switch panel, right Calls up the main menu. Confirms a selection/hides display messages



Swipe in the direction of the arrow (navigate).



Back



Makes or accepts calls/ switches to the redial mem-





Ends or declines calls/exits the phone book or redial memory.



Press to switch off the sound.

To increase volume: swipe upwards.

To reduce volume: swipe down.


₩

To call up favourites: press briefly.



To add favourites and themes: press and hold. Activates Voice Control Sys-

Overview of instrument cluster display



Messages on the display of the instrument cluster (example)

- 1 Time
- Outside temperature
- ③ Display section menu (→ page 134)
- Orive program (→ page 99)
- ⑤ Drive range (\rightarrow page 100) and recuperation display (\rightarrow page 91)
- Maximum possible range
- State of charge in % (→ page 132)
- Charging active
- Current range, depending on driving style and electrical consumers

Function of the charge level display

Percentage \bigcirc (\rightarrow page 132) indicates the state of charge of the high-voltage battery. In addition, the maximum range is displayed beside it and the current range is displayed above it.

When the drive system is ready for operation READY and the Reserve Level Charge High-Voltage Battery message appears or the indicator lamp on the instrument cluster lights up, the state of charge of the high-voltage battery has reached the reserve level.

You can find information about charging the highvoltage battery in the section "Charging the highvoltage battery" (\rightarrow page 102).

Display of the available power

WARNING Risk of accident due to reduced power of the drive system

If the drive system experiences a power output limitation, there is a risk of accident, particularly when accelerating and overtaking.

- Adapt your driving style and drive particularly carefully.
- Charge the high-voltage battery at a charging station immediately.



Display of the maximum available power

In the following operating conditions, the available power may be reduced:

- in very high or low outside temperatures
- · if there are very high power requirements over an extended period of time
- · if the state of charge of the high-voltage battery is very low
- if there is a malfunction in the drive system

You can improve the reduced power availability by charging the high-voltage battery (\rightarrow page 102).

Warnings in the event of low output

If the drive system had been exposed to very low temperatures, the instrument cluster may show the following warnings once the vehicle has been started:



Displays when drive power is low (example values)

- Alternating display: Reduced Drive System Performance See Operator's Manual and Reserve Level Charge High-Voltage Battery
- Maximum range shows xxx miles (xxx km)
- Current range shows xxx miles (xxx km)
- State of charge of the high-voltage battery in % appears in yellow
- 6 High-voltage battery indicator lamp lights up yellow


A warning tone also sounds.

Only around 30 % of the usual drive power is available.

In this case, do not switch on the windshield defrosting climate control function. Otherwise, the output will decline further.

Charge the high-voltage battery.

Adjusting the instrument lighting



Turn brightness control 1 upwards or downwards.

The lighting of the instrument cluster and the controls in the vehicle interior will be adjusted. In vehicles without brightness control

 nstrument lighting can be adjusted via the onboard computer (→ page 136).

Menus and submenus

Calling up functions on the service menu

On-board computer:

- **¬→** Service
- Select and confirm the desired function.

The following functions are available on the service menu:

- Announcements: message memory
 (→ page 235)
- Tires:
 - checking the tire pressure with the tire pressure monitoring system (→ page 179)
 - restarting the tire pressure monitoring system (→ page 180)
- ASSYST PLUS: calling up the service due date (→ page 152)

Calling up the assistant display

On-board computer:

¬→ Service

The following displays are available on the Assistance menu:

· Assistant display



Instrument cluster display

The following status displays are available on the assistant display:

- Lane markings solid and thick: Lane Keeping Assist on and ready to issue warnings
- Lane markings solid and thin: Lane Keeping Assist on and not ready to issue warnings
- Lane markings dotted: Lane Keeping Assist off
- Blind Spot Assist on and ready to issue warnings (lines of the radio waves green)
- Blind Spot Assist on and not ready to issue warnings (lines of the radio waves gray)
- Blind Spot Assist off

Calling up displays on the Trip menu


On-board computer:

¬→ Trip

Select the desired display and confirm.

The following displays are available on the trip menu:


- · Standard display
- Current Consumption
- Range
- ECO Display
- ATTENTION ASSIST
- Trip computer:
 - From Start
 - From Reset
- Digital speedometer



Standard display (example)

- Trip distance
- ② Distance unit

- Total distance
- Charging prediction at departure time (only) when charging is active and the vehicle is not in READY status)



Trip computer display (example)

- From start or from reset
- Average energy consumption (from start or from reset)
- Oriving time (from start or from reset)
- Average speed (from start or from reset)
- ⑤ Distance covered (from start or from reset)



ATTENTION ASSIST display: break in less than 15 mins

Resetting values on the trip menu of the on-board computer

On-board computer:

¬→ Trip

(i) The wording may differ on the main menu displayed. Therefore, pay attention to the menu overview for the instrument cluster.

You can reset the values of the following functions:

- Trip Odometer:
 - Reset Trip Odometer?
- · Trip computer:
 - From Start
 - From Reset
- ECO Display
- Current Consumption
- Range
 - Reset range
- ATTENTION ASSIST
- Select the function for which the value is to be reset and confirm this selection.
- Confirm the prompt Reset Values? with Yes.

Calling up the battery calibration menu

On-board computer:

¬→ Settings >> eSprinter

>> Battery Calibration

The menu indicates whether the high-voltage battery needs to be calibrated.

- Observe the notes on calibrating the high-voltage battery (\rightarrow page 152).
- Confirm the selection of Perform Calibration and carry out a normal or a special calibration $(\rightarrow page 153).$

or

Exit the menu without confirming.

Calling up settings on the on-board computer

On-board computer:

¬→ Settings

The following entries can be configured on the **Settings** menu:

eSprinter

- Selecting Charging Program
 - Standard
 - Work
 - Home
- Setting Departure Time
- Setting Pre-entry Climate Control at
- · Setting Max. State of Charge
- Carrying out Battery Calibration
- Trailer Settings

Assistance

- Switching ESP on/off
- Switching Lane Keeping Assist on/off
- Switching Active Brake Assist on/off
- Switching Blind Spot Assist on/off
- Switching ATTENTION ASSIST on/off

Light

- Switching Daytime Running Lights on/off
- Switching Int. Sw.-off Delay Time on/off
- Switching Ext. Sw.-off Delay Time on/off
- Switching Locator Lighting on/off
- Setting Instr. Cluster Lighting

Vehicle

- Setting Winter Tire Limit
- Switching Acoustic Lock on/off
- Switching Automatic Locking on/off
- Switching Rain Sensor on/off

Setting Heating

Display and Operation

- Selecting Language
- · Setting Time
- · Setting Date
- Setting Units
- Switching Operation: Acoustic Op. Feedback on/off and setting Touch Control Sensitivity

Factory Settings: Restoring settings

- Select an entry and confirm the selection.
- Make the necessary changes.

Mercedes me calls


Making a call via the overhead control panel

- (i) Mercedes me calls are not possible in every country. Contact an authorized Mercedes-Benz Center to find out whether these functions are available in your country.
- i Please note that product scopes can vary depending on the model series, year of production and equipment, as well as between private and commercial user accounts.

The following services have no limitation in the term:

- · Accident and Breakdown Management
- · Maintenance management
- Telediagnostics

Other services can be extended at the end of the initial term for a fee. The first activation of the services by the customer is possible within one year of initial registration or commissioning, depending on which happens first.



- me button for service or information calls
- SOS button cover
- SOS button (emergency call system)

Making a Mercedes me call

Press button ①.

Making an emergency call

- Briefly press the cover on so button 2 to open it.
- Press and hold Sos button for at least one second.

An emergency call can still be triggered when a breakdown assistance call is active. This has priority over all other active calls.

Information about the Mercedes me call using the overhead control panel

A call to the Mercedes-Benz Customer Center was initiated using the me button in the overhead control panel (\rightarrow page 137).

You can reach the desired service via the voice dialog system:

- · Accident and Breakdown Management
- Mercedes-Benz Customer Center for general information about the vehicle

You can find information on the following topics:

- · Activation of Mercedes me connect
- · Operating the vehicle
- Nearest authorized Mercedes-Benz Center
- Other products and services from Mercedes-Benz

Data is transmitted during the connection to the Mercedes-Benz Customer Center (→ page 138).

Arranging a service appointment via Mercedes me call

If you have activated the maintenance management service, relevant vehicle data is transferred automatically to the Mercedes-Benz customer center. You will then receive individual recommendations regarding the maintenance of your vehicle. You will receive an offer for the upcoming maintenance scopes from the service partner stored in Mercedes me.

Regardless of whether you have consented to the maintenance management service, you are reminded in the instrument cluster after a certain amount of time that a service is due.

To arrange a service appointment: select the me button for service or information calls $(\rightarrow page 137)$.

You are connected to the Mercedes-Benz customer center and if necessary, your call is forwarded to an appropriate specialist.

After your confirmation, the vehicle data is sent and the Mercedes-Benz customer center deals with your appointment. The information is then sent to your desired service outlet.

- They will contact you to confirm the appointment and, if necessary, to discuss the details.
- No request for consent to data transfer is made, if the Mercedes me connect Accident and Breakdown Management service is activated.

Consenting to data transfer for a Mercedes me call

Requirements:

 There is an active Mercedes me call via the buttons in the overhead control panel (→ page 137).

If the Mercedes me connect services are activated, no query for data transfer appears in the instrument cluster.

If the Mercedes me connect services are not activated, the following message appears in the instrument cluster Send Data?.

Confirm or decline the query with the ⊕ or ⊕ buttons in the instrument cluster.
If the data protection query is accepted via the ⊕, relevant identification data is transferred automatically.

Transferred data during a Mercedes me call

When you make a service call via Mercedes me, data is transmitted. This enables targeted advice and smooth service.

The following requirements must be met for the data transfer:

- · The vehicle is switched on.
- The necessary data transmission technology is supported by the mobile phone network provider.
- A sufficient mobile phone connection quality is provided.

Multi-stage transmission depends on the following factors:

- · Reason for the initiation of the call
- Available mobile radio transmission technology
- Activated Mercedes me connect services
- · Selected service in the voice dialog system
- (i) A request for consent to data transfer is only made if the corresponding Mercedes me connect service has not been activated.
- i The scope of the transmitted data depends on the vehicle model and equipment. For techni-

- cal reasons not all data is available at all times.
- i The prompt to confirm data transfer does not appear in all countries.

Data transfer when Mercedes me connect services are not activated

If no Mercedes me connect services are activated and the data protection query has been confirmed, the following data will be transferred:

- Vehicle identification number
- · Time of the call
- · Reason for the initiation of the call
- Confirmation of the data protection prompt
- Vehicle country code
- Call number of the communication platform installed in the vehicle

If a call is made for a service appointment via the service reminder, the following data is also transmitted:

· Current mileage and maintenance data

If the Accident and Breakdown Management selection has been made via the voice dialog system and no service has been activated, but the data protection query has been confirmed, the following data can be additionally requested from the vehicle by the Mercedes-Benz Customer Center:

· Current vehicle location

If the data protection request has been declined, the following data will be transferred to enable targeted advice and a smooth service:

- · Reason for the initiation of the call
- Rejection of the data protection prompt
- Vehicle country code
- Call number of the communication platform installed in the vehicle

Data transfer when Mercedes me connect services are activated

Only in the second step, only for the respective activated services, further case-specific data is transmitted in order to enable an optimal service.

An overview of the data transmitted can be found in the respective terms of use for Mercedes me connect services. You can obtain these in the Mercedes me Portal at: https://www.mercedes.me

Data processing

The data transmitted as part of the call will be deleted from the transmitting systems once the call has been completed, provided they are not used for other activated Mercedes me connect services.

The case-related data will be processed and stored in the Mercedes-Benz Customer Center and, if necessary for case processing, forwarded to the service partners commissioned by the Mercedes-Benz Customer Center. Please refer to the data protection information on the Mercedes me website at https://www.mercedes.me or in the recorded message immediately after the call to the Mercedes-Benz Customer Center has been set up.

(i) The recorded message is not available in every country.

Mercedes me connect

Information about Mercedes me connect

i Please note that product scopes can vary depending on the model series, year of production and equipment, as well as between private and commercial user accounts.

Mercedes me connect comprises a number of services.

Using the multimedia system or the overhead control panel, if available, you can use the following services, for example:

- · Accident and breakdown management (me
- Emergency Call System (automatic emergency call and SOS button)

Mercedes me connect Accident and Breakdown Management and the Mercedes-Benz Emergency Call System are available to you around the clock.

The me button and the SOS button can be found on the vehicle's overhead control panel $(\rightarrow page 137)$.

If the multimedia system is available in the vehicle, you can also call the Mercedes-Benz customer center using the multimedia system.

Please note that Mercedes me connect is a Mercedes-Benz service. In emergencies, call the national emergency services first using the standard national emergency service phone numbers. In emergencies, you can also use the emergency call system (\rightarrow page 163).

Please note the Mercedes me connect terms of use and the data protection information for Mercedes me connect. You can find these in your Mercedes me user account.

Further information about Mercedes me connect services can be obtained in the Mercedes me Portal: https://me.secure.mercedes-benz.com

Information on Mercedes me connect Accident and Breakdown Management

(i) Accident and Breakdown Management is not available in every country. Contact an authorized Mercedes-Benz Center to find out whether this function is available in your coun-

The Accident and Breakdown Management can, amongst others, include the following functions:

- Supplement to the Emergency Call System $(\rightarrow page 163)$
 - If necessary, the contact person at the Mercedes-Benz emergency call center forwards the call to Mercedes me connect Accident and Breakdown Management. However, call forwarding is not possible in all countries.
- Breakdown assistance on location by a technician and/or towing away of the vehicle to the nearest authorized Mercedes-Benz Center
 - You may be charged for these services.
- In the event of a breakdown or accident, extended vehicle data is sent, enabling optimum support from the Mercedes-Benz Customer Center and the appointed service partner or breakdown mechanic.
- If available: addition to the Mercedes me connect Telediagnostics service
 - With the Telediagnostics function, the service provider records certain wear and failure messages, insofar as these can be clearly interpreted and are available by monitoring diagnosable components.
- (i) These services are subject to technical restrictions such as mobile coverage and mobile network quality and the interpretability of the transmitted data in the processing systems. Under certain circumstances, this may result in delays or omission of the message in the instrument cluster.

Please note that the Mercedes me call is a Mercedes-Benz service. In the event of an emergency always call the national emergency services first or use the Mercedes-Benz emergency call system (\rightarrow page 163).

Further information about Mercedes me connect services can be obtained in the Mercedes me Portal: https://me.secure.mercedes-benz.com

Data transferred during Mercedes me connect call services

The data transferred during the Mercedes me connect call depends on:

- The reason for the initiation of the call
- The service selected in the voice dialog system
- The activated Mercedes me connect services

The data which is transferred is listed in the currently valid terms of use and data protection information of Mercedes me connect. These can be found at: https://www.mercedes.me under "My Mercedes me account", "Terms of use".

Mercedes me and apps

Information about Mercedes me

Requirements:

- To use the services, registration in the Mercedes me Portal must have been carried out.
- The terms of use for Mercedes me connect services have been agreed to.
- The services are activated.

The services can be activated in the Mercedes me Portal via the path Manage vehicle > My services.

When you log in with a user account to the Mercedes me Portal, then services and offers from Mercedes-Benz will be available to you.

 Please note that product scopes can vary depending on the model series, year of production and equipment, as well as between private and commercial user accounts.

Availability is country-dependent.

For more information consult an authorized Mercedes-Benz Center or visit the Mercedes me Portal: https://me.secure.mercedes-benz.com.

(i) Make sure that you always keep the Mercedes me Apps up to date.

Notes on operating safety



WARNING Risk of distraction from operating integrated communication equipment while the vehicle is in motion

If you operate communication equipment integrated in the vehicle when driving, you could be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.

You must observe the legal requirements for the country in which you are currently driving when operating the audio system.



WARNING Risk of accident or injury due to incorrect modifications on electronic component parts

Modification of electronic components, their software or wiring could impair their function and/or the function of other networked component parts or safety-relevant systems.

This can endanger the operating safety of the vehicle.

- Never tamper with the wiring and electronic component parts or their software.
- You should have all work on electrical and electronic components carried out at a qualified specialist workshop.

Observe the following information when using the radio:


- · Observe the safety notes in this manual.
- · Observe the road traffic regulations.

Anti-theft protection

This device is equipped with technical provisions to protect it against theft and cannot be used in another vehicle.

Overview and operation

Audio system overview



Control knob

Turn: sets the volume

Press briefly: switches sound off.

Press and hold: switches the audio system on/off.

If the media source is switched on: pause or playback

- Three-line display
- 3 Control knob

Turn: opens the station or media list.

Marks the next or previous menu entry.

Press briefly: calls up the station list or track list, selects a menu entry or accepts a call.

Back

Press briefly: moves up one menu or folder level.

Press and hold: calls up the main menu for the application.

- USB-C port
- Press briefly: next station or skips forwards a track

Press and hold: station search function forwards or fast forward

- Press briefly: previous station or skips back a track
 - Press and hold: station search function backwards or fast rewind
- Press briefly: calls up system settings.Press and hold: calls up radio text or ID3 tag.

 Press briefly: calls up the telephone, accepts or ends a call.

Press and hold: calls up the call list.

© Calls up USB mode, iPod[®] mode or Bluetooth[®] audio mode.

Requirement: the media source is connected with the audio system.

- Press briefly: calls up radio in the order FM -DAB - AM (if DAB is available) or FM - AM Press and hold: updates the DAB station landscape (if DAB is available).
- Press briefly: calls up station presets.
 Press and hold: saves a station in the open station presets.

Alternative: with the station presets open press and hold 3.

(i) Note for (5): only use a USB-C to Lightning cable certified by Apple® to connect an iPod®.

Switching the audio system off/on

Press and hold the left control knob. Depending on its status the audio system is activated or deactivated.

Adjusting the volume

To increase volume: turn the volume control clockwise.

- To decrease volume: turn the volume control counter-clockwise.
- To mute: press the volume control.

System settings

Audio settings

Setting the sound

Audio system:

¬→ SETUP → Audio settings → Sound

Equalizer

- Select Bass, Middle or Treble.
- Change the settings.

Balance and fader

- Select Balance or Fader.
- Change the settings.

Reset audio settings

Audio system:

- ¬→ SETUP → Audio settings
- >> Reset audio settings
- Confirm with YES.
 - The audio settings are reset.

Setting the time format

Audio system:

- ¬→ SETUP → Clock
- Select am/pm or 24h.

Resetting the audio system to the factory settings

Audio system:

- **¬→** SETUP
- Select Factory settings.
- Confirm the prompt with Yes.
 - The settings are reset to the factory settings.

Showing the software version

Audio system:

- **¬→** SETUP
- Select Software Version:.
 - The current software version is displayed.

Radio

Setting the frequency band

Audio system:

- RADIO
- Press the RADIO button repeatedly until the desired transmission range is set.

The transmission range changes in this order: FM -DAB.

(i) The DAB transmission range is not available in all countries.

Selecting a radio station

Audio system:

RADIO

Setting a station using the frequency

- Press the → or → button to change the frequency.
- (i) Press briefly: the next or previous station is

Press and hold: scrolls step-by-step through the frequencies.

Setting a station from the station list

- Press or turn the right-hand side control knob. The station list is shown.
- Select a station. The station is set.

Selecting stations via the station presets

- Call up the station presets (\rightarrow page 142).
- Select a station. The station is set.

Saving stations as favorites

Requirements:

 DAB or FM is set as the transmission range $(\rightarrow page 143).$

Audio system:

- RADIO
- Set a station.
- Press the 🔯 button. The station presets are shown.
- Select a position, then press and hold 🏠 or the right control knob. The station selected is saved.

Activating/deactivating the traffic information service

Audio system:

→ SETUP → Radio Settings → TA

When the function is switched on a traffic announcement will interrupt the currently activated radio or media source.

Select ON or OFF.

Setting DAB traffic information

Audio system:

¬→ SETUP → Radio Settings

- >> DAB traffic information
- Select one or more settings.
- i The DAB transmission range is not available in all countries.

Selecting Intellitext™

Requirements:

DAB is set as the station range (→ page 143).

Audio system:

► SETUP ► Radio Settings ► DAB Settings ► IntellitextTM

If the respective station supports IntellitextTM, you can have additional information shown such as news, weather information and sports alerts. This assumes that the broadcasting organization provides such information. IntellitextTM is only available is some countries.

- Select a category, for example:
 - News
 - Weather
 - Sports

If the News category is selected, three sub-categories can be selected:

Select Business, Politics or Health. Intellitext™ for the category selected is shown.

Showing the current program preview (EPG)

Requirements:

 DAB is set as the transmission range (→ page 143).

Audio system:

→ SETUP → Radio Settings → DAB Settings → EPG

Select a station.

The program preview is shown for this station.

- Press the left control knob.
- The program preview is shown.

Media

Starting playback of a USB device

Requirements:

A USB device is connected to the audio system.

Audio system:

™ MEDIA

- Press the MEDIA button repeatedly until the USB is the active media source.
- Press or turn the left control knob.
- Select a folder.
- Select a track. Playback starts.

Starting playback of Bluetooth® audio devices

Requirements:

- Bluetooth® is switched on
- A Bluetooth[®] audio device is connected with the audio system (→ page 146).

Audio system:

™EDIA

- Press the MEDIA button repeatedly until Bluetooth® is the active media source.
- Press or turn the left control knob.
- Select Playlists, Artists or Albums.
- (i) These categories are not available for the iPhone[®].
- Select a track. Playback starts.

Starting playback of an iPod®

Requirements:

- An iPod[®] is connected to the audio system.
- (i) Only use a certified USB-C to Lightning cable to connect an iPod®.

Audio system:



- Press the MEDIA button repeatedly until iPod® is the active media source.
- Press or turn the left control knob.

The following categories are displayed:

- Playlists
- Artists
- Albums
- Tracks
- Select a category.
- Select a track. Playback starts.

Showing track information

Requirements:

Playback from a USB device is active.

Audio system:

MEDIA

Press and hold the SETUP button. Information on albums, artists and track names is shown.

Controls playback

Requirements:

- · Playback from a USB device or Bluetooth® audio equipment is active.
- To select the next track: press | >>| .
- To select the previous track: press ◄.
- (i) If the current track has already been playing for more than eight seconds then you will skip back to the beginning of the track.
- To pause playback: press the left control knob.
- To fast forward/rewind: press the

 or button until the desired position is reached.

Setting playback options

Audio system:

¬→ SETUP → Audio settings → Play Mode

Activating/deactivating random playback

Select Mix.

Depending on its previous status the function is activated/deactivated.

Switching repeat on/off

Select Repeat.

The following settings are possible:

- OFF: No repetition.
- ALL: The complete playlist is repeated.
- ONE: The current track is repeated.
- Press repeatedly until the desired setting is reached.

Telephone

Telephony

Notes on telephony

WARNING Risk of distraction from operating integrated communication equipment while the vehicle is in motion

If you operate communication equipment integrated in the vehicle when driving, you could be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.
- WARNING Risk of accident from operating mobile communication equipment while the vehicle is in motion

Mobile communication devices distract the driver from the traffic situation. This can also cause the driver to lose control of the vehicle.

- As a driver, only operate mobile communication devices when the vehicle is stationary.
- As a vehicle occupant, use mobile communication devices only in the designa-

ted area, e.g. in the rear passenger compartment.

You must observe the legal requirements for the country in which you are currently driving when operating mobile communication equipment in the vehicle.

Further information can be obtained from an Mercedes-Benz or at: https://www.mercedes-benz.com/connect

Activating/deactivating Bluetooth®

Audio system:

- **TEL**
- Select Bluetooth.

Activating

Select ON.

Deactivating

- Select OFF.
- Switching on visibility of the audio system

Requirements:

Bluetooth[®] is activated on the audio system.

Audio system:

- **TEL**
- Select Make visible.

Connecting a mobile phone

Requirements:

- Bluetooth® is activated on the mobile phone (see the manufacturer's operating instructions).
- Bluetooth[®] is activated on the audio system.
- The visibility of the mobile phone is switched on (see the manufacturer's operating instructions).
- The visibility of the audio system is switched on.

Audio system:

→ TEL → Pair device

Authorization using Secure Simple Pairing

- Select a mobile phone.
 - A code is displayed on the audio system and on the mobile phone.
- If the codes match: select YES on the audio system.
- Confirm the code on the mobile phone.

Switching mobile phones

Requirements:

 At least two mobile phones are authorized on the audio system.

Audio system:

- **TEL** ▶ Select Device
- Select a mobile phone.

Adjusting the call/ringtone volume

Audio system:

- **TEL** ▶ Settings
- Select Volume.
- Set the volume for Ringtone or Call.

Setting the ringtone

Audio system:

- **TEL →** Settings
- Select Ringtone.
- Set the ringtone for Car or Phone.

Disconnecting a mobile phone

Audio system:

- → TEL → Delete Device
- Select a mobile phone.
- Select Yes.

Calls

■ Telephone operation

Audio system:

TEL

Making a call

- Select Dial Number.
- Enter a number.
- ➤ Select <a> □.
 - The call is made.
- i You can also make a call using the call list or the phone book.

Accepting a call

- Select .
- or
- Briefly press button TEL.

Rejecting a call

- or
- Press and hold the TEL button.

Activating functions during a call

Ending a call

Select .

Briefly press the TEL button.

Transferring a call to the mobile phone (private mode)

Select .

Sending DTMF tones

- ➤ Select :: .
- Enter the numbers.

Adjusting the volume

Set the volume using the control knob $(\rightarrow page 142).$

Accepting/rejecting a waiting call

Requirements:

• There is an active call (\rightarrow page 146).

If you receive a call while already in a call, a message is displayed.

- To accept: select . The incoming call is active. The previous call is
- To reject: select .
- To select a call: select 📳 (1) or 📳 (2).
- This function and behavior depends on your mobile phone network provider and the mobile phone (see the manufacturer's operating instructions).

Phone book

Downloading mobile phone contacts manually

Audio system:

TEL ▶ Settings

The function is also available. When connecting the mobile phone with the audio system, contacts are downloaded automatically.

- Select Phonebook download.
- Searching for contacts in the phone book

Audio system:

→ TEL >>> Phonebook

 Select the contact. Several phone numbers can be shown for contacts.

Call list

Making a call from the call list

Audio system:

TEL ▶ Call Lists

Within the call list the following entries are available for selection:

- · Dialled calls
- Received calls
- · Missed calls
- Select an entry. The stored calls are shown.
- Select an entry. The call is made.
- (i) Alternatively, you can call up the call list by pressing and holding the TEL button.

Notes on loading guidelines

WARNING Risk of injury from unsecured objects in the vehicle

When objects are unsecured or inadequately secured, they can slip, tip over or be thrown about, striking vehicle occupants.

This also applies to:

- Luggage or loads
- · Seats which have been removed and are being transported in the vehicle in an exceptional case

There is a risk of injury, particularly in the event of braking maneuvers or abrupt changes in direction.

- Always stow objects in such a way that they cannot be tossed about.
- Before traveling, secure objects, luggage or load to prevent them slipping or tipping over.
- When a seat is removed, keep it preferably outside the vehicle.

WARNING Risk of injury due to objects being stowed incorrectly

If objects in the vehicle interior are stowed incorrectly, they can slide or be thrown around and hit vehicle occupants. In addition, cup holders, open storage spaces and mobile phone receptacles cannot always retain all objects within.

There is a risk of injury, particularly in the event of sudden braking or abrupt changes in

- Always store objects such that they cannot be thrown around in such situations.
- Always make sure that objects do not protrude from storage spaces, parcel nets or storage nets.
- Close the lockable storage spaces before starting a journey.
- Stow and secure objects that are heavy, hard, pointed, sharp-edged, fragile or too large in the cargo compartment.

If you are using a roof luggage rack, please note the maximum roof load and the maximum load capacity of the roof luggage rack. (\rightarrow page 233) Camera-based driving systems and the sensor functions of the inside rear-view mirror may be impaired if you are transporting a load on the roof and it protrudes more than 16 in (40 cm) over the front edge of the roof. Therefore, make sure that the load does not protrude by more than 16 in (40 cm).

The handling characteristics of your vehicle are dependent on the load distribution.

Therefore, please observe the following notes when loading:

- When transporting a load, never exceed the gross vehicle weight rating or the gross axle weight rating for the vehicle (including occupants). The figures are specified on the vehicle identification plate on the B-pillar.
- The load must not protrude above the upper edge of the seat backrests.
- · If possible, always transport the load in the cargo compartment.
- Fasten the load to the cargo tie down rings and distribute the load evenly among them.
- · Use cargo tie down rings and fastening materials that are suitable for the weight and size of the load.

Notes on distributing the load within the vehicle

NOTE Damage to the floor covering due to uneven loading

Excessive point loading on the cargo compartment floor or on the load area can negatively affect the driving characteristics and could damage the floor covering.

Distribute the load evenly. When doing so, ensure that the overall center of gravity of the load is always as low and close to the center as possible and between the axles near the rear axle.

Observe the following notes:

- · always transport loads in the cargo compartment.
- always additionally secure the load with suitable load securing aids or lashing material.

Securing loads

Notes on load securing

WARNING Risk of accident and injury due to incorrect use of the lashing straps

The following can occur:

- The tie-down eyes may detach or the lashing strap may tear if the permissible load is exceeded
- · The load cannot be restrained

The load can slip, tip over or be flung about, striking vehicle occupants.

- Always tension the lashing straps in the proper manner and only between the described tie-down eyes.
- Always use lashing straps designed specifically for the loads.
- (i) Observe the information relating to the maximum loading capacity of the individual cargo tie-down points. If you combine various cargo tie-down points to secure a load, always take the maximum loading capacity of the weakest cargo tie-down point into account. During maximum full-stop braking, forces may act which can multiply the weight of the load. Always use several cargo tie-down points to distribute the load. Spread the load evenly between the cargo tie-down points or tie-down

Observe the Operating Instructions or the lashing strap manufacturer's instructions for the operation of the lashing strap.

Observe the information relating to the maximum loading capacity of the cargo tie-down points $(\rightarrow page 233)$.

As the driver, you are responsible for ensuring the following:

- · The load is secured against slipping, tipping, rolling or falling off.
 - Take usual traffic conditions as well as swerving or full brake application and bad roads into account.
- The applicable requirements and guidelines relating to load-securing practices are met. If this is not the case, this may constitute a punishable offense, depending on local legislation and any ensuing consequences. Observe country-specific laws.

Make sure that the load is secure before every journey and at regular intervals during a long journev. Adjust the load securing as necessary. Information on how to secure loads correctly can be obtained from the manufacturers of the load securing aids or tie downs for load securing, for example.

When securing loads, observe the following:

- Fill spaces between the load and the cargo compartment walls or wheel wells. For this purpose, use rigid load securing aids, such as chocks, wooden fixings or padding.
- · Attach secured and stabilized loads in all directions.

Use the cargo tie-down points or tie-down eyes and the loading rails in the cargo compart-

Only use tie downs, such as lashing rods, lock rods or lashing nets and lashing straps, which have been tested in accordance with current standards (e.g. DIN EN). Always use the cargo tie-down points closest to the load and pad sharp edges.

Loads, and heavy loads in particular, should preferably be secured using the tie-down eyes.


(i) You can obtain tie downs tested in accordance with current standards (e.g. DIN EN) from any specialist company or from a qualified specialist workshop.

Notes on the partition

Without a partition, vehicles that are approved as commercial vehicles (vehicle category N1, N2) do not fulfill standard ISO 27956, which describes the equipment for properly securing a load in delivery vehicles. If the vehicle is used to transport goods, retrofitting the partition is strongly recommended, as properly securing the load in vehicles without a partition will always be a complex operation.

(i) Nothing may be stowed in the area between the rear side of the seats and the partition.

Overview of cargo tie-down point



Cargo tie-down points (example: cargo van without loading rails)

Cargo tie-down rings

Secure loose loads with an approved lashing net or a tarp.

Always fasten the lashing net or tarp to all available cargo tie-down points. Make sure that the fastening hooks are secured against accidental opening.

If your vehicle is equipped with loading rails in the cargo floor, you can place lashing rods directly in front of and behind the load. The lashing rods directly absorb the potential shifting forces.

Securing loads on the cargo floor by lashing them down is recommended only for lightweight loads. Lay anti-slip mats under the load to assist in securing it.

Installing and removing cargo tie-down rings

- To install: slide the cargo tie-down ring through a recess in the loading rail close to the load until the locking mechanism engages in the recess.
- (i) When you pull the locking mechanism up and out of the recess, the cargo tie-down ring is able to move within the loading rail. Make sure that the locking mechanism is always engaged in a recess
- Check the cargo tie-down ring for firm seating.
- To remove: pull the locking mechanism up and pull the cargo tie-down ring towards the locking mechanism and out of the loading rail through a recess.

Carrier systems

Information on the roof luggage rack

WARNING Risk of injury if maximum roof load is exceeded


The vehicle center of gravity and the usual driving characteristics as well as the steering and braking characteristics will change.

If you exceed the maximum roof load, the handling as well as steering and braking characteristics are severely affected.

- Always comply with the maximum roof load and adjust your driving style.
- NOTE Vehicle damage due to failure to observe the maximum permissible clearance height

If the vehicle height exceeds the maximum permissible clearance height, the roof and other vehicle parts may be damaged.

- Please observe the maximum clearance height indicated.
- If the vehicle exceeds the permissible clearance height, do not drive in.
- Take the modified vehicle height into account in the case of roof superstructures or other carrier systems.



Mounting rails

Information about the maximum roof load can be found in the "Technical data" section (\rightarrow page 233).

Observe the following points for installing roof luggage racks:

- Tighten the screws of the roof luggage rack with a torque of 6.0 lb-ft (8 Nm) - 7.4 lb-ft (10 Nm) in the designated sliding blocks.
- The tightened screws should not touch the rails.
- · Ensure that the sliding blocks are not located in the areas around the plastic caps.
- · The sliding blocks must have the right crosssection.
- . The insides of the mounting rails must be free of dirt.
- · Re-tighten the screws uniformly after around 300 miles (500 km).

Mercedes-Benz recommends that you use only roof luggage racks that have been tested and approved for Mercedes-Benz. These help to prevent vehicle damage.


Have mounting rails retrofitted only at a qualified specialist workshop. Otherwise, you could damage the vehicle.

If your vehicle is equipped with mounting rails on the roof, you can install a roof luggage rack on the roof. Special fasteners (sliding blocks) are available as accessories for this purpose.

These fasteners are available from any authorized Mercedes-Benz Center.

Placing a load on the wheel arch

Comply with the important safety notes under "Notes on loading" (\rightarrow page 148).



Place the objects on wheel arch (2) and lash them using tie-down eyes \bigcirc (\rightarrow page 150).

(i) A wheel arch may be subjected to a load of 330 lb (150 kg).

ASSYST PLUS service interval display

Function of the ASSYST PLUS service interval display

The ASSYST PLUS service interval display on the instrument cluster provides information on the remaining time or distance before the next service due date.

You can hide this service message by using the back button on the left-hand side of the steering wheel.


You can obtain further information concerning the servicing of your vehicle from a qualified specialist workshop, e.g. an authorized Mercedes-Benz Cen-

Displaying the service due date

On-board computer:



The next service due date is displayed.



Bear in mind the following related topic:

· Operating the on-board computer

Have service work carried out regularly

NOTE Premature wear through failure to observe service due dates

Maintenance work which is not carried out at the right time or incompletely can lead to increased wear and damage to the vehicle.

- Adhere to the prescribed service inter-
- Always have the prescribed maintenance work carried out at a qualified specialist workshop.

Special service requirements

The prescribed service interval is based on normal vehicle use. Perform maintenance work more often than prescribed if the vehicle is operated under arduous operating conditions or increased loads.

Examples of arduous operating conditions:

- Frequent operation in mountainous terrain or on poor road surfaces
- Operation in particularly dusty conditions and/or if air-recirculation mode is frequently used

In these or similar operating conditions, have the interior air filter, for example, changed more frequently. Check the tires more frequently if the vehicle is operated under increased stress. You can obtain further information at a qualified specialist workshop.

Non-operational times with the battery disconnected

The ASSYST PLUS service interval display can calculate the service due date only when the battery is connected.

Display and note down the service due date on the instrument cluster before disconnecting the battery (\rightarrow page 152).

Calibrating the high-voltage battery

Notes on calibrating the high-voltage battery

Your vehicle's high-voltage battery is equipped with LFP technology (lithium iron phosphate). In comparison to NMC (nickel manganese cobalt), this technology is characterized by a particularly long service life and environmental safety.

In order to provide the most accurate range display, charging time prediction and charge level display, LFP technology requires regular calibrations of the high-voltage battery.

Two types of calibration are required for an accurate calibration of the high-voltage battery:

- A regular normal calibration of the state of charge of the high-voltage battery. This takes place during the process of fully charging the high-voltage battery (\rightarrow page 104, 153).
- A special calibration of the high-voltage battery. This is used to determine the age-related battery capacity, ideally twice a year. Among other things, the special calibration requires the high-voltage battery to be charged from a low state of charge (\rightarrow page 153).

A special calibration can also be performed manually (\rightarrow page 154).

Further information

- The amount of time the vehicle remains connected to a public charging station is increased if the high-voltage battery is calibrated during or after the charging process. Attention is drawn to extended charging times via display messages. If a public charging station is locked, additional fees may be incurred, depending on the operator's terms of use.
- (i) If the power supply is switched on or electrical consumers are used during calibration, the calibration may be aborted.
- (i) Setting a departure time may result in there being insufficient time for the planned calibra-
 - If you require the state of charge to be as high as possible by the departure time, set a departure time.
- (i) Low outside temperatures can have a negative impact on the calibration. It is advisable to perform the calibration at temperatures above 59 °F (15 °C).
- (i) The need for calibration:
 - is dependent on use
 - · is indicated by display messages in the instrument cluster (\rightarrow page 243).
 - can be verified via the on-board computer $(\rightarrow page 135).$
 - · can be covered by performing a manual calibration (\rightarrow page 154)

Why is regular calibration necessary?

(i) If the battery continues to be insufficiently calibrated, large deviations in the predicted range may result. There is a risk the vehicle's drive may experience a loss of output which either comes unexpectedly or for which a warning is issued too late. As a result, it may no longer be possible to continue the journey.

Batteries age over time and slowly lose some of their capacity, in other words, their ability to provide energy. This means that the 100% state of charge displayed in a vehicle that is one year old, for example, has a lower energy content than the 100% state of charge displayed in a new vehicle. During the calibration process, the exact energy content of the 100% state of charge is determined. The lower states of charge, the range and the charging time are calculated based on this determination.

Without calibration, the information displayed with respect to the range, the predicted range and the state of charge will become increasingly imprecise.

Calibrating the high-voltage battery

Requirements

- There is enough time and space to completely charge the high-voltage battery even if the charging time is extended.
- · You are familiar with the notes on calibrating the high-voltage battery (\rightarrow page 152).

Calibrating the high-voltage battery

The high-voltage battery can be calibrated in different ways:

- You confirm the display messages regarding calibration and follow the recommendations shown.
- · You call up the Battery Calibration menu and start the normal or special calibration from there (\rightarrow page 135).
- You perform the special calibration of the highvoltage battery manually (\rightarrow page 154). Manual calibration is also possible when charging with direct current (DC).

The requirements for calibration are indicated by the following display messages:

- To Ensure Max. Range, Perform Battery Calibration Start Charge Process to 100% A normal calibration is required.
- · To Ensure Max. Range, Perform Battery Calibration Extra Charging Time: XX min Start AC Charging to 100%

A special calibration is required.

Battery Calibration Required AC Charging to 100% Start Possible at State of Charge: Max. XX% Outside Temp.: Min. XX °F

A special calibration is required.

Perform a normal or special calibration as described below.

Performing a normal calibration

(i) Calibration will be carried out automatically during the next suitable charging process, once you have confirmed the calibration in the instrument cluster.

A calibration is suitable if the following conditions are met:

- You charge the vehicle up to a state of charge of 100%.
- Allow the vehicle to be charged until a state of charge of 100% has been reached.

Performing a special calibration

 Calibration will be carried out automatically during the next suitable charging process, once you have confirmed the calibration in the instrument cluster.

A calibration is suitable if the following conditions are met:

- The state of charge is at a maximum of XX % at the beginning of the charging process, see display message in the instrument cluster.
- You charge the vehicle using alternating current (AC) until a state of charge of 100% has been reached.
- The outside temperature is at least 59°F (15°C).
- No departure time is set before the end of the charging time.
- During calibration, charging breaks may occur. Do not disconnect the charging cable from the vehicle. Otherwise the calibration may be interrupted.
- i During the calibration, the charging time may be extended once only.
- Calibration can be interrupted if electrical consumers are connected or pre-entry climate control is activated.
- Confirm all display messages regarding calibration, provided the outside temperature and the state of charge conform to the required values shown in the display message. Calibration starts.
- Allow calibration to continue until the display message Battery Calibration Successful Max. Battery Output and Range Restored or Battery Calibration Was Not Possible See Operator's Manual appears.

Battery Calibration Was Not Possible See Operator's Manual

Check if a departure time has been preset that starts before the end of the charging time (incl. charging time extension) and deactivate it if possible (→ page 104).

- Check that the maximum state of charge is set to 100% (\rightarrow page 104).
- Check if an electrical consumer was used during calibration or the power supply was switched on.
- If possible, prevent the vehicle from cooling down too much or postpone calibration until the weather conditions are more favorable.
- Restart the calibration via the menu Battery Calibration in the instrument cluster (→ page 136).
- If the problems persist, perform a manual calibration of the high-voltage battery (→ page 154). Manual calibration is also possible when charging with direct current (DC).

Manually calibrating the high-voltage battery

Requirements

- The outside temperature is at least 59°F (15°C).
- The state of charge is less than 15%.
- You are familiar with the notes on calibrating the high-voltage battery (→ page 152).

Manually calibrating the high-voltage battery

The high-voltage battery can be manually calibrated if the automatic calibration fails repeatedly or it is not possible to charge the battery using alternating current (AC).

- Park the vehicle in the immediate vicinity of a charging station that has a minimum output of 11 kW.
- The vehicle must remain parked for at least six hours.
- i The remaining range of the high-voltage battery must be sufficient to reach the nearest charging station.
- (i) Do not start or move the vehicle during the six hours in which it is non-operational. The doors must remain closed and neither the pre-entry climate control nor any electrical consumers can be active.
- Connect the vehicle to the charging station.
- i While the vehicle is charging, electrical consumers can be active and the power supply can be switched on.

Charge the vehicle up to a state of charge of 100%.

When a state of charge of 100% has been reached, the calibration is finished.

Engine compartment

Opening and closing the hood

DANGER Risk of fatal injuries when carrying out maintenance work during the charging process

During the charging process, the high-voltage on-board electrical system is under high voltage.

Do not perform any maintenance work during the charging process.

WARNING Risk of accident due to driving with the hood unlocked

The hood may open and block your view.

- Never release the hood when driving.
- Before every trip, ensure that the hood is locked.

WARNING Risk of injury due to overheated

If you open the hood in the event of an overheated vehicle or fire in the engine compartment, the following situations may occur:

- · You may come into contact with hot gases.
- · You may come into contact with other escaping hot operating fluids.
- In the event of overheating or fire in the engine compartment, keep the hood closed and call the fire service.
- Allow the overheated vehicle to cool down first if you need to open the hood.

WARNING Risk of injury due to moving parts

Components in the engine compartment can continue to run or start unexpectedly even when the vehicle is switched off.

Observe the following before performing tasks in the engine compartment:

Switch off the vehicle.

- Never touch the danger zone surrounding moving components, e.g. the rotation area of the fan.
- Remove jewelry and watches.
- Keep items of clothing and hair away from moving parts.

WARNING Risk of burns from hot components in the engine compartment

Certain components in the engine compartment can be very hot, e.g. the drive system and the cooler.


Allow the drive system to cool down and touch only the components described below.

If you have to carry out any work in the engine compartment, touch only the following components:

- Hood
- Washer fluid reservoir cap
- Coolant expansion reservoir cap
- WARNING Risk of injury from using the windshield wipers when the hood is open

If the windshield wipers start moving when the hood is open, you could be trapped by the wiper linkage.

Always switch off the windshield wipers and vehicle before opening the hood.



- Park the vehicle safely and on a surface that is as level as possible.
- Switch off the drive system.
- Secure the vehicle against rolling away.

WARNING Risk of injury when the hood is opened


The hood may suddenly drop into the end position.

There is a risk of injury for anyone in the hood's range of movement.

- Before releasing the hood, ensure that the support is firmly seated in the holder.
- Open the hood only when there is no-one in its range of movement.

Opening the hood

- Pull handle 1 to release the hood.
- Reach into the gap and push the hood catch handle upwards.
- Open the hood and hold it up.



- Take support from the holder on the hood and pull it downwards.
- Insert the support into bracket ② below.

Closing the hood

WARNING Risk of accident and injury when opening and closing the hood

The hood may suddenly drop into the end position

There is a risk of injury for anyone in the hood's range of movement.

Do not open or close the hood if there is a person in the hood's range of movement.

! NOTE Damage to the hood

Pushing the hood closed with your hands could damage it.

- To close the hood, let it drop from the specified height.
- Lift the hood slightly.
- Move support to the holder on the hood and apply light pressure to engage it.
- Lower the hood and let it drop from a height of approximately 0.5 ft (15 cm).
- If it is still possible to lift the hood a little, open the hood again and let it drop from a height of approximately 0.7 ft (20 cm) until it engages correctly.

Checking the coolant level

If you have to carry out any work in the engine compartment, touch only the following components:

- Hood
- · Washer fluid reservoir cap
- · Coolant expansion reservoir cap

WARNING Risk of scalding from hot coolant

You may scald yourself if you open the cap when the drive system is at normal operating temperature.

- Allow the drive system to cool down before opening the cap.
- When opening the cap, wear protective gloves and safety glasses.
- Open the cap slowly to release pressure.

Allow the drive system and the cooling system to cool down before checking the coolant level or adding coolant.


The coolant temperature must be below 122°F (50°C).

NOTE Paintwork damage due to coolant

If coolant gets on painted surfaces, the paintwork can be damaged.

- Add coolant carefully.
- Remove spilled coolant.

Checking the coolant level



Coolant expansion reservoir (example)

- Park the vehicle on a level surface.
- Open the hood (\rightarrow page 155).
- Slowly turn coolant expansion reservoir cap 1 half a turn counter-clockwise to release overpressure.
- Turn coolant expansion reservoir cap 1 further and remove it.
- Check the coolant level. There is enough coolant in the coolant expansion reservoir if the coolant reaches upper MAX mark 2.

Adding coolant

Refill the coolant to upper MAX mark 2 on the coolant expansion reservoir.

Use only coolant approved by Mercedes-Benz to avoid damaging the engine cooling system.

- Replace coolant expansion reservoir cap (1) and tighten it in a clockwise direction.
- Start the vehicle.
- After about five minutes, switch off the vehicle again and allow it to cool down.
- Check the coolant level again and add coolant if necessary.
- (i) Observe additional coolant information $(\rightarrow page 228).$

Filling the windshield washer system

WARNING Risk of fire and injury from windshield washer concentrate


Windshield washer concentrate is highly flammable.

- Avoid fire, open flames, smoking and the creation of sparks when using windshield washer concentrate.
- **NOTE** Damage to the exterior lighting due to unsuitable windshield washer fluid

Unsuitable windshield washer fluid may damage the plastic surface of the exterior lighting.

Only use windshield washer fluids that are also suitable for use on plastic surfaces, e.g. MB SummerFit or MB WinterFit.

Adding washer fluid



Washer fluid reservoir (example)

- Pre-mix the washer fluid in the correct mixing ratio in a container.
- Open the hood (\rightarrow page 155).
- Pull cap 1 of the washer fluid reservoir upwards by the tab.
- Pour in the pre-mixed washer fluid.
- Push cap 1 onto the filler opening until it audibly engages.
- Close the hood (\rightarrow page 155).
- (i) Observe the further information about windshield washer fluid (\rightarrow page 229)

Cleaning and care

Notes on washing the vehicle in an automatic car wash

WARNING Risk of accident due to reduced braking effect after washing the vehicle

The braking effect is reduced after washing the vehicle.

After the vehicle has been washed, brake carefully while paying attention to the traffic conditions until the braking effect has been fully restored.

I NOTE Risk of damage to the paintwork and plastic components

If you wash your vehicle in Touchless Automatic Car Wash systems that use special cleaning agents, the cleaning agents used can damage the paintwork or plastic components of the vehicle.

Do not wash the vehicle in Touchless Automatic Car Wash systems that use special cleaning agents.

Make sure that the automatic car wash is suitable for the size of the vehicle.

Before washing the vehicle in an automatic car wash, fold in the outside mirrors and remove any additional antennas. Otherwise, the outside mirrors, antennas or the vehicle itself could be damaged.

Make sure any additional antennas are re-installed and that the outside mirrors are fully folded out again when you leave the automatic car wash.

To avoid damage to your vehicle, observe the following before using an automatic car wash:

- the side windows and the sliding window are completely closed.
- · the blower for ventilation and heating is switched off.
- the windshield wiper switch is in position [0].

If the vehicle is very dirty, wash off excess dirt before cleaning the vehicle in an automatic car wash.

(i) Removing the wax from the windshield and the wiper rubbers after washing the vehicle, will help avoid smearing and reduce wiper noise.

Notes on using a power washer



WARNING Risk of an accident when using power washers with round-spray nozzles

The water jet can cause externally invisible damage.

Components damaged in this way may unexpectedly fail.

- Do not use a power washer with roundspray nozzles.
- Have damaged tires or chassis parts replaced immediately.

Never use a power washer in the vehicle interior. The amount of water accumulated by the pressure the power washer generates and the associated spray could cause considerable damage to the

To avoid damage to your vehicle, observe the following when using a power washer:

- Maintain a distance of at least 11.8 in (30 cm) to the vehicle when using 25° flat-spray nozzles and concentrated-power jets and observe the information in the equipment manufacturer's operator's manual.
- Do not direct the nozzle of the power washer directly at sensitive parts such as tires, gaps, electrical components, batteries, lights and ventilation louvers.
- Maintain a minimum distance of 19.7 in (50 cm) from a reversing camera.

Washing the vehicle by hand

Observe the legal requirements. For example, in a number of countries, washing by hand is permitted only in specially designated wash bays. In this case, make sure that a specially designated wash bay is used for washing by hand.

- Use a mild cleaning product, e.g. car shampoo.
- Wash the vehicle with lukewarm water and a soft car sponge. When doing so, do not expose the vehicle to direct sunlight.
- Carefully spray the vehicle with water and dry off with a chamois. Be careful not to point the water jet directly towards the air inlet grilles. Do not run the blower.
- Do not let the cleaning product dry on the paintwork.

At the onset of winter, remove all traces of road salt deposits carefully and as soon as possible.

Notes on paintwork care

NOTE Paintwork damage and corrosion due to inadequate care

Failure to promptly and thoroughly remove dirt from bird droppings or other residue could result in paintwork damage and corrosion at a

Clean dirt off paint and matte finish thoroughly and as soon as possible.

Observe the notes on cleaning and care to avoid paintwork damage.

Paint

- · Insect remnants: soak with insect remover and then wipe the treated areas clean.
- · Bird droppings: soak with water and then wipe the treated areas clean.
- Tree resin, oils and greases: remove by rubbing gently with a cloth soaked in surgical spirit or lighter fluid.
- · Coolant and brake fluid: remove with a damp cloth and clean water.
- · Tar stains: use tar remover.
- Wax: use silicone remover.
- · Do not attach stickers, films or similar materials.
- · Remove any staining as soon as possible.

Matte finish

- · Use only care products approved for Mercedes-Benz.
- Do not polish the vehicle and light-alloy
- · Use only car washes that comply with the latest engineering standards. If in doubt, always consult the car wash operator, in particular regarding whether the car wash is suitable for cleaning and care of matte paint finishes.
- Do not use a car wash program with a final hot wax treatment.
- Do not use paint cleaners, buffing or polishing products, gloss preservers, e.g. wax.
- Always have paintwork repairs carried out at a qualified specialist workshop.

Notes on the care for vehicle parts



WARNING Risk of entrapment if the windshield wipers are switched on while the windshield is being cleaned

If the windshield wipers are set in motion while you are cleaning the windshield or wiper blades, you can be trapped by the wiper arm.

Always switch off the windshield wipers and the vehicle before cleaning the windshield or wiper blades.

Observe the following notes:

	Notes on cleaning and care	Preventing damage to the vehicle
Wheels/rims	Use water and acid-free wheel cleaner.	Do not use acidic alloy wheel cleaners to remove brake dust. Otherwise, wheel bolts and brake components could become damaged.
		To avoid corrosion of brake discs and pads, drive for a few minutes after cleaning before parking the vehicle. The brake discs and pads will warm up and dry out.
Windows	Clean windows inside and outside with a damp cloth and with a cleaning agent recommended for Mercedes-Benz.	Do not use dry cloths or abrasive or solvent-based cleaning agents to clean the insides of windows.

	Notes on cleaning and care	Preventing damage to the vehicle
Wiper blades	With the wiper blades folded out, carefully clean them with a damp cloth.	Do not clean the wiper blades too often.
Exterior light- ing	Clean the lenses with a wet sponge and mild cleaning agent (e.g. car shampoo).	Use only cleaning agents or cloths suitable for plastic lenses.
Sensors	Clean the sensors in the front and rear bumpers and in the radiator grill with a soft cloth and car shampoo.	When using a power washer, keep a minimum distance of 11.8 in (30 cm).
Rear view camera	Use clean water and a soft cloth to clean the camera lens.	Do not use a power washer.
Trailer hitch	 Remove traces of rust on the ball (e.g. with a wire brush). Remove dirt with a lint-free cloth. After cleaning, lightly oil or grease the ball head. Observe the notes on care in the trailer hitch manufacturer's Operator's Manual. 	Do not clean the ball neck with a power washer or solvent.
Sliding door	 Remove foreign objects from the vicinity of the contact plates and contact pins of the sliding door. Clean the contact plates and contact pins with a mild cleaning agent and a soft cloth. 	Do not oil or grease the contact plates or the contact pins.
aluminum side boards	Brush down the aluminum side boards with water and a neutral or mild alka- line cleaning agent.	Do not use abrasive cleaning agents to clean the side boards.

Notes on the cleaning and care of the interior

WARNING Risk of injury from plastic parts breaking off after the use of solvent-based care products

Care and cleaning products containing solvents can cause surfaces in the cockpit to become porous. When the airbags are deployed, plastic parts may break away.

Do not use any care or cleaning products containing solvents to clean the cockpit.

WARNING Risk of injury or fatal injuries from bleached seat belts

Bleaching or dyeing seat belts can severely weaken them.

This can, for example, cause seat belts to tear or fail in an accident.

Never bleach or dye seat belts.

! NOTE Damage to property due to incorrect leather care

The steering wheel, seat covers and other parts of the vehicle interior can be made of leather.

Leather becomes brittle and can crack if it is incorrectly cared for or cleaned.

- ▶ If it gets dirty, thoroughly wipe it with a damp cloth (water or mild soapy water) or use leather care agents or cleaners that have been recommended and approved by Mercedes-Benz. Then wipe it over again with a dry cloth.
- Do not use a microfiber cloth for cleaning.

- Do not soak the leather.
- Do not use cleaning agents containing solvents such as tar remover or wheel cleaner, polishes or waxes.

NOTE Property damage due to disinfec-

The interior includes a number of sensitive surfaces such as displays, plastics and leather.

Disinfectants can contain alcohol and other substances that penetrate and damage surfaces. Technology behind buttons and displays can also be damaged.

Do not use disinfectant on interior surfaces.

To prevent damage to the vehicle, observe the following notes for cleaning and care:

Seat belts

- Clean with lukewarm soapy water.
- · Do not use chemical cleaning agents.
- · Do not dry seat belts by heating them to over 176°F (80°C) or exposing them to direct sunlight.

Instrument cluster

- · Clean the surfaces carefully with a microfiber cloth and acrylic glass care product.
- · Do not use any other agents.

Display

- · Switch off the display and let it cool down.
- Clean the surface carefully with a microfiber cloth and a suitable display cleaning product (TFT LCD).
- · Do not use any other agents.

Digital inside rearview mirror

- · Clean the mirror glass with a cloth moistened with glass cleaner.
- · Clean the light sensors of the inside rearview mirror with a dry cotton cloth.
- · Do not spray the glass cleaner on the mirror
- · Do not use any other agents.

Plastic trim

- · Clean with a damp microfiber cloth.
- · If very dirty: use a cleaning agent recommended for Mercedes-Benz.

- · Do not attach stickers, films or similar materials.
- Do not allow to come into contact with cosmetics, insect repellent or sun creams.

Headliner

· Clean with a brush or dry shampoo.

Imitation leather seat covers

- Vacuum up dirt such as crumbs or dust and then use a damp cotton cloth and a 1% soap solution to clean the entire seat cover.
- · Use cleaning and care products recommended for Mercedes-Benz.
- Do not use a microfiber cloth.
- Do not use any oil-based cleaning and care products.
- · Do not spot-clean.

Cloth seat covers

- · Vacuum up dirt such as crumbs or dust and then use a damp microfiber cloth and a 1% soap solution to clean the entire seat cover.
- Use cleaning and care products recommended for Mercedes-Benz.
- Do not use any oil-based cleaning and care products.
- Do not spot-clean.

Steering wheel and gear or selector lever

· Clean with a damp cloth.

Pedals and floor mats

- · Clean with a damp cloth.
- · Do not use any cleaning and care products.

Real wood and trim elements

- · Clean with a microfiber cloth.
- Black piano-lacquer look: clean with a damp cloth and soapy water.
- · If very dirty: use a cleaning agent recommended for Mercedes-Benz.
- Do not use any cleaning agents, polishes or waxes containing solvents.

Vehicle interior

- · Clean with a damp cloth.
- Do not use a power washer.
- Allow the vehicle interior to dry completely after cleaning.
- · Do not allow liquids to penetrate into gaps or cavities.

162 Maintenance and care


Curtains

- The curtains may be dry-cleaned only.
- Do not wash the curtains.

Emergency

Removing the safety vest

- Remove the safety vest from the storage compartment in the driver's door.
- (i) Safety vests can also be stored in the storage compartments of the rear doors and the codriver door.



- Maximum number of washes
- Maximum wash temperature
- On not bleach
- Do not iron
- Do not tumble dry
- O not dry-clean
- This is a class 2 vest

The safety vest only fulfills the legally required standards if it is the correct size and is completely closed.

Replace the safety vest if:

- Damaged or if the reflex strips are dirty
- The maximum permitted number of washes is exceeded
- · The safety vest's fluorescence has faded

Removing the first-aid kit (soft sided)

The first-aid kit (soft sided) is located in the stowage compartment in the front passenger door.

Remove the first-aid kit (soft sided) from the stowage compartment.

Removing the warning lamp

The warning lamp is located in the stowage compartment in the front-passenger door.

Remove the warning lamp from the stowage compartment.

Emergency Call System

Information on the emergency call system

USA only: Your vehicle is equipped with the Emergency Call System ("eCall"). This feature can help save lives in the event of an accident, eCall in no way replaces assistance provided from dialing 911.

eCall only functions in areas where mobile phone coverage is available from the mobile phone network provider. Insufficient network coverage from the wireless service providers may result in an emergency call not being transmitted.

eCall is a standard feature in your Mercedes-Benz vehicle. In order to function as intended, the system relies on the transmission of data detailed in the "Emergency call system data transfer" section that follows (→ page 164). To disable eCall, a customer must visit an authorized Mercedes-Benz Service department to deactivate the vehicle's communication module.

Deactivation of this module prevents the activation of any and all Mercedes me connect services. After the deactivation of eCall, automatic emergency call and manual emergency call will not be available.

The vehicle must be switched on before an automatic emergency call can be made.

- (i) eCall is activated at the factory.
- (i) eCall can be deactivated by an authorized Mercedes-Benz dealer. Please note that in the event ownership of the vehicle is transferred to another owner in its deactivated state, eCall will remain deactivated unless the new owner visits an authorized Mercedes-Benz dealership to reactivate the system.

Overview of the emergency call system

eCall can help to reduce the time between an accident and the arrival of emergency services at the site of the accident. It helps locate an accident site in places that are difficult to access. However, even if a vehicle is equipped with eCall, this does not mean the system is ON. As such, eCall does not replace dialing 911 in the event of an accident.

An emergency call can be made automatically (\rightarrow) page 164) or manually (\rightarrow) page 164). Only make emergency calls if you or others are in need of rescue. Do not make an emergency call in the event of a breakdown or a similar situation.

If there is a malfunction of the emergency call system, the speakers, microphone, air bag or the SOS button, for example, are faulty.

You can recognize a malfunction in the emergency call system by the following displays:

- The red SOS NOT READY message appears in the display of the instrument cluster or in the media display.
- The SOS button lights up red continuously.

Triggering an automatic emergency call

Requirements:

- . The vehicle is switched on.
- The 12 V on-board electrical system battery is sufficiently charged.

If restraint systems such as air bags or Emergency Tensioning Devices have been activated after an accident, eCall may automatically initiate an emergency call.

When the emergency call is made:

- A voice connection is made to the Mercedes-Benz emergency call center.
- A message with accident data is transmitted to the Mercedes-Benz emergency call center.

The Mercedes-Benz emergency call center can transmit the vehicle position data to one of the emergency call centers.

The SOS button in the overhead control panel flashes until the emergency call is finished.

It is not possible to immediately end an automatic emergency call.

If no connection can be made to the emergency services either, a corresponding message appears in the media display.

Dial the local emergency number on your mobile phone.

If an emergency call has been initiated:

- Remain in the vehicle if the road and traffic conditions permit you to do so until a voice connection is established with the emergency call center operator.
- Based on the call, the operator decides whether it is necessary to call rescue teams and/or the police to the accident site.
- If no vehicle occupant answers, an ambulance is sent to the vehicle immediately.

Triggering a manual emergency call

Via the SOS button in the overhead control panel: press the SOS button for at least one second.

When the emergency call is made:

- A voice connection is made to the Mercedes-Benz emergency call center.
- A message with accident data is transmitted to the Mercedes-Benz emergency call center.
 - The Mercedes-Benz emergency call center can transmit the vehicle position data to one of the emergency call centers.
- Remain in the vehicle if the road and traffic conditions permit you to do so until a voice connection is established with the emergency call center operator.
- Based on the call, the operator decides whether it is necessary to call rescue teams and/or the police to the accident site.

If no connection can be made to the public emergency services, a corresponding message appears in the display.

 Dial the local emergency number on your mobile phone.

Transmitted data with the emergency call

Data transmitted by the eCall includes but is not limited to:

- Vehicle's GPS position data
- GPS position data on the route (a few () hundred meters before the incident)
- · Direction of travel
- Vehicle identification number
- Vehicle drive type
- Estimated number of people in the vehicle
- Whether the emergency call was initiated manually or automatically
- Time of the accident

Data transmitted is vehicle information. For any questions about the collection, use and sharing of the eCall system data, please contact MBUSA's Customer Assistance Center at 800-FOR-MERC.

For Canada, please contact MBC's Customer Assistance Center at 1-800-387-0100.

Customer requests for covered information should be submitted via the same channels.

For accident clarification purposes, the following measures can be taken up to an hour after the emergency call has been initiated:

- · The current vehicle position can be determined
- A voice connection to the vehicle occupants can be established

Flat tire

Notes on flat tires

WARNING Risk of accident due to a flat

A flat tire strongly impairs the vehicle's driving characteristics, as well as its steering and braking characteristics.

- Do not drive with a flat tire.
- Replace the flat tire with the spare wheel. Alternatively, consult a qualified specialist workshop.

In the event of a flat tire, the following options are available depending on your vehicle's equipment:

- · You can make a breakdown assistance call using the me button for a service and information call in the overhead control panel $(\rightarrow page 137)$.
- Change the wheel (→ page 190).

Batterv

Notes on the 12 V on-board electrical system bat-

WARNING Risk of an accident due to work carried out incorrectly on the battery

Work carried out incorrectly on the battery can, for example, lead to a short circuit. This can restrict functions relevant for safety systems and impair the operating safety of your vehicle.

You could lose control of the vehicle in the following situations in particular:

- When braking
- In the event of abrupt steering maneuvers and/or when the vehicle's speed is not adapted to the road conditions

- In the event of a short circuit or a similar incident, contact a qualified specialist workshop immediately.
- Do not drive on.
- Always have work on the battery carried out at a qualified specialist workshop.
- (i) Further information on ABS (→ page 114) Further information on $ESP^{\mathbb{R}}(\longrightarrow page 115)$

For safety reasons, Mercedes-Benz recommends that you use only batteries that have been tested and approved for your vehicle by Mercedes-Benz. These batteries provide increased impact protection to prevent vehicle occupants from suffering acid burns should the battery be damaged in an accident.

WARNING Risk of explosion due to electrostatic charge

Electrostatic charge can ignite the highly explosive gas mixture in the battery.

To discharge any electrostatic charge that may have built up, touch the metal vehicle body before handling the battery.

The highly flammable gas mixture is created while the battery is charging and when jump-starting.

WARNING Danger of chemical burns from the battery acid

Battery acid is caustic.

- Avoid contact with the skin, eyes or clothing.
- Do not lean over the battery.
- Do not inhale battery gases.
- Keep children away from the battery.
- Immediately rinse battery acid off thoroughly with plenty of clean water and seek medical attention immediately.



ENVIRONMENTAL NOTE Environmental damage due to improper disposal of batteries

Batteries contain pollutants. It is illegal to dispose of them with the household rubbish. Dispose of batteries in an environmentally responsible manner. Take discharged batteries to a qualified specialist workshop or to a collection point for used batteries.

Observe the safety notes and protective measures when handling batteries.



Risk of explosion



Fire, naked flames and smoking are prohibited when handling the battery. Avoid creating sparks.



Electrolyte or battery acid is corrosive. Avoid contact with the skin, eyes and clothing. Wear suitable protective clothing, in particular gloves, an apron and a safety mask. Immediately rinse electrolyte acid splashes off with clean water. If necessary, seek medical advice.



Wear eye protection.



Keep children at a safe distance.



Observe this Operator's Manual.

Consult a qualified specialist workshop if you wish to leave your vehicle parked up for long periods.

Notes on the high-voltage battery



DANGER Risk of fire and explosion from excessive internal pressure of the high-voltage battery

In the event of a vehicle fire, flammable gas can escape and ignite.

- If there is an unusual smell, smoke or burn marks, stop the charging process immediately.
- Leave the danger zone immediately. Secure the danger area at a sufficient distance.
- Call the fire service.

In order for the high-voltage battery to achieve the maximum possible service life, it should always be sufficiently charged. Have the battery's charge level checked if you park the vehicle for a long period of time. Exhaustive discharging caused by the vehicle standing idle for lengthy periods can damage the high-voltage battery. If the vehicle is idle for lengthy periods, run it for a few minutes once every four weeks to charge up the high-voltage battery.



Risk of explosion



Fire, naked flames and smoking are prohibited when handling the battery. Avoid creating sparks.



Electrolyte or battery acid is corrosive. Avoid contact with the skin, eyes and clothing. Wear suitable protective clothing, in particular gloves, an apron and a safety mask. Immediately rinse electrolyte acid splashes off with clean water. Consult a doctor if necessary.



Wear eye protection.



Keep children at a safe distance.



Observe this Operator's Manual.

Further information on charging the high-voltage battery (\rightarrow page 102).

Starting assistance and charging the 12 V onboard electrical system battery

- Have starting assistance provided only by a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.
- Have the 12 V on-board electrical system battery charged only at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Cen-

Replacing the 12 V on-board electrical system bat-

Only have the 12 V on-board electrical system battery replaced at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.

12-V-auxiliary battery under the front passenger seat or in the engine compartment

Only have work on the 12 V auxiliary battery carried out at a qualified specialist workshop, e.g. in a authorized Mercedes-Benz Center.

Towing or tow-starting

Permitted towing methods

In the event of a breakdown, Mercedes-Benz recommends that you have the vehicle transported instead of towed.

Use a tow rope or a tow bar when towing with both axles on the ground; other towing methods are not permissible.

If you notice that the vehicle has lost coolant, towing it away is not permitted. Have the vehicle transported.

WARNING Risk of accident due to limited safety-related functions during the towing process

Safety-related functions are limited or no longer available in the following situations:

- · The vehicle is switched off.
- The brake system or power steering system is malfunctioning.
- · The energy supply or the on-board electrical system is malfunctioning.

When your vehicle is towed away, significantly more effort may be required to steer and brake than is normally required.

- Use a tow bar.
- Make sure that the steering wheel can move freely before towing the vehicle away.
- NOTE Damage to the vehicle due to towing away incorrectly
- Observe the instructions and notes on towing away.
- NOTE Damage due to automatic braking

When Active Brake Assist or the HOLD function is activated, the vehicle brakes automatically in certain situations.

To avoid damage to the vehicle, deactivate these systems in the following or similar situa-

- When towing
- In a car wash
- **NOTE** Damage to drive system due to incorrect maneuvering

If the vehicle is moved rearwards when the drive system has failed, e. g. when pushing or maneuvering, the drive system can be damaged.

Move the vehicle rearwards only briefly and slowly.

Permitted towing methods



Both axles on the ground

Yes, a maximum of 30 miles (50 km) at 30 mph (50 km/h)

- If the transmission cannot be shifted into position N, transport the vehicle (→ page 169).
 A towing vehicle with lifting equipment is required for vehicle transport.
- If there is damage to the engine cooling system, the vehicle may only be moved with the drive axle raised.

Towing the vehicle with both axles on the ground

NOTE Damage due to towing away at excessively high speeds or over long distances

The drivetrain could be damaged when towing at excessively high speeds or over long distances.

- A towing speed of 30 mph (50 km/h) must not be exceeded.
- A towing distance of 30 miles (50 km) must not be exceeded.
- Observe the notes on permissible towing methods (→ page 167).
- Make sure that the battery is connected and charged.

If the 12 V on-board electrical system battery is discharged, please note the following points:

- · The drive system cannot be started.
- It is not possible to release or apply the electric parking brake.
- It is not possible to shift the transmission to position N or P.
- (i) Towing is not permitted in the following cases:
 - · If the drive system is not switched on.
 - If there is no driver in the vehicle being transported.
 - If the transmission cannot be shifted to position N.



Rear axle raised

Yes, if the steering wheel is fixed in the center position with a steering wheel lock

- If the display on the instrument cluster is not working.
- If the Towing Not Permitted See
 Operator's Manual display message is
 shown or another display message that
 indicates a problem.

Transporting the vehicle (\rightarrow page 169). A towing vehicle with lifting equipment is required to transport the vehicle.

WARNING Risk of accident when towing a vehicle which is too heavy

If the vehicle to be tow-started or towed away is heavier than the permissible gross mass of your vehicle, the following situations can occur:

- The towing eye may become detached.
- The vehicle/trailer combination may swerve or rollover.
- Before tow-starting or towing away, check if the vehicle to be tow-started or towed away exceeds the permissible gross mass.
- Information on the gross vehicle weight rating can be found on the vehicle identification plate (→ page 226).
- Do not open the driver's door or the front passenger door. Otherwise, the transmission will automatically shift to position P.
- Install the towing eye (\rightarrow page 169).
- Secure the towing device.
- ! NOTE Damage due to incorrect connection of the tow bar
- Only connect the tow rope or tow bar to the towing eyes.
- Deactivate automatic locking (→ page 41).

- Do not activate the HOLD function.
- Deactivate the tow-away alarm (\rightarrow page 53).
- Deactivate Active Brake Assist (→ page 118).
- Shift the transmission to position $\boxed{\mathbf{N}}$ $(\rightarrow page 101)$.
- $(\rightarrow page 112)$ Release the parking brake.
- **NOTE** Damage due to excessive tractive power

If you pull away sharply, the tractive power may be too high and the vehicles could be dam-

Pull away slowly and smoothly.

Towing the vehicle with the rear axle raised

WARNING Risk of accident when towing with the vehicle switched on

When towing with the rear axle raised and the vehicle switched on, ESP® may apply the brakes on the front axle in an uncontrolled manner.

The vehicle may skid.

- Switch the vehicle off before towing with the rear axle raised.
- **NOTE** Damage if the vehicle is switched on

If you leave the vehicle switched on while towing it with the rear axle raised, intervention by ESP® may damage the brake system.

- Switch off the vehicle.
- Observe the notes on permissible towing methods (\rightarrow page 167).
- Switch on the hazard warning light system $(\rightarrow page 70)$.
- Move the front wheels to the straight-ahead position.
- Release the parking brake (\rightarrow page 112).
- Switch off the vehicle.

Loading the vehicle for transport

- Observe the notes on permissible towing methods (\rightarrow page 167).
- Connect the tow bar to the towing eye to load the vehicle.


- Load the vehicle onto the transporter.
- Use the parking brake to secure the vehicle against rolling away.
- Only secure the vehicle by the wheels.

Towing eye storage location

The towing eye is located in the vehicle tool kit in the front passenger footwell (\rightarrow page 169).

Installing/removing the towing eye


Installing the front towing eve



- Press the top of the cover and remove the cover.
- Screw in towing eye (1) as far as it will go.

Removing the front towing eye

- Unscrew towing eye (1) counter-clockwise.
- Insert the cover with the tabs at the top and push in at the bottom until the cover engages.



Rear towing eye

- (i) Rear towing eye (2) is permanently attached to the vehicle.
- I NOTE Damage to the vehicle due to incorrect use of the towing eye or trailer hitch

When a towing eye or trailer hitch is used to recover a vehicle, the vehicle may be damaged in the process.

- Only use the towing eye or trailer hitch to tow away or tow start the vehicle.
- Do not use the towing eye or trailer hitch to tow the vehicle during recovery.

Tow-starting the vehicle

- If the drive system does not start, have the vehicle transported to the nearest qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.
- The drive system cannot be started by towstarting. Do not attempt to tow-start the vehicle.

Electrical fuses

Notes on electrical fuses

WARNING Risk of accident and injury due

to overloaded lines

If you manipulate or bridge a faulty fuse or if you replace it with a fuse with a higher amperage, the electric line could be overloaded.

This could result in a fire.

- Always replace faulty fuses with specified new fuses containing the correct amperage.
- **NOTE** Damage due to incorrect fuses

Electrical components or systems could be damaged by incorrect fuses.

Only use fuses which have been approved by Mercedes-Benz and which have the correct fuse rating.

The electrical fuses in your vehicle isolate defective circuits. If a fuse blows, all the components on the circuit and their functions will cease to operate

Blown fuses must be replaced with fuses of an equivalent specification, which you can determine by the color and fuse rating. The fuse allocation chart and further information on the electric fuses and relays can be found in the "Fuse allocation chart" supplement.

NOTE Damage or malfunctions caused by moisture

Moisture may cause damage to the electrical system or cause it to malfunction.

- When the fuse box is open, make sure that no moisture can enter the fuse box.
- When closing the fuse box, make sure that the seal of the lid is positioned correctly on the fuse box.

If the new fuse which has been inserted also blows, have the cause traced and rectified at a qualified specialist workshop.


Make sure of the following before replacing a fuse:

- The vehicle is secured such that it does not roll away.
- · All electrical consumers are switched off.
- . The vehicle is switched off.

The fuses are located in various fuse boxes:

- Fuse box in the co-driver footwell
 (→ page 171)
- Fuse box in the seat base of the driver's seat
 (→ page 171)

Opening the fuse box in the seat base of the driver's seat



- To open: press down and unclip fasteners 1 on the cover.
- Remove the cover.
- To close: press the cover firmly into the seat base until fasteners (1) clip in.

Opening and closing the fuse box in the co-driver's footwell

Opening the fuse box

Unlocking and removing the stowage compartment cover in the co-driver's footwell $(\rightarrow page 171).$



Example: vehicle tool kit insert

- Lift the insert at marked positions ①.
- Pull the insert out of clips 2.

Closing the fuse box

- Slide the insert into clips 2.
- Close the insert by pressing on marked positions 1.
- Put on the stowage compartment cover in the co-driver's footwell and lock it (\rightarrow page 171).

Vehicle tool kit

Information on the vehicle tool kit

The vehicle tool kit is located in the stowage compartment in the footwell on the front passenger side (\rightarrow page 171).


The vehicle tool kit contains:

- a towing eye
- a screwdriver with Torx®, Phillips and slotted

The vehicle tool kit may also contain the following, for example:

- an open-end wrench
- · a wheel wrench
- a release tool for the parking lock
- an insert bit
- · a socket wrench

Unlocking and removing the stowage compartment cover



- Remove the rubber mat from the co-driver's footwell.
- To unlock: turn quick-release fastener (1) counter-clockwise to position 1.
- Slightly raise and pull out the cover.

Inserting and locking the cover

- Slide in the cover and press it downwards.
- Press down quick-release fastener ① until it engages.
- To lock: turn quick-release fastener (1) clockwise to position (2).

Removing the vehicle tool kit



Example: vehicle tool kit insert


- Lift the insert at marked positions ①.
- Pull the insert out of clips 2.

Storing the vehicle tool kit

- ► Slide the insert into clips ②.
- Close the insert by pressing on marked positions ①.

Hydraulic jack

Information on the hydraulic jack



The hydraulic jack is located in side compartment above the co-driver door step.

The jack has a maximum weight of 16.5 lbs (7.5 kg) depending on the vehicle's equipment. You will find the maximum load capacity of the jack stated on the adhesive label attached to the jack. If there is a malfunction, please contact a qualified specialist workshop.


Jack maintenance:

- Clean and grease all moving parts after use.
- Extend and retract the pistons fully every six months.

Removing the pump lever rod and the jack

Requirements:

• The co-driver door is open.



- To open: press down and unclip fasteners
 on the cover.
- Remove the cover.
- Pull out the holder completely and place it on the step.



- Remove jack 2 and the pump lever rod.
- **To close:** press the cover firmly so that fasteners ① engage.

Information on noise or unusual driving characteristics

While driving, pay attention to vibrations, noises and unusual driving characteristics, e.g. pulling to one side. This may indicate damage to the wheels or tires. If you suspect that a tire is defective, reduce your speed. Stop the vehicle as soon as possible to check if wheels and tires have been damaged or are no longer functioning properly. Hidden tire damage could also be causing the unusual driving characteristics. If no signs of damage can be detected, have the tires and wheels checked at a qualified specialist workshop.

Notes on regularly inspecting wheels and tires

A

WARNING Risk of injury through damaged tires

Damaged tires can cause tire pressure loss.

 Check the tires regularly for signs of damage and replace any damaged tires immediately.

Check the wheels and tires of your vehicle for damage regularly, i.e. at least every two weeks, as well as after driving off-road or on rough roads. Damaged wheels can cause a loss of tire pressure.

Look out for the following types of damage, for example:

- · cuts in the tires
- · punctures in the tires
- · tears in the tires
- · bulges on tires
- · deformation or severe corrosion on wheels



WARNING Risk of hydroplaning due to insufficient tire tread

Insufficient tire tread will result in reduced tire grip.

Thus, you should regularly check the tread depth and the condition of the tread across the entire width of all tires.

Minimum tread depth for:

- Summer tires: 1/8 in (3 mm)
- M+S tires: 1/6 in (4 mm)
- For safety reasons, replace the tires before the legally prescribed limit for the minimum tread depth is reached.

Conduct the following checks regularly on all wheels, at least once a month or as required, e.g. before a long journey or when driving off-road:

- check the tire pressure (→ page 176)
- check the valve caps
 - Valves must be protected from moisture and dirt with valve caps specifically approved by Mercedes-Benz for your vehicle.
- visually inspect the tread depth and the tire contact surface across the whole tire width
 The minimum tread depth for summer use is ½ in (3 mm) and for winter use ½ in (4 mm).



Markings • show in which places the bar indicators (arrow) are integrated into the tire tread. They are visible as soon as the tread depth is approximately $\frac{1}{16}$ in (1.6 mm).

Information on driving with summer tires

At temperatures below 50 °F (10 °C) summer tires significantly lose elasticity and thus traction and stopping power. Change the tires on your vehicle to M+S tires . Using summer tires at very cold temperatures could cause cracks to form, thereby damaging the tires permanently. Mercedes-Benz cannot accept responsibility for this type of damage.

Always observe the maximum permissible speed specified for the mounted summer tires $(\rightarrow page 185)$.

After you mount the summer tires:

- restart the tire pressure monitoring system
 (→ page 180)
- check the tire pressure (→ page 176)

Information on M+S tires

WARNING Risk of accident caused by incorrect wheel and tire dimensions

The wheel or tire sizes and the tire type of the emergency spare wheel or spare wheel and the wheel to be replaced may differ. The emergency spare wheel or spare wheel can significantly impair driving characteristics of the vehi-

To prevent hazardous situations:

- Drive carefully.
- Never install more than one emergency spare wheel or spare wheel that differs in
- Only use an emergency spare wheel or spare wheel briefly.
- Do not deactivate ESP®.
- Have the emergency spare wheel or spare wheel of a different size replaced at the nearest qualified specialist workshop. The new wheel must have the correct dimensions.

WARNING Risk of an accident due to insufficient tire tread

M+S tires with a tread depth of less than 1/2 in (4 mm) are not suitable for use in winter and do not provide sufficient grip.

M+S tires with a tread depth of less than 1/2 in (4 mm) must be replaced immediately.

At temperatures below 50 °F (10 °C) use winter tires or all-season tires marked M+S.

Only winter tires bearing the 🛕 snowflake symbol in addition to the M+S marking provide the best possible grip in wintry road conditions.

Only these tires allow driving safety systems such as ABS and ESP® to also function optimally in winter. These tires have been developed specifically for driving in snow.

Use M+S tires of the same make and tread pattern on all wheels to maintain safe handling characteristics.

Observe the maximum permissible speed specified for the mounted M+S tires(\rightarrow page 185).

If you install M+S tires that have a lower maximum permissible speed than the maximum design speed of the vehicle, affix an appropriate information label in the driver's field of vision. You can obtain this at a qualified specialist workshop.

After you mounted the M+S tires, do the following:

- restart the tire pressure monitoring system $(\rightarrow page 180)$
- check the tire pressure (→ page 179)

Notes on snow chains

WARNING Risk of accident due to incorrectly installed snow chains

If you have installed snow chains on the front wheels, they may drag against the vehicle body or chassis components.

- Never install snow chains on the front wheels.
- Only install snow chains on the rear wheels in pairs.

WARNING Risk of accident due to unsuitable snow chains

Commercially available snow chains can come loose and damage chassis components or brake hoses.

Only install snow chains that have been approved by Mercedes-Benz for these tires.

For safety reasons, Mercedes-Benz recommends that you only use snow chains that have been tested and approved. You can obtain information about snow chains from any qualified specialist workshop.

WARNING Risk of accident due to snow chains breaking

If you drive too fast with snow chains, they can break, injure other persons, and damage the vehicle.

Observe the maximum permissible speed for operation with snow chains.

NOTE Damage to the wheel trim from mounted snow chains

If snow chains are mounted to steel wheels, the wheel trims can be damaged.

Remove the wheel trims of steel wheels before mounting snow chains.

Observe the following notes when using snow chains:

- Snow chains are only permissible for certain wheel/tire combinations. You can obtain information on this matter at a qualified specialist workshop.
- For safety reasons, only use snow chains that have been specifically approved for your vehicle by Mercedes-Benz, or snow chains with the same quality standard.
- The snow chains must be retightened after driving approximately 0.6 miles (1 km). This is the only way to ensure the snow chains are optimally installed with clearance to adjacent components.
- Use snow chains only when the road surface is completely snow-covered. Remove the snow chains as soon as possible when you come to a road that is not snow-covered.
- Local regulations may restrict the use of snow chains. Observe the applicable regulations before installing snow chains.
- If snow chains are installed, the maximum permissible speed is 30 mph (50 km/h).
- You can deactivate ESP[®] to start off
 (→ page 115). This allows the wheels to spin, achieving an increased propulsive force.

Tire pressure

Notes on tire pressure

WARNING Risk of accident due to insufficient or excessive tire pressure

Underinflated or overinflated tires pose in particular the following risks:

- · The tires can burst.
- The tires can wear excessively and/or unevenly.
- The driving characteristics as well as the steering and braking characteristics may be greatly impaired.
- Comply with the recommended tire pressures and check the tire pressure of all tires, including the spare wheel, regularly:
- Monthly
- · When the load changes

- Before embarking on a longer journey
- If operating conditions change, e.g. offroad driving
- Adjust the tire pressure, if necessary.

Driving with tire pressure that is too high or too low can:

- shorten the service life of the tires.
- contribute to tire damage
- adversely affect driving characteristics and thus driving safety, e.g. due to hydroplaning.

WARNING Risk of accident due to too low a tire pressure

Tires with pressure that is too low can overheat and burst as a consequence.

In addition, they also suffer from irregular wear, which can significantly impair the braking properties and the handling characteristics.

Avoid excessively low tire pressure.

tire pressure which is too low can lead to:

- tire defects as a result of overheating
- · impaired handling characteristics
- uneven wear
- increased fuel consumption

WARNING Risk of accident due to too high a tire pressure

Tires with excessively high pressure can burst. In addition, they also suffer from irregular wear, which can significantly impair the braking prop-

erties and the handling characteristics.

Avoid excessively high tire pressures.

tire pressure which is too high can lead to:

- · increased braking distance
- · impaired handling characteristics
- uneven wear
- impaired driving comfort
- susceptibility to damage

WARNING Risk of accident due to repeated pressure drop in the tires

The wheels, valves or tires could be damaged. Too low a tire pressure can lead to the tires bursting.

- Examine the tires for foreign objects.
- Check whether the tire has a puncture or the valve has a leak.
- If you are unable to rectify the damage, contact a qualified specialist workshop.

You can find information on recommended tire pressure for the vehicle's factory-installed tires on the following labels:

• tire and loading information and tire pressure table on the B-pillar of your vehicle $(\rightarrow page 181)$.

Observe the maximum tire pressure $(\rightarrow page 185).$

Use a suitable pressure gauge to check the tire pressure. The outward appearance of a tire does not permit any reliable conclusion about the tire pressure.

ENVIRONMENTAL NOTE Environmental damage due to insufficient or excessive tire pressure

Overinflating or underinflating your tires will shorten their service life.

Check the tire pressure regularly, but at least every 14 days.

Vehicles with a tire pressure monitoring system: you can also check the tire pressure via the instrument cluster.

Only check tire pressure when the tires are cold. Conditions for cold tires:

- The vehicle has been parked with the tires out of direct sunlight for at least three hours.
- The vehicle has travelled less than 1 mile (1.6 km).

A rise in the tire temperature of 18°F (10°C) increases the tire pressure by approx. 10 kPa (0.1 bar/1.5 psi). Take this into account when checking the tire pressure of warm tires.

The tire pressure recommended for increased load/speed in the tire pressure table may affect the ride comfort.

WARNING Risk of accident due to unsuitable accessories on tire valves

If you mount unsuitable accessories onto tire valves, the tire valves may be overloaded and

malfunction, which can cause tire pressure


Only screw standard valve caps or valve caps specifically approved by Mercedes-Benz for your vehicle onto the tire valve.

Notes on trailer operation


The applicable tire pressure for the tires of the rear axle is always the recommended tire pressure for a full load.

Overview of the tire pressure table

The tire pressure table can be found on the B-pillar on the driver's side.



- tire pressure table B-pillar
- (i) The data shown in the images is example data.



The tire pressure table shows the recommended tire pressure for the tires installed on this vehicle at the factory. The recommended tire pressures are valid for cold tires and different vehicle load conditions

If one or more tire sizes precede a tire pressure, the tire pressure information following is only valid for those tire sizes.

If the preceding tire sizes are supplemented by the symbol, the tire pressure information following shows alternative tire pressures.

The load conditions "partially laden" and "fully laden" are defined in the table by varying weights. Some tire pressure tables only show the rim diameter instead of the complete tire size, e.g. R16. The rim diameter is part of the tire size and can be found on the side wall of the tire (\rightarrow page 185).

Front axle tire pressures on vehicles with rear wheel drive and single tires Max. front axle load 4101 lbs (1860 kg)

tires/disk wheel	Load condition	Max. front axle load 4101 lbs (1860 kg)
LT245/75 R16 120/116Q	Fully laden	320 kPa (3.2 bar/46 psi)

Front axle tire pressures on vehicles with rear wheel drive and single tires Max. front axle load 4409 lbs (2000 kg)

tires/disk wheel	Load condition	Max. front axle load 4409 lbs (2000 kg)
LT245/75 R16 120/116Q	Fully laden	360 kPa (3.6 bar/52 psi) 1)

¹⁾ Only valid for vehicles with a long wheelbase 171 in (4350 mm) and a permissible gross mass of over 7716 lbs (3.5 t).

rear axle tire pressures on vehicles with rear wheel drive and single tires Max. rear axle load 5357 lbs (2430 kg)

tires/disk wheel	Load condition	Max. rear axle load 5357 lbs (2430 kg)
LT245/75 R16 120/116Q	Fully laden	480 kPa (4.8 bar/70 psi)
LT245/75 R16 120/116Q	Partially laden ²⁾	440 kPa (4.4 bar/64 psi) ²⁾

²⁾ It is only permissible to use this reduced tire pressure if it can be guaranteed by weighing the vehicle that the rear axle load of 4960 lbs (2250 kg) will not be exceeded. In case of doubt, inflate to 480 kPa (4.8 bar/70 psi).

Be sure to also observe the following further related subjects:

- Notes on tire pressure (→ page 176)
- Tire and Loading Information placard (→ page 181)
- Maximum tire pressure (→ page 185)

Tire pressure monitoring system

Function of the tire pressure monitoring system

A

DANGER Risk of accident due to incorrect tire pressure

Each tire, including the spare (if provided), should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tire inflation pressure label. (If your vehicle has tires of a different size than the size indicated on the vehicle placard or tire inflation pressure label, you should determine the proper tire inflation pressure for those tires.)

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS) that illuminates a low tire pres-

sure telltale when one or more of your tires is significantly under-inflated. Accordingly, when the low tire pressure telltale illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly under-inflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability. Please note that the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if under-inflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale.

Your vehicle has also been equipped with a TPMS malfunction indicator to indicate when the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists.

When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended. TPMS malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly.



The system checks the pressures and temperatures of the tires installed on the vehicle by means of a tire pressure sensor.

New tire pressure sensors, e.g. in winter tires, will automatically be calibrated during the first journey.

The tire pressure and the tire temperature will appear on the display of the instrument cluster $(\rightarrow page 132)$.

If there is a substantial loss of tire pressure, a warning will be issued:

- via display messages (→ page 246)
- via the (!) warning lamp on the instrument cluster (→ page 260)

It is the driver's responsibility to set the tire pressure to the recommended cold tire pressure suitable for the operating situation. Set the tire pressure for cold tires using a tire pressure gauge.

Note that the tire pressure monitoring system must first learn the correct tire pressure for the current operating situation.

In most cases, the tire pressure monitoring system will automatically update the new reference values after you have changed the tire pressure. However, you can also update the reference values by restarting the tire pressure monitoring system manually (\rightarrow page 180).

System limits

The system may be impaired or inoperative in the following situations:

- if the tire pressure has been set incorrectly
- if there is a sudden pressure loss caused, for example, by a foreign object penetrating the
- if there is a malfunction caused by another radio signal source
- · if there is a change in tire size

Bear in mind the following related topic:

Notes on tire pressure (→ page 176)

Checking the tire pressure with the tire pressure monitoring system

Requirements

· The vehicle is switched on.

On-board computer:

→ Service → Tires

One of the following displays will appear:

- . The current tire pressure and temperature for each wheel.
- · The current tire pressure for each wheel.
- Tire pressure will be displayed after driving a few minutes.: The teach-in process of the system is not vet complete. The tire pressure are already being monitored.
- Compare the tire pressure with the recommended tire pressure for the current operating status (\rightarrow page 177). Observe the notes on tire temperature (\rightarrow page 176).
- (i) The values displayed on the instrument cluster display may deviate from those of the tire pressure gauge, as they refer to sea level. At high elevations, the tire pressure value indicated by a pressure gauge will be higher than those shown by the on-board computer. In this case, do not reduce the tire pressure.

Bear in mind the following related topic:

Notes on tire pressure (→ page 176)

Restarting the tire pressure monitoring system

Requirements

- The recommended tire pressure is correctly set for the respective operating condition on each of the wheels (→ page 176).
- Restart the tire pressure monitoring system in the following situations:
 - The tire pressure has changed.
 - The wheels or tires have been changed or newly installed.

Instrument cluster:

¬→ Service → Tires

- Scroll down on the menu. A message reading Use current pressures as new reference values? will appear on the instrument cluster.
- Confirm the message to initiate a restart.

 A message reading Tire Press. Monitor Restarted will appear on the instrument cluster.

 Current warning messages will be deleted and the yellow (1) warning lamp will go out.

 Once you have been driving for a few minutes, the system will check whether the current tire pressure are within the specified range. The current tire pressures will then be accepted as reference values and monitored.

Bear in mind the following related topic:

Notes on tire pressure (→ page 176)

Radio equipment approval of the tire pressure monitoring system

Country	Radio equipment approval number
Canada	IC: 4008C-TSSRE4A Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Mexico	Model: TSSRE4A & TSSSG4G6, IFETEL: RLVHUTS17-0806
USA	FCC ID: YGOTSSRE4A This device complies with Part 15 of the FCC Rules. Operation is subject to the fol- lowing two conditions: (1) this device may not cause harmful interfer- ence, and (2) this device must accept any interference received, including interference that may cause undesired oper- ation. WARNING: Any changes or modifica- tion not expressly approved by the party responsible for compli- ance could void the user's authority to operate this equip- ment.

Loading the vehicle

Tire and Loading Information placard

WARNING Risk of an accident when driving with an overloaded tire


Overloaded tires may overheat and burst. Overloaded tires can impair the steering and handling characteristics and lead to brake fail-

- Observe the load rating of the tires.
- ► The load rating must be at least half the permissible axle load of the vehicle.
- Mercedes-Benz recommends you use the load-bearing index, which is given in the vehicle documents.
- Never overload the tires by exceeding the maximum load.

Only vehicles with a gross vehicle weight of less than 10,000 lbs (4,536 kg) have a Tire and Loading Information placard on the B-pillar on the driver's side.



Tire and Loading Information placard



(i) The data shown in the illustration are sample data.

The Tire and Loading Information placard shows:

- The maximum number of seats indicates the maximum number of occupants permitted to travel in the vehicle.
- · The maximum permissible load equals the gross weight of all vehicle occupants, the luggage and any payload.
- The recommended tire pressure for cold tires. The recommended tire pressures apply to the maximum permissible load and up to the maximum permissible vehicle speed.

Also observe the following information:

- The information about permissible weights on the vehicle identification plate (\rightarrow page 226)
- The information about tire pressures in the tire pressure table (\rightarrow page 177)

Additional related subjects:

- · Determining the maximum payload $(\rightarrow page 181)$
- Notes on tire pressure (→ page 176)

Steps to determine the correct load limit

The following steps have been developed as required of all manufacturers under Title 49, Code of U.S. Federal Regulations, Part 575 in accordance with the "National Traffic and Motor Vehicle Safety Act of 1966."

- Step 1: Locate the statement, "The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs." on the Tire and Loading Information placard of your vehicle.
- Step 2: Determine the combined weight of the driver and passengers who will be traveling in your vehicle.
- Step 3: Subtract the combined weight of the driver and passengers from XXX kg or XXX lbs.
- Step 4: The resulting figure equals the permissible payload for cargo and luggage. For example, if the "XXX" amount equals 1,400 lbs and there will be five 150 lb passengers in your vehicle, the available cargo and luggage load capacity is $650 \text{ lbs } (1,400 - 750 (5 \times 150) =$ 650 lbs).
- Step 5: Determine the combined weight of any cargo and luggage to be loaded into the vehicle. For safety reasons, this weight must not exceed the permissible payload calculated in step 4.

- Step 6: If your vehicle is towing a trailer, weight is transferred to your vehicle from the trailer. Consult these instructions in order to determine how this reduces the permissible load and luggage capacity of your vehicle.
- Note that not all vehicles are approved for trailer operation. Trailer operation is only permissible if a trailer hitch is installed and a trailer load is specified in your vehicle documents. If in doubt, ask an authorized Mercedes-Benz dealer.

Even if you have calculated the total payload carefully, you should still make sure that the maximum permissible gross weight and the maximum axle load of your vehicle are not exceeded. Information on this can be found on the vehicle identification plate.

 Weigh the laden vehicle – including driver, passengers and payload – on a suitable vehicle weighbridge.

The measured values must not exceed the maximum permitted values listed on the vehicle identification plate.

Additional related subjects:

- Sample calculation for determining the maximum payload (→ page 182)
- Tire and Loading Information placard (→ page 181)
- Tire pressure table
- Vehicle identification plate

Sample calculation for determining the maximum load

The following table has examples of how to calculate total and cargo load capacities with varying seating configurations and different numbers and sizes of occupants. The following examples use a maximum load of 1,500 lbs (680 kg). **This value is for illustrative purposes only.** Make sure you are using the actual load limit for your vehicle stated on your vehicle's Tire and Loading Information placard (→ page 181).

The higher the weight of all the occupants, the smaller the maximum load for luggage.

Step 1

	Example 1	Example 2
Combined maximum weight of occupants and load (data from the Tire and Loading Information placard)	1500 lbs (680 kg)	1500 lbs (680 kg)

Step 2


	Example 1	Example 2
Number of people in the vehicle (driver and occupants)	5	1
Distribution of the occupants	Front: 2 Rear: 3	Front: 1
Weight of occupants	Occupant 1: 150 lbs (68 kg) Occupant 2: 180 lbs (82 kg) Occupant 3: 160 lbs (73 kg) Occupant 4: 140 lbs (63 kg) Occupant 5: 120 lbs (54 kg)	Occupant 1: 200 lbs (91 kg)
Total weight of all occupants	750 lbs (340 kg)	200 lbs (91 kg)

Step 3

	Example 1	Example 2
Permissible load (maximum gross vehicle weight rating from the Tire and Loading Information placard minus the gross weight of all occupants)	1500 lbs (680 kg) - 750 lbs (340 kg) = 750 lbs (340 kg)	1500 lbs (680 kg) - 200 lbs (91 kg) = 1300 lbs (589 kg)

Tire labeling

Overview of tire labeling



- Uniform Tire Quality Grading Standards $(\rightarrow page 183)$
- 2 DOT (Department of Transportation), (TIN) Tire Identification Number (→ page 184)
- Maximum tire load (→ page 184)
- Maximum tire pressure (→ page 185)
- Manufacturer
- 6 Characteristics of the tire (→ page 185)
- Tire size designation, load-bearing capacity and speed rating (\rightarrow page 185)
- Tire name
- (i) The data shown in the illustration is sample data.

Information on tire quality grades

According to the requirements of the U.S. Department of Transportation's "Uniform Tire Quality Grading Standards" tire manufacturers must grade their tires using the following three performance factors:



- Tread wear grade
- Traction grade
- Temperature grade
- (i) The data shown in the illustration is sample data.
- (i) This grading is not legally prescribed for Canada, but specified in most cases anyway.

Tread wear grade

The tread wear grade is a comparative grading based on tread wear grade tests conducted under controlled conditions on a specified U.S. Department of Transportation test track. For example, a tire graded 150 would wear one and one-half times as well on the government test track as a tire graded 100.

The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate conditions.

Traction grade



DANGER Risk of accident due to inadequate traction

The traction grade assigned to this tire is based on straight-ahead braking traction tests.

Always adapt your driving style and drive at a speed to suit the prevailing traffic and weather conditions.

- **NOTE** Damage to the drivetrain from wheelspin
- Avoid wheelspin.

The traction grades - from highest to lowest - are AA, A, B and C. These grades relate to the tire's ability to come to a standstill on a wet pavement under controlled conditions on a specified U.S. government test surface made from asphalt and concrete.

Temperature grade

WARNING Risk of accident from tire overheating and tire failure

Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause excessive heat build-up and possible tire failure.

- Observe the recommended tire pressure.
- Regularly check the pressure of all the tires.
- Adjust the tire pressure, if necessary.

The temperature grades are A (highest grade), B and C. These relate to a tire's resistance to heat and its ability to release heat on a specified test wheel in laboratory tests under controlled conditions. Sustained high temperatures can cause the material of the tire to degenerate and reduce tire life. In addition, excessively high temperatures can lead to sudden tire failure. Grade C refers to a performance which all passenger vehicle tires must exhibit, according to the U.S. Department of Transportation's requirements.

Information on DOT and TIN (Tire Identification Number)

U.S. tire regulations indicate that every tire manufacturer or retreader must imprint a TIN in or on the sidewall of each tire produced.




(i) The data shown in the illustration is sample data.

The TIN is a unique identification number for tires and consists of the following components:

- DOT (Department of Transportation): tire symbol 1 indicates that the tire complies with the requirements of the U.S. Department of Transportation.
- Manufacturer identification code: manufacturer identification code 2 provides information about the tire manufacturer. New tires have a code with two symbols. Retreaded tires have a code with four symbols. For further information about retreaded tires, see $(\rightarrow page 188).$
- **Tire size:** identifier (3) describes the tire size.
- **Tire type code:** tire type code **(4)** can be used by the manufacturer as a code to describe specific characteristics of the tire.
- Date of manufacture: date of manufacture (5) provides information about the age of a tire. The 1st and 2nd numbers indicate the calendar. week and the 3rd and 4th numbers indicate the year of manufacture (e.g. "3208" refers to the 32nd week of the year 2008).

Information on maximum tire load



(i) The data shown in the illustration is sample

Maximum tire load 1 is the maximum permissible weight for which the tire is approved.

Do not overload the tires by exceeding the maximum permissible load. The maximum permissible load can be found on the vehicle's Tire and Loading Information placard on the B-pillar on the driver's side (\rightarrow page 181).

Information on maximum tire pressure



(i) The data shown in the illustration is sample

Maximum permitted tire pressure 1 for which the tire is approved must not be exceeded.

Information on tire characteristics



(i) The data shown in the illustration is sample


This information describes the type of tire cord and the number of layers in sidewall 1 and under tire tread 2.

Tire size designation, load-bearing capacity and speed rating

WARNING Risk of injury through exceeding the specified tire load-bearing capacity or the permissible speed rating

Exceeding the specified tire load rating or the permissible speed rating may lead to tire damage and to the tires bursting.

- Therefore, only use tire types and sizes approved for your vehicle model.
- Observe the tire load rating and speed rating required for your vehicle.



- First letter(s)
- Nominal tire width in millimeters
- Aspect ratio in %
- Tire code
- Rim diameter
- 6 Load-bearing index, Single tires
- Load-bearing index, twin tires
- Speed rating
- (i) The data shown in the illustration is sample

Further information about reading tire data can be obtained from any qualified specialist workshop.

First letter(s) :

- "LT": light truck tires according to US manufacturing standards
- "C": tires for commercial usage in accordance with European manufacturer standards

Aspect ratio (in percent) 3:

The size ratio between the tire height and tire width and is shown in percent (tire height divided by tire width).

Tire code (1) (tire type):

• "R": radial tire

Rim diameter 63:

The diameter of the bead seat (not the diameter of the rim flange). The rim diameter is specified in inches (in).

Load-bearing index 6 and 7:

Numerical code which specifies the maximum load-bearing capacity of a tire ("91" equals, e.g. 1,356 lb (615 kg)).

The tire load-bearing capacity must be at least half the permissible axle load of the vehicle. Do not overload the tires by exceeding the maximum permissible load of the tires.

See also:

- Maximum permissible load on the Tire and Loading Information placard (→ page 181)
- Maximum tire load (→ page 184)

Speed rating (8):

Specifies the approved maximum design speed of the tire.

An electronic speed limiter prevents your vehicle from exceeding a speed of 130 mph (210 km/h).

Ensure that your tires have the required speed rating. You can obtain information on the required speed rating at an authorized Mercedes-Benz Center.

Summer tires

Index	Speed rating
L	Up to 75 mph (120 km/h)
М	Up to 81 mph (130 km/h)
N	Up to 87 mph (140 km/h)
Р	Up to 93 mph (150 km/h)
Q	Up to 100 mph (160 km/h)
R	Up to 106 mph (170 km/h)

Summer, all-season and winter tires

Index	Speed rating
L M+S ¹	Up to 75 mph (120 km/h)
M M+S ¹	Up to 81 mph (130 km/h)
N M+S ¹	Up to 87 mph (140 km/h)
P M+S ¹	Up to 93 mph (150 km/h)

Index	Speed rating
Q M+S ¹	Up to 100 mph (160 km/h)
R M+S ¹	Up to 118 mph (170 km/h)

¹: Or "M+S 🔌 " for winter tires.

Winter tires are marked with the A snowflake symbol and fulfill the requirements of the Rubber Manufacturers Association (RMA) and the Rubber Association of Canada (RAC) regarding the tire traction on snow.

Information on definitions (tires and loading)

Tire structure and characteristics: describes the number of layers or the number of rubber-coated layers in the tire tread and the tire wall. These are made of steel, nylon, polyester and other materials.

Bar: metric unit for tire pressure. 14.5038 pounds per square inch (psi) and 100 kilopascals (kPa) are the equivalent of 1 bar.

DOT (Department of Transportation): DOT marked tires fulfill the requirements of the U.S. Department of Transportation.

Average weight of vehicle occupants: the number of occupants for which the vehicle is designed multiplied by 150 lbs (68 kg).

Uniform Tire Quality Grading Standards: a uniform standard to grade the quality of tires with regards to tread quality, tire traction and temperature characteristics. The quality grading assessment is made by the manufacturer in accordance with test specifications of the U.S. government. The quality grade of a tire is imprinted on the sidewall of the tire.

Recommended tire pressure: the recommended tire pressure is the pressure specified for the tires installed on the vehicle at the factory.

The Tire and Loading Information placard contains the recommended tire pressures for cold tires, the maximum permissible load and the maximum permissible vehicle speed.

The tire pressure table contains the recommended tire pressures for cold tires under various operating conditions, i.e. load and/or speed of the vehicle.

Increased vehicle weight due to optional equipment: the combined weight of all standard and

optional equipment available for the vehicle, regardless of whether it is actually installed on the vehicle or not.

Rim: the part of the wheel on which the tire is installed.

GAWR (Gross Axle Weight Rating): GAWR is the gross axle weight rating. The actual load on an axle must never exceed the Gross Axle Weight Rating. You can find the Gross Axle Weight Rating on the B-pillar on the driver's side.

Speed rating: the speed rating is part of the tire identification. It specifies the speed range for which a tire is approved.

GVW (Gross Vehicle Weight): the Gross Vehicle Weight includes the weight of the vehicle including fuel, tools, the spare wheel, accessories installed, occupants, luggage and the trailer drawbar noseweight if applicable. The Gross Vehicle Weight must never exceed the Gross Vehicle Weight Rating (GVWR) specified on the B-pillar on the driver's side.

GVWR (Gross Vehicle Weight Rating): the GVWR is the maximum permitted gross weight of the fully laden vehicle (weight of the vehicle including all accessories, occupants, fuel, luggage and the trailer drawbar noseweight if applicable). The Gross Vehicle Weight Rating is specified on the vehicle identification plate on the B-pillar on the driver's side.

Maximum weight of the laden vehicle: the maximum weight is the sum of the vehicle's curb weight, weight of the accessories, maximum load and the weight of the factory-installed optional equipment.

Kilopascal (kPa): metric unit for tire pressure. 6.9 kPa are the equivalent of 1 psi. Another unit for tire pressure is bar. 100 kilopascals (kPa) are the equivalent of 1 bar.

Curb weight: the weight of a vehicle with standard equipment including the maximum capacity of fuel. oil and coolant. It also includes the air-conditioning system and optional equipment if these are installed on the vehicle, but does not include passengers or luggage.

Maximum tire load: the maximum tire load is the maximum permissible weight in kilograms or lbs for which a tire is approved.

Maximum permissible tire pressure: maximum permissible tire pressure for one tire.

Maximum load on one tire: maximum load on one tire. This is calculated by dividing the maximum axle load for one axle by two.

PSI (pounds per square inch): standard unit of measurement for tire pressure.

Aspect ratio: relationship between tire height and tire width in percent.

Tire pressure: pressure inside the tire applying outward force to every square inch of the tire's surface. The tire pressure is specified in pounds per square inch (psi), in kilopascals (kPa) or in bar. The tire pressure should only be corrected when the tires are cold.

Tire pressure of cold tires: the tires are cold when the vehicle has been parked with the tires out of direct sunlight for at least three hours and the vehicle has been driven less than 1 mile (1.6 km).

Tire contact surface: the part of the tire that comes into contact with the road.

Tire bead: the purpose of the tire bead is to ensure that the tire sits securely on the wheel rim. There are several wire cores in the tire bead to prevent the tire from changing length on the wheel rim.

Side wall: the part of the tire between the tread and the tire bead.

Special equipment weight: the combined weight of those optional extras that weigh more than the replaced standard parts and more than 5 lbs (2.3 kg). Special equipment, such as high-performance brakes, level control system, a roof luggage rack or a high-performance battery, are not included in the curb weight and the weight of the accessories.

TIN (Tire Identification Number): a unique identification number which can be used by a tire manufacturer to identify tires, for example, in a product recall, and thus identify the purchasers. The TIN is made up of the manufacturer identification code, tire size, tire type code and the manufacturing date.

Load-bearing index: the load-bearing index (also load index) is a code that contains the maximum load-bearing capacity of a tire.

Traction: traction is the result of friction between the tires and the road surface.

Wear indicator: narrow bars (tread wear bars) that are distributed over the tire tread. If the tire tread is level with the bars, the wear limit of 1/16 in (1.6 mm) has been reached.

Distribution of vehicle occupants: distribution of vehicle occupants over designated seat positions in a vehicle.

Maximum permissible payload weight: nominal load and luggage load plus 150 lbs (68 kg) multiplied by the number of seats in the vehicle.

Changing a wheel

Notes on selecting, installing and replacing tires

You can obtain information regarding permissible wheel/tire combinations at a qualified specialist workshop.

A

WARNING Risk of accident due to incorrect wheel and tire dimensions

If wheels and tires of the wrong size are used, the service brakes or wheel suspension components may be damaged.

Always replace wheels and tires with ones that fulfill the specifications of the original part.

For wheels, pay attention to the following:

- Designation
- Type
- Permissible wheel load
- Wheel offset

For tires, pay attention to the following:

- Designation
- Manufacturer
- Type
- Load-bearing index
- Speed rating

A

WARNING Risk of injury through exceeding the specified tire load-bearing capacity or the permissible speed rating

Exceeding the specified tire load rating or the permissible speed rating may lead to tire damage and to the tires bursting.

- Therefore, only use tire types and sizes approved for your vehicle model.
- Observe the tire load rating and speed rating required for your vehicle.

NOTE Vehicle and tire damage due to tire types and sizes that have not been approved

For safety reasons, only use tires, wheels and accessory parts which have been specially approved by Mercedes-Benz for your vehicle.

These tires have been specially adapted for use with driving systems and driving safety systems. such as ABS or ESP®.

Otherwise, certain properties, such as handling characteristics, vehicle noise emissions and consumption could be adversely affected. Other wheel sizes may cause the tires to come into contact with the vehicle body and axle components when under load. This may result in damage to the tire or the vehicle.

Only use tires, wheels and accessory parts that have been checked and recommended by Mercedes-Benz.

NOTE Driving safety put at risk by retreaded tires

Retreaded tires are not checked or recommended by Mercedes-Benz, as previous damage is not always detected during the retread process

Driving safety cannot, therefore, be guaranteed.

Do not use used tires when their previous usage is unknown.

Accessories that are not approved for your vehicle by Mercedes-Benz, or are not being used correctly, can impair operating safety.

Before purchasing and using non-approved accessories, visit a qualified specialist workshop and inquire about:

- suitability
- · legal provisions
- · factory recommendations

Observe the following points when selecting, installing and replacing tires:

- Use only tyres and wheels of the same type, design (winter tyres, all-season tyres) and make.
- Only install wheels of the same size and tread pattern on one axle (left and right).

It is only permissible to deviate from this in the event of a flat tire to drive to the specialist workshop.

- · Only install tires of the correct size on the wheels.
- · Vehicles with a tire pressure monitoring system: all installed wheels must be equipped with functioning sensors for the tire pressure monitoring system.
- At temperatures below 50 °F (10 °C), use winter tires or all-season tires marked M+S on all wheels.

Winter tires bearing the A snowflake symbol in addition to the M+S marking provide the best possible grip in wintry road conditions.

- Only use tires with the same tread pattern.
- · Observe the maximum permissible speed for the mounted tires.

If this is below the vehicle's maximum permissible speed, this must be indicated on a label in the driver's field of vision.

- · Break in new tires at moderate speeds for the first 60 miles (100 km).
- Replace the tires after six years at the latest, regardless of wear.

For more information on wheels and tires, contact a qualified specialist workshop.

Vehicles with single tires:

For vehicles with single tires and a GVWR of less than or equal to 9,480 lbs, only use tires of size LT 245/75 R16 that have been approved for this vehicle by the manufacturer. It is not permissible to use tires of different dimensions; doing so may lead to the general operating permit being rendered invalid.

Also observe the following further related subjects:

- Notes on tire pressure (→ page 176)
- Tire and Loading Information placard $(\rightarrow page 181)$
- · Tire size designation, load capacity and speed rating (\rightarrow page 185)
- Tire pressure table (→ page 177)
- · Notes on the emergency spare wheel $(\rightarrow page 194)$

Notes on changing wheels



WARNING Risk of injury through different wheel sizes

Rotating the front and rear wheels can severely impair the driving characteristics.

The wheel brakes or suspension components may also be damaged.

Rotate front and rear wheels only if the wheels and tires are of the same dimensions.

On vehicles that have the same size front and rear wheels, rotate the wheels according to the intervals in the tire manufacturer's warranty book in your vehicle documents. If this is not available, rotate the tires every 3,000 (5,000) to 6,000 miles (10,000 km), depending on the degree of wear. Ensure that the direction of rotation is maintained.

It is imperative to observe the instructions and safety notes on "Changing a wheel" when doing so.

Wheel size groups

The determined vehicle speed is displayed in the instrument cluster and is important for controlling the driving safety systems and driving systems. The display accuracy of the speedometer and the odometer is legally prescribed. Determining the speed is dependent on the tire size or the rolling circumference of the tires. The rim diameter is always specified in inches.

For this reason, the vehicle control units can be coded for the following wheel size groups:

Wheel size group 3

- LT245/75 R16
- (i) Mercedes-Benz recommends that you stay within a wheel size group when changing a tire. In this way, you avoid the need to recode the control units.

If you change the wheel size of your vehicle, for instance when changing wheels for winter operation, check it is assigned to the correct wheel size group. If the wheel size group changes, you must have your vehicle's control units recoded at a qualified specialist workshop.

Otherwise, the display accuracy of the speedometer and the odometer will be outside the legally prescribed tolerance. It may also be lower, i.e. the current road speed is then higher than the speed shown on the speedometer. If a deviation is outside the range of tolerance, driving safety systems and driving systems may be operationally impaired or may detect a malfunction and switch themselves off.

Information on the direction of the tires' rotation

Tires with a specified direction of rotation have additional benefits, e.g. if there is a risk of hydroplaning. You will only gain these benefits if the correct direction of rotation is observed.

An arrow on the sidewall of the tire indicates its correct direction of rotation.

You may also install a spare wheel against the direction of rotation. Observe the time restriction on use as well as the speed limitation specified on the spare wheel.

Notes on storing wheels

Observe the following when storing wheels:

- Wheels that have been removed should be stored in a cool, dry and, if possible, dark place.
- Protect the tires from oil, grease and fuel.


Overview of tire-change tool kit

Required tire-changing tools may include, for example:

- Jack
- Wheel wrench
- (i) You will find the maximum load capacity of the jack stated on the adhesive label attached to the jack.

The jack is maintenance-free. If there is a malfunction, please contact a qualified specialist workshop.

Vehicles with rear wheel drive




The tire-change tool kit is located in stowage compartment above the step of the front passenger door and in the stowage compartment in the footwell on the front passenger side.

Preparing the vehicle for a wheel change

Requirements

- The tire-change tool kit is available.
- The vehicle is not on a slope.
- The vehicle is on solid, non-slippery and level ground.
- Apply the parking brake.
- Move the front wheels to the straight-ahead position.
- Engage P.
- Switch off the vehicle.
- Make sure that the vehicle cannot be switched on.
- Take the vehicle tool kit from the footwell on the co-driver side (→ page 171).



Vehicles with rear-wheel drive

- Take the jack and the tire-change tool kit out of the storage compartment (\rightarrow page 190).
- If necessary, remove the wheel trim.
- Assemble the lug wrench extension using the middle rod and the rod with the largest diameter from the three-piece jack pump lever.
- Starting with the middle rod, slide the lug wrench extension as far as it will go onto the lug wrench.
- Using the lug wrench, loosen the wheel nuts or bolts on the wheel you wish to change by about one full turn. Do not unscrew the wheel nuts or bolts completely.
- Raise the vehicle (\rightarrow page 191).

3^Raising the vehicle when changing a wheel

WARNING Risk of injury from incorrect positioning of the jack

If you do not position the jack correctly at the appropriate jacking point of the vehicle, the jack could tip with the vehicle raised.

Only position the jack at the appropriate jacking point of the vehicle. The base of the jack must be positioned vertically under the jacking point of the vehicle.

WARNING Risk of injury from vehicle tip-

On slopes, the jack could tip with the vehicle raised.

- Never change a wheel on a slope.
- Consult a qualified specialist workshop.

NOTE Damage to the vehicle due to the

If you do not position the jack at the jack support points provided for this purpose, you could damage your vehicle.

Only position the jack at the jack support points provided for this purpose.

Requirements

- · There is nobody in the vehicle.
- The vehicle is prepared for changing a wheel $(\rightarrow page 190)$.

Only position the jack on the jack support points intended for this purpose. Otherwise you could damage the vehicle.


Important notes on using the jack:

- Only use the vehicle-specific jack that has been tested and approved by Mercedes-Benz to raise the vehicle. If the jack is used incorrectly, it could tip over while the vehicle is raised.
- The jack is designed only to raise the vehicle for a short time while a wheel is being changed and is not suitable for carrying out maintenance work under the vehicle.
- Avoid changing a wheel on uphill or downhill slopes.
- The jack must be placed on a firm, flat and non-slip surface. If necessary, use a large, flat, load-bearing and non-slip support.
- · The base of the jack must be positioned vertically under the jack support point.

Safety instructions while the vehicle is raised:


- Do not put your hands or feet under the vehi-
- Do not lie underneath the vehicle.
- Do not start the vehicle and do not release the parking brake.
- Do not open or close any doors.

Vehicles with rear-wheel drive




Jack support points

Only use the middle rod and the pump handle rod with the largest diameter for the jack as a wheel wrench extension. Only fit the middle rod on the wheel wrench, and always as far as it will go. Otherwise, the rods could bend and deform so much that they can no longer be used as pump handles for the jack.




- ➤ To prepare the hydraulic jack: Insert the third rod of the jack's pump handle into the wheel wrench extension.
- Close the pressure release screw 3.
- ➤ To do this, use the flattened section on the pump handle to turn the pressure release screw clockwise to the stop.
- i Do not turn the pressure release screw more than one or two full turns. Hydraulic fluid could otherwise escape.

- Insert the pump handle (i) with the largest rod pointing forward into the recess on the jack and secure by turning it clockwise.
- Place the jack vertically beneath the jack support points described below.



Jack support point, front axle



Jack support point, rear axle

- Place the jack beneath the jack support point.
- Raise the vehicle until the tire is a maximum of 1.2 in (3 cm) off the ground.
- ▶ Loosen and remove the wheel (\rightarrow page 192).

Removing a wheel

Requirements:

The vehicle is raised (→ page 191).

When changing a wheel, avoid applying any force to the brake discs since this could impair the level of comfort when braking.

- NOTE Damage to threading from dirt on wheel bolts
- Do not place wheel bolts in sand or on a dirty surface.
- Unscrew the wheel bolts or nuts with the wheel nut wrench
- On front wheels with wheel nuts, remove the wheel nut cover.
- Remove the wheel.

installing a new wheel

Requirements

• The wheel is approved (\rightarrow) page 192).

WARNING Risk of accident from losing a

Oiled, greased or damaged wheel bolt/wheel nut threads or wheel hub/wheel mounting bolt threads can cause the wheel bolts/wheel nuts to come loose.


- Never oil or grease the threads.
- In the event of damage to the threads, contact a qualified specialist workshop immediately.
- Have the damaged wheel bolts or damaged hub threads replaced.
- Do not continue driving.

WARNING Risk of injury from tightening wheel bolts and nuts

If you tighten the wheel bolts or wheel nuts when the vehicle is raised, the jack could tip.

- Only tighten wheel bolts or wheel nuts when the vehicle is on the ground.
- Observe the information on the choice of tires $(\rightarrow page 188).$
- Observe the instructions and safety notes on changing a wheel (\rightarrow page 188).
- For safety reasons, only use wheel bolts or wheel nuts which have been approved by Mercedes-Benz and for the wheel in question.

When you install the steel spare wheel, it is essential to use the short wheel bolts for a steel wheel. Using other wheel bolts when installing the steel spare wheel may damage the brake system.



- Wheel bolt for light-alloy wheel
- Wheel bolt for steel wheel
- Clean the wheel and wheel hub contact surfa-
- Slide the wheel which is to be installed onto the wheel hub and push it on.

Vehicles with steel wheels

- Use the short wheel bolts intended for the steel spare wheel, which are found in the vehicle tool kit
- Screw in the wheel bolts until they are handtight.

Vehicles with light alloy wheels

- Use the long wheel bolts intended for the lightallov spare wheel, which are found in the vehicle tool kit.
- Screw in the wheel bolts until they are handtight.

Lowering the vehicle after a wheel change

WARNING Risk of accident due to incorrect tightening torque

The wheels could come loose if the wheel bolts or wheel nuts are not tightened to the prescribed torque.

- Ensure that the wheel bolts or wheel nuts are tightened to the prescribed tightening torque.
- If you are not sure, do not move the vehicle. Contact a qualified specialist workshop and have the tightening torque checked immediately.

Requirements:


 The new wheel has been installed (→ page 193).

Observe the notes on raising the vehicle $(\rightarrow page 191)$.

Vehicles with rear-wheel drive

Only use the middle rod and the pump lever rod with the largest diameter for the jack as a lug wrench extension. Only insert the middle rod on the lug wrench, and always as far as it will go. Otherwise, the rods could bend and deform so much that they can no longer be used as pump levers for the jack.

- Using the pump lever, slowly turn the drain screw on the jack approximately one revolution and carefully lower the vehicle.
- Place the jack to one side.
- Pull the rod with the smallest diameter off the pump lever.
 - The shortened pump lever serves as a lug wrench extension.
- Starting with the middle rod, slide the lug wrench extension as far as it will go onto the lug wrench.



- Tighten the wheel bolts or nuts evenly in the sequence indicated (1) to 3).
 - Specified tightening torque:
 - Steel wheel bolts: 177 lb-ft (240 Nm)
 - Light alloy wheel bolts: 133 lb-ft (180 Nm)
- Push the piston on the hydraulic jack in again and close the pressure release screw.
- (i) You can now install the hub caps on steel wheels with wheel bolts. The installing procedure depends on whether the hub cap acts as

- a trim that covers the whole wheel, or just covers the center.
- Wheel with wheel trim: position the opening in the wheel trim for the tire valve over the tire valve.
- Push the edge of the hub cap onto the wheel rim with both hands until it engages into place. Make sure the hub cap retaining catches engage on the steel wheel.
- Wheel with central hub cap: position the retaining lugs of the central hub cap over the wheel bolts.
- Hit the middle of the hub cap to engage it on the wheel.
- Secure the faulty wheel in the spare wheel
- Check the tire pressure of the newly installed wheel and adjust it if necessary.
- Retighten the wheel bolts or wheel nuts to the specified tightening torque after the vehicle has been driven 31 miles (50 km).
- When using a wheel or spare wheel with a new or newly painted wheel rim, have the wheel bolts or wheel nuts retightened after approximately 620 miles (1,000 km) to 3,100 miles (5,000 km).
- Vehicles with a tire pressure monitoring system: all wheels installed must be equipped with functioning sensors.

Make sure to observe the following further related subject:

Notes on tire pressure (→ page 176)

Spare wheel

Notes on the emergency spare wheel and spare wheel

Emergency spare wheel: wheel and/or tire dimensions as well as the type of tire are different from the wheel to be replaced.

(i) A label with the speed limitation can be found on the emergency spare wheel.

Spare wheel: wheel and tire dimensions as well as the type of tire correspond to the other installed wheels.

A installed emergency spare wheel or spare wheel changes the driving characteristics and bears risks.

WARNING Risk of accident due to incorrect wheel and tire dimensions.

Mounting an emergency spare wheel or spare wheel may severely impair the driving characteristics.

There is an increased risk of an accident.

To prevent hazardous situations:

- Check the tire pressure of the spare wheel or emergency spare wheel once installed and, if necessary, adjust.
- The emergency spare wheel may only be used temporarily and must be replaced with a standard wheel as soon as possible.
- Never install more than one emergency spare wheel.
- Adapt your driving style and drive carefully in emergency spare wheel mode.
- Do not switch off ESP®.
- Do not use snow chains on the emergency spare wheel.
- Replace the emergency spare wheel after six years at the latest, regardless of wear.
- When using an emergency spare wheel or spare wheel (different from the wheel to be replaced), you must not exceed a permissible top speed of 50 mph (80 km/h).
- Have the emergency spare wheel or spare wheel replaced by a qualified specialist workshop (\rightarrow page 188).
- The tire pressure of the emergency spare wheel or spare wheel must be checked before starting a journey and, if necessary, adjusted $(\rightarrow page 177)$.

The following should be checked regularly, particularly prior to long journeys:

- · that the emergency spare wheel or spare wheel is firmly secured
- the tire pressure of the emergency spare wheel or spare wheel (adjust the tire pressure if necessary) (\rightarrow page 177)
- the fastenings of the emergency spare wheel holder or spare wheel holder


The spare wheel is located either in the load compartment or in a spare wheel holder under the vehicle.

Replace the tires after six years at the latest, regardless of wear. This also applies to the spare wheel.


(i) If you have installed an emergency spare wheel or a spare wheel, the tire pressure monitoring system will not function for this wheel. The emergency spare wheel or spare wheel is not equipped with a sensor for the tire pressure monitoring system.

installing and removing the spare wheel

Vehicles with rear-wheel drive: removing the spare wheel (panel van or crewbus)



Bolt covers for the retaining hooks (example: panel



- Open the rear doors.
- Insert a screwdriver into the recesses (2) and pry off the covers 1.

- Using the lug wrench from the vehicle tool kit, turn the now visible bolts counter-clockwise by approximately 20 turns.
- Slightly raise the spare wheel carrier 4 and unhook left-hand retaining hook 3.
- Assemble the pump lever for the jack and slide it into the sleeve (§) on the right-hand side of the spare wheel carrier (4).
- Raise the spare wheel carrier with the pump lever and unhook the right-hand retaining hook so.
- Slowly lower the spare wheel carrier 4 to the ground.
- Lift the spare wheel carrier (a) slightly and pull the pump lever out of the sleeve.
- Use the pump lever to lift the spare wheel beyond the rear edge of the spare wheel carrier (a).
- Carefully remove the spare wheel from the spare wheel carrier ⑥. The spare wheel is heavy. When the spare wheel is removed, the center of gravity changes owing to the heavy weight of the wheel. The spare wheel may slip down or tip over.


Vehicles with rear-wheel drive: installing the spare wheel (panel van or crewbus)

- ➤ Carefully place the spare wheel onto the spare wheel carrier <a>


 The spare wheel is heavy.When you place the spare wheel onto the spare wheel carrier <a>

 the center of gravity changes owing to the weight of the wheel. The spare wheel may slip down or tip over.
- Slide the pump lever for the jack into the sleeve (5) on the spare wheel carrier (4).
- Raise the spare wheel carrier (4) with the pump lever and attach the right-hand retaining hook (3).
- Slightly raise the spare wheel carrier 4 and attach the left-hand retaining hook 3.
- Pull the pump lever out of the sleeve 5.
- Using the lug wrench, tighten the bolts for the retaining hooks (3) by turning them clockwise.
- Attach and snap in the covers ①.
- Close the rear doors.

Vehicles with rear-wheel drive: removing the spare wheel (vehicle with lowered chassis)



Bolt covers for the retaining hooks (example: panel van)




- Open the rear doors.
- Insert a screwdriver into the recesses ② and pry off the covers ①.
- Using the lug wrench from the vehicle tool kit, turn the now visible bolts counter-clockwise by approximately 20 turns.
- Slightly raise the spare wheel carrier (a) and unhook the left-hand retaining hook (a).
- Assemble the pump lever for the jack and slide it into the sleeve (a) on the right-hand side of the spare wheel carrier (a).
- Raise the spare wheel carrier with the pump lever and unhook the right-hand retaining hook
 3.
- Prepare the jack.

- Place the jack beneath the corresponding jack support point.
- Move the pump lever up and down until the tire is raised a maximum of 1.18 in (3 cm) off the
- Carefully remove the spare wheel from the spare wheel carrier (4). The spare wheel is heavy. When the spare wheel is removed, the center of gravity changes owing to the heavy weight of the wheel. The spare wheel may slip down or tip over.
- install the spare wheel on the vehicle.
- Lower the vehicle.

Vehicles with rear-wheel drive: installing the spare wheel (vehicle with lowered chassis)

- (i) In the event of a flat tire, you may only place the defective wheel inside the vehicle. An intact wheel may be stored in the spare wheel carrier only when the vehicle is unladen. A laden vehicle must first be raised.
- Carefully place the spare wheel onto the spare wheel carrier <a>a. The spare wheel is heavy. When you place the spare wheel onto the spare wheel carrier (4), the center of gravity changes owing to the weight of the wheel. The spare wheel may slip down or tip over.
- Slide the pump lever for the jack into the sleeve (5) on the spare wheel carrier (4).
- Raise the spare wheel carrier 4 with the pump lever and attach the right-hand retaining hook 3.
- Slightly raise the spare wheel carrier 4 and attach the left-hand retaining hook (3).
- Pull the pump lever out of the sleeve (5).
- Using the lug wrench, tighten the bolts for the retaining hooks (3) by turning them clockwise.
- Attach and snap in the covers 1.
- Close the rear doors.

Vehicles with rear-wheel drive: removing the spare wheel (chassis)



- Loosen the wing nuts (3) manually and remove them.
- Loosen the nuts 2 to the thread end.
- Slightly raise the spare wheel carrier (4) and unhook the left-hand retaining hook 1.
- Assemble the pump lever for the jack and slide it into the sleeve on the right-hand side of the spare wheel carrier (4).
- Raise the spare wheel carrier 4 with the pump lever and unhook the right-hand retaining hook 1.
- Slowly lower the spare wheel carrier (4) to the ground.
- Lift the spare wheel carrier (4) slightly and pull the pump lever out of the sleeve.
- Use the pump lever to lift the spare wheel beyond the rear edge of the spare wheel carrier.
- Carefully remove the spare wheel from the spare wheel carrier. The spare wheel is heavy. When the spare wheel is removed, the center of gravity changes owing to the heavy weight of the wheel. The spare wheel may slip down or tip over.

Vehicles with rear-wheel drive: installing the spare wheel (chassis)

Carefully place the spare wheel onto the spare wheel carrier 4. The spare wheel is heavy. When you place the spare wheel onto the spare wheel carrier, the center of gravity changes owing to the weight of the wheel. The spare wheel may slip down or tip over.

198 Wheels and tires

- Slide the pump lever for the jack into the sleeve on the spare wheel carrier 4.
- Raise the spare wheel carrier with the pump lever and attach the right-hand retaining hook no.
- Slightly raise the spare wheel carrier and attach the left-hand retaining hook ①.
- Pull the pump lever out of the sleeve.
- Tighten the nuts 2.
- Start the wing nuts (3) and tighten them.

Information on the technical data

The given data only applies to vehicles with standard equipment. You can obtain further information at a qualified specialist workshop.

On-board electronics

Notes on work on the engine electronics

NOTES Premature wear through improper maintenance

Improper maintenance may cause vehicle components to wear more quickly and the vehicle's operating permit may be invalidated.

Always have work on the engine electronics and related components carried out at a qualified specialist workshop.

Two-way radios

Installation notes for two-way radios

WARNING Risk of accident due to improper work on two-way radios

If two-way radios are manipulated or retrofitted incorrectly, the electromagnetic radiation from the two-way radios can interfere with the vehicle electronics and jeopardize the operating safety of the vehicle.

- You should have all work on electrical and electronic components carried out at a qualified specialist workshop.
- WARNING Risk of accident due to improper operation of two-way radios

If you use two-way radios in the vehicle improperly, their electromagnetic radiation can disrupt the vehicle's electronics. This is the case in the following situations, in particular:

- The two-way radio is not connected to an exterior antenna.
- The exterior antenna is installed incorrectly or is not a low-reflection antenna.


This could jeopardize the operating safety of the vehicle.

Have the low-reflection exterior antenna installed at a qualified specialist workshop.

- When operating two-way radios in the vehicle, always connect them to the lowreflection exterior antenna.
- **NOTE** Invalidation of the operating permit due to failure to comply with the instructions for installation and use


The operating permit may be invalidated if the instructions for installation and use of two-way radios are not observed.

- Only use approved frequency bands.
- Observe the maximum permissible output power in these frequency bands.
- Only use approved antenna positions.



Cab Chassis (standard cab)

Front roof area



Cargo Van

- Front roof area
- Rear roof area

Use Technical Specification ISO/TS 21609 (Road Vehicles - EMC guidelines for installation of aftermarket radio frequency transmitting equipment) when retrofitting two-way radios. Comply with the legal requirements for detachable parts.

If your vehicle has pre-installation for two-way radio equipment, use the power supply or antenna connections intended for use with the pre-installation. Observe the manufacturer's supplements during installation.

■ Transmission output of two-way radios

The maximum transmission outputs (PEAK) at the base of the antenna must not exceed the values in the following table:

Frequency band and maximum transmission output

Frequency band	Maximum transmis- sion output
2 -m- frequency band 144 - 174 MHz	50 W
4-m-frequency band 74 - 88 MHz	30 W
Terrestrial Trunked Radio (TETRA) 380 - 460 MHz	10 W
Mobile telephony 2G	2 W
Mobile telephony 3G/4G/5G	0.5 W

There are no restrictions on use of the following devices in the vehicle:

- Two-way radios with a maximum transmission output of up to 100 mW
- Two-way radios with transmitter frequencies in the 380-410 MHz frequency band and a maximum transmission output of up to 2 W (trunked radio system/Tetra)
- Mobile phones (2G/3G/4G/5G)

There are no restrictions on positioning the antenna on the outside of the vehicle for the following frequency bands:

- Terrestrial Trunked Radio (TETRA)
- 2G/3G/4G/5G

Radio regulations

Regulatory radio identifiers and specific notes

The tables and sections contain the following regulatory radio information:

- Manufacturer information
- Required regulatory radio identifiers, listed by country/region:
 - Manufacturer's specifications
 - Model designations
 - Radio equipment approval numbers
- Specific information on wireless components

Further information and updates are available at the following web address:

https://regulatoryradioinformation.corpinter.net/vans/us



Manufacturer overview

Manufacturer	Manufacturer information
Bosch	Robert Bosch GmbH, Daimlerstraße 6, 71229 Leonberg, Ger- many
Continental Automotive	Continental Automotive GmbH, Siemensstraße 12, 93055 Regensburg, Germany
Continental Automotive Technologies	Continental Automotive Technologies GmbH, VDO-Straße 1, 64832 Babenhausen, Germany
Garmin	Garmin International, Inc., 1200 E. 151st Street, Olathe, Kansas 66062, United States
Harman Becker	Harman Becker Auto- motive Systems GmbH, Becker-Goehr- ing-Straße 18, 76307 Karlsbad, Germany

Manufacturer	Manufacturer information
HELLA	HELLA KGaA Hueck & Co., Rixbecker Straße 75, 59552 Lippstadt, Germany
Hirschmann	Hirschmann Car Com- munication GmbH, Stuttgarter Straße 45-51, 72654 Neckar- tenzlingen, Germany
Huf Baolong	Huf Baolong Electronics Bretten GmbH, Gewerbestraße 40, 75015 Bretten, Germany
MARQUARDT	MARQUARDT GmbH, Schloßstraße 16, 78604 Rietheim-Weil- heim, Germany
Meta System	Meta System S.P.A., Via T. Galimberti 5, 42124 Reggio Emilia, Italy
Schrader	Schrader Electronics Ltd., 11 Technology Park, Belfast Road, Antrim BT41 1QS, Northern Ireland, Uni- ted Kingdom
Veoneer	Veoneer Sweden AB, Wallentinsvägen 22, 44737 Vårgårda, Sweden
Visteon	Visteon Electronics GmbH, Amalienbad- straße 41a, 76227 Karlsruhe, Germany
WITTE-Velbert	WITTE-Velbert GmbH & Co. KG, Hoeferstr. 3-15, 42551 Velbert, Germany

Algeria




Homologué par l'ARPCE Référence du Certificat de conformité

Manufacturer	Model desig- nation	Radio equip- ment approval number
Continental Automotive	MARS Keyless (locking sys- tem)	122/H/ANF/ 2021
HELLA	DM4 (locking system)	123/H/ANF/ 2021
Hirschmann	920510A (locking system)	4001/1.69- DA/ 3005/DT/DG /ARPT/17
Huf Baolong	TSSRE4A (tire pressure sensor)	198/H/ANF/ 2021
Huf Baolong	TSSSG4G6b (tire pressure monitoring system con- trol unit)	67/H/ANF/ 2021
MARQUARDT	DC12B (lock- ing system)	189/H/ANF/ 2021

Argentina

Regulatory radio identification



Australia

Regulatory radio identification



Manufacturer	Model designation
Bosch	MRR1Rear (radar sensor)
Bosch	MRRe14FCR (radar sensor)
Bosch	FR5CPCCF (radar sensor)
Continental Automotive	MARS Keyless (locking system)
Continental Automo- tive Technologies	NTG7Q MID LF2 (head unit)



Manufacturer	Model designation
Continental Automotive Technologies	NTG7Q HIGH LF2 (head unit)
Continental Automotive Technologies	NTG7Q PREMIUM LF2 (head unit)
Huf Baolong	TSSRE4Uf (tire pressure sensor)
Huf Baolong	TSSSG4G6b (tire pressure monitoring system control unit)

Bahamas

Manufacturer	Model desig- nation	Radio equip- ment approval number
Bosch	MRR1Rear (radar sensor)	URCA_TA/ 2017_184
Bosch	MRRe14FCR (radar sensor)	URCA_TA/ 2017_157
Bosch	FR5CPCCF (radar sensor)	URCA_TA_20 19_195
Continental Automotive	MARS Keyless (locking sys- tem)	URCA_TA/ 2017_119
HELLA	DM4 (locking system)	URCA_TA/ 2017_078
Hirschmann	920510A (locking system)	URCA_TA/ 2019_019
Huf Baolong	TSSRE4A (tire pressure sensor)	URCA_TA/ 2017_094
MARQUARDT	DC12B (lock- ing system)	URCA_TA_20 19_128
MARQUARDT	MS2 (locking system)	URCA_TA/ 2017_021

Belarus

Regulatory radio identification



Botswana

Regulatory radio identification

Manufacturer	Model desig- nation	Radio equip- ment approval number
Bosch	MRRe14FCR (radar sensor)	BOCRA/TA/ 2019/4674
Bosch	FR5CPCCF (radar sensor)	BOCRA/TA/ 2019/4975
Bosch	MRR1Rear (radar sensor)	BOCRA/TA/ 2017/3788
Continental Automotive	MARS Keyless (locking sys- tem)	BOCRA/TA/ 2019/4661

Manufacturer	Model desig- nation	Radio equip- ment approval number
HELLA	DM4 (locking system)	BOCRA/TA/ 2019/4662
Huf Baolong	TSSRE4Uf (tire pressure sensor)	BOCRA/TA/ 2019/5079
MARQUARDT	DC12B (lock- ing system)	BOCRA/TA/ 2019/4388
MARQUARDT	MS2 (locking system)	BOCRA/TA/ 2019/5135

Brazil

Note on the two-way radio systems in the vehicle:

These systems are not protected against harmful interference and must not cause interference in properly approved systems.

■ ANATEL		
Manufacturer	Model desig- nation	Radio equip- ment approval number
Continental Automotive	MARS Keyless (locking sys- tem)	03189-1 <i>7</i> -02 856
Continental Automotive Technologies	NTG7Q MID LF2 (head unit)	04336-23-02 149
Continental Automotive Technologies	NTG7Q HIGH LF2 (head unit)	04338-23-02 149
Continental Automotive Technologies	NTG7Q PRE- MIUM LF2 (head unit)	04337-23-02 149
HELLA	DM4 (locking system)	04689-17-05 364
Hirschmann	920510A (locking sys- tem)	20595-22-08 058



Manufacturer	Model desig- nation	Radio equip- ment approval number
Huf Baolong	TSSRE4A (tire pressure sensor)	05181-17-06 643
Huf Baolong	TSSRE4Uf (tire pressure sensor)	07137-19-08 137
MARQUARDT	DC12B (lock- ing system)	01395-11-02 930
MARQUARDT	MS2 (locking system)	00616-17-02 930
Schrader	GG4 (tire pressure sensor)	0381-13-800
Schrader	HSW4 (tire pressure sensor)	0381-13-800 1

Brunei Darussalam

Regulatory radio identification



Manufacturer	Model desig- nation	Radio equip- ment approval number
Bosch	FR5CPCCF (radar sensor)	DTA-004222
Bosch	LRR3 (radar sensor)	DTA-011039
Bosch	MRR1Rear (radar sensor)	DTA-006601
Bosch	MRRe14FCR (radar sensor)	DTA-006678
Continental Automotive	MARS Keyless (locking sys- tem)	DTA-017264



Manufacturer	Model desig- nation	Radio equip- ment approval number
HELLA	DM4 (locking system)	DTA-020187
Hirschmann	920510A (locking system)	DTA-000718
Huf Baolong	TSSRE4A (tire pressure sensor)	DTA-000310
Huf Baolong	TSSRE4Uf (tire pressure sensor)	DTA-021806
Huf Baolong	TSSSG4G6b (tire pressure monitoring system con- trol unit)	DTA-003757
MARQUARDT	DC12B (lock- ing system)	DTA-000068
MARQUARDT	MS2 (locking system)	LPD-38890

Eurasian Economic Union



LIIL		
Manufacturer	Model designation	
Bosch	FR5CPCCF (radar sensor)	
Bosch	LRR3 (radar sensor)	
Bosch	MRR1Rear (radar sensor)	
Bosch	MRRe14FCR (radar sensor)	
Continental Automotive	MARS Keyless (locking system)	

ERC	
Manufacturer	Model designation
HELLA	DM4 (locking system)
Hirschmann	920510A (locking system)
Huf Baolong	TSSRE4A (tire pressure sensor)
Huf Baolong	TSSRE4Uf (tire pressure sensor)
Huf Baolong	TSSSG4G6b (tire pressure monitoring system control unit)
MARQUARDT	DC12B (locking system)
MARQUARDT	MS2 (locking system)

Ghana

Regulatory radio identification

Manufacturer	Model desig- nation	Radio equip- ment approval number
		NCA APPROVED
Bosch	FR5CPCCF (radar sensor)	ZRO- M8-7E3-230
Continental Automotive	MARS Keyless (locking system)	BR3-1M- GE2-16A
Continental Automotive Technologies	NTG7Q MID LF2 (head unit)	7M-7E7-X09- DSR
Continental Automotive Technologies	NTG7Q HIGH LF2 (head unit)	7M-7E7-X05- DSR
Continental Automotive Technologies	NTG7Q PRE- MIUM LF2 (head unit)	7M-7E7-X03- DSR
HELLA	DM4 (locking system)	BR3-1M- GE2-157

Manufacturer	Model desig- nation	Radio equip- ment approval number
Huf Baolong	TSSRE4A (tire pressure sensor)	SR0-1M-7E4- 24B
Huf Baolong	TSSRE4Uf (tire pressure sensor)	7E5-7M-XCB- RDR
MARQUARDT	DC12B (lock- ing system)	ZRO-M8-7E3- X51
MARQUARDT	MS2 (locking system)	BR3-1M- GE-129

Indonesia

,		
Manufacturer	Model desig- nation	Radio equip- ment approval number
Bosch	LRR3 (radar sensor)	74264/ SDPPI/2021 7163
Bosch	MRR1Rear (radar sensor)	74267/ SDPPI/2021 7163
Bosch	MRRevo14F (radar sensor)	74265/ SDPPI/2021 7163

Manufacturer	Model desig- nation	Radio equip- ment approval number
Bosch	MRRe14FCR (radar sensor)	74266/ SDPPI/2021 7163
Bosch	FR5CPCCF (radar sensor)	67882/ SDPPI/2020 7163 Dilarang mela- kukan peruba- han spesifi- kasi yang dapat menim- bulkan gang- guan fisik dan/atau elektromagne- tik terhadap lingkungan sekitarnya

Manufacturer	Model desig- nation	Radio equip- ment approval number
Continental Automotive	MARS Keyless (locking sys- tem)	69379/ SDPPI/2020 7163
		Ţ
		Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya
Continental Automotive Technologies	NTG7Q MID LF2 (head unit)	88477/ SDPPI/2023 7163
		Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya

Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number
Continental Automotive Technologies	NTG7Q HIGH LF2 (head unit)	88579/ SDPPI/2023 7163 Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya	Garmin	VIS (Headunit)	Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya
Continental Automotive Technologies	NTG7Q PRE-MIUM LF2 (head unit)	88478/ SDPPI/2023 7163 Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya	Harman Becker	NTG6N ENTRY/MID (Headunit) Production: Germany	64019/ SDPPI/2019 7163 Dilarang mela- kukan peruba- han spesifi- kasi yang dapat menim- bulkan gang- guan fisik dan/atau elektromagne- tik terhadap lingkungan sekitarnya

Manufacturer	Model designation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number
Harman Becker	NTG6N HIGH (Headunit) Production: Germany	Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya	Harman Becker	NTG6N HIGH (Headunit) Production: Hungary	Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya
Harman Becker	NTG6N ENTRY/MID (Headunit) Production: Hungary	63775/ SDPPI/2019 7163 Dilarang mela- kukan peruba- han spesifi- kasi yang dapat menim- bulkan gang- guan fisik dan/atau elektromagne- tik terhadap lingkungan sekitarnya	Harman Becker	NTG7 MID (Headunit)	65544/ SDPPI/2020 7163 Dilarang mela- kukan peruba- han spesifi- kasi yang dapat menim- bulkan gang- guan fisik dan/atau elektromagne- tik terhadap lingkungan sekitarnya

Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number
Harman Becker	NTG7 HIGH (Headunit)	70513/SDPPI/2020 7163 Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya	Harman Becker	NTG7 PRE- MIUM PLUS (Headunit)	70512/SDPPI/2020 7163 Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya
Harman Becker	NTG7 PRE- MIUM (Headunit)	65543/ SDPPI/2020 7163 Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya	Harman Becker	NTG7 RSU (control unit)	Dilarang mela-kukan perubahan spesifi-kasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya

Manufacturer	Model designation	Radio equip- ment approval number
Hirschmann	920510A (locking sys- tem)	81434/ SDPPI/2022 7163
		\triangle
		Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya
HELLA	DM4 (locking system)	69378/ SDPPI/2020 7163
		Dilarang mela- kukan peruba- han spesifi- kasi yang dapat menim- bulkan gang- guan fisik dan/atau elektromagne- tik terhadap lingkungan sekitarnya

Manufacturer	Model desig- nation	Radio equip- ment approval number
Huf Baolong	TSSRE4A (tire pressure sensor)	72438/ SDPPI/2021 7163
MARQUARDT	DC12B (lock- ing system)	59840/ SDPPI/2019 7163
		\triangle
		Dilarang mela- kukan peruba- han spesifi- kasi yang dapat menim- bulkan gang- guan fisik dan/atau elektromagne- tik terhadap lingkungan sekitarnya

Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	MS2 (locking system)	67372/ SDPPI/2020 7163 Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya

Manufacturer	Model desig- nation	Radio equip- ment approval number
Schrader	MC34MA4 (tire pressure monitoring system con- trol unit)	25626/ SDPPI/2015 3612
Visteon	Connect 5 (Headunit)	61671/ SDPPI/2019 7163
		Dilarang mela- kukan peruba- han spesifi- kasi yang dapat menim- bulkan gang- guan fisik dan/atau elektromagne- tik terhadap lingkungan sekitarnya

Israel

Manufacturer	Model desig- nation	Radio equip- ment approval number
		Approval number of the Ministry of Communications:
Bosch	LRR3 (radar sensor)	55-08334
Bosch	MRR1Rear (radar sensor)	55-08333

Manufacturer	Model desig- nation	Radio equip- ment approval number
Bosch	MRRe14FCR (radar sensor)	55-08395
Bosch	FR5CPCCF (radar sensor)	55-08783
Continental Automotive	MARS Keyless (locking sys- tem)	55-13749
Continental Automotive Technologies	NTG7Q MID LF2 (head unit)	51-90718
Continental Automotive Technologies	NTG7Q HIGH LF2 (head unit)	51-90717
Continental Automotive Technologies	NTG7Q PRE- MIUM LF2 (head unit)	51-90719
Harman Becker	NTG7 HIGH-IL (Headunit)	51-89476
Harman Becker	NTG7 PRE- MIUMPLUS-IL (Headunit)	51-89475
HELLA	DM4 (locking system)	55-14271
Huf Baolong	TSSRE4A (tire pressure sensor)	63-66757
Huf Baolong	TSSRE4Uf (tire pressure sensor)	63-66757
Huf Baolong	TSSSG4G6b (tire pressure monitoring system con- trol unit)	63-68102
MARQUARDT	DC12B (lock- ing system)	55-12215


Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	MS2 (locking system)	51-85192
WITTE-Velbert	SDHTAG3NFC (locking sys- tem)	55-12216

Jamaica

Regulatory radio identification

Manufacturer	Model designation
Continental Automotive	MARS Keyless (locking system)
HELLA	DM4 (locking system)
Hirschmann	920510A (locking system)
Huf Baolong	TSSRE4A (tire pressure sensor)
Huf Baolong	TSSRE4Uf (tire pressure sensor)
Huf Baolong	TSSSG4G6b (tire pressure monitoring system control unit)
MARQUARDT	DC12B (locking system)
MARQUARDT	MS2 (locking system)

Japan



Canada

Regulatory radio identification

Manufacturer	Model desig- nation	Radio equip- ment approval number
Continental Automotive Technologies	NTG7Q MID LF2 (head unit)	IC: NTG7QMIDLF 2
Continental Automotive Technologies	NTG7Q HIGH LF2 (head unit)	IC: NTG7QHIGLF 2
Continental Automotive Technologies	NTG7Q PRE- MIUM LF2 (head unit)	IC: NTG7QPREF2
Hirschmann	920510A (locking system)	IC:8653A-920 510A
Huf Baolong	TSSRE4A (tire pressure sensor)	IC: 4008C- TSSRE4A
Huf Baolong	TSSRE4Uf (tire pressure sensor)	IC: 3702A- TSSRE4UF

Kuwait

Regulatory radio identification

Manufacturer	Model desig- nation	Radio equip- ment approval number
Huf Baolong	TSSRE4A (tire pressure sensor)	5420
Huf Baolong	TSSRE4Uf (tire pressure sensor)	3591
Huf Baolong	TSSSG4G6b (tire pressure monitoring system con- trol unit)	3271

Malaysia

MEME		
Manufacturer	Model desig- nation	Radio equip- ment approval number
Bosch	FR5CPCCF (radar sensor)	CIDF1500049 0
Bosch	LRR3 (radar sensor)	CIDF1500049 0
Bosch	MRR1Rear (radar sensor)	CIDF1500049 0
Bosch	MRRe14FCR (radar sensor)	CIDF1500049 0
Bosch	MRRevo14F (radar sensor)	CIDF1500049 0
Continental Automotive	MARS Keyless (locking system)	CIDF1500057
Continental Automotive Technologies	NTG7Q MID LF2 (head unit)	RCCT/92G/ 0423/ S(23-0350)
Continental Automotive Technologies	NTG7Q HIGH LF2 (head unit)	CCT/91G/ 0323/ S(23-1291)
Continental Automotive Technologies	NTG7Q PRE- MIUM LF2 (head unit)	RGQB/05A/ 0323/ S(23-1293)
HELLA	DM4 (locking system)	CIDF1500057
Hirschmann	920510A (locking system)	RFFK/01A/ 1117/ S(17-3581)
Huf Baolong	TSSRE4A (tire pressure sensor)	HIDF1500015
Huf Baolong	TSSRE4Uf (tire pressure sensor)	HIDF1500015

MEME		
Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	DC12B (lock- ing system)	RAUU/62A/ 0311/ S(11-0263)
MARQUARDT	MS2 (locking system)	RDDK/31A/ 0217/ S(17-0405)

Morocco


Manufacturer	Model desig- nation	Radio equip- ment approval number
		AGREE PAR L'ANRT MAROC
Bosch	FR5CPCCF (radar sensor)	MR 20575 ANRT 2019-07-29
Bosch	LRR3 (radar sensor)	MR 5371 ANRT 2010 2019-12-05
Bosch	MRR1Rear (radar sensor)	MR 9186 ANTR 2014-04-22
Bosch	MRRe14FCR (radar sensor)	MR 13900 ANTR 2017-05-04
Continental Automotive	MARS Keyless (locking system)	MR 13681 ANTR 2017-04-04
HELLA	DM4 (locking system)	MR 14426 ANTR 2017-07-28
MARQUARDT	DC12B (lock- ing system)	MR 6698 ANTR 2021-11-04

Manufacturer	Model designation	Radio equip- ment approval number
Hirschmann	920510A (locking system)	MR 14779 ANTR 2017-09-25
Huf Baolong	TSSRE4A (tire pressure sensor)	AGREE PAR L'ANRT MAROC MR 14320 ANRT 2017 Date d'agre- ment: 07/07/2017
Huf Baolong	TSSRE4Uf (tire pressure sensor)	AGREE PAR L'ANRT MAROC MR 20944 ANRT 2019 Date d'agre- ment: 07/07/2017
MARQUARDT	DC12B (lock- ing system)	AGREE PAR L'ANRT MAROC MR 6698 ANTR 2021 Date d'agre- ment: 04/11/2021
MARQUARDT	MS2 (locking system)	MR 13300 ANTR 2017-02-15
Schrader	MC34MA4 (tire pressure monitoring system con- trol unit)	AGREE PAR L'ANRT MAROC MR 6706 ANTR Date d'agre- ment: 2011-11-17

Mexico

Regulatory radio identification

NOM		ANCE
Manufacturer	NYCE Model designation	Radio equip- ment approval number
Bosch	LRR3 (radar sensor)	IFETEL: RCPBOLR09- 0828
Bosch	MRR1Rear (radar sensor)	IFETEL: RCPBOMR14- 0922
Bosch	MRRe14FCR (radar sensor)	IFETEL: RCPBOMR17- 0598
Continental Automotive	MARS Keyless (locking sys- tem)	IFETEL: RLVDAMA18- 1827
Continental Automotive Technologies	NTG7Q MID LF2 (head unit)	IFETEL: MEMENT23 - 12200
Continental Automotive Technologies	NTG7Q HIGH LF2 (head unit)	IFETEL: MEMENT23 - 11923
Continental Automotive Technologies	NTG7Q PRE- MIUM LF2 (head unit)	IFETEL: MEMENT23 - 12204
HELLA	DM4 (locking system)	IFETEL: RLVHEDM17- 10
Hirschmann	920510A (locking system)	IFETEL: RLVHI9217-1 754
Huf Baolong	TSSRE4A (tire pressure sensor)	IFETEL: RLVBHTS19-1 995
MARQUARDT	DC12B (lock- ing system)	IFETEL: RLVMADC11- 0446



Mongolia

APPROVED In MONGCUA ID APPROVED		
Manufacturer	Model desig- nation	Radio equip- ment approval number
Continental Automotive	MARS Keyless (locking sys- tem)	A18000328
HELLA	DM4 (locking system)	A18000329
Huf Baolong	TSSRE4A (tire pressure sensor)	A19000569
Huf Baolong	TSSSG4G6b (tire pressure monitoring system con- trol unit)	A21000451
MARQUARDT	DC12B (lock- ing system)	A19000371
MARQUARDT	MS2 (locking system)	A18000289

Niger

Regulatory radio identification

Manufacturer	Model desig- nation	Radio equip- ment approval number
Continental Automotive	MARS Keyless (locking sys- tem)	083/ ARCEP/DG/1 9
HELLA	DM4 (locking system)	082/ ARCEP/DG/1 9
MARQUARDT	DC12B (lock- ing system)	008/ ARCEP/DG/1 9
MARQUARDT	MS2 (locking system)	014/ ARCEP/DG/1 9

Nigeria

Regulatory radio identification

Manufacturer	Model designation
Bosch	FR5CPCCF (radar sensor)
Bosch	MRR1Rear (radar sensor)
Bosch	MRRe14FCR (radar sensor)
Continental Automotive	MARS Keyless (locking system)
HELLA	DM4 (locking system)
Hirschmann	920510A (locking system)
Huf Baolong	TSSRE4Uf (tire pressure sensor)
Huf Baolong	TSSSG4G6b (tire pressure monitoring system control unit)
MARQUARDT	DC12B (locking system)
MARQUARDT	MS2 (locking system)

Oman

Manufacturer	Model designation	Radio equip- ment approval number
Bosch	FR5CPCCF (radar sensor)	TRA/TA-R/ 7983/19 D172338
Bosch	LRR3 (radar sensor)	TRA/TA-R/ 1049/09
Bosch	MRR1Rear (radar sensor)	TRA/TA-R/ 1849/14
Bosch	MRRe14FCR (radar sensor)	TRA/TA-R/ 4353/17
Continental Automotive	MARS Keyless (locking sys- tem)	TRA/TA-R/ 4158/17 D080134
HELLA	DM4 (locking system)	TRA/TA-R/ 4548/17 D080134
Hirschmann	920510A (locking sys- tem)	TRA/TA-R/ 4748/17 D080134
Huf Baolong	TSSRE4Uf (tire pressure sensor)	TRA/TA-R/ 8240/19
MARQUARDT	DC12B (lock- ing system)	TRA/TA-R/ 0227/11 D080353


Pakistan

Regulatory radio identification




Paraguay

CONATEL		
Manufacturer	Model desig- nation	Radio equip- ment approval number
Bosch	FR5CPCCF (radar sensor)	CONATEL 2019-09- I-0508
Bosch	MRRe14FCR (radar sensor)	CONATEL 2017-06- I-0000162
Bosch	MRR1Rear (radar sensor)	CONATEL 2019-05- I-000236
Continental Automotive	MARS Keyless (locking sys- tem)	CONATEL 2017-05- I-0000136 y
HELLA	DM4 (locking system)	2022-06- I-0388 y 2017-08- I-0000261
Hirschmann	920510A (locking system)	CONATEL 2023-01- 1-0058



Philippines

Regulatory radio identification





OMMISION .		
Manufacturer	Model desig- nation	Radio equip- ment approval number
HELLA	DM4 (locking system)	ESD-1715539 C
Hirschmann	920510A (locking system)	ESD-1715811 C
Huf Baolong	TSSRE4A (tire pressure sensor)	ESD-1715393 C
Huf Baolong	TSSRE4Uf (tire pressure sensor)	ESD-1920803 C
MARQUARDT	DC12B (lock- ing system)	ESD-1105216 C
MARQUARDT	MS2 (locking system)	ESD-1715652 C

Zambia



Manufacturer	Model desig- nation	Radio equip- ment approval number
Continental Automotive	MARS Keyless (locking sys- tem)	ZMB/ ZICTA/TA/ 2019/3/3
HELLA	DM4 (locking system)	ZMB/ ZICTA/TA/ 2019/3/4
MARQUARDT	DC12B (lock- ing system)	ZMB/ ZICTA/TA/ 2019/5/17
MARQUARDT	MS2 (locking system)	ZMB/ ZICTA/TA/ 2018/9/30

Serbia Regulatory radio identification

Δ Δ Δ		
Manufacturer	Model desig- nation	Radio equip- ment approval number
Bosch	FR5CPCCF (radar sensor)	И011 19
Bosch	LRR3 (radar sensor)	И011 19
Bosch	MRR1Rear (radar sensor)	И011 17
Bosch	MRRe14FCR (radar sensor)	И005 17
Continental Automotive	MARS Keyless (locking sys- tem)	И005 20
Continental Automotive Technologies	NTG7Q MID LF2 (head unit)	И005 23
Continental Automotive Technologies	NTG7Q HIGH LF2 (head unit)	И005 23
Continental Automotive Technologies	NTG7Q PRE- MIUM LF2 (head unit)	И005 23
HELLA	DM4 (locking system)	И005 20
Hirschmann	920510A (locking system)	И005 20
Huf Baolong	TSSRE4A (tire pressure sensor)	И005 23
Huf Baolong	TSSRE4Uf (tire pressure sensor)	И005 22

ΔΔ		
Manufacturer	Model desig- nation	Radio equip- ment approval number
Huf Baolong	TSSSG4G6b (tire pressure monitoring system con- trol unit)	И005 22
MARQUARDT	DC12B (lock- ing system)	И005 20
MARQUARDT	MS2 (locking system)	И011 17

Singapore

Manufacturer	Model desig- nation	Radio equip- ment approval number
		Complies with IMDA Stand-ards
Bosch	FR5CPCCF (radar sensor)	DA105282
Bosch	LRR3 (radar sensor)	DB101762
Bosch	MRR1Rear (radar sensor)	DA105282
Bosch	MRRevo14F (radar sensor)	DA103365
Bosch	MRRe14FCR (radar sensor)	DB03227
Continental Automotive	MARS Keyless (locking sys- tem)	DA105282
Continental Automotive Technologies	NTG7Q MID LF2 (head unit)	DA105282
Continental Automotive Technologies	NTG7Q HIGH LF2 (head unit)	DA105282

Manufacturer	Model desig- nation	Radio equip- ment approval number
Continental Automotive Technologies	NTG7Q PRE- MIUM LF2 (head unit)	DA105282
HELLA	DM4 (locking system)	DA103365 N3308-22
Hirschmann	920510A (locking system)	N1412-18
Huf Baolong	TSSRE4A (tire pressure sensor)	DA105282
Huf Baolong	TSSRE4Uf (tire pressure sensor)	DA103365
Huf Baolong	TSSSG4G6b (tire pressure monitoring system con- trol unit)	DA28467
MARQUARDT	DC12B (lock- ing system)	DA103365
MARQUARDT	MS2 (locking system)	DA103787
Meta System	ITS/TPS (interior protection)	DA103365
Meta System	MUW II (inte- rior protec- tion)	DA103365
Veoneer	6208428 (radar sensor)	N2743-16
Veoneer	24 GHz MMR (radar sensor)	N2955-17
WITTE-Velbert	SDHTAG3NFC (locking sys- tem)	DA107248 N1755-20

South Africa

I C A:S A		
Manufacturer	Model desig- nation	Radio equip- ment approval number
Bosch	FR5CPCCF (radar sensor)	TA-2019/120 0
Bosch	MRR1Rear (radar sensor)	TA-2014/212
Bosch	MRRe14FCR (radar sensor)	TA-2017/201 3
Bosch	LRR3 (radar sensor)	TA-2009/464
Continental Automotive	MARS Keyless (locking sys- tem)	TA-2016/350 0
Continental Automotive Technologies	NTG7Q MID LF2 (head unit)	TA-2023/009
Continental Automotive Technologies	NTG7Q HIGH LF2 (head unit)	TA-2023/011
Continental Automotive Technologies	NTG7Q PRE- MIUM LF2 (head unit)	TA-2023/009 0
HELLA	DM4 (locking system)	TA-2017/251
Hirschmann	920510A (locking system)	TA-2017/235 0
Huf Baolong	TSSRE4A (tire pressure sensor)	TA-2017/139 3
Huf Baolong	TSSRE4Uf (tire pressure sensor)	TA-2019/185 3



Manufacturer	Model desig- nation	Radio equip- ment approval number
Huf Baolong	TSSSG4G6b (tire pressure monitoring system con- trol unit)	TA-2019/144 0
MARQUARDT	DC12B (lock- ing system)	TA-2011/370
MARQUARDT	MS2 (locking system)	TA-2016/331 4
Schrader	MC34MA4 (tire pressure monitoring system con- trol unit)	TA-2011/137 0

South Korea

Regulatory radio identification



2		
Manufacturer	Model desig- nation	Radio equip- ment approval number
Continental Automotive Technologies	NTG7Q LF2 (head unit)	R-R-TeH- NTG7QLF2
Hirschmann	920510A (locking system)	R- C-0HR-92051 0A
Huf Baolong	TSSRE4A (tire pressure sensor)	R-CRM- HHFTSSRE4A
Huf Baolong	TSSRE4Uf (tire pressure sensor)	R-CRM-HHF- TSSRE4A
Huf Baolong	TSSSG4G6b (tire pressure sensor)	R-R-HEB- TSSSG4G6B

Thailand

Regulatory radio identification


Manufacturer	Model desig- nation	Radio equip- ment approval number
Continental Automotive Technologies	NTG7Q PRE- MIUM LF2 (head unit)	130111-23-0 132
		CLASS A NBTC ID.130111-23-0132

Togo

Regulatory radio identification

Manufacturer	Model desig- nation	Radio equip- ment approval number
Continental Automotive	MARS Keyless (locking sys- tem)	No. 040/19
HELLA	DM4 (locking system)	No. 039/19
MARQUARDT	DC12B (lock- ing system)	No. 057/19
MARQUARDT	MS2 (locking system)	No. 008/19

Ukraine





Uzbekistan

Regulatory radio identification



Manufacturer	Model designation
Continental Automotive	MARS Keyless (locking system)
HELLA	DM4 (locking system)
MARQUARDT	DC12B (locking system)
MARQUARDT	MS2 (locking system)

United Arab Emirates



هيئة تنظيم الاتصالات والحكومة الرقمية TELECOMMUNICATIONS AND DIGITAL GOVERNMENT REGULATORY AUTHORITY

Manufacturer	Model desig- nation	Radio equip- ment approval number
Bosch	FR5CPCCF (radar sensor)	TA RTTE: ER74533/19, DA36758/14
Continental Automotive	MARS Keyless (locking system)	TRA ER56005/17, DA44932/15

Manufacturer	Model designation	Radio equip- ment approval number
Continental Automotive Technologies	NTG7Q MID LF2 (head unit)	TDRA ER17731/23, DA76163/18
Continental Automotive Technologies	NTG7Q HIGH LF2 (head unit)	TDRA ER17730/23, DA76163/18
Continental Automotive Technologies	NTG7Q PRE- MIUM LF2 (head unit)	TDRA ER17732/23, DA76163/18
HELLA	DM4 (locking system)	TRA ER56616/17, DA44932/15
Hirschmann	920510A (locking system)	TRA ER59686/17
Huf Baolong	TSSRE4A (tire pressure sensor)	TRA ER57806/17 DA36976/14
Huf Baolong	TSSRE4Uf (tire pressure sensor)	TRA ER75266/19
Huf Baolong	TSSSG4G6b (tire pressure monitoring system con- trol unit)	TRA ER7307/19 DA0086237/ 12

Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	DC12B (lock- ing system)	TRA ER0067828/ 11 DA0018994/ 09
MARQUARDT	MS2 (locking system)	TRA ER52668/17, DA0018994/ 09

United Kingdom



Manufacturer	Model designation
Continental Automo- tive	MARS Keyless (locking system)
Continental Automo- tive Technologies	NTG7Q MID LF2 (head unit)
Continental Automo- tive Technologies	NTG7Q HIGH LF2 (head unit)
Continental Automo- tive Technologies	NTG7Q PREMIUM LF2 (head unit)
Hirschmann	920510A (locking system)
HELLA	DM4 (locking system)
Huf Baolong	TSSRE4A (tire pressure sensor)
Huf Baolong	TSSSG4G6b (tire pressure monitoring system control unit)
MARQUARDT	DC12B (locking system)
MARQUARDT	MS2 (locking system)
Schrader	HSW4T (tire pressure sensor)

United States

Regulatory radio identification

Manufacturer	Model desig- nation	Radio equip- ment approval number
Continental Automotive Technologies	NTG7Q MID LF2 (head unit)	FCC ID: NTG7QMIDLF 2
Continental Automotive Technologies	NTG7Q HIGH LF2 (head unit)	FCC ID: NTG7QHIGLF 2
Continental Automotive Technologies	NTG7Q PRE- MIUM LF2 (head unit)	FCC ID: NTG7QPRELF 2
Hirschmann	920510A (locking system)	FCC ID: XTJ920510A
Huf Baolong	TSSRE4A (tire pressure sensor)	FCC ID: YGOTSSRE4A
Huf Baolong	TSSRE4Uf (tire pressure sensor)	FCC ID: OYGTSSRE4U F
Schrader	HSW4T (tire pressure mon- itoring system control unit)	FCC ID: MRXMC34MA 4

Information on installation clearances Charging unit for the wireless charging of mobile devices (WMI):

This equipment complies with FCC and IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 0 cm (in contact) between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un Environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 0 cm (in contact) de distance entre la source de rayonnement et votre corps. Ce transmetteur ne doit pas être place au même endroit ou utilise simultanément avec un autre transmetteur ou antenne.

Radar sensors:

ARS4-C (ADC), ARS4-B (ADC), ARS4-A (ADC), FR5CPCCF (Bosch), MRR1REAR (Bosch), MRREVO14F (Bosch), LRR3 (Bosch), 77V12BSM (Veoneer), 77V12CRN (Veoneer), MMRV1 (Veoneer)

Radiofrequency radiation exposure Information:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.

Vietnam

Q			
Manufacturer	Model desig- nation	Radio equip- ment approval number	
Bosch	FR5CPCCF (radar sensor)	Mercedes- Benz Vietnam Company Limited	
Bosch	MRR1Rear (radar sensor)	Mercedes- Benz Vietnam Company Limited	
Bosch	MRRe14FCR (radar sensor)	Mercedes- Benz Vietnam Company Limited	
Continental Automotive	MARS Keyless (locking system)	Mercedes- Benz Vietnam Company Limited B074824041 9AF04A2	



Manufacturer	Model desig- nation	Radio equip- ment approval number
HELLA	DM4 (locking system)	Mercedes- Benz Vietnam Company Limited CO20403032 1AF04A3
Hirschmann	920510A (locking system)	C051226112 0AF04A3
Hirschmann	920510A (locking system)	C029018121 8AF04A2 Supplier number: 16833352
MARQUARDT	DC12B (lock- ing system)	Suntech Viet- nam Technol- ogy Company Limited C007621012 1AF04A3
MARQUARDT	MS2 (locking system)	Suntech Viet- nam Technol- ogy Company Limited C007521012 1AF04A3

Information about the specific absorption rate (SAR)

Information on the specific absorption rate

The values have been determined and tested in accordance with Décret n° 2019-1186 regarding the indication of the specific absorption rate of radio-based vehicle components.

Further information and updates are available at the following web address:

https://regulatoryradioinformation.corpinter.net/ vans/us




Information on the specific absorption rate

Vehicle components	SAR value in W/kg	Limit value to be used
ECE DE003 & ECE DE004 compensator	< 0.2 W/kg	2 W/kg
DAI RSE	1.8 W/kg	2 W/kg
D-WMI2020A	0.018 W/kg	4 W/kg
HERMES communication module	< 0.4 W/kg	2 W/kg
RAMSES communication module	0.036 W/kg	2 W/kg
NRCS2P	0.003 W/kg	2 W/kg

Vehicle components	SAR value in W/kg	Limit value to be used
NTG6	0.199 W/kg	4 W/kg
NTG7	0.08 W/kg	2 W/kg
NTG7RSU	0.07 W/kg	2 W/kg
SM-T230NZ tablet PC	0.7 W/kg	4 W/kg
Radio data transmission tele- phone system	0.24 W/kg	2 W/kg


Vehicle identification plate, vehicle identification number (VIN) and engine number

Vehicle identification plate



Depending on the vehicle model, the vehicle identification plate is located on the seat box of the driver's seat or on the B-pillar.


i The data is vehicle-specific and may differ from that shown. Always observe the specifications on your vehicle identification plate.



Vehicle identification plate (example: USA, complete vehicles)

- Vehicle manufacturer
- VIN (vehicle identification number)
- Permissible gross mass

- 4 Permissible gross mass of vehicle combination
- Maximum permissible front axle load
- Maximum permissible rear axle load
- Manufacturing date
- Paint code



Vehicle identification plate (example: USA, incomplete vehicles)


- Vehicle manufacturer
- VIN (vehicle identification number)
- Permissible gross mass
- Permissible gross mass of vehicle combination
- Maximum permissible front axle load
- Maximum permissible rear axle load
- Manufacturing date
- Paint code



Vehicle identification plate (example: Canada, complete vehicles)

- Vehicle manufacturer
- VIN (vehicle identification number)

- Permissible gross mass
- Permissible gross mass of vehicle combination
- Maximum permissible front axle load
- Maximum permissible rear axle load
- Manufacturing date
- Paint code



Vehicle identification plate (example: Canada, incomplete vehicles)

- Vehicle manufacturer
- VIN (vehicle identification number)
- Permissible gross mass
- Permissible gross mass of vehicle combination
- Maximum permissible front axle load
- Maximum permissible rear axle load
- Manufacturing date
- Paint code


The permissible gross mass comprises the vehicle weight, all vehicle occupants, the fuel and the load. The maximum gross axle weight rating is the maximum weight that can be carried by one axle (front or rear axle).

Do not exceed the permissible gross mass or the maximum gross axle weight rating of the front or

The vehicle identification plate may also include the following data:

- Payload
- · Curb weight
- Number of passenger seats

VIN engraved underneath the hood



Engraved VIN (1) is located underneath the hood.

VIN below the windshield



The VIN is also attached as a label on the lower section of the windshield 2.

Emission Control Information label



Example: Emission Control Information label

(i) The data is vehicle-specific and may differ from that shown.

Electric motor number

The engine number is attached to the bottom of the electric motor at the front. Further information can be obtained at a qualified specialist workshop.

Operating fluids and capacities Notes on operating fluids

WARNING Risk of injury due to harmful operating fluids

Operating fluids can be toxic.

- When using, storing and disposing of operating fluids, observe the imprints on the respective original containers.
- Always keep operating fluids in the sealed original container.
- Always keep children away from operating fluids.

ENVIRONMENTAL NOTE Pollution of the environment due to irresponsible disposal of operating fluids

Incorrect disposal of operating fluids can cause considerable damage to the environment.

Dispose of operating fluids in an environmentally responsible manner.

Operating fluids include the following:

- Lubricants
- Coolant
- Brake fluid
- · Windshield washer fluid
- · Climate control system refrigerant

Only use products which have been approved for your vehicle by Mercedes-Benz. Damage caused to the vehicle by using products that have not been approved is not covered by the Mercedes-Benz warranty or goodwill gestures.

You can identify operating fluids approved by Mercedes-Benz by the following labels on the container:

- MB-Freigabe (e.g. MB-Freigabe 325.5)
- MB-Approval (e.g. MB-Approval 325.5)

Further information on approved operating fluids is available from the following sources:

- In the MB Specifications for operating fluids at https://operatingfluids.mercedes-benz.com (with details of specification).
- At a qualified specialist workshop

Additives for approved operating fluids are neither required nor permitted. Additives can cause engine

damage and must therefore not be added to the operating fluids.

Notes on brake fluid

Observe the notes on operating fluids (\rightarrow page 228).

A

WARNING Risk of an accident due to vapor pockets forming in the brake system

The brake fluid constantly absorbs moisture from the air. This lowers the boiling point of the brake fluid. If the boiling point is too low, vapor pockets may form in the brake system when the brakes are applied hard.

This causes the braking effect to be impaired.

Have the brake fluid renewed at the specified intervals.

Have the brake fluid replaced every two years at a qualified specialist workshop.

! NOTE Damage to paint, plastic or rubber by brake fluid

There is a risk of damage to property if brake fluid comes into contact with paint, plastic or rubber.

 If paint, plastic or rubber comes into contact with brake fluid, rinse with water immediately.

Observe the notes on paintwork/matte paintwork care (\rightarrow page 159).

Only use brake fluid approved by Mercedes-Benz in accordance with MB-Freigabe or MB-Approval

Information on brake fluid is available at the following locations:

- In the MB Specifications for operating fluids 331.0 at https://operatingfluids.mercedesbenz.com
- · At a qualified specialist workshop

Coolant

Notes on coolant

Observe the notes on operating fluids $(\rightarrow page 228)$.

WARNING Risk of fire- and injury from antifreeze

If antifreeze comes into contact with hot component parts in the engine compartment, it may ignite.

- Allow the drive system to cool down before you add antifreeze.
- Make sure that no antifreeze spills out next to the filler opening.
- Thoroughly clean the antifreeze from component parts before starting the vehicle.
- ! NOTE Damage caused by incorrect coolant
- Only add coolant that has been premixed with the required antifreeze protection.

Information on coolant is available at the following locations:

- In the MB Specifications for operating fluids 320.1 at https://operatingfluids.mercedesbenz.com
- · At a qualified specialist workshop
- ! NOTE Overheating at high outside temperatures

If an inappropriate coolant is used, the engine cooling system is not sufficiently protected against overheating and corrosion at high outside temperatures.

- Always use coolant approved for Mercedes-Benz.
- Observe the instructions in the MB Specifications for operating fluids320.1.
- **NOTE** Paintwork damage due to coolant
- Do not spill coolant on painted surfaces.

Have the coolant regularly replaced at a qualified specialist workshop.

Note the proportion of anti-corrosion agent/antifreeze in the engine cooling system within the following temperature ranges:

- A minimum of 50 % (antifreeze protection down to about -35°F (-37°C))
- A maximum of 55 % (antifreeze protection down to -49°F (-45°C))

Coolant filling capacity

Missing values were not available at the time of going to press.

Coolant

Model	Capacity
Vehicles with 56 kWh high-voltage battery	About 5.6 gal (21.1 liters)
Vehicles with 81 kWh high-voltage battery	About 5.2 gal (19.6 liters)
Vehicles with 113 kWh high-voltage battery	About 4.9 gal (18.5 liters)

Windshield washer fluid

Notes on windshield washer fluid

Observe the notes on operating fluids (\rightarrow page 228).

WARNING Risk of fire and injury from windshield washer concentrate

Windshield washer concentrate is highly flammable. If it comes into contact with hot components, it may ignite.

- Make sure that windshield washer concentrate is not spilled near to the filler opening.
- NOTE Damage to the exterior lighting due to unsuitable windshield washer fluid

Unsuitable windshield washer fluid may damage the plastic surface of the exterior lighting.

- Only use windshield washer fluid which is also suitable for use on plastic surfaces, e.g. MB SummerFit or MB WinterFit.
- ! NOTE Blocked spray nozzles caused by mixing windshield washer fluids
- Do not mix MB SummerFit and MB WinterFit with other windshield washer fluids.

Do not use distilled or de-ionized water. Otherwise, the fill level sensor may give a false reading.

Information on the windshield cleaning agent

Recommended windshield cleaning agent:

- above freezing point: e.g. MB SummerFit
- below freezing point: e.g. MB WinterFit

Mixing ratio

For the correct mixing ratio, refer to the information on the anti-freeze container.

Mix the washer fluid with windshield cleaning agent all year round.

Filling capacities

Windshield washer system

Washer fluid	5.8 qt (5.5 l)

Refrigerant

Notes on refrigerant

Observe the notes on operating fluids (\rightarrow page 228).

- Your vehicle's climate control system is filled with the refrigerant R134a. The refrigerant R134a contains fluorinated greenhouse gas.
- I NOTE Damage due to incorrect refrigerant or refrigerant compressor oil

If the incorrect refrigerant or refrigerant compressor oil (PAG oil) is used, this can damage the climate control system.

- Use only R-134a refrigerant and the PAG oil approved for your vehicle by Mercedes-Benz.
- Do not mix the approved PAG oil with another PAG oil.

Maintenance work, such as refilling refrigerant or replacing components, may be carried out only by a qualified specialist workshop. All applicable regulations, as well as SAE standard J639, must be adhered to.

Have all work on the climate control system carried out at a qualified specialist workshop.



Example: refrigerant information label

- Symbols for hazard and service information
- Refrigerant capacity

- 3 Applicable standards
- PAG oil part number
- 6 Refrigerant type

Symbols 1 advise you of the following:

- · Potential dangers
- Having maintenance work carried out at a qualified specialist workshop

Vehicle data

Vehicle dimensions

The following section contains important technical data for your vehicle. Your vehicle documents contain further vehicle-specific and equipment-dependent technical data such as vehicle dimensions and weights.

High-voltage battery

Energy content and charging times

	High-voltage battery 81 kWh
Туре	Lithium-ion
Usable energy content	81 kWh
Charging time - Mode 3 at up to 9.6 kW charging power	approx. 9 h 30 min
Charging time - Mode 4 at up to 50 kW charg- ing power	approx. 1 h 7 min
Charging time - Mode 4 (optional) at up to 115 kW charg- ing power	approx. 32 min

Energy content and charging times

	High-voltage battery 113 kWh
Туре	Lithium-ion
Usable energy content	113 kWh

	High-voltage battery 113 kWh
Charging time - Mode 3 at up to 9.6 kW charging power	approx. 12 h 30 min
Charging time - Mode 4 at up to 50 kW charg- ing power	approx. 1 h 33 min
Charging time - Mode 4 (optional) at up to 115 kW charg- ing power	approx. 42 min

Charging time – Mode 3 applies to AC charging from 0% to 100% of the usable battery capacity.

Charging time – Mode 4 applies to DC charging from 10% to 80% of the usable battery capacity.

The charging time depends on battery condition, ambient temperature and charging power. The charging power depends on supply voltage, current and the type of power supply.

The charging time may be extended by the battery calibration function. Observe the notes on calibrating the high-voltage battery (\rightarrow page 152)

Trailer hitch

Notes on the trailer hitch



WARNING Risk of accident due to impermissible attachment of a trailer tow hitch

If you install a trailer tow hitch or other components, the longitudinal frame member is weakened and can break. The trailer may become detached from the vehicle.

There is a risk of an accident.

Only retrofit a trailer tow hitch if permissible.

Observe the notes on trailer operation (\rightarrow page 125).

Retrofitting a trailer hitch is only permissible if a towing capacity is specified in your vehicle documents.

You can obtain further information on the trailer hitch at a qualified specialist workshop.

Mercedes-Benz recommends that you have a trailer hitch retrofitted at an authorized Mercedes-Benz Center.

Only use a trailer hitch which has been tested and specially approved by Mercedes-Benz for your vehicle.

Use only a ball neck that has been approved for your vehicle and for your Sprinter trailer hitch. Notes on the permissible dimensions of the ball neck can also be found on the identification plate of the trailer hitch.

The maximum permissible towing capacity for unbraked trailers is 1,653 lbs (750 kg).

Trailer loads

The permissible weights and loads can also be obtained from the following sources of information:

- Vehicle documents
- The identification plates of the trailer coupling, trailer and vehicle

The values approved by the manufacturer can be found in the following table. If the figures differ, the lowest figure will apply. Use a calibrated weighing device to check compliance with weight restrictions before you start your journey.

Maximum permissible weights and loads Vehicle type, gross vehicle weight and curb weight

Vehicle model	Gross vehicle weight rating (GVWR)	Permissible curb weight ⁷⁾
3500	9900 lbs (4.490 t) (Canada only)	7400 lbs (3.357 t)
	9989 lbs (4.531 t) (USA only)	

Maximum permissible curb weight of a vehicle in ready-to-drive condition without driver or vehicle occupants, including all fluids and their reservoirs when filled up to 100%.

Front axle load, rear axle load, gross weight of vehicle combination (standard, optional) Vehicle type 3500 with a maximum gross vehicle weight rating of 9900 lbs (4.490 t) (Canada only) and 9989 lbs (4.531 t) (USA only)

Permissible front axle load GAWR (FA)	Permissible rear axle load GAWR (RA)
4080 lbs (1.851 t)	7060 lbs (3.202 t)
4410 lbs (2.000 t) 1)	

¹⁾ Front axle with increased load capacity.

Gross vehicle combination weight, trailer load, tongue weight Vehicle type 3500 with a maximum gross vehicle weight rating of 9900 lbs (4.490 t) (Canada only)

Permissible gross weight for vehicle/trailer combination (GCWR) 6), 9)	Gross trailer weight (GTW), braked ⁶⁾	Tongue weight rating (TWR)
15250 lbs (6.917 t) ³⁾	7500 lbs (3.402 t) ³⁾	750 lbs (0.340 t) ³⁾

Vehicle type 3500 with a maximum gross vehicle weight rating of 9990 lbs (4.531 t) (USA only)

Permissible gross weight for vehicle/trailer combination (GCWR) 6), 9)	Gross trailer weight (GTW), braked ⁶⁾	Tongue weight rating (TWR)
15250 lbs (6.917 t) ³⁾	7500 lbs (3.402 t) ³⁾	750 lbs (0.340 t) ³⁾

³⁾ Only NAFTA trailer cross member, towing capacity 7500 lbs (3.400 t).

i If the trailer coupling is retrofitted, adapt the type plates accordingly with the altered maximum permissible weights. Please consult an authorized Mercedes-Benz Center if you have any further questions.

⁶⁾ In trailer operation, do not exceed any individual maximum permissible gross weight of those specified in the table.

⁹⁾ Any vehicle not equipped with a trailer coupling as standard cannot tow a trailer. In this case, the maximum gross vehicle weight rating corresponds to the maximum permissible gross weight for the vehicle combination.

MERCEDES-BENZ AG

IMPORTANT INFORMATION FOR BODY BUILDERS

This vehicle and engine conform to all applicable US EPA, CARB and Canadian regulations at the time of manufacture for vehicles <UO> 10000 lbs GVWR and has a maximum unloaded vehicle weight (UVW) of <UVW> lbs.

INFORMATIONS IMPORTANTES POUR LES CARROSSIERS

Le véhicule et le moteur sont conformes aux directives EPA CARB (E.-U.) et du Canada applicables à la date de production du véhicule ayant un PNBV
 -UD> à 10000 (b) et un poids à vide max. de
 -UV> b

A 907 584 26 0

The bodybuilder label is found on the front-end module above the radiator and contains the vehicle's maximum permissible curb weight.

Cargo tie-down points and carrier systems

Loading capacity of the cargo tie-down point and tie-down eyes

! NOTE Risk of accident if the maximum loading capacity of the cargo tie-down points is exceeded

During maximum full-stop braking, for example, forces act that can multiply the weight force of the load.

- If various cargo tie-down points are combined to secure a load, always take the maximum loading capacity of the weakest cargo tie-down point into account.
- Always use several cargo tie-down points to distribute and spread the load. Distribute the load on the cargo tie-down points evenly.

Rated tensile force is the maximum permissible tensile force.

Further information on the cargo tie-down point and tie-down eyes can be obtained in the "Transporting" section (\rightarrow page 148).

Tie-down eyes

Rated tensile force of tie-down eyes

Tie-down eyes	Rated tensile force
Cargo Van	1798.5 lbf (800 daN)

Loading rails

Rated tensile force of cargo tie-down point in the cargo compartment


Cargo tie-down point	Rated tensile force
Loading rails on cargo floor	1124.0 lbf (500 daN)
Lower loading rail on side wall	449.6 lbf (200 daN)
Upper loading rail on side wall	281.0 lbf (125 daN)

The values specified apply only to loads resting on the cargo floor under the following conditions:

Conditions:

- the load is secured to two cargo tie-down point on the rail
- the distance to the nearest load-securing point on the same rail is approximately 3 ft (1 m).

Information about roof luggage racks



The vehicle center of gravity and the usual driving characteristics as well as the steering and braking characteristics will change.

If you exceed the maximum roof load, the handling as well as steering and braking characteristics are severely affected.

Always comply with the maximum roof load and adjust your driving style.

WARNING Danger of accident due to uneven loading

The driving characteristics, as well as steering and braking characteristics, may be greatly impaired.

- Load the vehicle evenly.
- Secure the load against sliding.

The driving, braking and steering characteristics of the vehicle will change with the type of load, the weight and the center of gravity of the load. ! NOTE Risk of accident if the maximum permissible roof load is exceeded

If the weight of the roof luggage, including the roof luggage rack, exceeds the maximum permissible roof load, there will be a risk of an accident.

- Ensure that the weight of the roof luggage and roof luggage rack does not exceed the maximum permissible roof load.
- The roof luggage rack supports must be arranged at an even distance from each other.

Further information about safety measures can be found in the "Transport" section (\rightarrow page 148).

Max. roof load/pairs of roof luggage rack supports

Vehicles with	Maximum roof load	Minimum number of pairs of sup- ports
Roof	661 lbs (300 kg)	6
High roof	331 lbs (150 kg)	3

This information applies if the load is distributed evenly across the entire roof area.

If the roof luggage rack is shorter, reduce the load proportionately. The maximum load per pair of roof luggage rack supports is 110 lbs (50 kg).

The loading guidelines and other information about load distribution and load securing can be found in the "Transport" section (\rightarrow page 148).

Display messages

Introduction

Function of display messages

Display messages appear on the instrument clus-

The display messages with graphic displays can be displayed in simplified format in the Operator's Manual and may deviate from the display on the instrument cluster. The instrument cluster shows high-priority display messages in red. In addition, a warning tone sounds for specific display messages.

Act in accordance with the display messages and comply with the additional instructions in this Operator's Manual.

In	addition,	symbols	are	shown	for	some	display
m	essages:						

i	Further information	
	Hide display messages	

You can use the left-hand Touch Control to select between the symbols by swiping to the left or right. Pressing i displays further information on the instrument cluster. Pressing hides the display message.

You can hide low-priority display messages by pressing the figure button or with the left-hand Touch Control. The display messages are saved in the message memory.

Rectify the cause of a display message as quickly as possible.

You cannot hide high-priority display messages. The instrument cluster will show these display messages until their causes have been rectified.

Calling up saved display messages

On-board computer:

→ Service → 1 Message

If there are no display messages, No Messages will appear on the instrument cluster display.

- Browse through the display messages by swiping upwards or downwards on the left-hand Touch Control.
- To exit the message memory: press the = button.

Safety systems

Display messages



Left Side Curtain Airbag Malfunction Service Required (example)

Possible causes/consequences and ▶ Solutions

* The respective window air bag is malfunctioning (\rightarrow page 33).

WARNING Risk of injury or fatal injury due to a malfunction in the window curtain airbag

The window curtain airbag might be triggered unintentionally or might not be triggered at all in the event of an accident.

- Have the window curtain airbag checked and repaired immediately at a qualified specialist workshop.
- Consult a qualified specialist workshop immediately.



Front Left Malfunction Service Required (example)

* The corresponding restraint system is malfunctioning (\rightarrow page 28).

WARNING Risk of injury due to malfunctions in the restraint system

Components in the restraint system may be activated unintentionally or not deploy as planned in an accident.

► Have the restraint system checked and repaired immediately at a qualified specialist workshop.

Recognition of a restraint system malfunction:

- The prestraint system warning lamp does not light up when the vehicle is switched on.
- The prestraint system warning lamp lights up continuously or repeatedly during a journey.
- Consult a qualified specialist workshop immediately.



SRS Malfunction Service Required

* The restraint system is malfunctioning (\rightarrow page 28).

WARNING Risk of injury due to malfunctions in the restraint

Components in the restraint system may be activated unintentionally or not deploy as planned in an accident.

► Have the restraint system checked and repaired immediately at a qualified specialist workshop.

Recognition of a restraint system malfunction:

- The restraint system warning lamp " does not light up when the vehicle is switched on.
- The restraint system warning lamp [] lights up continuously or repeatedly during a journey.
- Consult a qualified specialist workshop immediately.

Display messages



Parking Brake Inoperative

Possible causes / consequences and ▶ Solutions

* A malfunction has occurred in the system; the parking brake is inoperative.

WARNING Risk of an accident due to a brake system malfunc-

If the brake system is malfunctioning, braking characteristics may be impaired.

- Drive on carefully.
- ► Have the brake system checked immediately at a qualified specialist workshop.
- Park the vehicle on a level surface only and secure it against rolling away.
- Have the brake system checked at a qualified specialist workshop immediately.



Incline Too Steep See Operator's Manual

* The on-board electrical system voltage is low or a malfunction has occurred in the system; the holding force may not be sufficient for the incline.

WARNING Risk of accident if the electrical parking brake has insufficient holding force

If the electrical parking brake does not have sufficient holding force on a steep incline, the vehicle may roll away.

- Park the vehicle on a level surface only and secure it against rolling away.
- Shift the automatic transmission to position [P].

Observe the notes on parking the vehicle (\rightarrow page 110).



Parking Brake See Operator's Manual

* The on-board electrical system voltage is low or a malfunction has occurred in the system; the closing force may not be sufficient for the incline.

WARNING Risk of an accident due to a brake system malfunc-

If the brake system is malfunctioning, braking characteristics may be impaired.

- Drive on carefully.
- Have the brake system checked immediately at a qualified specialist workshop.
- Park the vehicle on a level surface only and secure it against rolling away.
- Have the brake system checked at a qualified specialist workshop immediately.

Check Brake Pads See Operator's Manual

* The brakepads have reached their wear limit.

Display messages	Possible causes/consequences and ▶ Solutions
	 ★ WARNING Risk of accident due to restricted braking power When the brake pads have reached their wear limit, the braking power may be restricted. ▶ Drive on carefully. ▶ Have the brake system checked immediately at a qualified specialist workshop.
	Consult a qualified specialist workshop.
	* There is insufficient brake fluid in the brake fluid reservoir.
	WARNING Risk of an accident due to low brake fluid level
Check Brake Fluid Level	 If the brake fluid level is too low, the braking effect and the braking characteristics may be impaired. Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances. Consult a qualified specialist workshop. Do not add brake fluid.
	 Stop the vehicle immediately in accordance with the traffic conditions. Do not continue driving! Contact a qualified specialist workshop. Do not add brake fluid.
Active Brake Assist Functions Limited See Operator's Manual	* Active Brake Assist is malfunctioning. Consult a qualified specialist workshop.
Active Brake Assist Functions Currently Limited See Operator's Manual	 * Active Brake Assist is temporarily unavailable. The ambient conditions are outside the system limits (→ page 116). Drive on. When the ambient conditions are within the system limits, the system will be available again. If the display message does not disappear, stop the vehicle in accordance with the traffic conditions and restart it.
Radar Sensors Dirty See Operator's Manual	 * The radar sensor system is malfunctioning. Possible causes: Dirt on the sensors Heavy precipitation Extended country driving without other traffic, e.g. in the desert Driving systems and driving safety systems may be malfunctioning or temporarily unavailable. When the causes have been eliminated, the driving systems and driv-

ing safety systems will be available again.

> Stop in accordance with the traffic conditions.

If the display message does not disappear, proceed as follows:

Display messages	Possible causes/consequences and ▶ Solutions
	Clean all sensors (→ page 159).
	Restart the vehicle.
SOS NOT READY	* The emergency call system is not available.
	Possible causes for this include:
	The vehicle is switched off.
	The emergency call system is malfunctioning.
	Switch on the vehicle. If an emergency call is unavailable, a message to this effect will appear on the instrument cluster.
	Consult a qualified specialist workshop.
	You can find more information on the regional availability of the emergency call system at: http://www.mercedes-benz.com/ connect_ecall
	* EBD, ABS and ESP® are malfunctioning.
FRD	Other driving systems and driving safety systems may also be mal- functioning.
(ABS)	WARNING Risk of skidding if EBD, ABS and ESP® are malfunctioning
Inoperative See Operator's Manual	The wheels may block during braking and ESP® does not perform any vehicle stabilization.
	The steerability and braking characteristics are heavily impaired and the braking distance may increase. In addition, other driving safety systems are switched off.
	Drive on carefully.
	Have the brake system checked immediately at a qualified specialist workshop.
	▶ Drive on carefully.
	Consult a qualified specialist workshop immediately.
	* ESP® is malfunctioning.
2 2	Other driving systems and driving safety systems may also be mal- functioning.
Inoperative See Operator's Manual	The brake system continues working with the normal effect. Braking distance may increase in an emergency braking situation.
	▲ WARNING Risk of skidding if ESP [®] is malfunctioning
	If ESP® is malfunctioning, ESP® cannot carry out vehicle stabilization. In addition, other driving safety systems are switched off.
	Drive on carefully.
	► Have ESP [®] checked at a qualified specialist workshop.
	► Drive on carefully.
	Consult a qualified specialist workshop immediately.

Display messages



Currently Unavailable See Operator's Manual

Possible causes / consequences and ▶ Solutions

* ESP® is temporarily unavailable.

Other driving systems and driving safety systems may also be malfunctioning.

MARNING Risk of skidding if ESP® is malfunctioning

If ESP® is malfunctioning, ESP® cannot carry out vehicle stabilization. In addition, other driving safety systems are switched off.

- Drive on carefully.
- ► Have ESP® checked at a qualified specialist workshop.
- Carefully drive some gentle curves at a speed greater than 19 mph (30 km/h) on a suitable stretch of road.
- If the display message does not disappear, visit a qualified specialist workshop immediately. Drive carefully when doing so.



Currently Unavailable See Operator's Manual

* ABS and ESP® are temporarily unavailable.

Other driving systems and driving safety systems may also be temporarily unavailable.

▲ WARNING Risk of skidding if ABS and ESP® are malfunction-

The wheels may block during braking and $\ensuremath{\mathsf{ESP}}^{\ensuremath{\$}}$ does not perform any vehicle stabilization.

The steerability and braking characteristics are heavily impaired and the braking distance may increase. In addition, other driving safety systems are switched off.

- Drive on carefully.
- Have ABS and ESP® checked immediately at a qualified specialist workshop.
- Carefully drive some gentle curves at a speed greater than 19 mph (30 km/h) on a suitable stretch of road.
- If the display message does not disappear, visit a qualified specialist workshop immediately. Drive carefully when doing so.



Inoperative See Operator's Manual

* ABS and ESP® are malfunctioning.

Other driving systems and driving safety systems may also be malfunctioning.

The brake system continues working with the normal effect. Braking distance may increase in an emergency braking situation.

▲ WARNING Risk of skidding if ABS and ESP[®] are malfunctioning

The wheels may block during braking and ESP® does not perform any vehicle stabilization.

The steerability and braking characteristics are heavily impaired and the braking distance may increase. In addition, other driving safety systems are switched off.

Display messages	Possible causes/consequences and ▶ Solutions
	 Drive on carefully. Have ABS and ESP[®] checked immediately at a qualified specialist workshop.
	Drive on carefully.Consult a qualified specialist workshop immediately.

Driving systems

Display messages	Possible causes/consequences and ▶ Solutions
CRUISE CONTROL Inoperative	* Cruise control is malfunctioning.Consult a qualified specialist workshop.
	* Cruise control has been deactivated.
Off (%)	If a warning tone also sounds, this means cruise control has deactivated itself automatically (\rightarrow page 118).
	* Cruise control cannot be activated as not all activation conditions have been met.
mph	Observe the activation conditions for cruise control (→ page 119).
	* The camera view is restricted. Possible causes:
	Dirt on the windshield in the camera's field of visionHeavy precipitation or fog
/= \	Driving systems and driving safety systems may be malfunctioning or temporarily unavailable.
₩	When the causes have been eliminated, the driving systems and driving safety systems will be available again.
	If the display message does not disappear:
Currently Unavailable Camera View Restricted	Stop in accordance with the traffic conditions.Clean the windshield.
	If necessary, consult a qualified specialist workshop.
	* The radar sensor system is malfunctioning. Possible causes:
	Dirt on the sensors Lleavy presinitation
	 Heavy precipitation Extended country driving without other traffic, e.g. in the desert
OFF	, ,
∂!♂	The following systems may be affected: Active Distance Assist DISTRONIC
Currently Unavailable	 Active distance assist distribution. Blind Spot Assist (→ page 123)
Radar Sensors Dirty	 Active Brake Assist (→ page 123) Active Brake Assist (→ page 116)
	Driving systems and driving safety systems may be malfunctioning or temporarily unavailable.

Display messages	Possible causes/consequences and ▶ Solutions
	When the causes have been eliminated, the driving systems and driving safety systems will be available again.
	If the display message does not disappear:
	Stop in accordance with the traffic conditions.
	Clean all sensors (→ page 159).
	Restart the vehicle.
	If necessary, consult a qualified specialist workshop.
HOLD	* The HOLD function has been deactivated because the vehicle is slipping or an activation condition has not been met.
Off	Reactivate the HOLD function later on or check the HOLD function's activation conditions (→ page 120).
Blind Spot Assist Inoper-	* Blind Spot Assist is malfunctioning (\rightarrow page 123).
ative	Consult a qualified specialist workshop.
Blind Spot Assist Trailer Not Monitored	* When you establish an electrical connection with the trailer, Blind Spot Assist will remain available but the area beside the trailer will not be monitored. The function of Blind Spot Assist may be restricted as a result (→ page 123).
	 Press the left-hand Touch Control and acknowledge the display message.
Blind Spot Assist Cur-	* Blind Spot Assist is temporarily unavailable (\rightarrow page 123).
rently Unavailable See Operator's Manual	The system limits have been reached (\rightarrow page 123).
Operator 3 Manual	 Drive on. When the causes have been eliminated, the system will be available again. or
	If the display message does not disappear, stop the vehicle in accordance with the traffic conditions and restart it.
	If necessary, clean the rear bumper. If the bumper is very dirty, the sensors in the bumper may malfunction.
~	* ATTENTION ASSIST is malfunctioning.
T OFF	Consult a qualified specialist workshop.
Attention Assist Inoperative	
FOFF	 * ATTENTION ASSIST has detected fatigue or increasing inattentiveness on the driver's part (→ page 122). ▶ If necessary, take a break.
Attention Assist: Take a Break!	

Climate control

Display messages	Possible causes/consequences and ▶ Solutions
Pre-entry Climate Con- trol Available Again via Week Profile after Vehi- cle Start	 Pre-entry climate control was activated more than three times during a week profile without a journey taking place. The function has been deactivated in order to conserve energy. Start the vehicle for ten seconds. Pre-entry climate control is operational again.
Pre-entry Climate Con- trol Available Again via SmartKey after Vehicle Start	 You have attempted to switch on pre-entry climate control more than three times with the engine switched off. Let the vehicle run for ten seconds. Pre-entry climate control is operational again.
Currently unavailable High-voltage battery charging not completed	 * The high-voltage battery is charging. Pre-entry climate control cannot be switched on. Wait until the charging process has achieved a minimum charge.
Currently unavailable Charge high-voltage battery	 * The high-voltage battery's state of charge is too low. Pre-entry climate control cannot be switched on. ▶ Charge the high-voltage battery (→ page 102).
Pre-Entry Climate Ctrl. (Via SmartKey) Inopera- tive HV Battery Low	 * The high-voltage battery's state of charge is too low. Pre-entry climate control cannot be switched on. ▶ Charge the high-voltage battery (→ page 102). When the high-voltage battery is sufficiently charged, pre-entry climate control will be operational again.

Drive system

Display messages	Possible causes/consequences and ▶ Solutions
Battery calibration required AC charging at state of charge: max. XXX% Outside tempera- ture: min. XX°C	 * The high-voltage battery is not calibrated. ▶ Calibrate the high-voltage battery (→ page 152).
To guarantee max. range, carry out battery calibration Begin charg- ing process up to 100%	 * The high-voltage battery is not calibrated. ▶ Calibrate the high-voltage battery (→ page 152).

Display messages	Possible causes/consequences and ▶ Solutions
To guarantee max. range, carry out battery calibration Charging time extension: X min Begin AC charging up to 100%	 * The high-voltage battery is not calibrated. ▶ Calibrate the high-voltage battery (→ page 152).
High-volt. Bat. Overheat. Stop, everyone out! Outside if Poss.	 * The high-voltage battery has overheated. There is a risk of fire. Stop the vehicle immediately in accordance with the traffic conditions. If possible, park the vehicle in the outdoors and make sure that all occupants exit the vehicle. Do not drive on. If smoke develops, leave the danger zone and call the fire service immediately. Consult a qualified specialist workshop even if there are no external signs of a fire.
High-volt. Bat. Overheated Stop now, outside if poss.	 * The high-voltage battery has overheated. There is a risk of fire. Stop the vehicle immediately in accordance with the traffic conditions. If possible, stop the vehicle in the open air and ensure that all vehicle occupants get out. Do not drive on. If smoke is present, leave the danger zone and call the fire service immediately. Consult a qualified specialist workshop even if there are no external signs of a fire.
High-voltage battery maintenance urgently required. Do Not Restart And Consult Dealer	 * The high voltage battery has reached the end of its service life. (→ page 152). Do not switch off the drive system. If you do, a restart will generally not be possible. ► Have the necessary maintenance work on the high-voltage battery carried out at a qualified specialist workshop.
Note the range. Visit a workshop.	 * A battery from the battery pack is malfunctioning. > Consult a qualified specialist workshop. > Note the changed range.
Note the range	 * The useful capacity of the high-voltage battery system has changed. Note the changed range that is displayed.
Charger Cable Connected	* You cannot pull away while the charging cable is connected. Disconnect the charging cable from the vehicle.

Dianlas manages	Descible severe (severe and N. Calutions
Display messages	Possible causes/consequences and ► Solutions
Reserve Level Charge High-Voltage Battery	 * The charge level of the high-voltage battery has reached the reserve level. ▶ Charge the high-voltage battery (→ page 102).
_ = 1	* The drive system is malfunctioning.
Towing Not Permitted See Operator's Manual	 Have the vehicle transported only using a transporter or trailer (→ page 167).
Reduced Drive System Performance See Opera-	* The drive system is outside the operating temperature range, e.g. due to extreme outside temperatures.
tor's Manual	Drive system power output is reduced.
	 Drive on carefully. Once the operating conditions return to normal, the full output will be available again.
	* The high-voltage battery is not charged sufficiently.
	Drive system power output is reduced.
	Drive on carefully.
	ightharpoonup Charge the high-voltage battery immediately ($ ightharpoonup$ page 102).
	* If the drive system power output is still reduced, there is a malfunction in the drive system.
	Drive on carefully.
	Consult a qualified specialist workshop.
[- <u>i</u> +]	 * The drive system is malfunctioning. A warning tone also sounds. Consult a qualified specialist workshop.
Malfunction	* There is a serious malfunction if the display message and warning tone are repeated at short intervals. You must stop the vehicle immediately in accordance with the traffic conditions because the drive system is automatically deactivated.
	Stop the vehicle immediately in accordance with the traffic conditions.
	Switch off the vehicle and consult a qualified specialist workshop.
- 1	* In addition, the indicator lamp on the instrument cluster lights up.
	The 12 V battery is no longer being charged.
s. Operating Instructions	Stop immediately in accordance with the traffic conditions and switch off the drive system.
	Secure the vehicle against rolling away (\rightarrow page 110).
	Do not drive on.
	Consult a qualified specialist workshop.

Display messages	Possible causes/consequences and ▶ Solutions
Stop Immediately Drive will be deactivated Charge high-voltage battery	 * The charge level of the high-voltage battery is so low that driving is no longer possible. ▶ Park the vehicle and charge the high-voltage battery (→ page 102).
Malfunction Consult a workshop	 * There are malfunctions in the drive and/or cooling system. Consult a qualified specialist workshop.
Do Not Restart Vehicle Service Required	 * A malfunction has occurred in the high-voltage on-board electrical system. A warning tone also sounds. Do not switch off the drive system. Consult a qualified specialist workshop immediately.
Stop Switch Engine Off	 * There is a serious malfunction in the drive system. A warning tone also sounds. > Stop the vehicle immediately in accordance with the traffic conditions. Do not continue driving! > Consult a qualified specialist workshop immediately.
Acoustic Presence Indicator Inoperative	 * The sound generator (acoustic vehicle alerting system) is malfunctioning. No driving noises are being produced. As a result, your vehicle may not be heard by other road users in certain situations. Drive with particular care. Consult a qualified specialist workshop.

Tires

Display messages	Possible causes/consequences and ➤ Solutions
Tire Pressure Monitor Inoperative No Wheel Sensors	 * The wheels installed do not have suitable tire pressure sensors. The tire pressure monitoring system is deactivated. Install wheels with suitable tire pressure sensors.
Wheel Sensor(s) Missing	 * There is no signal from the tire pressure sensor of at least one tire. No pressure value is displayed for the tire in question. Have the faulty tire pressure sensor replaced at a qualified specialist workshop.
Tire Press. Monitor Currently Unavailable	* There is interference from a powerful radio signal source. As a result, no signals from the tire pressure sensor are received. The tire pressure monitoring system is temporarily unavailable.
	Drive on. The tire pressure monitoring system will restart automatically as soon as the cause has been rectified.

Display messages Possible causes/consequences and ▶ Solutions * The tire pressure in one or more tires has dropped suddenly. The wheel position is shown. **WARNING** Risk of an accident from driving with a flat tire Warning Tire Malfunction • The tires can overheat and cause a fire. • The driving characteristics as well as the steering and braking may be greatly impaired. You could then lose control of the vehicle. Do not drive on with a flat tire. Observe the notes on flat tires. Information about flat tire (\rightarrow page 165). Stop the vehicle in accordance with the traffic conditions. Check the tires. * The tire pressure in one or more tires has dropped significantly. The wheel position is shown. WARNING Risk of an accident due to insufficient tire pressure · The tires can burst. • The tires can wear excessively and/or unevenly. . The driving characteristics as well as the steering and braking may be greatly impaired. You could then lose control of the vehicle. Observe the recommended tire pressures. Adjust the tire pressure if necessary. Stop in accordance with the traffic conditions. Check the tire pressure (\rightarrow page 176) and the tires. * The tire pressure is too low in at least one tire, or the difference in tire pressure between the individual wheels is too great. Check the tire pressure, and add air if necessary. Please Correct Tire Pres-When the tire pressure has been set correctly, re-start the tire sure pressure monitoring system (\rightarrow page 180). Tire Pressure Monitor * The tire pressure monitoring system is malfunctioning. Inoperative Consult a qualified specialist workshop.

Key

Display messages Possible causes/consequences and > Solutions * This message reminds you not to leave your key in the vehicle. Take the key with you when you get out of the vehicle. Don't Forget Your Key

Display messages	Possible causes/consequences and ▶ Solutions
Place Key in Marked Space See Operator's Manual	 * Key detection is malfunctioning. ▶ Change the key's position in the vehicle. ▶ Start the vehicle with the key in the marked space (→ page 93).
Key Not Detected (red display message)	 * The key is not detected and may no longer be in the vehicle. The key is no longer in the vehicle and you switch off the vehicle: You can no longer start the vehicle. You cannot lock the vehicle centrally. Ensure that the key is in the vehicle. If the key detection function is malfunctioning due to a strong radio signal source, proceed as follows: Stop the vehicle immediately in accordance with the traffic conditions. Place the key in the slot for starting with the key (→ page 93).
Key Not Detected (white display message)	 * The key is currently not detected. Change the key's position in the vehicle. If the key is still not detected, start the vehicle with the key in the slot (→ page 93).
Replace Key Battery	 * The key battery is flat. ▶ Replace the battery (→ page 39).
Obtain a New Key	 * The key needs to be replaced. Consult a qualified specialist workshop.

Vehicle

Display messages	Possible causes/consequences and ▶ Solutions
Air Con. Energy Saving Mode Activ.	* The air-conditioning energy-saving mode is active (\longrightarrow page 83)
Socket flap open	* The socket flap is open.Close the socket flap.
Refill Washer Fluid	 * The washer fluid level in the washer fluid reservoir has dropped below the minimum. ▶ Add washer fluid (→ page 157). If the display message still appears: ▶ Consult a qualified specialist workshop.

Display messages	Possible causes/consequences and ▶ Solutions
	* At least one door is open. Close all the doors.
	* The hood is open.
	WARNING Risk of accident due to driving with the hood unlocked
	The hood may open and block your view. Never release the hood when driving. Before every trip, ensure that the hood is locked.
	Stop the vehicle immediately in accordance with the traffic conditions.Close the hood.
	* The steering power assistance is malfunctioning.
Steering Malfunction	★ WARNING Risk of an accident due to altered steering characteristics
Increased Physical Effort See Operator's Manual	If the power assistance of the steering fails partially or completely, you will need to use more force to steer. If safe steering is possible, drive on carefully. Visit or consult a qualified specialist workshop immediately.
	If safe steering is possible, drive on carefully.Visit or consult a qualified specialist workshop immediately.
	* The steering is malfunctioning. Steerability is heavily impaired.
	▲ WARNING Risk of accident if steering capability is impaired
Steering Malfunction Stop Immediately See Operator's Manual	If the steering does not function as intended, the vehicle's operating safety is jeopardized. Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances. Consult a qualified specialist workshop.
	 Stop the vehicle immediately in accordance with the traffic conditions. Do not continue driving! Contact a qualified specialist workshop.
Shift to 'P' or 'N' to Start Engine	 You have attempted to start the vehicle in drive range D or R. Select drive range P or N.
To Engage Transmiss. Position R First Depress the Brake	 You have attempted to shift from position D or N to position R. Depress the brake pedal. Shift the transmission to position R.

Display messages	Possible causes/consequences and ▶ Solutions
Auxiliary Battery Mal- function	 * The auxiliary battery for the transmission is no longer being charged. Consult a qualified specialist workshop. Until then, always shift the transmission to position P manually before you switch off the engine. Before leaving the vehicle, apply the parking brake.
Reversing Not Possible: Service Required	 * The transmission is malfunctioning. It is no longer possible to select reverse gear. Consult a qualified specialist workshop.
Vehicle Operational Switch the Ignition Off Before Exiting	* You are about to exit the vehicle when it is in a ready-to-drive state. When you exit the vehicle, switch off the vehicle and take the key with you.
Do Not Change Trans- mission Position Service Required	 * The transmission is malfunctioning or there is a malfunction in the high-voltage on-board electrical system. If transmission position is selected, consult a qualified specialist workshop and do not change the transmission position. For all other transmission positions, park the vehicle in a safe location. Inform a qualified specialist workshop or breakdown service.
Only Shift to 'P' when Vehicle is Stationary	* The transmission can be shifted to position $\boxed{\textbf{P}}$ only when the vehicle is at a standstill.
To Deselect P or N, Depress Brake and Start Engine	 You have attempted to shift out of drive range P or N into another drive range. Depress the brake pedal. Start the drive system.
Apply Brake to Shift from 'P'	 You have attempted to shift out of drive range P and into another drive range. Depress the brake pedal.
N Permanently Active Risk of Rolling Away	 * Drive range N has been selected while the vehicle is rolling or being driven. To stop, depress the brake pedal and engage drive range P while the vehicle is stationary. To continue your journey, select drive range D or R.
Risk of Rolling Driver's Door Open and Transmis- sion Not in P	 * The driver's door is not fully closed and drive range R, N or D is selected. When you park the vehicle, select drive range P and additionally secure the vehicle using the parking brake.
Risk of rolling, driver's seat not occupied and transmission not in P	* Driver's seat detection does not detect a person on the driver's seat and drive range $[R]$, $[N]$ or $[D]$ is selected.

Display messages	Possible causes/consequences and ▶ Solutions
	When you park the vehicle and leave the driver's seat, select drive range P and additionally secure the vehicle using the parking brake.
Veh. Tracking Activated See Op. Manual or mobile app	 * The vehicle has activated services from Mercedes me at its disposal. Locating the vehicle may be possible using Mercedes me connect. Check the status of the activated services at http://mercedes.me. Ask the vehicle owner for the details. Vehicles with MBUX and navigation: deactivate Vehicle Tracker via the system settings.
Transmission Malfunction: Stop Vehicle	 * The transmission is malfunctioning. The transmission automatically shifts to position N. Stop the vehicle immediately in accordance with the traffic conditions. Shift the transmission to position P. Consult a qualified specialist workshop.

Lights

Display messages	Possible causes/consequences and ➤ Solutions
Adaptive Highbeam Assist Camera View Restricted See Opera- tor's Manual	 * The camera view is restricted. Possible causes: dirt on the windshield in the camera's field of vision heavy precipitation or fog
	Driving systems and driving safety systems may be malfunctioning or temporarily unavailable.
	When the causes have been eliminated, the driving systems and driving safety systems will be available again.
	If the display message does not disappear:
	Stop in accordance with the traffic conditions.
	Clean the windshield.
Adaptive Highbeam Assist Currently Unavail- able See Operator's Man- ual	 * Adaptive Highbeam Assist is temporarily unavailable. The system limits have been reached (→ page 71). ▶ Drive on. When the causes have been eliminated, the system will be available again. The display message Adaptive Highbeam Assist Now Available appears.
Adaptive Highbeam Assist Inoperative	 * Adaptive Highbeam Assist is malfunctioning. Consult a qualified specialist workshop.
Switch On Headlamps	* You are driving without low beam. Turn the light switch to the D position. or Turn the light switch to the AUTO position.

Display messages	Possible causes/consequences and ▶ Solutions
Switch Off Lights	* You are leaving the vehicle and the light is still switched on. Turn the light switch to the AUTO position.
AUTO Lamp Function Inoperative	 * The light sensor is malfunctioning. Consult a qualified specialist workshop.
Malfunction See Operator's Manual	 * The exterior lighting is malfunctioning. ▶ Consult a qualified specialist workshop. * Vehicles with trailer hitch: a fuse may have blown. ▶ Stop in accordance with the traffic conditions. ▶ Check the fuses, and replace them if necessary(→ page 170).
Low Beam Left (example)	 * The corresponding light source is defective. Consult a qualified specialist workshop. or Check whether changing the bulb is permitted.

Indicator and warning lamps


Overview of indicator and warning lamps

Some systems will perform a self-test when the vehicle is switched on. Some indicator and warning lamps may briefly light up or flash. This behavior is non-critical. These indicator and warning lamps indicate a malfunction only if they light up or flash after the vehicle has been started or during a journey.

F

Indicator an	d warning lamps:
■ D	Low beam (→ page 68)
- 200 -	Standing lights (→ page 68)
≣D	High beam (→ page 69)
\$	Turn signal lights (\rightarrow page 69)
0\$	Rear fog light (→ page 68)
*	Seat belt not fastened (\rightarrow page 258)
BRAKE and	USA: Brakes (red) (→ page 253)
(())	Canada: Brakes (red) (→ page 253)
(())	Brakes (yellow) (→ page 253)
(as)	ABS malfunction (\rightarrow page 253)

 $ESP^{\mathbb{R}}$ (\rightarrow page 253)



Safety systems

Warning/indicator lamp



and



Electric parking brake applied red indicator lamp (USA) does not light up



Electric parking brake applied red indicator lamp (Canada) does not light



Electric parking brake malfunctioning yellow indicator lamp lights up

Possible causes/consequences and ▶ Solutions

*Vehicles with electric parking brake: the red electric parking brake indicator lamp does not light up. The yellow electric parking brake indicator lamp lights up.

Meaning of the indicator lamps:

- The red indicator lamp does not light up: the electric parking brake has been released.
- The yellow indicator lamp lights up: the electric parking brake is malfunctioning.
- Note the messages on the instrument cluster.
- Switch the vehicle off and on.
- If the fault message persists, consult a qualified specialist work-
- Park the vehicle only on level ground and secure it against rolling away (\rightarrow page 111).





Red electric parking brake applied indicator lamp (USA) lights up



Red electric parking brake applied indicator lamp (Canada) lights up



Electric parking brake malfunctioning yellow indicator lamp lights up *Vehicles with electric parking brake: the red and yellow electric parking brake indicator lamps light up.

Meaning of the indicator lamps:

- The red electric parking brake indicator lamp lights up: the electric parking brake has been applied.
- The yellow electric parking brake indicator lamp lights up: the electric parking brake is malfunctioning.
- Note the messages on the instrument cluster.
- Switch the vehicle off and on.
- If the fault message persists, consult a qualified specialist workshop.
- If it is not possible to release the electric parking brake, do not drive the vehicle.



and



Red electric parking brake applied indicator lamp (USA) flashes



Red electric parking brake applied indicator lamp (Canada) flashes



Electric parking brake malfunctioning vellow indicator lamp lights up

Possible causes/consequences and ▶ Solutions

*Vehicles with electric parking brake: the red electric parking brake indicator lamp flashes. The yellow electric parking brake indicator lamp lights up.

Meaning of the indicator lamps:

- The red electric parking brake indicator lamp flashes: the activation status of the electric parking brake is unknown.
- The yellow electric parking brake indicator lamp lights up: the electric parking brake is malfunctioning.
- Note the messages on the instrument cluster.
- Switch the vehicle off and on.
- Engage and release the electric parking brake using the switch while depressing the brake pedal.
- If the fault message persists, park the vehicle on level ground and secure it against rolling away (\rightarrow page 111).
- Consult a qualified specialist workshop.
- Do not drive the vehicle when the red indicator lamp is flashing, as the brake system may overheat.



and



Red electric parking brake applied indicator lamp (USA) lights up



Red electric parking brake applied indicator lamp (Canada) lights up



The electric parking brake malfunctioning yellow indicator lamp does not light up

*Vehicles with electric parking brake: the electric parking brake red indicator lamp lights up. The electric parking brake yellow indicator lamp does not light up.

Meaning of the indicator lamps:

- The electric parking brake red indicator lamp lights up: the electric parking brake has been applied.
- The electric parking brake yellow indicator lamp does not light up: there are no faults with the electric parking brake.
- Do not drive the vehicle if the electric parking brake has been applied.





and



Red parking brake applied indicator lamp (USA) lights up



Red parking brake applied indicator lamp (Canada) lights up

Possible causes / consequences and ▶ Solutions

*Vehicles with manual parking brake: the parking brake red indicator lamp lights up.

Meaning of the indicator lamp:

- The parking brake red indicator lamp lights up: the parking brake has been applied.
- Do not drive the vehicle if the parking brake has been applied.



Brake system warning lamp (yellow)

*The yellow brakes warning lamp lights up while the vehicle is switched on.

WARNING Risk of an accident due to a brake system malfunc-

If the brake system is malfunctioning, braking characteristics may be impaired.

- Drive on carefully.
- Have the brake system checked immediately at a qualified specialist workshop.
- Drive on carefully at an adjusted speed and at a sufficient distance from the vehicle in front.
- If the instrument cluster shows a display message, comply with it.
- Consult a qualified specialist workshop.



and



Brake warning lamp (red) (USA)



Brake warning lamp (red) (Canada)

*The red brakes warning lamp lights up while the vehicle is on. Possible causes:

- The brake force boosting is malfunctioning.
- The EBD (electronic brake force distribution) is malfunctioning.
- There is insufficient brake fluid in the brake fluid reservoir.

WARNING Risk of accident and injury if brake force boosting is malfunctioning

If brake force boosting is malfunctioning, increased brake pedal force may be necessary for braking. The braking characteristics may be impaired. The braking distance can increase in emergency braking situations.

- Stop in a safe location immediately. Do not continue driving.
- Consult a qualified specialist workshop.

Possible causes / consequences and ▶ Solutions

WARNING Risk of an accident if the EBD (electronic brake force distribution) malfunctions

If the EBD malfunctions, the wheels may lock during braking. The braking characteristics may be impaired.

The braking distance can increase in emergency situations.

- Stop in a safe location immediately. Do not continue driving.
- Consult a qualified specialist workshop.

WARNING Risk of an accident due to low brake fluid level

If the brake fluid level is too low, the braking effect and the braking characteristics may be impaired.

- Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances.
- Consult a qualified specialist workshop.
- Do not add brake fluid.
- Stop the vehicle immediately in accordance with the traffic conditions. Do not continue driving!
- Consult a qualified specialist workshop.



and



Brake warning lamp (red) (USA)

*Only in the USA: The brake system red warning lamp lights up while the engine is on.

Possible cause:

The brakepads have reached their wear limit.

WARNING Risk of accident due to restricted braking power

When the brake pads have reached their wear limit, the braking power may be restricted.

- Drive on carefully.
- Have the brake system checked immediately at a qualified specialist workshop.
- Drive on carefully.
- Consult a qualified specialist workshop immediately.



Restraint system warning lamp

*The red restraint system warning lamp is on while the vehicle is switched on.

The restraint system is malfunctioning.

WARNING Risk of injury due to malfunctions in the restraint system

Components in the restraint system may be activated unintentionally or not deploy as planned in an accident.

► Have the restraint system checked and repaired immediately at a qualified specialist workshop.



Warning/indicator lamp	Possible causes/consequences and ▶ Solutions
	 Detection of a restraint system malfunction: The restraint system warning lamp does not light up when the vehicle is switched on. The restraint system warning lamp lights up continuously or repeatedly during a journey. Drive on carefully. Note the messages on the instrument cluster. Consult a qualified specialist workshop immediately.
ESP® warning lamp lights up	*The yellow ESP® warning lamp lights up while the vehicle is switched on. ESP® is malfunctioning and/or has been deactivated automatically. Other driving systems and driving safety systems may also be malfunctioning.
	▲ WARNING Risk of skidding if ESP [®] is malfunctioning
	If ESP® is malfunctioning, ESP® cannot carry out vehicle stabilization. In addition, other driving safety systems are switched off. Drive on carefully. Have ESP® checked at a qualified specialist workshop. Drive on carefully. Note the messages on the instrument cluster.
	Consult a qualified specialist workshop.
ESP® warning lamp flashes	*The ESP® yellow warning lamp flashes during a journey. ESP® intervenes (→ page 115). Adapt your driving style to the weather and road conditions.
2	*The yellow ESP® OFF warning lamp lights up while the vehicle is on. ESP® has been switched off by the driver.
ESP® OFF warning lamp	▲ WARNING Risk of skidding when driving with ESP [®] deactivated
	ESP® does not act to stabilize the vehicle. The availability of further driving safety systems is also limited. Drive on carefully. Deactivate ESP® only for as long as the situation requires. If ESP® cannot be activated, ESP® is malfunctioning. Have ESP® checked immediately at a qualified specialist workshop.
	ightharpoonup Comply with instructions to switch ESP® off ($ ightharpoonup$ page 115).



ABS warning lamp

Possible causes/consequences and ▶ Solutions

*The yellow ABS warning lamp lights up while the vehicle is switched on. ABS is malfunctioning.

If an additional warning tone sounds, this means the EBD is malfunctioning.

Other driving systems and driving safety systems may also be malfunctioning.

WARNING There is a risk of skidding if EBD or ABS is malfunctioning

The wheels may lock during braking.

The steerability and braking characteristics are heavily impaired and the braking distance may increase. In addition, other driving safety systems are switched off.

- Drive on carefully.
- Have the brake system checked immediately at a qualified specialist workshop.
- Drive on carefully.
- Note the messages on the instrument cluster.
- Consult a qualified specialist workshop.

Seat belt

Warning/indicator lamp



Seat belt warning lamp flashes

Possible causes/consequences and ▶ Solutions

*The red seat belt warning lamp flashes and an intermittent warning tone sounds.

The driver or front passenger does not have their belt on while the vehicle is in motion (speeds above 15 mph (25 km/h)).

Put on the seat belt (→ page 27).

There are objects on the front passenger seat.

Remove the objects from the front passenger seat.



Seat belt warning lamp lights up

*The red seat belt warning lamp lights up after the vehicle has started.

A warning tone may also sound.

When the vehicle is stationary: the seat belt warning lamp reminds drivers and front passengers to put on their seat belt.

 \triangleright Put on the seat belt (\rightarrow page 27).

Objects on the front passenger seat may prevent the seat belt warning lamp from going out.

Driving systems

Warning/indicator lamp



Warning lamp for distance warning function

Possible causes/consequences and ▶ Solutions

*The red distance warning lamp lights up while you are driving and a warning tone sounds.

You are approaching an obstacle at too high a speed.

- Be ready to apply the brakes immediately.
- Increase the distance.

Vehicle

Warning/indicator lamp



Electric power steering warning lamp (red)

Possible causes/consequences and ▶ Solutions

*The red power steering warning lamp lights up while the vehicle is switched on.

The power steering assistance or the steering itself is malfunctioning.



WARNING Risk of accident due to impaired steering ability

If the steering no longer functions as intended, the operational safety of the vehicle is at risk.

- Consult a qualified specialist workshop.
- Note the messages on the instrument cluster display.

Drive system

Warning/indicator lamp



System malfunction warning lamp

Possible causes/consequences and ▶ Solutions

*The red system error warning lamp is lit while the vehicle is in a state of operational readiness READY.

There is a malfunction in the drive system.

Note the messages on the driver display and the instrument cluster display.



Reduced warning lamp power

- * The yellow reduced power warning lamp is lit. Drive system power output is reduced.
- Note the messages on the instrument cluster display.



Electrical malfunction warning lamp

- *The red electrical malfunction warning lamp lights up. A malfunction has occurred in the electrical system.
- Note the messages on the instrument cluster display.



High-voltage battery reserve

*The yellow warning lamp for the charge level of the high-voltage battery

The state of charge of the high-voltage battery has reached the reserve level.

Charge the high-voltage battery (→ page 102).



High-voltage battery warning

Possible causes/consequences and ▶ Solutions

*The red warning lamp lights up while the drive system is on.
There is a malfunction in the drive system.

ΩI

The high-voltage battery's condition of charge is too low.

Note the messages on the instrument cluster display.

Tires

Warning/indicator lamp



Tire pressure monitoring system warning lamp flashes

Possible causes/consequences and ▶ Solutions

*The yellow tire pressure monitoring system warning lamp (pressure loss/malfunction) flashes for approximately one minute and then remains lit.

The tire pressure monitoring system is malfunctioning.

A

WARNING There is a risk of an accident if the tire pressure monitoring system is malfunctioning

The tire pressure monitoring system cannot issue a warning if there is pressure loss in one or more of the tires.

Tires with insufficient tire pressure may impair the driving characteristics as well as steering and braking.

- Have the tire pressure monitoring system checked at a qualified specialist workshop.
- Consult a qualified specialist workshop.



Tire pressure monitoring system warning lamp lights up

*The yellow tire pressure monitoring system warning lamp (pressure loss/malfunction) lights up.

The tire pressure monitoring system has detected a loss of pressure in at least one tire.

MARNING Risk of an accident due to insufficient tire pressure

- The tires can burst.
- The tires can wear excessively and/or unevenly.
- The driving characteristics as well as the steering and braking may be greatly impaired.

You could then lose control of the vehicle.

- Observe the recommended tire pressures.
- Adjust the tire pressure if necessary.
- Stop the vehicle in accordance with the traffic conditions.
- Check the tire pressure and the tires.

1, 2, 3	Assistance system114
3-zone automatic climate control (con-	Assistant display (on-board computer) 134
trol panel)84	ASSYST PLUS, After-sales service cen-
	ter, Service, Service interval display,
A	Vehicle maintenance Battery disconnection periods 152
A/C function	Displaying the service due date 152
ABS	Function/notes 152
Accident and Breakdown Management	Regular maintenance work 152
Mercedes me connect	Special service requirements 152
Acoustic presence indicator 90	Attachments
Active Brake Assist	ATTENTION ASSIST
Function	Function
Setting	Switching on/off
Active Lane Keeping Assist Activating/deactivating	Attention assistant
Adaptive Highbeam Assist	Audio settings (audio system) Balance/fader143
Function	Balance/fader
Switching on/off	Playback options
Adding fluid to the windshield washer	Resetting
system	Audio system
Adjusting the lights (driving abroad) 68	Activating/deactivating 142
Adjusting the volume (audio system) 142	Adjusting the volume
Air bag	Bluetooth [®] audio device playback 144 Controls playback 145
Inflating	Controls playback
Overview 33	Notes
Warning lamp 28	Operating unit
Air vents	Overview
Adjusting (front) 87	Resetting
Air-recirculation mode 86	Setting the time
Alarm system	Showing the software version
Animals	USB playback
Anti-lock braking system 114	Authorised workshop
Anti-skid chain	Automatic climate control
Anti-theft alarm system	Automatic driving lights
Activating/deactivating 52	Automatic locking
Activating/deactivating interior pro-	after closing the last door
tection	Automatic measures after an accident 29
Function	Available power display
Stopping the alarm	Axle load
Switching the tow-away alarm on/off 53	Axie loau
Tow-away alarm 53	В
Anti-theft protection	Back support, Lumbar support 60
Immobilizer 52	Backing up lamp
Apps, Mercedes me	Replacing light sources
Mercedes me connect	BAS
Ashtray	Basic information
ASR (acceleration skid control) 114	Dasio IIIIOIIIIatioII

Battery, 12 V battery, Vehicle battery	Brake Assist System 1	1 /
Charging		
Charging the 12 V battery of the on-		228
board electrical system	Brakeforce Distribution 1	16
Disconnecting the auxiliary battery	Braking assistance 1	14
(front passenger seat) 167	Breakdown	
High-voltage battery 166	Changing a wheel 1	90
Jump-starting (vehicle) 167	Overview of assistance	12
Key	Roadside Assistance	16
Notes (vehicle battery) 165	Tow-starting 1	70
Replacing the 12 V on-board electri-		69
cal system battery 167	8	68
Battery calibration	Transporting the vehicle 1	69
Menu (on-board computer) 135	Breaking-in notes	94
Belt	Bulbs	73
Adjusting the height27	Buttons (steering wheel)	
Fastening 27	buttons (steering wheel)	υZ
Notes on wearing correctly 27	C	
Unfastening 33		
Blind Spot Assist	Calibration	
Function 123	Automatically calibrating the high- voltage battery 1	53
Switching on/off 124	High-voltage battery (on-board com-	JU
Bluetooth®		35
Connecting a mobile phone 146	Manually calibrating the high-volt-	00
Bluetooth® (audio system)		54
Activating/deactivating	Notes on calibrating the high-volt-	٠.
		52
Bluetooth® audio device (audio system)	Call list	
Starting playback 144		47
Bodies (body/equipment mounting	Calls, Telephone operation	
directives)		46
Bottle holder 65	1 0	47
Brake		46
ABS (anti-lock braking system) 114	0	46
Activating/deactivating the HOLD	0	47
function 120		46
Active Brake Assist 116		46
BAS (Brake Assist System) 114		37
Braking with parking brake 96	Car key	38
Breaking-in notes	Car wash (care)1	58
Downhill gradient		50
Driving instructions	Carwach	E 0
EBD (Electronic Brakeforce Distribution)		58 59
,		58
Heavy/light loads		59
Limited braking effect (salt-treated	0	59
roads)96		59
New brake disks/brake linings 96		58
new brake linings/brake disks		59
Post-collision brake	•	59
Recuperation 91		59
Wet road surfaces 96	,	

Cargo compartment lamp (motion detector)	72	Securing to the front passenger seat with the seat belt	. 37
Cargo compartment ventilation		The most important information in	
Cargo tie-down point		brief	. 34
	200	Children	
Cargo tie-down points Overview	150	Avoiding dangers in the vehicle	
	150	Basic instructions	
Cargo tie-down rings Loads	233	Special seat belt retractor	
	233	Cigarette lighter	65
Carpet Cleaning	160	Clean varnish	159
	100	Cleaning	
Central locking system Button	41	Paint	159
		Vehicle interior	160
Change of address	16	Washing by hand	158
Change of ownership	16	Climate control	
Changing a wheel		A/C function	
8	193	Activating/deactivating	
Lowering the vehicle	193	Air distribution settings Air vents (front)	
Preparing		Air-recirculation mode	
Raising the vehicle Removing a wheel	191	Automatically regulating	
	172	Cargo compartment ventilation	
Changing bulbs	74	(roof ventilator)	87
High beam		Clearing fogged up windows	. 86
Indicator (front) Low beam		Control panel for 3-zone automatic	
Characteristics of the tire		climate control	. 84
		Control panel for dual-zone auto-	0.0
Charge level display 103,	132	matic climate control	
Charge level/charge display	103	Energy-saving use Notes	
Charging		Pre-entry climate control	
At departure time	104	Refrigerant	
Battery	167	Setting the air distribution	
Charge level display	103	Switching the rear window heater	
01 , 0 ,	109	on/off	87
Charging station, mode 3 Configuring week profile	106 104	Switching the windshield heater	
Ending the charging process	104	on/off	87
Fast charging station, mode 3/4	107	Co-driver bench seat	
	105	Folding the seat surface forwards/	
Mains socket, mode 2	105	backwards	61
Notes on charging the high-voltage		COC papers, CERTIFICATE OF CON-	
*	102	FORMITY	199
, , , , , , , , , , , , , , , , , , , ,	166	Cockpit	
Starting the charging process	107	Instrument panel	6
	106	Coffee cup symbol	122
Charging settings	104	Combination switch	
Child seat		Lights	69
Adjusting the vehicle seat	36	Rear window wiper	. 77
Basic instructions	34	Windshield wipers	
Front passenger seat	36	Components relevant to radio regula-	
Risks/dangers	34	tion	
		Declaration of conformity	. 18

Conversions	14	Digital inside rear view mirror	. 80
Coolant		Digital speedometer	134
Capacity		DIRECT SELECT lever	
Checking level	156	Drive ranges	100
Copyright	0.4	Engaging drive position	101
License	24	Engaging neutral	101
Copyrights		Engaging park position automatically	101 101
Trademarks	25	Engaging reverse gear Function	100
Cornering light	70	Selecting park position	101
Correct use	19	Transmission position display	100
Crosswind Assist	115	Disconnect device (high-voltage on-	
Cruise control		board electrical system)	. 90
Activating/deactivating	119	Display	
Buttons	119	Cleaning	160
Calling up a speedFunction	119 118	Display (on-board computer)	132
Increasing/decreasing the speed	119	Display message, Message (instrument	
Requirements:	119	cluster)	
Selecting	119	Calling up in the on-board computer	235
Setting a speed	119	Notes	235
Storing a speed	119	Display messages	
Cup holders		€∋ mph	241
Center console	65	Attention Assist Inoperative	242
Customer Assistance Center (CAC)	20	Attention Assist: Take a Break!	242
D		AUTO Lamp Function Inoper-	
		ative	252
DAB announcements (audio system)	1 // /	Charger Cable Connected	244
Setting	144	(b) Check Brake Fluid Level	238
Damage Limited protection	32	Check Tires	247
•		Currently Unavailable Cam-	247
Data processing in the vehicle		era View Restricted	241
Data protection rights	24	© Currently Unavailable See	24
Data storage Data protection rights	24	Operator's Manual	240
Electronic control units			240
Event Data Recorder		Currently Unavailable See	
Onboard Logic Unit		Operator's Manual	240
Online services	23	Don't Forget Your Key	247
Dealership	19	Front Left Malfunction	
Declaration of conformity		Service Required (example)	236
Components relevant to radio regu-		(P) Incline Too Steep See Opera-	
lation	18	tor's Manual	237
Definitions (tires and loading)	186	(a) Inoperative See Operator's	
Departure time		Manual	240
Pre-entry climate control	88	Inoperative See Operator's	۷+۱
Deployed components			000
Limited protection		Manual	239
Deployment situations	29	EBD Inoperative See Operator's	000
Diagnostics connection	18	Manual	239

Key Not Detected (red dis-		(!) Warning Tire Malfunction	247
play message)	248	Wheel Sensor(s) Missing	246
Key Not Detected (white dis-		Active Brake Assist Functions Cur-	
play message)	248	rently Limited See Operator's Man-	
Left Side Curtain Airbag Mal-		ual	238
function Service Required (example)	236	Active Brake Assist Functions Limi-	
Low Beam Left (example)	252	ted See Operator's Manual	238
Malfunction Consult a work-		Adaptive Highbeam Assist Camera	
shop	246	View Restricted See Operator's	
Malfunction See Operator's		Manual	251
Manual	252	Adaptive Highbeam Assist Currently	
Malfunction	245	Unavailable See Operator's Manual	251
Obtain a New Key	248	Adaptive Highbeam Assist Inopera-	
© Off	241	tive	251
HOLD Off	242	Air Con. Energy Saving Mode Activ	248
Parking Brake Inoperative	237	Apply Brake to Shift from 'P'	250
Parking Brake See Operator's		Auxiliary Battery Malfunction	250
Manual	237	Blind Spot Assist Inoperative	242
(!) Please Correct Tire Pressure	247	Blind Spot Assist Trailer Not Moni-	
Refill Washer Fluid	248	tored	242
Replace Key Battery	248	Check Brake Pads See Operator's	
Reserve Level Charge High-		Manual	237
Voltage Battery	245	CRUISE CONTROL Inoperative	241
s. Operating Instructions	245	Currently Unavailable Radar Sen-	
SRS Malfunction Service		sors Dirty	241
Required	236	Do Not Change Transmission Posi-	
Steering Malfunction		tion Service Required	250
Increased Physical Effort See Oper-		Do Not Restart Vehicle Service	
ator's Manual	249	Required	246
Steering Malfunction Stop		N Permanently Active Risk of Roll-	
Immediately See Operator's Manual	249	ing Away	250
Stop Immediately Drive will		Note the range	244
be deactivated Charge high-voltage		Note the range. Visit a workshop	244
battery	246	Only Shift to 'P' when Vehicle is	0.50
Stop Switch Engine Off	246	Stationary	250
Switch Off Lights	252	Place Key in Marked Space See	0.40
Switch On Headlamps	251	Operator's Manual	248
Towing Not Permitted See		Radar Sensors Dirty See Operator's	000
Operator's Manual	245	Manual Drive System Performance	238
Yeh. Tracking Activated See		Reduced Drive System Performance	215
Op. Manual or mobile app	251	See Operator's Manual	245
✓ Vehicle Operational Switch		Reversing Not Possible: Service	250
the Ignition Off Before Exiting	250	Required	200

Risk of Rolling Driver's Door Open		Driving in winter	97
and Transmission Not in P	250	Electric mode	90
Risk of rolling, driver's seat not		General driving tips	94
occupied and transmission not in P	250	Light adjustment when driving abroad Limit speed	68 95
		Limit speed Limited braking effect (salt-treated	93
Socket flap open	248	roads)	96
SOS NOT READY	239	New brake disks/brake linings	96
Tire Press. Monitor Currently		Parking brake	96
Unavailable	246	Recuperation	91
Tire Pressure Monitor Inoperative	247	Slippery road surfaces	97
Tire Pressure Monitor Inoperative		Subjecting brakes to a load	96
No Wheel Sensors	246	Wet road surfaces (brake)	96
To Deselect P or N, Depress Brake	210	Driving notes	0.5
* - I	250	Transport by rail	95
and Start Engine	250	Driving safety system	
To Engage Transmiss. Position R		ABS (anti-lock braking system)	114
First Depress the Brake	249	Active Brake AssistASR (acceleration skid control)	116 114
Transmission Malfunction: Stop		ATTENTION ASSIST	122
Vehicle	251	BAS (Brake Assist System)	114
Displaying range (trip menu)	134	Blind Spot Assist	123
Displaying total distance (trip		Cruise control	118
menu), Odometer	134	EBD (Electronic Brakeforce Distribu-	
Distance warning	116	tion)	116
Door		ESP [®] (Electronic Stability Program) ESP [®] Crosswind Assist	115 115
Activating/deactivating the auto-		ESP® trailer stabilization	116
matic locking mechanism	. 41	Hill Start Assist	120
Locking/unlocking mechanical key		HOLD function	120
Opening (from the inside)	40	Lane Keeping Assist/Active Lane	
Unlocking (from the inside)	40	Keeping Assist	124
Door control panel	10	Overview	114
DOT, Tire Identification Number (TIN)	184	Your responsibility	113
Double co-driver's seat	61	Driving system	114
Drinking and driving		Driving tips	
Drive position display	100	Driving off-road	97
		Driving on flooded roads	96
Drive program display	100	Driving on wet roads Hydroplaning	96 96
Drive system, Engine	. 90	_	
Manually disconnecting Starting (in emergency operation	. 90	Drowsiness detection	
mode)	93	Drunk driving	94
Starting (start/stop button)		Dual-zone automatic climate control	
Switching off (start/stop button)		(control panel)	83
Driving in winter	97	Dynamic handling control system	115
Driving instructions		F	
Acoustic presence indicator (sound		_	11/
generator)		EBD, Electronic Brakeforce Distribution	116
Brakes		EC general operating permit number	226
Breaking-in notes		ECO display	
Downhill gradient	96 94	Function	99

Resetting		Energy consumption (on-board com-	104
Electric closing aid (sliding door)	44	puter)	134
Electric mode	00	Engaging drive position (transmission)	101
Notes	. 90	Engaging reverse gear	101
Electric parking brake Automatically applying	111	Engine electronics	199
Emergency braking	112	Engine number	226
Manually applying/releasing	112	Environmental protection Driving style	12
NotesReleasing automatically	111	Environmentally friendly driving style	
Electric sliding door	112	ESC, Electronic Stability Control	
Function	44	ESP®	110
Open/close with button	45	Activating/deactivating	115
open/close with key button		Crosswind Assist	115
Opening with the door handle		Function	115
Opening/closing (from the inside)		Trailer stabilization	116
Resetting Unlocking manually		Event Data Recorder	24
Electrical fuses	0	Exterior lighting	
Notes	170	Care	
Electronic Stability Program		Replacing illuminants (front)	. 73
Activating/deactivating	115	F	
Electronics		Factory settings (audio system)	143
Engine electronics	199	Fastening	
Installing two-way radios	199	First aid	,
Emergency First-aid kit (soft sided)	163	First-aid kit (soft sided)	163
Overview of assistance		First-aid kit (soft sided)	163
Safety vest	163	Flat tire	
Warning lamp	163	Changing a wheel	190
Emergency braking		Tire-change tool kit	190
Electric parking brake	112	Floor mats	67
Emergency call system	4 / 4	Free software	. 24
Automatic emergency call	164 163	Frequencies	
Information Manual emergency call	164	Mobile phone	
Overview	163	Two-way radios	200
Transferred data	164	Front air bag	
Emergency key		Inflating	29
Removing/inserting	39	Front seat	
Emergency operation mode		8-way adjustment options Adjusting (electrically)	
Starting the vehicle		Adjusting manually	
Emergency release (vehicle socket)	109	Manually adjusting	. 55
Emergency shutoff (high-voltage on-		Memory function	
board electrical system)		Rotating	
Emergency start (drive system)	170	Function the event of an accident	. 30
Emergency Tensioning Devices	20	Fuse how (so driver feetwell)	171
Inflating	29	Fuse box (co-driver footwell) Fuse box (seat base of driver's seat)	1 <i>7</i> 1
Energy consumption SmartKey	. 39	Notes	170

G		Hydroplaning	96
General operating permit number (EC)	226		
Genuine parts	13	Identification plate	2
Getting in/getting out	43	Immobilizer	
Grab handles			
Using	43	Inattention detection	Z 2
Gross axle weight rating	226	Incorrect behavior by vehicle occupants Limited protection	30
Н		Indicator Changing bulbs (front)	7/
Handling characteristics			/-
Unusual		Indicator lamps Overview	-
hands-free system	145	Inside rear view mirror	•
Hazard warning light system	70	Digital inside rear view mirror	80
Head restraint		Inside rear view mirror display	
Manually adjusting		Rear view camera 1	2
Headlamp flashing	69	Inside rearview mirror	
Heating system	82	Adjusting/setting anti-glare mode	81
High beam		Installation of accessories	
Activating/deactivating		Limited protection	
Adaptive Highbeam Assist Changing bulbs	71 74	Installations	14
High-voltage battery, Battery (high-volt-	74	Instrument cluster, Instrument display	33
age on-board electrical system)		, , , , ,	33
Calibrating (on-board computer	=		32
menu) Calibration	135 153	Function/notes 1	31
Charge level display	103	Overview	
Charge port, emergency release	109	. ,	31
Charging at time of departure	104	Instrument cluster display (on-board	32
Charging duration	230		
Charging station, mode 3 Configuring week profile	106 104	Instrument lighting, Dashboard lighting 1	30
Disconnect device	90	Instrument panel Cockpit	,
Ending the charging process	109		
Energy content	230	Intelligent light system Adaptive Highbeam Assist	71
Fast charging station, mode 3/4 General notes on charging	107 102	Cornering light	70
Mains socket, mode 2	105	Intellitext™ (audio system)	
Manually calibrating	154	Setting1	44
Notes	166	Interior lamp	
Notes on calibrating	152	Replacing illuminants (rear	_
Starting the charging process Type	107 230	passenger compartment)	/(
Wallbox, mode 3	106	Interior lighting	71
High-voltage on-board electrical system		Box bodies Cargo compartment	72
Indicator lamps on vehicle socket	105	Motion detector (rear passenger	, ,
Hill Start Assist	120	compartment)	72
HOLD function			72
Notes	120	Setting	/
Switching on/off	120		

Interior motion sensor Activating/deactivating	High beam
Function 53	Light switch
Internet	Low beam
Mercedes me connect 139	Parking light
iPod® (audio system)	Responsibility with lighting systems 68
Starting playback145	Turn signal light
	Limit speed
J	Notes
Jack	
Hydraulic172	Limited Warranty
Removing from stowage compart-	Load
ment (hydraulic jack) 172	Determining the maximum
Storage location	Sample calculation
Storage location (hydraulic jack) 172	Load distribution
Journeys abroad	Load securing
Light adjustment low beam 68	Cargo tie-down points
Jump-start connection, Starting assis-	Notes
tance	Load-bearing capacity (tires) 185
K	Loading
	Definitions
Key	Loading guidelines
Battery	Loading information table 181
Central locking system	Locking/unlocking
Emergency key	Activating/deactivating the auto-
Fastening to keyring	matic locking mechanism
Functions	Doors (interior) 40
Pre-entry climate control 88	Mechanical key 43
Problem40	Low beam
Radio connection	Activating/deactivating 68
Unlocking setting 39	Changing bulbs 74
	Light adjustment when driving abroad 68
L	Lubricants
Lamp	Notes on operating fluids 228
Lane Keeping Assist	Lumbar support (4-way)
Function 124	11 ()/
System limits	M
Trailer operation 124	M+S tires
License plate lamp	Maintenance
Replacing light bulbs 76	Carpet
Light switch (overview) 68	Display
Lights, Lighting	Paint
Adaptive Highbeam Assist 71	Plastic trim
Adjusting the instrument lighting 133	Real wood/trim elements 160
Automatic driving lights	Roof lining
Combination switch	Seat belt
Cornering light	Seat cover
Hazard warning lights	Vehicle
Headlamp flashing	Malfunction
1 10 adia i i p 1 a i g c	Restraint system 28

Malfunction message	225	Modification	20
Notes on display messages	235 226	Limited protection	
Maximum load	220	Motion detector (cargo compartment) Mounting a load	
Determining	181	_	
Sample calculation		Multi Purpose Vehicle (MPV)	19
Maximum tire load	184	Multifunction steering wheel Overview of buttons	132
Maximum tire pressure	185		102
MBUX multimedia system		N	
Mercedes me & Apps	140	Nominal tensile load of cargo tie-down	
Mechanical key		rings	233
Locking/unlocking the door		0	
Medical aids	20	Objects in the vehicle interior	
Memory function	40	Limited protection	. 31
Outside mirrors Seat		Occupant safety	
Menu (on-board computer)		Air bag	
Assistance graphic	134	Automatic measures after an accident	
Battery calibration	135	Basic information	
Service		Information on the child restraint	34
Settings		system	. 29
Trip		Information on the correct seat	
Mercedes me Apps	140	position	26
Mercedes me calls	107	Pets in the vehicle	31
Arranging a service appointment Consenting to the transfer of data	137 138	On-board computer	101
Information on call using overhead	100	Assistant display menuBattery calibration menu	135
control panel	137	Displaying the service due date	152
Making a call via the overhead con-	407	Instrument cluster display	132
trol panel Transferred data	137 138	Service menu	134
	130	Settings menu	136 134
Mercedes me connect Accident and Breakdown Manage-		Trip menu	
ment	139	On-board diagnostic interface	18
Information	139	On-board electronics Engine electronics	199
Making a call via the overhead con-	407	Installing two-way radios	199
trol panelTransferred data	137 140	Onboard Logic Unit	. , ,
		Data storage	23
Message memory	235	Online services	
Mirror Adjusting/setting anti-glare mode		Online services	23
(inside rearview mirror)	81	Open-source software	24
Adjusting/setting anti-glare mode		Opening/closing the hood	155
(outside mirrors)	79	Operating fluids	
Mirrors		Brake fluid	228
Digital inside rear view mirror	. 80	Notes	228
Mobile phone	200	Notes on coolant (drive system) Refrigerant (air conditioning system)	228
Frequencies Maximum transmission output		Windshield cleaning agent	229

Operating safety Audio system	Protection Limited
Operator's Manual	Pulling away
Outside mirrors	ruillig away
Adjusting/setting anti-glare mode 79	Q
Blind Spot Assist	QR code rescue card21
Folding in/out	Qualified specialist workshop
Memory function	<u> </u>
	R
Overhead control panel Adjusting the interior lighting	Radar sensors
Overview 8	Care
	Radio (audio system) DAB announcements
P	DAB announcements
Paint code	Program preview (EPG)
Park position	Saving radio stations
Engaging101	Selecting the frequency band 143
Selecting automatically 101	Setting stations
Parking for an extended period 113	Switching traffic announcements on/off
Parking light 68	,
Partition sliding door	Radio connection Key
Opening/closing 49	-
Permissible gross mass	Radio regulations Regulatory radio identification
Permitted towing methods	Real wood (care)
Overview 167	Rear compartment lighting (motion
Pets in the vehicle	detector)
Phone book (audio system)	Rear fog light
Downloading mobile phone contacts 147	Rear view camera
Searching for contacts	Inside rear view mirror display 121
Placing a load on the wheel arch	Rear window wiper
Plastic trim (care)	Switching on/off77
Post-collision brake	Rear-end doors
Power display	open over 90°48
Function/notes 131	Opening/closing (from the inside)
Power supply	Opening/closing (from the outside) 47
Switching on (start/stop button)	Rear-view camera
Power washer (care)	Display/hide the inside rear-view mirror display 122
Pre-entry climate control	Recuperation
Activating	Function91
Switching on/off via the button	Setting
Via the key 88	Refrigerant (air conditioning system) 230
Program selector button, Drive pro-	Registration
grams	Regulating headlamp range
Drive program display 100	Regulatory radio information
Drive programs	Specific absorption rate
Selecting the drive program	Replacement key. Spare key

Replacing Fuses	Adjusting electrically (front)	
	Adjusting the head restraint manually 6:	
Replacing light bulbs	Adjusting the seat surface (co-	_
Interior lamp (rear passenger com-	driver bench seat)	1
1 /	Correct driver's seat position 5	
	Door control panel 10	0
	Folding the folding seat up/down 6:	2
	Memory function 58, 6	0
Replacing light sources	Rotating (front seat) 6	
0 1 1	Side impact air bag	3
1 71	Switching seat heating on/off	3
	Seat helt	
Reporting safety defects	Adjusting the height	7
Rescue card, QR code 2	.1 Cleaning	0
Rescue separation point (high-voltage	Fastening 2	7
	Notes on wearing correctly 2	7
Responsibility	Unfastening 33	
Driving safety systems 11	3 Warning lamp 2	8
Restraint system	Seat belt warning 29	8
Basic information 2	Seat cover (care) 16	0
	4 Securing loads	
_ 1 2	9 Cargo tie-down rings 15	0
,	Securing luggage 14	8
Information on function	Selector lever 10	n
Information on the correct seat	6 Self-test	Ĭ
I control of the cont	2 Restraint system	Ω
	,	
	Selisors (care)	
	Service (on-board computer) 13	4
Warning lamp 2	8 Service center 1	9
Reversing camera	Setting a limit speed for winter tires 12	0
Care 15	Setting the air distribution 8	6
Roadside Assistance (breakdown) 1	6 Settings (on-board computer) 13	6
Roll-away prevention 12	Shifting to neutral (transmission) 10	1
Roof lining (care) 16	O Side windows	
Roof load	Opening/closing 5	0
Roof luggage rack, Carrier system	Problem 5	
Loads23	Resetting 5	1
Securing		5
Roof ventilator	Sliding door	
Activating/deactivating cargo com-	electric sliding door 4-	4
	electrical closing aid	
partment ventuation	_ Function 4	-
S	Open/close with button 4	
	Onening (closing (from the inside)	3
Safety system	opening/closing (from the outside) 43	3
Safety vest 16	Slippery road surfaces	7
Seat, Driver's seat	SmartKey	•
4-way lumbar support 6	Deactivating the function 3	0
8-way adjustment options 5	8 Deadiffating the full official	/

Energy consumption	39	Switching on the vehicle (start/stop	
Snow chains	175	button)	
Socket		Switching seat heating on/off	. 63
Trailer hitch	127	Switching the rear window heater on/off	. 87
Socket (12 V)		Switching the windshield heater on/off	87
Center console (front)	. 66		
Socket (115 V)		T	
Front center console		Technical data	
Notes	. 66	Coolant filling capacity	229
Socket flap	107	Information	199
SOS button	137	Notes on trailer hitch Radio regulations	231
Sound generator	90	Specific absorption rate (SAR)	225
Spare parts	. 13	Tire pressure monitoring system	180
Spare wheel		Vehicle dimensions	230
Installing/removing	195	Vehicle identification plate	226
Notes	194	Telephone	
Special seat belt retractor	. 36	Activating functions during a call	147
Specialist workshop		Connecting a mobile phone	146 147
Specific absorption rate (SAR)		Incoming call during an existing call Notes	147
Speed control	220	Secure Simple Pairing	146
Cruise control	118	Setting the ringtone	146
Speed rating (tires)	185	Telephone operation	146
	134	Telephone (audio system)	
Speedometer (digital)		Disconnecting a mobile phone	146
Start-off assist	120	Replacing a mobile phone	146
Start/stop button	110	Setting the ringtone	146
Parking the vehicleStarting the vehicle		Tire and Loading Information placard	181
Switching on the power supply or	. /0	Tire Identification Number (TIN)	184
the vehicle	. 92	Tire information table	181
Starting-off aid	120	Tire labeling, Labeling (tires)	
Steering wheel		Characteristics(TIN)	185
Adjusting	63	DOT, Tire Identification Number (TIN) Load-bearing capacity	184 185
Buttons		Maximum tire load	184
Driver's air bag		Maximum tire pressure	185
Steering wheel heater		Overview	183
Steering wheel heater		Size designation	185
Stopping the alarm	. 52	Speed rating	185
Stowage areas	64	Temperature grade Tire quality grades	183 183
Stowage compartment (vehicle tool kit)	171	Tread wear grade	183
Stowage space		Tire load (maximum)	184
Armrest		Tire pressure	
Bottle holder		Checking manually	179
Center console Door		Maximum	185
Glove box		Notes	176
		Restarting the tire pressure moni-	100
Substances hazardous to health		toring system	180
Summer tires	174		

Tire pressure monitoring system		Towing methods	167
178,		Towing eye	
Tire pressure table	177	Installing/removing	169
Tire pressure monitoring system		Storage location	169
Checking the air pressure	179	Towing methods	
Checking the temperature	179	Both axles on the ground	168
Function	178	Overview	167
Restarting	180	Track information	
Technical data	180	Displaying	145
Tire pressure table	177	Traffic announcements (audio system)	
Tire temperature		Switching on/off	144
Checking	179	•	' '
Tire pressure monitoring system	178	Trailer hitch	150
Tire tread	174	Care Coupling/uncoupling a trailer	159 127
Tire-change tool kit	190	Information	128
_	170	Information about trailer operation	125
Tires	105	Notes	231
Characteristics	185	Permissible trailer loads and trailer	20
Checking	1 <i>7</i> 4 1 <i>7</i> 9	drawbar noseweights	129
Checking the temperature Definitions	186	Power supply	130
Direction of rotation	190	Socket	127
DOT, Tire Identification Number (TIN)	184	Trailer loads	231
Installing	193		20
Load-bearing capacity	185	Trailer operation	127
M+S tires	175	Coupling/uncoupling a trailerInformation	128
Maximum tire load	184	Lane Keeping Assist	124
Maximum tire pressure	185	Notes	125
Mounting	188	Permissible trailer loads and trailer	120
Noise	174	drawbar noseweights	129
Overview of tire labeling	183	Power supply	130
Removing	192	Setting	128
Replacing	190	Socket	127
Restarting the tire pressure moni-		Trailer loads	231
toring system	180	Trailer stabilization	116
Selection	188	Transmission	
O	185	DIRECT SELECT lever	100
Snow chains	1 <i>7</i> 5 185	Drive program display	100
Speed rating Storing	190	Drive programs	
Summer tires	174	Drive ranges	100
Tire and Loading Information placard	181	Engaging drive position	101
Tire pressure monitoring system	178	Engaging neutral	101
Tire pressure table	177	Engaging reverse gear	101
Tire quality grades	183	Program selector button	. 99
Unusual handling characteristics	174	Selecting park position	101
Wheel size categories	189	Transmission position display	100
Tow-away alarm		Transport (vehicle)	169
Activating/deactivating	53	Transport by rail	
Function	53		
Tow-starting	170	Trim element (care)	160
_		Trip	4.0
Towing Raised rear axle	169	Displaying total distance	134
ivaisen igai axie	109	Menu (on-board computer)	134

Trip computer	Vehicle data
Displaying	Vehicle height 230
Resetting	Vehicle length 230
Trip distance, Distance recorder, Trip	Vehicle width
odometer	Wheelbase230
Displaying	Vehicle equipment 15
Resetting	Vehicle identification number 226
Turn signal light	Vehicle identification plate 226
Changing bulbs (rear)	Vehicle key 38
Two-way radios Frequencies	Vehicle operation outside the USA or
Installation	Canada15
Maximum transmission output 200	Vehicle socket
	Emergency release 109
U	Indicator lamps 105
Unfastening	Vehicle tool kit, Tool
Unlocking setting	Removing
USB device (audio system)	Stowage compartment
Showing track information	Towing eye 169
Starting playback	Vehicle's high-voltage on-board electri- cal system
Using the chock 113	Charge port, emergency release 109
-	Disconnect device
V	Manually disconnecting 90
Vehicle, Starting the vehicle	Rescue separation point 90
Activating/deactivating the auto-	Vents
matic locking mechanism 41	VIN
Correct use	VII
Data storage	W
Diagnostics connection	Warning lamp 163
Equipment	
Limited Warranty	Warning system
loading	Warning/indicator lamp
lock automatically41	ABS warning lamp 258
Locking/unlocking (from the inside) 41	(P) and 253, 254, 255, 256
Locking/unlocking mechanical key 43	(I) Brake system warning lamp
Lowering	(yellow)
Medical aids	(1) Brake warning lamp (red)
Parking for an extended period 113	(Canada)255
Problem notification	Brake warning lamp (red)
QR code rescue card	(USA)
Raising	(®) Electric parking brake
Registration	
Starting (in emergency operation mode)	applied red indicator lamp (Canada)
Starting (start/stop button)	does not light up
Switching off (start/stop button) 110	PARK Electric parking brake
Switching on the power supply	applied red indicator lamp (USA)
(start/stop button)92	does not light up253
Towing away	5 1

(P) Electric parking brake mal-		Warning lamp for distance	
functioning yellow indicator lamp		warning function	59
lights up	254	Warning/indicator lamps	
⊚ ! Electric power steering warn-	20.	Overview	52
	259	Warranty terms and conditions 1	
ing lamp (red)	239	-	
Electrical malfunction warn-		Washer fluid	
ing lamp	259	Washing by hand 15	8
🐉 ESP® OFF warning lamp	257	Wear	
ESP® warning lamp flashes	257	Limited protection 3	
ESP® warning lamp lights up	257	WET WIPER SYSTEM 7	′8
High-voltage battery reserve	259	Wheel rotation	39
		Wheel wrench	0
High-voltage battery warning	260	Wheels	
(P) Red electric parking brake		Care 15	59
applied indicator lamp (Canada) flas		Changing 18	
hes	254	Characteristics of the tire	
(e) Red electric parking brake		Checking	
applied indicator lamp (Canada)		Checking the air pressure	
lights up	254	Definitions	
PARK Red electric parking brake		DOT, Tire Identification Number (TIN) 18	
applied indicator lamp (USA) flashes	254	Flat tire 16	5
PARK Red electric parking brake	254	Installing	
		Load-bearing capacity	
applied indicator lamp (USA) lights		Maximum tire load	
up	254	Maximum tire pressure	
Red parking brake applied		Noise	
indicator lamp (Canada) lights up	255	Overview of tire labeling 18	
PARK Red parking brake applied		Removing 19	
indicator lamp (USA) lights up	255	Replacing 188, 19	0
Reduced warning lamp power	259	Restarting the tire pressure moni-	. ^
Restraint system warning		toring system	
	256	Size designation	
lamp	230	Snow chains	
*	0.50	Speed rating 18	35
Seat belt warning lamp flashes	258	Storing19	0
Seat belt warning lamp lights		Tire and Loading Information placard 18	
up	258	Tire pressure	
System malfunction warning		Tire pressure monitoring system 17 Tire pressure table 17	
lamp	259	Tire quality grades	
The electric parking brake		Tread wear grade	
malfunctioning yellow indicator		Unusual handling characteristics 17	
- ·	254	Wheel size categories 18	39
lamp does not light up	204	Wheels (care)	59
(!) Tire pressure monitoring sys-	0.40	Window curtain air bag 3	3
0 1	260	Windows	
(!) Tire pressure monitoring sys-			50
tem warning lamp lights up	260	Windows (care)	59

Windshield
Replacing the wiper blades 77
Windshield cleaning agent 229
Windshield wiper
Replacing wiper blades (rear window) 79
Switching on/off (rear window) 77
Windshield wipers
Replacing the wiper blades
WIPER SYSTEM)
Replacing the wiper blades (wind-
shield)
Switching on/off
Switching on/off (windshield) 77
Winter operation
Winter tires
Notes
Setting a default limit speed 120
Wiper blades
Care
Replacing (rear window)
Replacing (WET WIPER SYSTEM)
Workshop 19





